Pro PCB Design Tips

🔧 Core Principles

Principle Tip

Try multiple layouts; route a bit, and if it feels off, rip it up and redo. Component

Placement Optimization starts with smart, thoughtful placement.

Schematic First Your schematic must be clean, readable, and organized—every time,

all the time. Schematic is the master design guide.

Group Organize by function and priority: High-Speed, Power, Digital,

Components Analog, RF, Thermal needs, mechanical/enclosure considerations.

Layout & Routing Guidelines

Area **Best Practice**

Polarity & Keep uniform (e.g., all e-caps polarity aligned). Public restrooms

Orientation have design languages; your board should be intuitive.

From Symbol to All footprints should originate from a symbol in your

Footprint schematic-maintain traceability.

Clearances & Respect minimum clearances, edge constraints, and mechanical

Constraints outlines.

Choose trace width based on current; size vias appropriately for Trace Widths & Vias

current and thermal demands. Use online calculators.

Planes Use solid **Power and Ground planes** for signal integrity and

thermal performance.

Thermal Relief Consider thermal pads, heatsinks, relief spokes, and reflow profiles.

Heat is a layout constraint.

Calculators:

https://www.digikey.com/en/resources/online-conversion-calculators

Electronics Parts:

Pro Suppliers: <u>Digikey.com mouser.com Arrow.com Newark.com</u>

Hobby Suppliers Adafruit.com Sparkfun.com Pololu.com



Step Tip

Footprint Print your layout on paper and place parts on it to check fit. Catch

Verification issues early.

Silkscreen Mark Pin 1, polarity, reference designators, test points, and all

Essentials power/GND lines clearly. Label everything circuit critical.

Test Points Add them liberally—access for probing and troubleshooting is critical. PI

troubleshooting. Footprints are free; design flexibility and troubleshooting

your layout stage.

Extra Footprints Add alternates for key components where possible. Flexibility is free in

early prototypes.

Design Smarter

Area Tip

Differential Pairs Route them together, equal length, controlled impedance where

needed.

BoM Control Maintain clean documentation—this **is** part of engineering. All parts

should have a *reputable* vendor source and purchasing part number.

ERC/DRC Rules Don't ignore them. They catch what you can't see.

Copy Good

Ideas

Look at other designs—great layouts are studied and borrowed.

Datasheets Read them thoroughly. Seriously. All of it. Twice.

Mindset & Process

- You won't get it perfect on the first revision—focus on progress, not perfection.
- Assemble your own boards: The best lessons are mistakes.
- **Design with failure in mind**: Build in alternate circuits, debug features, and flexibility.

EDA (Design and Layout) Software:

KiCAD https://www.kicad.org/download/