



How to Connect?

Step 0: Plug the UART cable in the system and make sure application is running.


Step 1: Click the combo box with label **COM PORT**.




Step 3: Click and select the Tec-UART.




Step 3: Click the Connect button.



Step 4: Message will pop up reading “Communication established successfully!” click OK.



Note: After connecting successfully Connection status will read “Connected” in green colour.



Online data will be received automatically after successful connection.