

USER'S Manual

FSM-Extractor

January, 2019

Revision Sheet

Release No.	Date	Revision Description	Writer
Rev. 0	05/01/19	User's Manual Created	Ercüment TÜRK

User's Manual Page ii

USER'S MANUAL

TABLE OF CONTENTS

		Page #
1.0	GENERAL INFORMATION	1-1
1.1	System Overview	1-1
1.2	Acronyms and Abbreviations	1-1
2.0	Program SUMMARY	2-1
2.1	Program Summary	2-1
3.0	GETTING STARTED	3-1
3.1	Launch the Program	3-1
4.0	USING the Results	4-1
4.1	Results	4-1

		1.0 General Information
	1.0	GENERAL INFORMATION
User's Manual		

1.0 GENERAL INFORMATION

1.1 System Overview

The "FSM-Extractor" is designed to generate and show the all Mealy FSM transactions, input and output alphabet, state list. It accept the system code which is written in Verilog as an input. After program starts, "PQ-FSM.fsm" is created and stored.

1.2 Acronyms and Abbreviations

FSM - Finite State Machine

User's Manual Page 1-1

	2.0 System Summary
2.0	SYSTEM SUMMARY

2.0 PROGRAM SUMMARY

2.1 Program Summary

To keep everything simple, the main GUI consists of 4 main parts; which are enumerated below:




Figure 1

- 1. Red Verilog source code path
- 2. Green Save results of FSM-Extractor into PQ-FSM.fsm file
- 3. Blue Start the program

User's Manual Page 2-1

		3.0	Getting Started
3	.0	GETTING	STARTED

3.0 GETTING STARTED

3.1 Launch the Program

We first start by running "VtoFSM.jar". This will begin the "VtoFSM".



Figure 2

When the program is opened, a screen like Figure 3 welcomes us, -Click "Open File" > on the program to load "Verilog code"



Figure 3

- The Verilog file is selected from the file dialog screen. As seen in Figure 4




Figure 4

-Click "Play Button >" on the program to generate the all FSM information for PQ-Analysis. (Figure 5)



Figure 5

Note: "Save the FSM Textfile" selection must be enabled to store results.

After generate procedure finishes, PQ-FSM.fsm file is created in same file with the program. (Figure 6)

.git	5.01.2019 21:49	Dosya klasörü	
🥒 .settings	1.02.2018 00:48	Dosya klasörü	
🕢 bin	5.01.2019 20:47	Dosya klasörü	
✓ src	1.02.2018 00:48	Dosya klasörü	
🔊 .classpath	31.01.2018 22:39	CLASSPATH Dosyası	1 KB
🔊 .project	31.01.2018 22:39	PROJECT Dosyası	1 KB
FSM-Extractor User_Manual.docx	5.01.2019 21:52	Microsoft Word B	358 KB
📝 Lights.v	4.02.2018 15:38	V Dosyası	15 KB
PQ-FSM.fsm	5.01.2019 21:45	FSM Dosyası	2 KB

Figure 6

-Click "Help Button >" to see this manual. (Figure 7)



Figure 7

	4.0 Using the Results
4.0	USING THE RESULTS

4.0 USING THE RESULTS

4.1 Results

The result is stored in PQ-FSM.fsm. (Figure 8). This file is used by another tool which name is PQ-Analysis. All input and output alphabet and transition list are absence in this result. Actually this file is a abstraction of a FSM.

```
Input Alphabet:
i_4442 i_0 i_XXXX i_2444 i_4144 i_4244 i_4414 i_4424 i_4441i_1444
Output Alphabet: 0 1444 0 4444 0 4144 0 4244 0 4414 0 4424 0 4441 0 4442 0 2444
M 0000
M_0001
M 0010
M 0011
M 0100
M 0101
M 0110
M 0111
M 1000
Start State:
M 0000
Transition List:
M_0000 --i_4442/0_1444--> M_1000
M_0000 --i_0/0_4444--> M_0000
M_0000 --i_XXXX/O_4444--> M_0000
M 0001 --i 2444/0 4144--> M 0010
M 0001 --i 0/0 4444--> M 0000
M 0001 --i XXXX/O 4444--> M 0000
M 0010 --i 4144/O 4244--> M 0011
M 0010 --i 0/0 4444--> M 0000
M_0010 --i_XXXX/0_4444--> M_0000
M_0011 --i_4244/0_4414--> M_0100
M_0011 --i_0/0_4444--> M_0000
M_0011 --i_XXXX/0_4444--> M_0000
M_0100 --i_4414/0_4424--> M_0101
M_0100 --i_0/0_4444--> M_0000
M_0100 --i_XXXX/O_4444--> M_0000
M_0101 --i_4424/0_4441--> M_0110
M_0101 --i_0/0_4444--> M_0000
M_0101 --i_XXXX/0_4444--> M_0000
M_0110 --i_4441/0_4442--> M_0111
M 0110 --i 0/0 4444--> M 0000
```

Figure 8

User's Manual Page 4-1