bus

File: bus.kicad_sch

power

File: power.kicad_sch

buffers

File: buffers.kicad_sch

fpanel

File: fpanel.kicad_sch

Z80CPU

File: Z80CPU.kicad_sch

DMA

File: DMA.kicad_sch

GALS

File: GALS.kicad_sch

IM2

File: IM2.kicad_sch

waitstate

File: waitstate.kicad_sch

mapper

File: mapper.kicad_sch

SPARE SOCKETS FOR DEBUGGING



Sheet: /
File: processor.Z80.kicad_sch

Title:

Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 1/11







Sheet: /bus/
File: bus.kicad_sch

Title:

Size: B | Date: | **Rev:**
KiCad E.D.A. kicad (6.0.11) | Id: 2/11





NOTE: PROCESSOR BOARD MUST
BE THE START OF THE BAI/BAO CHAIN.
BAO ORIGINATES WITH CPU BUSACK.
NO BAI SIGNAL TO PROCESSOR BOARD.





NOTE: DMA1 BYPASS
INSTALL JUMPERS ON
PINS 1-2 AND 3-4 IF NO DMA

NOTE: DMA2 BYPASS
INSTALL JUMPERS ON
PINS 1-2 AND 3-4 IF NO DMA













TEND IS AN OUTPUT FROM DMA



IO ADDRESS SELECT CIRCUIT

Note: IO Address Port $08-$0B
1-2 =on - A7 (low)
3-4 =on - A6 (low)
5-6 =on - A5 (low)
7-8 =on - A4 (low)
9-10 =off - A3 (high)
11-12 =on - A2 (low)







DMA Transfer LED triggered
whenever a DMA
transfer is in progress and
the pulse signal is active.
DMA software configuration
needs to program the
activation of the pulse signal.





Sheet: /DMA/
File: DMA.kicad_sch

Title:

Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 3/11















Sheet: /power/		
File: power.kicad_sch		
Title:		
Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 4/11

CPU WS GAL16V8





CPU DATA DIR GAL22V10





SPARE GAL FOR DEBUGGING



DMA CS GAL22V10





DMA RDY GAL22V10





Sheet: /GALS/
File: GALS.kicad_sch

Title:

Size: B | Date: | **Rev:**
KiCad E.D.A. kicad (6.0.11) | Id: 5/11

Z80 BUS INTERFACE

















Sheet: /buffers/		
File: buffers.kicad_sch		
Title:		
Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 6/11

Interrupt Mode 2 (IM2) Circuit



Sheet: /IM2/		
File: IM2.kicad_sch		
Title:		
Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 7/11

FRONT PANEL LED OUTPUT





U33 NOTE: USE 74HCT374 TO SOURCE OR SINK ADEQUATE CURRENT TO DRIVE LEDS ON FRONT PANEL

FRONT PANEL SWITCH INPUT





Sheet: /fpanel/		
File: fpanel.kicad_sch		
Title:		
Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 8/11

Wait State Generator Circuit



Sheet: /waitstate/		
File: waitstate.kicad_sch		
Title:		
Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 9/11





Tri-state address, data, & control bus during DMA







Reset Button Circuit

Sheet: /Z80CPU/
File: Z80CPU.kicad_sch

Title:

Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 10/11

Z80 MEMORY MAPPER AND EXPANSION IO PORT DECODER

IO ADDRESS SELECT CIRCUIT

INTERRUPT FILTER CIRCUIT

Note: IO Address Port $10-$1F
1-2 =on - A7 (low)
3-4 =on - A6 (low)
5-6 =on - A5 (low)
7-8 =off - A4 (high)



CPU MAPPER GAL16V8





1.8432 OR 7.3728 MHz TTL OSCILLATOR





MEMORY PAGING SRAMS



UPPER ADDRESS LINES PULL-DOWN RESISTORS











Sheet: /mapper/		
File: mapper.kicad_sch		
Title:		
Size: B	Date:	**Rev:**
KiCad E.D.A. kicad (6.0.11)		Id: 11/11