bus

File: bus.kicad_sch

power

File: power.kicad_sch

buffers

File: buffers.kicad_sch

fpanel

File: fpanel.kicad_sch

6809CPU

File: 6809CPU.kicad_sch

GALS

File: GALS.kicad_sch

bus sharing

File: bussharing.kicad_sch

mapper

File: mapper.kicad_sch

Sheet: /
File: processor.6809.kicad_sch

Title: Duodyne 6809 CPU board

Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 1/9



Sheet: /bus/
File: bus.kicad_sch

Title: Duodyne 6809 CPU board

Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 2/9









SPARE GATES



Sheet: /power/		
File: power.kicad_sch		
Title: Duodyne 6809 CPU board		
Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 4/9

IO Address Port $50-$5F

$50 Front Panel (RW)
$51
$52 PAGER (WR)
$53
$54
$55
$56-$57 I2C(RW)
$58-$5F UART (RW)

ADDRESS DECODER



IO DECODER



BUS SIGNALS



Sheet: /GALS/
File: GALS.kicad_sch

Title: Duodyne 6809 CPU board

Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 5/9

Z80 BUS INTERFACE

























Sheet: /buffers/
File: buffers.kicad_sch

Title: Duodyne 6809 CPU board

Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 6/9

FRONT PANEL LED OUTPUT



U33 NOTE: USE 74HCT374 TO SOURCE OR SINK ADEQUATE CURRENT TO DRIVE LEDS ON FRONT PANEL



J11 NOTE:

PINS 5, 7, 9, 11, 13, 15, 17, 19 ARE FOR LED STATUS FOR ROMWBW FRONT PANEL INDICATOR

PINS 6, 8, 10, 12, 14, 16, 18, 20 ARE FOR SWITCH INPUTS FOR ROMWBW FRONT PANEL

PINS 21, 23 ARE FOR I2C CONNECTION (SDA & SCL)

PINS 25, 27, 29, 31, 33, AND 35 ARE FOR TTL SERIAL CONNECTOR TO UART

PINS 29, 37 ARE FOR SERIAL VCC POWER ENABLE

PINS 22, 24 ARE FOR EXTERNAL RESET SWITCH

PINS 26, 28 ARE FOR IM2 CIRCUIT ENABLE

PINS 30, 32 ARE FOR INTERRUPT 0 ENABLE

PINS 34, 36 ARE FOR WAIT STATE CIRCUIT ENABLE

FRONT PANEL SWITCH INPUT





Sheet: /fpanel/
File: fpanel.kicad_sch

Title: Duodyne 6809 CPU board

Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 8/9

PROCESSOR, 6809











NOTE: RESET SELECT ALLOWS FOR RESET TO ORIGINATE:
1. ON PROCESSOR BOARD RESET BUTTON CIRCUIT ONLY (NONE)
2. FROM EXTERNAL BUS RES_IN (1-2 CLOSED)
3. TRANSMITTED TO EXTERNAL BUS (2-3 CLOSED)

Reset Button Circuit

Sheet: /6809CPU/
File: 6809CPU.kicad_sch

Title: Duodyne 6809 CPU board

Size: USLedger | Date: 2023-12-30 | **Rev: V1.00**
KiCad E.D.A. kicad (6.0.11) | Id: 9/9

Note: IO Address Port $95
1–2 =off – A7 (high)
3–4 =on – A6 (low)
5–6 =on – A5 (low)
7–8 =off – A4 (high)
9–10 =on – A3 (low)
11–12 =off – A2 (high)
13–14 =on – A1 (low)
15–16 =off – A0 (high)











Sheet: /bus sharing/
File: bussharing.kicad_sch

Title: Duodyne 6809 CPU board

Size: A4	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 9/9

















Sheet: /mapper/
File: mapper.kicad_sch

Title: Duodyne 6809 CPU board

Size: B	Date: 2023-12-30	**Rev: V1.00**
KiCad E.D.A. kicad (6.0.11)		Id: 11/9