Lumen City E-Bike · Owner's Manual

Model LC-3

1. Your Lumen City

Thank you for choosing the Lumen City LC-3, an electric city bike with a mid-drive motor, a removable battery and an 8-speed hub gear. Read this manual before your first ride and keep it for future reference.

Specifications: motor 250 W rated (Lumen M2, mid-drive), torque 65 Nm, battery 540 Wh (36 V, 15 Ah), weight 23.4 kg with battery, maximum rider plus cargo weight 130 kg. Assistance stops at 25 km/h, as required by EU rules for e-bikes.

2. Battery and charging

Charge the battery fully before your first ride. With the included 4 A charger, a full charge from empty takes about 4.5 hours, and 0 to 80% takes about 2.5 hours. Charge the battery at room temperature, between 10 and 30 degrees Celsius.

Range depends on the assistance level, the terrain, the rider's weight and the temperature. On flat ground at 20 degrees: Eco mode up to 110 km, Tour mode up to 75 km, Boost mode up to 45 km. In winter, expect up to 30% less range.

If you will not ride the bike for more than a month, store the battery at 50 to 70% charge in a dry place, and top it up every 3 months. Never store the battery completely empty: a deeply discharged battery may not be covered by the warranty.

3. Display and assistance modes

Press the power button for 2 seconds to turn the system on. Use the + and - buttons to switch between the assistance modes: Off, Eco, Tour and Boost. Hold the - button for 3 seconds to activate walk assist (up to 6 km/h), useful when pushing the bike up a ramp.

Hold the + and - buttons together for 5 seconds to switch the display between kilometres and miles.

4. Error codes

When the system detects a problem, the display shows an error code. Most codes clear after turning the system off and on again. If a code keeps coming back, contact your dealer.

Code	Meaning	What to do
E01	Battery communication error	Remove and re-insert the battery, clean the contacts
E02	Battery temperature too high or too low	Let the battery reach 10-30 °C before riding
E03	Speed sensor signal lost	Check the magnet on the rear wheel is aligned with the sensor
E04	Throttle or button stuck	Release all buttons and restart the system
E05	Motor communication error	Restart; if it persists, contact your dealer
E06	Low battery voltage	Charge the battery; assistance is reduced
E07	Motor overheating	Stop riding and let the motor cool down for 10 minutes
E08	Torque sensor fault	Do not pedal while turning the system on; restart
E09	Firmware update failed	Repeat the update from the Lumen app over Bluetooth

5. Maintenance

Check the tyre pressure every week: 2.5 to 4 bar, as printed on the tyre. Clean and lubricate the chain every 300 km, or after riding in the rain. Never use a pressure washer: water can get into the motor and the battery contacts.

Take your Lumen City to an authorised dealer for a service after the first 500 km and then once a year. The first service is free and keeps your warranty valid.

Brake pads should be replaced when they are thinner than 1.5 mm. The hub gear needs an oil change every 5,000 km.

6. Safety

Always wear a helmet. Turn on the integrated lights when visibility is low: they are powered by the main battery and keep working for 2 hours after the battery reaches the reserve level. Do not modify the motor or the speed limit: it is illegal and voids the warranty.