


Case 20: The Smart Airer

Contents

- [22.1. Purpose](#)
- [22.2. Link:](#)
- [22.3. Materials Required](#)
- [22.4. Bricks build-up](#)
- [22.5. Installation Methods of Hardwares](#)
- [22.6. Hardware Connection](#)
- [22.7. Software Platform](#)
- [22.8. Coding](#)

22.1. Purpose


To make a smart arer.



22.2. Link:





[micro:bit Wonder Building Kit](#)







22.3. Materials Required















Video link: <https://youtu.be/ZjROexNQT1I>







22.4. Bricks build-up






















6**7****8**











12**13****14**






15**16****17**




18**19****20**



21**22****23**

24**25****26**

27**28****29**

30**31****32**


33**34****35**

36**37**

22.5. Installation Methods of Hardwares


Install the water level sensor with the bricks.

Sensor Connection Diagram



22.6. Hardware Connection

Connect two [motors](#) to M1 and M2, the [servo](#) to S1 and the [water level sensor](#) to P1 ports on [Wukong breakout board](#).




[MakeCode](#)


22.8. Coding

Add extensions


Click “Advanced” in the MakeCode to see more choices.



Search with Wukong in the dialogue box to download it.



Program



Link:https://makecode.microbit.org/_diR3FMErAfWF

Result

when button A is pressed, the two windows open outward and the airlor extends outward. When button B is pressed, the airlor retracts inward and the two windows close inward. When button A is pressed, the two windows open outward and the airlor extends outward, the water level sensor will detect the current rain value, and when the rain value is greater than 10, the airlor will automatically retract and the two windows will automatically close.