

STIHL

BATTERY CHAIN SAW

MSA 120 C-B

MODEL CONFIGURED ON FLOOR

12" BAR

\$299⁹⁹

BATTERY & PERFORMANCE

BATTERY SYSTEM AK 36 V	BAR LENGTH 12 in.
WEIGHT (W/O BATTERY) —	RUN TIME (UP TO) —



8 86661 58694 3

STORE SKU

7019744D

OTHER CONFIGURATIONS

Options listed may not be in stock

12" Bar

\$299⁹⁹

SKU

7019744D

CHAIN PART #

—

BAR PART #

—

STIHL

BATTERY CHAIN SAW

MSA 160 C-B

MODEL CONFIGURED ON FLOOR

12" BAR

\$329⁹⁹

BATTERY & PERFORMANCE

BATTERY SYSTEM AP 36 V	BAR LENGTH 12 in.
WEIGHT (W/O BATTERY) —	RUN TIME (UP TO) —



8 86661 57669 2

STORE SKU

7000588D

OTHER CONFIGURATIONS

Options listed may not be in stock

12" Bar

\$329⁹⁹

SKU

7000588D

CHAIN PART #

—

BAR PART #

—

STIHL

BATTERY CHAIN SAW

MSA 160.0 C-B

MODEL CONFIGURED ON FLOOR

12" BAR · 71 PM3 64

\$399⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 300 S	WEIGHT (W/O BATTERY) 6.8 lb
RUN TIME (UP TO) Up to 62 min	CHAIN TYPE —



8 86661 87482 8

STORE SKU

7035315D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar · 71 PM3 64	\$399⁹⁹
SKU	7035315D
CHAIN PART #	3670-005-0064
BAR PART #	3005-008-3405

14" Bar · 71 PM3 72	\$409⁹⁹
SKU	7033886D
CHAIN PART #	3670-005-0072
BAR PART #	3005-008-3409

STIHL

BATTERY CHAIN SAW

MSA 161 T

MODEL CONFIGURED ON FLOOR

12" BAR · 71 PM3 65

\$329⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 200	WEIGHT (W/O BATTERY) 4.6 lb
RUN TIME (UP TO) Up to 42 min	CHAIN TYPE 1/4" STIHL PICCO™ For in-tree...



8 86661 93660 1

STORE SKU

7020120D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar · 71 PM3 65	\$329⁹⁹
SKU	7020120D
CHAIN PART #	3670-005-0065
BAR PART #	3005-008-3405

STIHL

BATTERY CHAIN SAW

MSA 190.0 T

MODEL CONFIGURED ON FLOOR

12" BAR

\$399⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 300 S	WEIGHT (W/O BATTERY) 5.7 lb
RUN TIME (UP TO) Up to 48 min	CHAIN TYPE 3/8" PS3



1 98520 04811 1

STORE SKU

7053807D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar	\$399⁹⁹
SKU	7053807D
CHAIN PART #	—
BAR PART #	—

14" Bar	\$409⁹⁹
SKU	7062357D
CHAIN PART #	—
BAR PART #	—

Standard	\$409⁹⁹
SKU	—
CHAIN PART #	—
BAR PART #	—

STIHL

BATTERY CHAIN SAW

MSA 200.0 C-B

MODEL CONFIGURED ON FLOOR

12" BAR

\$399⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 300 S	WEIGHT (W/O BATTERY) 6.8 lb
RUN TIME (UP TO) Up to 50 min	CHAIN TYPE 3/8" STIHL PICCO™



8 86661 87490 3

STORE SKU

7035378D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar	\$399⁹⁹
SKU	7035378D
CHAIN PART #	—
BAR PART #	—

14" Bar · 61 PS3 50	\$409⁹⁹
SKU	7035377D
CHAIN PART #	3699-005-0050
BAR PART #	3005-000-4409

16" Bar · 61 PS3 55	\$419⁹⁹
SKU	7035379D
CHAIN PART #	3699-005-0055
BAR PART #	3005-000-4413

STIHL

BATTERY CHAIN SAW

MSA 220.0 C-B

MODEL CONFIGURED ON FLOOR

14" BAR · 61 PS3 50

\$439⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 300 S	WEIGHT (W/O BATTERY) 6.8 lb
RUN TIME (UP TO) Up to 40 min	CHAIN TYPE 3/8" PS3



8 86661 87498 9

STORE SKU

7033888D**OTHER CONFIGURATIONS**

Options listed may not be in stock

14" Bar · 61 PS3 50	\$439⁹⁹
SKU	7033888D
CHAIN PART #	3699-005-0050
BAR PART #	3005-000-4409

16" Bar · 61 PS3 55	\$449⁹⁹
SKU	7033887D
CHAIN PART #	3699-005-0055
BAR PART #	3005-000-4413

18" Bar · 61 PS3 61	\$459⁹⁹
SKU	7033889D
CHAIN PART #	3699-005-0061
BAR PART #	3005-000-4417

STIHL

BATTERY CHAIN SAW

MSA 220.0 TC-0

MODEL CONFIGURED ON FLOOR

12" BAR · 63 PS3 44

\$449⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 300 S	WEIGHT (W/O BATTERY) 5.95 lb.
RUN TIME (UP TO) Up to 22 mins.	CHAIN TYPE 3/8" PS3



8 86661 69345 0

STORE SKU

7027509D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar · 63 PS3 44	\$449⁹⁹
SKU	7027509D
CHAIN PART #	3616-005-0044
BAR PART #	3005-000-4805

14" Bar · 63 PS3 50	\$459⁹⁹
SKU	7027510D
CHAIN PART #	3616-005-0050
BAR PART #	3005-000-4809

14" Bar · 61 PS3 50	\$459⁹⁹
SKU	7033892D
CHAIN PART #	3699-005-0050
BAR PART #	3005-000-4409

STIHL

BATTERY CHAIN SAW

MSA 300.0 C-0

MODEL CONFIGURED ON FLOOR

16" BAR · 23 RS3 67

\$859⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 500 S Only	WEIGHT (W/O BATTERY) 9.92 lb.
RUN TIME (UP TO) Up to 44 min	CHAIN TYPE .325" RS3 chain



8 86661 73506 8

STORE SKU

7027507D**OTHER CONFIGURATIONS**

Options listed may not be in stock

16" Bar · 23 RS3 67	\$859⁹⁹
SKU	7027507D
CHAIN PART #	3694-005-0067
BAR PART #	3003-000-3313

18" Bar · 23 RS3 74	\$869⁹⁹
SKU	7027303D
CHAIN PART #	3694-005-0074
BAR PART #	3003-008-3317

20" Bar · 23 RS3 81	\$879⁹⁹
SKU	7027508D
CHAIN PART #	3694-005-0081
BAR PART #	3003-008-3321

STIHL

BATTERY CHAIN SAW

MSA 300.1 C-0 SET

MODEL CONFIGURED ON FLOOR

STANDARD

\$1,249⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM AP 500 S	WEIGHT (W/O BATTERY) 6.4 lb
RUN TIME (UP TO) Up to 18 min	CHAIN TYPE 3/8" RDR "RESCUE" chain



1 98520 09369 2

STORE SKU

—

OTHER CONFIGURATIONS

Options listed may not be in stock

Standard	\$1,249⁹⁹
SKU	—
CHAIN PART #	—
BAR PART #	—

STIHL

BATTERY CHAIN SAW

MSA 60.0 C-B SET

MODEL CONFIGURED ON FLOOR

12" BAR · 71 PM3 64

\$349⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM

AK 20

WEIGHT (W/O BATTERY)

6.0 lb

RUN TIME (UP TO)

Up to 40 min

CHAIN TYPE

1/4" STIHL PICCO™

7 95711 95671 4

STORE SKU

7033500D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar · 71 PM3 64**\$349⁹⁹**

SKU

7033500D

CHAIN PART #

3670-005-0064

BAR PART #

3005-008-3405**STIHL**

BATTERY CHAIN SAW

MSA 70.0 C-B SET

MODEL CONFIGURED ON FLOOR

12" BAR · 71 PM3 64

\$399⁹⁹**BATTERY & PERFORMANCE**

BATTERY SYSTEM

AK 30

WEIGHT (W/O BATTERY)

6.0 lb

RUN TIME (UP TO)

Up to 45 min

CHAIN TYPE

1/4" STIHL PICCO™

7 95711 95718 6

STORE SKU

7029016D**OTHER CONFIGURATIONS**

Options listed may not be in stock

12" Bar · 71 PM3 64**\$399⁹⁹**

SKU

7029016D

CHAIN PART #

3670-005-0064

BAR PART #

3005-008-3405

STIHL

BATTERY CHAIN SAW

MSA 70.0 C-B

MODEL CONFIGURED ON FLOOR

STANDARD

\$349⁹⁹

BATTERY & PERFORMANCE

BATTERY SYSTEM AK 30	WEIGHT (W/O BATTERY) 6.0 lb
RUN TIME (UP TO) Up to 45 min	CHAIN TYPE 1/4" STIHL PICCO™



8 86661 68335 2

STORE SKU

—

OTHER CONFIGURATIONS

Options listed may not be in stock

Standard

\$349⁹⁹

SKU	—
CHAIN PART #	—
BAR PART #	—

STIHL

BATTERY CHAIN SAW

MSA 80.0 C-B SET

MODEL CONFIGURED ON FLOOR

14" BAR · 71 PM3 72

\$499⁹⁹

BATTERY & PERFORMANCE

BATTERY SYSTEM AK 30 S	WEIGHT (W/O BATTERY) 7.3 lb
RUN TIME (UP TO) Up to 35 min	CHAIN TYPE 1/4" STIHL PICCO™



8 86661 68411 3

STORE SKU

7035591D

OTHER CONFIGURATIONS

Options listed may not be in stock

14" Bar · 71 PM3 72

\$499⁹⁹

SKU	7035591D
CHAIN PART #	3670-005-0072
BAR PART #	3005-008-3409

STIHL

BATTERY CHAIN SAW

MSA 80.0 C-B

MODEL CONFIGURED ON FLOOR

14" BAR · 71 PM3 64

\$429⁹⁹

BATTERY & PERFORMANCE

BATTERY SYSTEM AK 30 S	WEIGHT (W/O BATTERY) 7.3 lb
RUN TIME (UP TO) Up to 35 min	CHAIN TYPE 1/4" STIHL PICCO™



8 86661 68468 7

STORE SKU

7035589D

OTHER CONFIGURATIONS

Options listed may not be in stock

14" Bar · 71 PM3 64

\$429⁹⁹

SKU

7035589D

CHAIN PART #

3670-005-0064

BAR PART #

3005-008-3409