Sample Wireless (example)
Fictional spec sheet for the RF Recon example jobs.

EX-IND-3B: Industrial signal booster, B2 / B13 / B71

Bands	B2 1930-1990 MHz, B13 746-756 MHz, B71 617-652 MHz
Rule	FCC Part 20 industrial booster, carrier consent
Gain	up to 80 dB per band
Output	33 dBm composite
Monitoring	SNMP v2c traps over the LTE modem

SAMPLE · FICTIONAL
EXAMPLE