


# **Parts Manual**


Model Components P	age
Blower Housing, Air Cleaner	4
Carburetor, Fuel Supply	6
Cylinder Head, Rocker Arm Cover, Intake Manifold	10
Cylinder, Crankshaft, Camshaft, Air Guides, Piston, Rings, Connecting Rod	12
ECU Module	16
Engine Sump, Lubrication, Oil Cooler	18
Engine/Valve Gasket Set, Carburetor Overhaul Kit	22
Flywheel, Controls, Wire Harness, Alternator, Starter	24
Poplacement Engine	26

Not koluction




### Blower Housing, Air Cleaner

REF NO	PART NO	QTY	DESCRIPTION
163	691001		GASKET, Air Cleaner
186A	799158		CONNECTOR, Hose -(EVAP)
186B	845141		CONNECTOR, Hose -(EVAP)
291	592581		THERMOSTAT
304	591669		HOUSING, Blower -Used Before Code Date 18120300
304	597767		HOUSING, Blower -Used After Code Date 18120200
305	691005		SCREW -(Blower Housing)
305A	790690		SCREW -(Blower Housing) Blower Housing To Air Cleaner Base
431	798860		ELBOW, Intake
445	792105		FILTER, A/C Cartridge
467	790697		KNOB, Air Cleaner Cover
703A	592584		CLIP
918	799160		HOSE, Vacuum
964	799159		CAP, Connector
968	798584		COVER, Air Cleaner
1040	798585		PLATE, Trim
1193	592577		SCREW -(Thermostat)
1386	592580		VANE, Air
1474	592579		STUD -Air Vane
1475	592578		NUT -Air Vane




# Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
51	594427		GASKET, Intake
51A	690949		GASKET, Intake
53	690951		STUD -(Carburetor)
95	690718		SCREW -(Throttle Valve)
98	699721		KIT, Idle Speed
104	694918		PIN, Float Hinge
105	797410		VALVE, Float Needle
108	699723		VALVE, Choke
117	842633		JET, Main -(Standard)
118	842082		JET, Main -(High Altitude) (5000 > 9000 Feet)
122	798759		SPACER, Carburetor
125	796870		CARBURETOR
130	796875		VALVE, Throttle
131	796872		KIT, Throttle Shaft
133	699724		FLOAT, Carburetor
135	699729		TUBE, Fuel Transfer
137	690994	4	GASKET, Float Bowl
141	796228		KIT, Choke Shaft
142	796871		NOZZLE, Carburetor
150	841649		GASKET, Nozzle
163	691001		GASKET, Air Cleaner
186A	799158		CONNECTOR, Hose -(EVAP)
186B	845141		CONNECTOR, Hose -(EVAP)
186C	594428		CONNECTOR, Hose
187	791766		LINE, Fuel -(Cut To Required Length)
217	799771		SPRING, Choke Return
231	690718		SCREW -(Choke Valve)
240	695666		FILTER, Fuel
276	695410		WASHER, Sealing
385	797409		SCREW -(Fuel Pump) (Fuel Pump Mounted To Blower Housing)
387	808656		PUMP, Fuel
418	795912		PLATE, Carburetor Cover
601	691038		CLAMP, Hose
633	699813		SEAL, Choke/Throttle Shaft
654	690958		NUT -(Carburetor)
672	690234		GASKET, Carburetor Plate
918	799160		HOSE, Vacuum
947	798779		SOLENOID, Fuel
964	799159		CAP, Connector
975	799114		BOWL, Float
987	691000		SEAL, Throttle Shaft
1124	690988		SEAL, O-Ring -(Fuel Transfer Tube)
1124A	841653		SEAL, O-Ring -(Fuel Transfer Tube)




### Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
1126	690991		SCREW -(Fuel Transfer Tube)
1127	695407		SCREW -(Float Bowl) (Float Bowl to Carburetor Body)
1128	690990		SCREW -(Carburetor Nozzle)
1169	690990		SCREW -(Carburetor Cover Plate)




# Cylinder Head, Rocker Arm Cover, Intake Manifold

<b>REF NO</b>	PART NO	QTY	DESCRIPTION
5	799088		HEAD, Cylinder -(Cylinder #1)
5A	799089		HEAD, Cylinder -(Cylinder #2)
7	796851		GASKET, Cylinder Head
13	592244		SCREW -(Cylinder Head)
33	793557		VALVE, Exhaust
34	793556		VALVE, Intake
35	694865		SPRING, Valve -(Intake)
36	694865		SPRING, Valve -(Exhaust)
42	499586		KEEPER, Valve
45	690977		TAPPET, Valve
50	797503		MANIFOLD, Intake
51	798759		SPACER, Carburetor
51A	690949		GASKET, Intake
53	690951		STUD -(Carburetor)
54	699816		SCREW -(Intake Manifold)
122	798759		SPACER, Carburetor
163	691001		GASKET, Air Cleaner
192	690083		ADJUSTER. Rocker Arm
213	691021		BRACKET, Choke Control
337	792015		PLUG, Spark
383	19576S		WRENCH, Spark Plug PLUG
415	794903		-(Sump)
613	690341		SCREW -(Muffler)
635A	66538S		BOOT, Spark Plug
654	690958		NUT -(Carburetor)
798	697890		SCREW -(Rocker Arm)
868	690968		SEAL, Valve
883	690970		GASKET, Exhaust
914	691127		SCREW -(Rocker Cover)
918A	593998		HOSE, Vacuum -(Length 3.2 Inches)
964	799159		CAP, Connector
1022	690971		GASKET, Rocker Cover
1023	793146		COVER, Rocker -(Cylinder #1)
1023A	499600		COVER, Rocker -(Cylinder #2)
1026	690981		ROD, Push -(Steel)
1026A	690982		ROD, Push -(Aluminum)
1029	690972		ARM, Rocker
1029A	807323		ARM, Rocker
1100	791959		PIVOT, Rocker Arm




### Cylinder, Crankshaft, Camshaft, Air Guides, Piston, Rings, Connecting Rod

REF NO	PART NO QTY	DESCRIPTION
1	594971	CYLINDER ASSEMBLY -Used After Code Date 15071500
1A	591696	CYLINDER ASSEMBLY -Used Before Code Date 15071600
2	797673	KIT, Bushing/Seal -(Magneto Side)
3	391086S	SEAL, Oil -(Magneto Side)
8	792185	BREATHER ASSEMBLY -Used Before Code Date 14110500
9	690937	GASKET, Breather -Used Before Code Date 14110500
10	691108	SCREW -(Breather Assembly)
11	594163	TUBE, Breather -Used After Code Date 14110400
11A	792184	TUBE, Breather -Used Before Code Date 14110500
16	796855	CRANKSHAFT
24	796335	KEY, Flywheel
25	796910	PISTON ASSEMBLY -(.020 Oversize)
25	796909	PISTON ASSEMBLY -(Standard)
26	796912	SET, Ring -(.020 Oversize)
26	796911	SET, Ring -(Standard)
27	690975	LOCK, Piston Pin
28	844023	PIN, Piston
29	796209	ROD, Connecting
32	690976	SCREW -(Connecting Rod)
45	690977	TAPPET, Valve
46	796853	CAMSHAFT
212	695238	LINK, Throttle
227	798856	LEVER, Governor Control
250	690957	RETAINER, Breather -Used Before Code Date 14110500
252	794389	COLLECTOR, Oil -Used Before Code Date 14110500
306	796852	SHIELD, Cylinder -Used Before Code Date 18112900
306	84002166	SHIELD, Cylinder -Used After Code Date 18112800
306A	591666	SHIELD, Cylinder -(Cylinder #2)
307	691003	SCREW -(Cylinder Shield)
307A	691108	SCREW -(Cylinder Shield)
377	690979	KEY, Woodruff
405	697820	SCREW -(Back Plate)
447	691003	SCREW -(Air Guide Cover)
505	691029	NUT -(Governor Control Lever)




### Cylinder, Crankshaft, Camshaft, Air Guides, Piston, Rings, Connecting Rod


PART NO (	QTY DESCRIPTION
594325	PLATE, Baffle
690311	BOLT -(Governor Control Lever)
593465	PLATE, Back
594164	COVER, Breather Passage
594326	SCREW -(Baffle Plate)
690959	PIN, Locating
594988	PIN, Locating
690980	GEAR, Timing
100106	SEALANT, Liquid
591667	COVER, Air Guide -(Valley)
	Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
594166	REED, Breather
594165	SCREW -(Breather Reed)
794467	LABEL, Warning
797669	LABEL, Warning
	594325 690311 593465 594164 594326 690959 594988 690980 100106 591667  594166 594165




#### **ECU Module**

REF NO	PART NO	QTY	DESCRIPTION
318	691127		SCREW -(Mounting Bracket)
318A	792629		SCREW -(Mounting Bracket)
493	797176		BRACKET, Mounting -(Electronic Choke)
640	796913		WIRE ASSEMBLY -(Thermistor)
929	691003		SCREW -(Choke Control Bracket)
1436	796918		MOTOR, Stepper/Bracket
1438	796352S		MODULE, Electronic Choke
1439	794904		SCREW -(Thermistor Wire Assembly)
1458	699891		SCREW -(Stepper Motor)










# Engine Sump, Lubrication, Oil Cooler

REF NO	PART NO	QTY	DESCRIPTION
4	594973		SUMP, Engine -Used After Code Date 15071500
4A	797502		SUMP, Engine -Used Before Code Date 15071600
12	594195		GASKET, Crankcase
15	690946		PLUG, Oil Drain
20	795387		SEAL, Oil -(PTO Side)
22	694966		SCREW -(Crankcase Cover/Sump)
186	796532		CONNECTOR, Hose -(Oil Drain)
219	793338		GEAR, Governor
220	799772		WASHER -(Governor Gear)
221	841026		CUP, Governor
287	697820		SCREW -(Dipstick Tube)
305	691005		SCREW -(Blower Housing)
400	796862		COOLER, Oil
404	690442		WASHER -(Governor Crank)
415	794903		PLUG -(Sump)
448	796865		BRACKET, Oil Cooler
512	594200		HOSE, Oil Drain
523	594528		DIPSTICK
524	691032		SEAL, O-Ring
525	691037		TUBE, Dipstick
552	796638		BUSHING, Governor Crank
552A	690553		BUSHING, Governor Crank
601A	841597		CLAMP, Hose
615	698290		RETAINER, Governor Shaft
616	691045		CRANK, Governor
691	790574		SEAL, Governor Shaft
742	690328		RETAINER, E Ring
750	796208		SCREW -(Oil Pump Cover)
829	796867		HOSE, Oil Cooler -(Oil Cooler Hose)
842	691031		SEAL, O-Ring -(Dipstick Tube)
847	594609		SCREW, Dipstick tube
850	100106		SEALANT, Liquid
943	796222		SEAL, O-Ring -(Oil Pump Cover)
965	796221		COVER, Oil Pump
1017	796214		SCREEN, Oil Pump
1024	796220		PUMP, Oil
1027	798576		FILTER, Oil -(Orange)
1028	796864		ADAPTER, Oil Filter
1366	799131		DIVERTER, Oil Cooler
1373	695629		SCREW -(Oil Cooler Bracket)










### Engine Sump, Lubrication, Oil Cooler

REF NO	PART NO	QTY	DESCRIPTION
1374	796863		SEAL, O-Ring -(Oil Cooler Diverter)








# Engine/Valve Gasket Set, Carburetor Overhaul Kit

REF NO	PART NO	QTY	DESCRIPTION
3	391086S		SEAL, Oil -(Magneto Side)
7	796851		GASKET, Cylinder Head
9	690937		GASKET, Breather -Used Before Code Date 14110500
12	594195		GASKET, Crankcase
20	795387		SEAL, Oil -(PTO Side)
51	798759		SPACER, Carburetor
51A	690949		GASKET, Intake
104	694918		PIN, Float Hinge
105	797410		VALVE, Float Needle
121	799132		KIT, Carburetor Overhaul
122	798759		SPACER, Carburetor
137	690994		GASKET, Float Bowl
150	841649		GASKET, Nozzle
163	691001		GASKET, Air Cleaner
276	695410		WASHER, Sealing
358	799117		GASKET SET, Engine
524	691032		SEAL, O-Ring
633	699813		SEAL, Choke/Throttle Shaft
672	690234		GASKET, Carburetor Plate
691	790574		SEAL, Governor Shaft
842	691031		SEAL, O-Ring -(Dipstick Tube)
868	690968		SEAL, Valve
883	690970		GASKET, Exhaust
943	796222		SEAL, O-Ring -(Oil Pump Cover)
987	691000		SEAL, Throttle Shaft
1022	690971		GASKET, Rocker Cover
1095	694013		GASKET SET, Valve
1124	690988		SEAL, O-Ring -(Fuel Transfer Tube)
1124A	841653		SEAL, O-Ring -(Fuel Transfer Tube)



# Flywheel, Controls, Wire Harness, Alternator, Starter

REF NO	PART NO	QTY	DESCRIPTION
23	594169		FLYWHEEL
73	494439		SCREEN, Rotating
74	698425		SCREW -(Rotating Screen)
75	691056		WASHER -(Flywheel)
188	691108		SCREW -(Control Bracket)
216	691022		LINK, Choke -(Manual Choke)
222	798916		BRACKET, Control
265	691024		CLAMP, Casing
267	792629		SCREW -(Casing Clamp)
309	590476		MOTOR, Starter
332	691059		NUT -(Flywheel)
333	592846		ARMATURE, Magneto
334	691061		SCREW -(Magneto Armature)
363	19203		PULLER, Flywheel
405	697820		SCREW -(Back Plate)
474	592830		ALTERNATOR -(10-16 Amp Regulated)
501	593490		REGULATOR
526	691108		SCREW -(Regulator)
537	594920		KIT, Governor/Idle Spring
563	799359		SCREW -(Debris Screen Guard)
635A	66538S		BOOT, Spark Plug
697	591909		SCREW -(Starter Motor) (Drive Cap)
703	691010		CLIP
703A	592584		CLIP
729	593826		CLIP, Wire
789B	591392		HARNESS, Wiring
851	493880S		TERMINAL, Spark Plug
877	399916		WIRE/CONNECTOR, Alternator
934	592604		SCREW -(Fan Retainer)
949	798767		GUARD, Debris Screen
1005	791236		FAN, Flywheel
1012	592556		RETAINER, Link
1054	280275		TIE, Cable
1059	698516		KIT, Screw/Washer -(Alternator)
1119	691183		SCREW -(Alternator)
1448	690260		WASHER -(Magneto Armature)

### Replacement Engine

REF NO	PART NO	QTY	DESCRIPTION
	49\$8770015	1	Replacement Engine
	797510	1	Replacement Short Block
			Top No-Load Speed: 3500 -Trim: ALL
			Service Note: Transfer the Blower Housing and Rotating Screen Group.
			Service Note: Transfer Oil Drain Flex Hose
			Service Note: Transfer the Governor Spring and Governor Idle Spring to the replacement engine.
			Service Note: Transfer Manual Choke Control Assembly from the original engine to replacement engine.

26

