

Projector Information:

Turning them on - If the Projectors are off, the stream Deck button named “All TOGGLE” will display with a **RED** background. Press it once for all the front projectors to turn on, and wait about 20 – 30 seconds for the button to turn **GREEN**. Wait another 5 – 10 seconds for the image to display. In the end, you will wait a minute for all of the front projectors to turn on. The center screen will display before the other ones, due to the warm-up state of the side projectors.

Turning them off – If the projectors are on, the Stream Deck button named “ALL TOGGLE” will display with a background color of **GREEN**. Press it once for all the front Projectors to turn off. Wait about 5 – 10 seconds for the projectors to turn off. Once all the projectors are off, the button (“All TOGGLE”) will display with a background of **RED**, indicating the projectors are no longer on.

Notes to be aware of:

The side projectors will take a while to warm up, but the center projector is a laser projector and does not take any time to boot up. Because of this, only press the button once, and give it time. Pressing it multiple times may cause the projector to confuse the commands and not turn on.

The back projector is not controlled by the Stream Deck. You will have to control the projector via the remote.