Thursday, Sep 16th Notes:

- Want to have a small &, One way to achieve 1s a longer channel

DX 1 rownside is Risser

Litakes up more space and is more expensive

## Device Capacitances - 6

## In summary:

	Cut-off	Triode	Saturation
C <sub>GS</sub>	$C_{ov}$	$C_{ov} + \frac{C_1}{2}$	$C_{ov} + \frac{2}{3}C_1$
$C_{\sf GD}$	$C_{ov}$	$C_{ov} + \frac{C_1}{2}$	$C_{ov}$
$C_{GB}$	$\frac{C_1 \cdot C_2}{C_1 + C_2} \langle C_{GB} \langle C_1$	0	0
C <sub>SB</sub>	$C_5$	$C_5 + \frac{C_2}{2}$	$C_5 + \frac{2}{3}C_2$
C <sub>DB</sub>	$C_6$	$C_6 + \frac{C_2}{2}$	$C_6$