

[Skip to main content](#)



UNIVERSAL AUDIO

- [Shop](#)
- 1. [Universal Audio Support Home](#)
- 2. [Product Manuals](#)
- 3. [UAFX Manuals](#)

Search...

 [UAD Promo](#)



Del-Verb Ambience Companion Manual



Updated December 22, 2025 21:54

 This article contains complete operating instructions for the UAFX Del-Verb Ambience Companion effects pedal.

- [Del-Verb Quick Start](#)
- [Get the Latest Firmware](#)
- [Del-Verb Overview](#)
- [Del-Verb Power](#)
- [Del-Verb Connections](#)
- [Del-Verb Operation](#)
- [Del-Verb Controls](#)
- [Del-Verb Effect Details](#)
- [Del-Verb Delays](#)
- [Del-Verb Reverbs](#)
- [Del-Verb Settings in the UAFX Control App](#)
- [Del-Verb MIDI CCs](#)
- [Del-Verb Specifications](#)
- [Del-Verb Safety](#)


Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)


Accept All

Accept Essentials Only



Bill Putnam Jr.

Del-Verb Quick Start



[Download Del-Verb Quick Start](#)

Get the Latest Firmware

Be sure to update your pedal's firmware with UA Connect to get the latest features and functionality. To learn how to use UA Connect with your UAFX pedals, [go here](#).

[Get UA Connect and UAFX Control](#)

Del-Verb Overview

Pack your bags and embark on a delay and reverb fantasy.

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

With the UAFX Control mobile app, you can add tap tempo, download custom voicings for each effect, and configure MIDI CCs.

Del-Verb Features


- The most authentic vintage reverb and delay effects ever captured in a single effects pedal
 - "Golden unit" spring reverb tank, pulled from a classic '60's American guitar amp
 - Vintage German studio plate reverb sourced from The Plant (Sausalito, CA)
 - Bit-for-bit vintage '80s studio digital reverb algorithms
 - Definitive emulation of iconic tape echo unit and legendary preamp
 - Classic bucket-brigade analog delay effects with the color, texture, and tone of the original hardware
 - Pristine, studio-grade digital delays with dynamic and inspiring modulation textures
 - Add tap tempo, download custom effect voicings, and more with the UAFX Control app
 - Silent switching, buffered bypass, analog dry through, optional spillover/trails, stereo/dual mono operation
-

Del-Verb Power

To learn how to power your UAFX pedal, [go here](#).

Del-Verb Connections

To learn how to connect your UAFX pedals, [go here](#).



Del-Verb Operation

You use the knobs and switches on Del-Verb to switch between the delay and reverb effects, and change the delay sound settings. Each of the six effects can optionally be assigned voicings (factory-configured effect settings) within the UAFX Control app.

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Delay | Reverb*

The left footswitch toggles delay on/off. The right footswitch toggles reverb on/off. When toggled on, the footswitch's LED stays lit.

Effects | Tap Tempo

The left footswitch toggles both delay and reverb on/off. Tap the right footswitch two or more times to set the quarter note tempo.

Delay | Tap Tempo

The left footswitch toggles delay on/off. Tap the right footswitch two or more times to set the quarter note tempo. Reverb is always on in this footswitch mode; adjust the reverb level with the Reverb knob.

**Default setting from factory and after restoring defaults*

Delay | Reverb

Delay: Press the left footswitch to toggle delay on/off. When enabled, the left footswitch LED stays lit.

Reverb: Press the right footswitch to toggle reverb on/off. When enabled, the right footswitch LED stays lit.

Effects | Tap Tempo

Bypass: Press the left footswitch to toggle delay AND reverb. When delay and reverb are on, the left footswitch LED stays lit.

Tap Tempo: Tap (don't hold) the right footswitch twice or more to set the quarter note tempo for the delay. The right footswitch LED blinks at the current tempo.

Delay | Tap Tempo

Bypass: Press the left footswitch to toggle delay. When delay is on, the left footswitch LED stays lit. Reverb is always on, and the level is controlled with the Reverb knob.

Tap Tempo: Tap (don't hold) the right footswitch twice or more to set the quarter note tempo for the delay. The right footswitch LED blinks at the current tempo.

Effect Bypass Routing

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Del-Verb's knobs and switches control each delay effect similarly, but the effects vary, depending on the currently selected effect. See the individual delay and reverb effect details section for complete control descriptions.

Delay Time

Adjusts the delay time. Del-Verb's delay time ranges, and whether delay time changes alter pitch, vary per effect. Note that quarter note tempo can also be tapped with the right footswitch, when tap tempo is enabled with UAFX Control.

When switching between effect types when very long delay times are set with the Delay knob or by tap tempo, delay times are automatically adjusted to compensate for the maximum available length.

Effect	Delay time range	Pitch altered by delay change?
Tape EP-III	80-700 ms	Yes
Analog DMM	110-1068 ms	Yes
Precision	120-1500 ms	No*

*Pitch is altered with delay changes with certain voicings (labeled "glide").

Feedback

Adjusts the number of repeats. The Tape EP-III and Analog DMM will self-oscillate at higher feedback levels, and the Precision will repeat indefinitely at maximum feedback, but does not self-oscillate.

Self-Oscillation/Runaway Audio

When your sound is set to self-oscillate or repeat indefinitely with very high feedback, turning off the pedal does not stop the feedback. In Trails Off mode, it continues to run in the background and will return when you turn the pedal back on. In Trails On mode, it continues to play.

To stop runaway audio, adjust Feedback lower. To quickly stop runaway audio, reduce Feedback to the minimum setting.

Mix

Adjusts the level of delay that is mixed in with the dry signal. When you rotate this knob fully clockwise, the signal becomes 100% wet — you only hear the delayed signal and the dry signal is muted (kill dry).

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Reverb

Adjusts the level of reverb that is mixed in with the dry signal. When you rotate this knob fully clockwise, the signal becomes fully 100% wet — you only hear the reverb signal and the dry signal is muted (kill dry). Fully counter-clockwise, there is no reverb signal.

Delay Effect

Select the delay effect with this switch.

Reverb Effect

Select the reverb effect with this switch.

Left Footswitch

Press to toggle the effects (Effects + Tap Tempo mode) or to toggle the Delay effect (Delay + Reverb mode).

Left Footswitch LED

The left footswitch LED stays lit when both effects are active (Effects + Tap Tempo mode) or when the Delay effect is active (Delay + Reverb mode).

Right Footswitch

When in Delay + Reverb mode (default), the right footswitch toggles reverb on/off. When in Effects + Tap Tempo mode, the right footswitch taps tempo.

Right Footswitch LED

When in Delay + Reverb mode (default), the right footswitch LED stays lit when the reverb is active. When in Effects + Tap Tempo mode, the right footswitch LED flashes at the current tempo.

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Whether it's the warm repeats of a '70s Maestro EP-III tape echo, the thick color of an Electro-Harmonix Memory Man, or UA's modern-sounding Precision Delay, Del-Verb's suitcase is packed with the definitive effects found in UA's mothership — Starlight Echo Station — for easy access to killer sounds in a flash.*

Note: You can select and assign alternate Tape EP-III, Analog DMM, and Precision delay voicings using the UAFX Control app.

The following delay effects are available on Del-Verb.

Effect	Description
TAPE EP-III	A glorious system of motors and tape, vintage early-'70s tape echo units are beyond legend — and Del-Verb's Tape EP-III is, soup-to-nuts, the most complete circuit emulation of the classic hardware. From its wow/flutter randomness to the sound of the tape splice, every eccentric trait of the hardware is here. Plus, you can tweak your repeats with New or Worn tape, for tons of color and texture. Syrupy repeats, thick modulation, and mind-bending sci-fi effects are calling cards of this vintage American bucket-brigade delay. Del-Verb captures the best characteristics of multiple handpicked units from the late-'70s/early-'80s, modeling the entire circuit — right down to the unpredictable clock rate dumping — giving you startling "whoosh" effects, astonishing vibrato and chorus textures, and all the hazy zaniness of the original.
ANALOG DMM	
PRECISION	Featuring pristine, mirror-image repeats with dynamic, shimmering modulation effects, the Precision effect is a goldmine of modern delays. Easily craft with touch-sensitive, studio-grade flange and chorusing textures and pepper your creations with ping-ponging repeats, adding movement and interest to your parts.

**All trademarks are property of their respective owners and used only to represent the effects modeled as part of Del-Verb Reverb Companion.*

Tape EP-III Control Details

Control	Description	Additional Info
Delay Time	Delay time range is 80-700 ms.	Delay pitch varies as delay time is changed. Past about 3 o'clock, delay repeats begin to self-

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Analog DMM Control Details

Control	Description	Additional Info
Delay Time	Delay time range is 110-1068 ms.	Delay pitch varies as delay time is changed.
Feedback	Amount of delay repeats.	Past about 3 o'clock, delay repeats begin to self-oscillate.
Mix	Level of delay signal mixed with dry signal.	When fully clockwise, the dry signal is muted (delay is 100% wet).
Color	Input gain; adds gain to delay repeats.	Leave at noon to match hardware gain, increase beyond noon to add overdrive and harmonics.
Mod	Modulation type and depth; modulation is off at noon.	Speed is fixed to match the original hardware. The left half of the knob controls Vibrato amount, and the right half of the knob controls the Chorus amount. Set the knob at noon to disable modulation.

Precision Control Details

Control	Description	Additional Info
Delay Time	Delay time is 120-1500 ms.	Delay pitch does not vary as the delay time is changed, except with specific "glide" voicings.
Feedback	Amount of delay repeats.	Fully clockwise, delay repeats repeat indefinitely. However, they do not self-oscillate.
Mix	Level of the delay signal mixed with the dry signal.	When fully clockwise, the dry signal is muted (delay is 100% wet).
Color	Delay tone (flat at noon).	To the left, cuts treble. To the right, adds treble. At noon, tone is flat.
Mod	Modulation rate, depth, feedback, and mix.	Combines control of multiple parameters to provide light to heavy modulation. The left half of the knob controls flanger modulation and the right half controls chorus modulation. Set the knob at noon to disable modulation.

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

circuit's unique tube clipping character. The end result is all the drip, clang, whistles, and overtones of real tube-driven spring reverb.

Tip: With the UAFX Control app, you can load voicings on Del-Verb that use each of the three reverb tanks we modeled.

PLATE 140

The dense, haunting sound of late-1950s studio plate reverb is integral to more than 60 years of classic recorded guitar tones. Del-Verb's uniquely voiced plate — sourced from The Plant recording studio in Sausalito, California — frames your tones in hazy ambience as warm as the midday sun.

HALL 224

Introduced in the late 1970s, digital studio reverb allowed progressive guitarists to venture further into atmospheric exploration — fueling the platinum pop and alt-rock guitar tones of the 80s, 90s, and beyond. Del-Verb's Hall 224 effect gives you the exact, bit-for-bit algorithm of a studio staple, with all of its lush, grainy tails and mesmerizing modulation textures.

Del-Verb Settings in the UAFX Control App

With the UAFX Control app, you can change the operation of your pedal to suit your preferences.

- Tap Settings at the bottom right of the screen to access the settings for the pedal. You may need to scroll down on this screen to see all available settings.
- Tap Voicings at the bottom left to access the voicings for your effects. The screen is updated with voicings for each effect type as you change the switch settings.

 del-verb-in-app.png

Selecting Del-Verb Voicings

Voicings are factory sounds that you can apply to each Del-Verb effect. Voicings can change the fundamental character of a Del-Verb delay or reverb, in various ways. When you select a Voicing for a Del-Verb effect, that Voicing is saved with the effect type, and recalled every time you switch to that effect. Knob and tempo settings are still recalled when you switch to an effect type, even when a Voicing is applied.

Each effect type has a default Voicing, which appears in UAFX Control as "Default [effect type]".

For a list of Del-Verb Voicings [go here](#).

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Configuring Trails Bypass


Del-Verb bypass modes can be set for trails off or trails on. Bypass routing determines how the pedal behaves when the effect is off.

In both Trails modes, and when the effects are both on and off, the input signal always remains analog dry-through and the pedal output is always buffered. For additional details about why you might want to use trails or no trails bypass, [see this article](#).

To set Del-Verb bypass for trails off or trails on

Under Trails, tap Off or On.


Trails Off



When Trails is set to Off, the delay and reverb effects stop immediately when the pedal is bypassed.

Note: If the Footswitch Mode is Delay | Reverb, switching off delay or reverb in Trails Off mode does not stop the other effect from playing out.

Trails On



When bypass routing is set for trails on bypass and the effect is off, the effect plays out naturally, rather than stopping suddenly.

Del-Verb footswitch modes

Footswitch modes can be changed in UAFX Control to suit your preferences. You can configure the switches to toggle effects on and off with tap tempo for the delay, or to individually enable delay and reverb effects.


Choosing a footswitch mode

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)


Delay | Reverb



In Delay | Reverb mode, you can toggle delay and reverb effects on and off individually. There is no tap tempo in this mode.

- **Left Footswitch** toggles Delay on/off
- **Right Footswitch** toggles Reverb on/off

Delay | Tap Tempo



In Delay | Tap Tempo mode:

- **Left Footswitch** toggles delay on/off
- **Right Footswitch** taps delay tempo
- Reverb is always available; adjust the reverb level with the Reverb knob

Del-Verb MIDI CCs

For MIDI setup and configuration, including MIDI channel assignment, MIDI Program Change assignment, and MIDI CC assignment, see the [USB MIDI with UAFX Pedals Manual](#).

Sending multiple CCs

If you are sending multiple CCs in order to make multiple changes to a sound, send MIDI messages in the following order.

- Bypass / unbypass
- Effect select
- All other changes

Sending the effect selection first allows the pedal to load the initial algorithm, then make the changes to the CCs you specify. If messages are sent out of order, the pedal may not reflect your intended changes.

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

			0 = Tape EP-III
14	Delay Select	0-2	1 = Analog DMM
			2 = Precision
			0 = 1/4
			1 = Dotted 1/8
25	Division	0-5	2 = 1/8
			3 = 1/8 triplet
			4 = Dual 1/4 + dotted 1/8
			5 = Dual 1/4 + 1/8
24	Feedback	0-127	
12	FS Left	0,1	1 toggles footswitch
13	FS Right	0,1	1 toggles footswitch
22	Mix	0-127	
			Tape EP-III: 0-63 = Mint tape, 64-128 = Worn tape
27	Mod	0-127	Analog DMM: 0 = Mod off, 1-63 Vibrato, 64-127 = Chorus
			Precision: 0 = Mod off, 1-63 = Flanger, 64-127 = Chorus
28	Reverb	0-127	
			0 = Bypass
20	Reverb Bypass	0,1	1 = Unbypass
			(always only bypasses Reverb regardless of footswitch mode)

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Power requirements (power supply sold separately)	Isolated 9VDC, center-negative, 400mA minimum
Inputs	2 x ¼" unbalanced TS (input 2 for stereo connections)
Outputs	2 x ¼" unbalanced TS (output 2 for stereo connections)
Bypass modes (switchable within UAFX Control app)	Buffered bypass with or without trails
Input impedance	500 Kilohms (Mono In) 1 Megohms (Stereo In)
Output impedance	500 Ohms
Maximum input level	12.2 dBu
Maximum output level	12.1 dBu
Frequency response	20 Hz to 20 kHz, ±1 dB
USB Type-C	For registration and firmware updates via computer
Wireless technology	Bluetooth v5
Transmitted Frequency Range	2.400 GHz – 2.4835 GHz
Maximum Output Power	+4.35 dBm

Height: 2.56 inches / 6.5 cm

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Del-Verb Safety

 **Caution:** To help maintain the safety of your product, the chosen power supply must be a certified power supply complying with Limited Power Source (LPS) requirements with the following characteristics and electrical ratings: Isolated 9VDC, center-negative, 400 mA minimum, 2.1x5.5 mm barrel connector. Additional details at help.uaudio.com.

 Before using this unit, be sure to carefully read the applicable items of these operating instructions and the safety suggestions. Afterwards, keep them handy for future reference. Take special care to follow the warnings indicated on the unit, as well as in the operating instructions.

- Read the instructions.
- Keep these instructions.
- Heed all warnings.
- Follow all instructions.
- Do not use this apparatus near water.
- Clean only with dry cloth.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat source such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other.
- Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use with attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- This equipment does not contain a fuse or any other user-replaceable parts.
- A compliance marking label is provided on bottom of the unit.

United States Class B Manual Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

License exempt. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Taiwan NCC Warning Statement

本公司產品取得NCC 低功率射頻器材審驗證明依據「低功率射頻器材技術規範」之新警語如下:「取得審明之低功率射頻器材, 非經核准, 公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時, 應立即停用, 並改善至無干擾時方得繼續使用。

The company's products have obtained the NCC low-power radio frequency equipment verification certificate according to the new warnings of "Low-power radio frequency equipment technical specifications" as follows: "The low-power radio frequency equipment that has obtained the verification certificate shall not be changed by the company, firm or user without approval. Frequency, increase power, or change the features and functions of the original design. The use of low-power radio frequency equipment shall not affect flight safety and interfere with legal communications; continue to use.



Used electrical and electronic equipment should not be mixed with general household waste. Please dispose in accordance with local regulations.

- IEC 62368-1
- FCC ID: 2AXKQ2029
- IC ID: 26610-2029

20250908

Articles in this section

- [Powering your UAFX Pedals](#)
- [Connecting Your UAFX Pedals](#)
- [UAFX Control Manual](#)

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

Shop

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

- [Apollo](#)
- [Volt](#)
- [Microphones](#)
- [Guitar Pedals](#)
- [Find a Dealer](#)

Explore

- [About](#)
- [Careers](#)
- [UA Giving](#)
- [Press](#)
- [Legal](#)
- [Accessibility](#)

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)

- [Contact Us](#)
- [Get Support](#)
- [UAD Forum](#)


Subscribe and save

[Sign up for the UA Newsletter](#)

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..


[Privacy Policy](#)



Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..


[Privacy Policy](#)



Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)



Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)



Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)




VISA

Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)



Privacy Settings

This site uses third-party website tracking technologies to provide and continually improve our services, and to display advertisements according to users' interests. I agree and may revoke or change my consent at any time with effect for the future. To learn more about our Privacy and Do Not Sell statements, please refer to our Privacy Policy linked below..

[Privacy Policy](#)