# ECED3204 - Lab #4

| STUDENT NAME(s):       |  |
|------------------------|--|
| STUDENT NUMBER(s): B00 |  |

#### **Pre-Lab Information**

It is recommended that you read this entire lab ahead of time. Doing so will save you considerable time during the lab, as you will be required to write some simple C code during this lab!

# **Overall Objective**

This lab has several main objectives:

- Learn about using timers for event timing
- Learn about Pulse Width Modulation (PWM)
- Learn about Input Capture mode to measure pulse width

NOTE: This lab has a video overview at <a href="http://www.youtube.com/watch?v=OEyqhfrqMgo&hd=1">http://www.youtube.com/watch?v=OEyqhfrqMgo&hd=1</a>

# Part #1: Timing Events

## **Objective**


• Familiarize yourself with using a timer and interrupt.

#### **Required Materials**

- Microprocessor Module with Programmer
- Breadboard
- USB Cable
- Power Supply
- Computer with Atmel Studio 6.2 and Programmer Utility installed
- Push Button


## **Background**

The timer system in the ATMega644P can be used for a variety of purposes. In this first part of the lab we will use the 'overflow interrupt' of the timer. The timer system has an 8-bit or 16-bit register (depending on the timer being used), which is incremented on a rate you can choose. See Chapter 11 of the course textbook for more information.




#### **Procedure**

1. Build a similar circuit from **Part #1** of **Lab #3**, except connect the switch **to PORTD.6**. For reference the schematic is shown below – we will only use the LED in Part 1 and Part 2, but will use the switch in Part 3.



# Which might look as follows:



2. Start a new C/C++ project (see Lab #1 for details), copy the following template into it:

#include <avr/io.h>

```
#include <avr/interrupt.h>
volatile unsigned int tick;
#define LED ON() PORTD |= 1<<7</pre>
#define LED OFF() PORTD &= \sim (1 << 7)
int main(void)
    DDRD |= 1<<7;
  //Timer configuration
  TCCR0A = ?
  TCCR0B = ?
  //Interrupt mask enables
  TIMSK0 = ?
  //Enable global interrupts
  sei();
  while (1);
ISR (SPECIFY NAME HERE)
   //Code here
```

3. Before being able to compile this code, we need to finish a few things. The first is to determine the setup of TCCROA and TCCROB. We want the timer to overflow somewhere between 100-5000 times per second.

The clock source for the AVR is a 14745600Hz crystal (we learned this in Lab #1). If you used this to directly drive an 8-bit counter, the counter would overflow at the rate of  $14745600 \div 2^8 = 14745600 \div 256 = 57600$  times per second. That is too fast!

Finding Table 13-9, you can see some prescaler settings:

**Table 13-9.** Clock Select Bit Description (Continued)

| CS02 | CS01 | CS00 | Description                              |
|------|------|------|--|
| 0    | 1    | 1    | clk <sub>I/O</sub> /64 (From prescaler)  |
| 1    | 0    | 0    | clk <sub>I/O</sub> /256 (From prescaler) |

Using a prescaler of 64 would mean the timer now overflows 900 times per second. This tells us the setting for two bits in the TCCR0B register, as these CS00/CS01/CS02 bits are present in this register:

| 7     | 6     | 5 | 4 | 3     | 2    | 1    | 0    |        |
|-------|-------|---|---|-------|------|------|------|--------|
| FOC0A | FOC0B | - | - | WGM02 | CS02 | CS01 | CS00 | TCCR0B |

We will use the default (all-0) settings for TCCR0A:

| 7      | 6      | 5                               | 4                               | 3 | 2 | 1     | 0     | _      |
|--------|--------|---------------------------------|---------------------------------|---|---|-------|-------|--------|
| COM0A1 | COM0A0 | COM <sub>0</sub> B <sub>1</sub> | COM <sub>0</sub> B <sub>0</sub> | - | - | WGM01 | WGM00 | TCCR0A |

See the datasheet for a description of those bits. This means our setup area of the code looks like this:

```
//Timer configuration
TCCR0A = 0;
TCCR0B = (1 << CS00) | (1 << CS01);</pre>
```

4. Next you need to fill in the SPECIFY\_NAME\_HERE section of the code, which is the interrupt vector. This routine will get called every time the interrupt occurs. You can find a list of all the names at <a href="http://www.nongnu.org/avr-libc/user-manual/group\_avr\_interrupts.html">http://www.nongnu.org/avr-libc/user-manual/group\_avr\_interrupts.html</a> - you must be VERY CAREFUL to ensure you use a name that exists on the ATmega644P device! In this case look for the TIMERO\_OVF\_vect name, as shown in the following:

| THVIBACO_OVFO_VCCC | DIO_OVERGEOWV | TIME/COUNCIO OVERTION   | רדר אורער אוד, הו אורער אודיים, הו ווווער אודיים, הו ווווערר אודיים, הו ווווערר אודיים, הו ווווערר אודיים, הו   |
|--------------------|---------------|-------------------------|---|
| TIMER0_OVF_vect    | SIG_OVERFLOW0 | Timer/Counter0 Overflow | AT90S1200, AT90S2333, AT90S4414, AT90S4433, AT90S4434, AT90S8515, AT90S8535, AT90PWM216, AT90PWM216, AT90PWM216, AT90PWM316, AT90PWM316, AT90PWM316, AT90PWM316, AT90PWM316, AT90PWM316, AT90PWM32, AT90PWM31, AT90PWM31, AT90CAN128, AT90CAN32, AT90CAN64, ATmega103, ATmega128, ATmega1284P, ATmega166, ATmega161, ATmega162, ATmega163, ATmega325, ATmega323, ATmega323, ATmega3250, ATmega3250, ATmega3290, ATmega48, ATmega64, ATmega649, ATmega649, ATmega649, ATmega488, ATmega640, ATmega1280, ATmega1281, ATmega2560, ATmega16HVA, ATmeyn11, ATmiy12, ATmiy12, ATmiy131, ATmiy12, ATmiy148, ATmiy261, ATmiy141, ATmiy861, AT90USB128, AT90USB1287, AT90USB1286, AT90USB1287, AT90USB1286, AT90USB647, AT90USB646 |

5. Finally, you need to enable the 'overflow' interrupt, which is done by setting bit 1 of the TIMSKO register:

|   | 7 | 6 | 5 | 4 | 3 | 2      | 1      | 0     | _      |
|---|---|---|---|---|---|--------|--------|-------|--------|
|   | - | - | - | - | - | OCIE0B | OCIE0A | TOIE0 | TIMSK0 |
| • | R | R | R | R | R | R/W    | R/W    | R/W   |        |
|   | 0 | 0 | 0 | 0 | 0 | 0      | 0      | 0     |        |

6. At this point, your code should look similar to this:

```
int main(void)
{
    DDRD |= 1<<7;

    //Timer configuration
    TCCR0A = 0;
    TCCR0B = (1 << CS00) | (1 << CS01);

    //Interrupt mask enables</pre>
```

```
TIMSK0 |= 1 << TOIE0;

//Enable global interrupts
sei();

while(1);
}

ISR(TIMERO_OVF_vect)
{
   //Code here
;
}</pre>
```

7. Finally, program the interrupt service routine (ISR) to toggle the LED. An example implementation is as follows, using the 'tick' variable to keep track of how many runs through the interrupt routine have occurred:

8. Adjust the delay to blink 5 seconds on, 5 seconds off.

# Part #2: PWM Output

## **Objective**

• Generate a PWM signal with a variable duty cycle.

#### **Required Materials**

Setup from Part #1

# **Background**

The timer system in the ATMega644P can be used for a variety of purposes. In this first part of the lab we will use the 'overflow interrupt' of the timer. The timer system has an 8-bit or 16-bit register (depending on the timer being used), which is incremented on a rate you can choose. See Chapter 11 of the course textbook for more information.

#### **Procedure**

- 1. Build the same circuit from **Part #1** of this lab, or if you just completed Part #1 leave your circuit as-is.
- 2. Using Timer 2, generate a Pulse Width Modulation (PWM) signal of around 2-10 kHz. Output this on in PD7 (which is the OC2A pin). You will need the following references in the datasheet:
  - Section 15.11.1 TCCR2A Register
  - Section 15.11.2 TCCR2B Register

You should configure timer/counter 2 as the following:

- o PWM, Phase Correct (WGM2 = 0, WGM1 = 1, WGM0 = 0)
- Clock divider = IOClock / 8
- o OC2A pin operating in non-inverting mode

The following shows the basic operating instructions:

```
#include <avr/io.h>
int main(void)
{
    DDRD |= 1<<7;
    //Set clock divider to be /8
    TCCR2B = ??
    //Set waveform generation mode
    TCCR2A |= ??
    //Set output on OC2A pin
    TCCR2A |= ??
    //Set PWM to half-way (50% duty cycle)
    OCR2A = 127;</pre>
```

```
while(1);
```

- 3. The LED should be partially illuminated now. You can also check with an oscilloscope you are getting an appropriate signal.
- 4. Set the OCR2A register to various values in the range 0-255, and observe the effect on the output signal. Use an oscilloscope to measure how the duty cycle changes, and measure the frequency as well of the PWM output.
- 5. Add some code to slowly increase the value, and see what happens. For example here is a complete code listing:

```
#include <avr/io.h>
#include <util/delay.h>
int main(void)
{
    DDRD |= 1<<7;
    //Set clock divider to be /8
    TCCR2B = 1<<CS21;
    //Set waveform generation mode
    TCCR2A |= 1<<WGM20;
    //Set output on OC2A pin
    TCCR2A |= 1<<COM2A1;

    OCR2A = 0;
    while(1) {
         OCR2A++;
         _delay_ms(50);
    }
}</pre>
```

# Part #3: Input Capture

## **Objective**

Measure the time a button is pressed using the input capture

#### **Required Materials**

- Setup from Part #1
- Push-Button wired into PORTD.6 (should have been done in Part #1)

## **Background**

The timer system in the ATMega644P can be used for a variety of purposes. This section will use the 'Input Capture' functionality, which is used to measure the length of a pulse. You can use this for many features, such as:

- 1) Measuring the width of a pulse
- 2) Measuring the duty cycle of a signal
- 3) Measuring the frequency of a signal

We will measure the length of time a push-button is pressed. If the button is pressed for a length of time inside our 'allowed' range, an LED will light up. If you press the button for too short or too long of a time, the LED will not light up.

NOTE: This lab has a video overview at <a href="http://www.youtube.com/watch?v=OEyqhfrqMgo&hd=1">http://www.youtube.com/watch?v=OEyqhfrqMgo&hd=1</a> . It may be useful to see the system operating to understand the push button operation.

#### **Procedure**

- 1. Ensure you have the same setup as previous parts, including the button connect to PORTD.6
- 2. Start a new project (or re-use the project from the previous parts), and load the following template:

```
#include <avr/io.h>
#include <avr/interrupt.h>
#include <stdint.h>
#include <util/delay.h>

#define LED_ON() PORTD |= 1<<7
#define LED_OFF() PORTD &= ~(1<<7)

volatile unsigned char current_edge = 0;
volatile uint16_t starting_cnt;
volatile uint16_t ending_cnt;
int main(void)
{
    //LED as output
    DDRD = 1<<7;
    //Pull-up on ICP
    PORTD |= 1<<6;</pre>
```

```
//Defaults
  TCCR1A = 0;
   //Enable noise cancel, look for falling edge
  TCCR1B = ???
   //Clock divided by 1024
  TCCR1B |= ???
   //Input capture interrupt Enable
  TIMSK1 |= ???
  //Enable interrupts
  sei();
  uint16 t timediff;
  while(1){
          if(current edge == 2){
                 //Check for normal (no wrap-around)
                 if (starting_cnt < ending_cnt) {</pre>
                        //A - B
                        timediff = ending_cnt - starting_cnt;
                 } else {
                        //wrap around
                        //(0xffff + A) - B, done without requiring signed
math
                        timediff = starting_cnt - ending_cnt;
                        timediff = 0xffff - timediff;
                 }
                 if ((timediff > 10000) && (timediff < 30000)){
                        LED ON();
                        \overline{\text{delay ms}}(5000);
                 LED OFF();
                 current edge = 0;
  }
ISR(TIMER1_CAPT_vect)
   if(current edge == 0){
         //Save timestamp
          starting_cnt = ???;
          //Switch to rising edge
          TCCR1B |= ????
          current edge = 1;
   } else if (current_edge == 1) {
          //Save timestamp
          ending_cnt = ICR1;
          //Switch to falling edge
          TCCR1B &= \sim (?????);
          current_edge = 2;
```

```
}
TIFR1 |= (1<<ICF1);</pre>
```

3. Using the register settings for TIMER1 from the ATMega644A datasheet, fill in the blanks above. The objective of this code is to measure the length of time the push-button signal is **low**, as when the button is pressed the input capture line goes low.

# **Lab Questions**

- 1. In Part 1, we uses an interrupt which is called periodically. What is the fastest number of times we could call that interrupt using the timer overflow interrupt (i.e. using the lowest possible clock prescaller, giving you the fastest clock operation)? Would you foresee any issues calling the interrupt that quickly?
- 2. What was the frequency of the PWM signal?
- 3. How would you use the input capture feature to measure the distance to an object if you have a "Time of Flight" sensor, which generates a pulse indicating how long it took a sound echo to reflect off an object?
- 4. In Part 3, the button must be pressed for between 10 000 and 30 000 counts of the input capture register. Based on the Timer1 prescaler settings and the system operating frequency, what duration does that correspond to?