

General controls

GT spectra controls

Open a minicube in .h5 format
Open previous/next file in the current directory
Save the figure with all loaded images.

Active Hyp

VNIR

SWIR

When both VNIR and SWIR are open, choose the one you want to be active for color image controls and metadata reading.

CSV (*.csv)
TXT (*.txt)
PNG (*.png)
JPG (*.jpg)
SVG (*.svg)

Save GT spectra values
Save graphical image of GT spectra

Std

Show/Hide standard deviation distribution

Hyperdoc App Window




Image controls

Metadata

RGB default : All sliders are disabled and fixed to the default wavelength.

RGB user : Use the three sliders to assign RGB channels to chosen wavelengths

Grayscale : Only one slider is enabled to choose the wavelength of the grayscale image.

Transparency control of GT image overlay

Image Choice

- RGB default
- RGB user
- Grayscale

GT Transparency = 0 %

Choose Metadata to display

GTLabels
aged
bands
cubeinfo
date
device