
## FSCC Driver Manual Installation


Starting in Windows 7 we require a manual installation of the FSCC driver to ensure the ports get assigned in the correct order.

This installation guide is for a 4 port FSCC card. Installing a 2 port FSCC card is the same but half as long.




From the Device Manager's perspective the 4 port FSCC card is essentially dual 2 port FSCC cards.

To start you need to determine which device is for ports 1 & 2 and which is for ports 3 & 4 by going into the properties for each device.




Looking at the 'Location information' for each device will show you where it is located on your computer bus.


For ports 1 & 2 you will choose the device with the lower 'device #'. In this specific situation we are choosing 'device 4' over 'device 5'.




Now that we have found our first device we need to install our multifunction driver.




The driver isn't on your system yet so we need to browse to it.



Point to the extracted driver directory for your specific architecture.







Now that we have installed the multifunction driver we need to install the individual synchronous and asynchronous driver for each port.

In Windows 7 these can be arranged randomly and it is important to install them in the correct order to ensure the port numbering is how you would expect. You need the driver for each one in this order.


Fscc\Port1 Fscc\Port2 SerialFC\Port1 SerialFC\Port2




You can find which device is which by looking at the 'Hardware Ids'.





Once we find our first device (Fscc\Port1) we install the driver.







The driver for these individual devices is in the same directory as the multifunction driver we initially installed.







You now need to look for the 2nd device (Fscc\Port2).










You now need to look for the 3rd device (SerialFC\Port1).









You now need to look for the 4th device (SerialFC\Port2).







You have now correctly installed ports 1 & 2. If you have a 2 port card you can start using your device. If you are using a 4 port device you will have to repeat the process for ports 3 and 4.