

How to download the firmware



STEP1:





STEP2:



STEP3:










Chose USB serial port









OK