Steps

Install Alarm server

```
*Download Apache ActiveMQ 5.9.0 //At this time, the download link on Apache website doesn't
work. Instead, downloaded it from openlogic
*unzip activemq
>./activemq start
>yum list installed mysql-server //check if mysql server has been installed, if not, install it
>yum list installed mysql //check if mysql client has been installed, if not, install it
>sudo /sbin/service mysqld start //start mysql server
>cd /home/controls/bldemo/css/BEAST
*copy MYSQL_USER.sql and ALARM_MYSQL.sql from BEAST source code plugin
org.csstudio.alarm.beast to here
>mysql -u root <MYSQL USER.sql //create user alarm with password $alarm
>mysql -u root <ALARM_MYSQL.sql
>cd /home/controls/css/BEAST/
>wget http://ics-web.sns.ornl.gov/css/nightly/alarm_server_3.2.16-linux.gtk.x86_64.zip
>unzip alarm server 3.2.16-linux.gtk.x86 64.zip
*Since I need full priviledge on ALRM table, I increased my previlege:
      >mysql -u root
      mysgl>GRANT ALL ON ALARM.* TO alarm@'%';
      mysql> flush privileges;
>cd /home/controls/bldemo/css/BEAST
*create alarm server script to start alarm from service (replace chenxh to your user name)
-----alarm server script------
ALARM SERVER=/home/controls/css/BEAST/AlarmServer 3.2.16
# Use 4809 for telnet access
CONSOLE=4809
# Combine global settings with beam-line settings
INI=/tmp/alarm server.ini
cat /home/controls/css/settings.ini /home/controls/bldemo/css/settings.ini >$INI
ARGS="-console $CONSOLE -data $ALARM SERVER/workspace -consoleLog
-pluginCustomization $INI"
USER=chenxh
unset DISPLAY
function start()
      su - $USER -c "nohup $ALARM_SERVER/AlarmServer $ARGS
>>$ALARM SERVER/console.log 2>&1 &"
function stop()
```

```
echo close | nc localhost $CONSOLE
}
case $1 in
start)
       start
stop)
       stop
restart)
       stop
       start
status)
       ps aux | fgrep AlarmServer | grep -v fgrep
console)
       telnet localhost $CONSOLE
*)
       echo "Usage: $0 {start|stop|restart|status|console}"
     exit 2
esac
>sudo cp alarm_server /etc/rc.d/init.d/
>sudo chkconfig --add alarm_server
>sudo chkconfig alarm server on
>sudo chkconfig --list alarm_server
>service alarm_server //check if it is successfully installed
>service alarm_server start
Install Alarm UI to CSS
*Menu->Help->Insatll New Software...
*Select Work with to: "SNS update-site - http://ics-web.sns.ornl.gov/css/updates/"
*Install Optional SNS Control Room Tools
*After Install, restart CSS
*Menu->Edit->Preference->CSS Applications->Alarm->Alarm System
*In the URL entries, replace "localhost" to "192.168.37.197"
*Click OK and Restart CSS.
*Menu->Window->Open Perspective->Alarm
```

Resources

http://sourceforge.net/apps/trac/cs-studio/wiki/BEASTManual