

INSERT BATTERIES

\POLARITY

INDICATORS

AS SHOWN,

4 PLACES

PRESSURE SENSOR


(BLACK WIRE, 4 PINS)

MOTOR


(COLORED WIRES)

\POWER


(BLACK WIRE, 2 PINS)







APPLY VENT ID LABEL HERE. NOTE ORIENTATION.



GENERAL NOTES

- SEE ARENA PLM FOR PART NUMBER REFERENCE
- DESIGNATORS AND CURRENT REVISIONS. [•] CALLOUTS ARE APPLIED TO TOLERANCES THAT MAY REQUIRE SPECIAL QUALITY CONTROL PROCESSES.

 QUALITY CONTROL INSTRUCTIONS ARE OUTSIDE THE SCOPE OF THIS DRAWING AND ARE DEFINED BY EXTERNAL DOCUMENTATION TO BE AGREED TO WITH THE MANUFACTURER.
- ALL DIMENSIONS AND TOLERANCES MUST BE HELD REGARDLESS OF THE USE OF QUALITY CONTROL SYMBOLS

- [◆]
 (X.XX) DIMENSIONS ARE USED AS REFERENCE ONLY AND ARE NOT SUBJECT TO TOLERANCES.
 UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS AND TOLERANCES ARE APPLICABLE AT 20 DEGREES CELCIUS (68 DEGREES FAHRENHEIT) IN ACCORDANCE WITH ANSI/ASME B89.6.2
 ALL HOMOGENOUS MATERIALS AND PROCESSES IN THIS DRAWING SHALL BE COMPLIANT TO THE EU ROHS DIRECTIVE 2011/65/EC
 REFER TO DETAILED WORK INSTRUCTIONS FOR ASSEMBLY SPECIFICATIONS SUCH AS SCREW TORQUE AND GLUE VOLUME.

ASSEMBLY OVERVIEW:

(FOR REFERENCE ONLY. REFER TO DETAILED WORK INSTRUCTIONS FOR PRODUCTION ASSEMBLY INSTRUCTIONS)

1. REMOVE THE MAGNETIC FACEPLATE COVER.

REMOVE THE VENT BOARD COVER FROM THE BALLJOINT FACEPLATE.
ATTACH THE BATTERY POWER CABLE TO THE BATTERY PCA.
INSERT THE BATTERY PCA AS SHOWN. ENSURE SNAPS ARE FULLY ENGAGED. ENSURE WIRES ARE ROUTED BENEATH THE BOARD AS

SHOWN.
CONNECT THE THREE CABLE HARNESSES TO THE VENT BOARD AS SHOWN. ENSURE THE MOLEX CONNECTORS ARE FULLY SEATED.
PLACE THE VENT BOARD INTO POSITION AND SNAP THE VENT BOARD COVER ON TOP OF IT. ENSURE THE WIRES ARE NOT TANGLED OR DAMAGED, AND ARE HIDDEN UNDER THE BOARD.
REMOVE TAPE AND REMOVE THE PRESSURE SENSOR COVER.
ATTACH THE PRESSURE SENSOR BOARD TO THE PRESSURE SENSOR CABLE HARNESS. SEAT THE PRESSURE SENSOR IN POSITION ON THE

MAIN BODY AS SHOWN.

USE SCREWS TO ATTACH THE PRESSURE SENSOR COVER TO THE MAIN BODY WHERE SHOWN.

APPLY 1 VENT ID LABEL CENTERED ON THE VENT BOARD COVER. ENSURE THAT TEXT ORIENTATION IS AS SHOWN IN DRAWING.

APPLY 1 VENT ID LABEL ONTO THE MAIN BODY AS SHOWN. ENSURE

THE LABEL EDGE IS ALIGNED WITH OUTER BOX NOTCH.
INSERT THE 4 BATTERIES INTO THE BATTERY PACK. USE THE POLARITY
INDICATORS ON THE BATTERY PACK TO ENSURE CORRECT POLARITY.
APPLY 2 ARROW STICKERS TO THE BATTERY PACK AS SHOWN.
APPLY 1 ARROW STICKER TO THE BALLJOINT FACEPLATE AS SHOWN.

RE-ATTACH THE MAGNETIC FACEPLATE COVER.
THE ASSEMBLED BATTERY PACK IS SHIPPED ALONGSIDE THE VENT. DO

SCALE:1:2 THIS DOCUMENT IS THE PROPERTY OF ECOVENT, NEITHER THIS DOC HERIN MAY BE USED, REPRODUCED OR DISCLOSED TO THIRD PARTI

NOT INSTALL THIS ITEM. DRAWING NO. 201-00009 ECO DATE BY 000082 02/27/16 AK DESCRIPTION DO NOT SCALE DRAWING. WORK TO DIMENSION INITIAL RELEASE (FROM 901-00009 DRAWING) PART NUMBER AND DRAWING NUMBER UPDATE DCO-000043 3/25/16 AK DCO-000044 3/29/16 AK VENT 12X6 FLOOR 901-00009 DESCRIPTION