Workflow

Step 1 | Sign contract

Step 2 | Create order

Step 3 | Add shipment(s)

Step 4 | Receive shipment(s)

Step 6 | Monitor and validate

Step 5 | Rack and stack

Edit order

Change order status

Manage inventory

Track machines

Onboarding

Onboard new customers

Receive new machines

Deploy new machines

Create and change pool

Run-time Operations

Machine status

configs

troubleshooting

Machine diagnosis and repair **Customer support requests**

Machine tickets

Inventory tickets

Ops Reference

Adjust S9 frequency and voltage

Machine statuses

Bulk update machines

Filtering overview

Machine types

Minder Training Center

Counts

Temperatures

Machine tickets

Repairs

Servers

Support Requests

Customer Success


Tags Repair Center Workflow



Receive shipment(s)

Overview **Receiving Machines**

Overview



Receiving Machines


The following flowchart describes the process the DCT who receives the shipment should follow to unload and get machines out onto the floor:

TO RECEIVE MACHINE SHIPMENTS AT THE DATA CENTER

- 1. Send a message in Teams to the appropriate Deployments channel when the truck arrives.
- 2. Photograph truck contents from the rear of the truck before unloading. Photograph anything that looks unusual, or not quite right.
- 3. Mark pallets before unloading: T1 #1 x75 = Truck 1 Pallet 1 75 Machines.
- 4. Photograph all damage to pallets on all sides of pallets as you unload. When in doubt, take a photo. Keep damaged items separate from undamaged.

Ensure that the machines on the order form for the customer match the machines that are received in the truck. If the machine type does not match, escalate to a supervisor. Do not accept the shipment.

- 5. Sign shipping documents noting any damage that you saw and photographed.
- 6. Unbox and separate by model type if under 500 machines. Send out for on rack deployment if over 500 machines.
- 7. Scan serial numbers into Excel.



PREVIOUS Step 3 | Add shipment(s) NEXT

Step 5 | Rack and stack