















Communities **▼** Why PC? **Builds** History **Meet the PCMR Team**

Posted by u/KingSwaggleV Intel® Pentium® M 1.4ghz, Intel® 855GM, 2GB RAM 3 years ago

Posts

Windows 10 forces me to enter a bluetooth pin even though I don't have one.

Tech Support Solved

I was going to play GH3 today, and noticed that my wiimote wasn't being connected to my PC. I then went to the Bluetooth settings and tried to connect the wiimote, but when i do, it says i require a pin. I don't have a pin and the wiimote shouldn't need one, but it forces me to put one in, and everything i tried has come up incorrect.

I am using the Windows 10 Creators Update, but have never had this problem before the update, as i could just click connect without a pin.

Any help/advise would be greatly appreciated!

■ 13 Comments Give Award Share •••

100% Upvoted

This thread is archived

New comments cannot be posted and votes cannot be cast

SORT BY BEST -

- [deleted] 5 points · 3 years ago
- I have found an extremely easier way to do this. Go to the control panel, and under Hardware and Sound, click on "Add a Device". Your computer should detect the remote after you press and hold that tiny red button on the back of the remote and will probably show up as "Nintendo RVL-CNT-01" or something. Click it and click next when the prompt for the pin shows up. Give it about a minute and it should connect!

Share Report Save

- KingSwaggleV Intel® Pentium® M 1.4ghz, Intel® 855GM, 2GB RAM 🎤 1 point · 3 years ago · edited 3 years ago
- Im trying that now but doesnt want to seem to work. Just says to try again or refer to manufactuers manual.

EDIT: Of course as soon as i send that it starts to work... Thanks!

Give Award Share Report Save

- ifatwork2 2 points · 3 years ago
- Hit cancel when it prompts you for a pin. The device should automatically pair. You may have to do it a few times to get it to connect.

Give Award Share Report Save

- KingSwaggleV Intel® Pentium® M 1.4ghz, Intel® 855GM, 2GB RAM 🥕 1 point · 3 years ago · edited 3 years ago
- I've been trying this, but no luck still. I've looked elsewhere and it says to put in '1111' '1234' '0000' and stuff, but still doesn't work. Any other suggestions?

EDIT: Well fuck, as soon as i said that, i carried on with the cancelling technique and it finally connected. Thanks for the help!

Give Award Share Report Save

- jfatwork2 3 points · 3 years ago
- Ok, here is what I did to connect mine.

Put Bluetooth in pairing mode on computer, Start searching for new devices, Push 1 and 2 simultaneously on the controller and hold for like 5 seconds, It should appear in devices, click pair or connect.. what ever the button on the





Q Search

tnese steps.





Now this is specifically for the Wii mote with motion Plus, apparently the Non-Motion plus pairs significantly easier. Also, it doesn't work almost at all with any after-market controllers. It has to be a Nintendo Controller.

If the problem persists, you may have to replace your blue-tooth dongle. (I actually had to do this as well)

I will say this though, If you enter a code of any kind into the windows prompt you have a 100% chance of failure to pair the device.

Also, once paired it will still be a pain in the ass to connect once you turn the remote off. I pretty much have to re-Pair the Wii-Mote every other time I use it. I didn't have the opportunity to connect a wii-mote on any other operating system so I dont know if this is a specific windows 10 pain in the ass problem, but everyone else seems to think so.

keep me posted.

Give Award Share Report Save

- 🛧 KingSwaggleV Intel® Pentium® M 1.4ghz, Intel® 855GM, 2GB RAM 🎤 2 points · 3 years ago
- Works like a charm, thank you!

Give Award Share Report Save

- ♠ ifatwork2 3 points · 3 years ago
- No Problem Brother. Game On.

Give Award Share Report Save

- ♠ DJOctavio Specs/Imgur here 2 points · 3 years ago
- ♣ Uh, how do you put bluetooth to pairing mode? The new Windows Update confuses me.

Give Award Share Report Save

- ♠ jfatwork2 1 point · 3 years ago
- ◆ On the computer its "Search" or "Scan" for new devices. The WII-mote should be blinking which indicates it is in pairing mode. If you do not have the bluetooth options menu in windows, then it more than likely your bluetooth device is not installed properly. It can be bad drivers (or no drivers), Bad usb port, incompatible device vs your current version of windows, or even just a Bad device. These devices basically hate existing so they have a pretty high failure rate.

Give Award Share Report Save

- ♠ Azzayo 1 point · 3 years ago
- is it the cancel button at the bottom right to close the add devices window or the cancel button to next to the connect button?

Give Award Share Report Save

- ♠ jfatwork2 1 point · 3 years ago
- The Cancel that appears on the prompt that appears asking for a code.

Give Award Share Report Save

- NinjGames shhhhh 1 point · 3 years ago
- took me like 20 mins but i got it

Give Award Share Report Save

- KingSwaggleV Intel® Pentium® M 1.4ghz, Intel® 855GM, 2GB RAM 🥕 1 point · 3 years ago
- Yh it's a tough one. Look at the other peoples comments, like adding from control panel instead of adding through the Bluetooth windows 10 menu.

Give Award Share Report Save