A SUBSIDIARY OF R H WHITE COMPANIES, INC.

41 Central Street
Auburn, MA 01501
TEL 888-377-7678
FAX 508-248-2895

January 9th, 2013

Mr. George Zoto
MA DEP Southeast Regional Office
20 Riverside Drive
Lakeville MA 02347

Re: **Updated Total Coliform Sampling Plan**
Facility Location: Corn Hill Condominiums- Truro
PWS ID#: 4300027

Dear Mr. Zoto:

Please find enclosed a copy of an updated total coliform sampling plan for Corn Hill Condominiums in response to the sanitary survey conducted on July 3rd, 2012. As can be seen, the plan now reflects two distribution routine sample (RS) sites.

Should you have any question, please feel free to contact our office at 888-377-7678.

Respectfully yours,
WHITEWATER, INC.

Roy A. Maher
Operations Supervisor

cc: Allison Rescigno, MA DEP SERO
Truro Health Department
Vijay Jain, WhiteWater, Inc.

MassDEP Drinking Water Program - SERO
COLIFORM SAMPLING PLAN
Small Systems – Quarterly (population <1,000)

Please fill in the highlighted areas and return for approval to your DEP Regional Office

PWS ID#: **4300027** PWS Name: **Corn Hill Condominiums** PWS Town: **Truro**

Population Winter: **0** *# RS Winter samples:* **0**	Population Summer: **45** *# RS Summer samples:* **2**	TANKS: **N/A** *# RS Tank samples:* **0**

# RS Winter + # RS Tanks = **(RS)** samples required for Winter:	**0**	per	**Quarter**
# RS Summer + # RS Tanks = **(RS)** samples required for Summer:	**2**	per	**Quarter**
No. of raw water **(RW)** samples required:	**0**	per	**Quarter**
No. of plant tap **(PT)** samples required:	**0**	per	**Quarter**
TOTAL Number of Samples Required Winter (RS + PT +RW):	**0**	per	**Quarter**
TOTAL Number of Samples Req. Summer (RS + PT + RW):	**2**	per	**Quarter**

* Sample Type, Sample Code#, and DEP Approved Sample Site must correspond to the sample columns on the DEP Total Coliform Report Form

Sample Type*		Sample Code#*		DEP Approved Sample Site* Sampling Point Name and/or Street Address		Sampling Frequency		
RS		**001**		**Unit 6 Spigot**		**1**	per	**Quarter**
UR		**1a**		**Unit 12 Spigot**				
DR		**1b**		**Unit 17 Spigot**				
AR		**1c**		**Unit 8 Spigot**				
RS		**002**		**Unit 19 Spigot**		**1**	per	**Quarter**
UR		**2a**		**Unit 19 Bathroom**				
DR		**2b**		**Unit 19 Kitchen**				
AR		**2c**		**Unit 19 Spigot**				

Key to Sample Type Codes			
RS	Routine Sample site	(tap representative of the water system)	Example **Sample Code # 001**
UR	Upstream Repeat sample site	(tap upline of the RS sample tap)	Example **Sample Code # 1a**
DR	Downstream Repeat sample site	(tap downline of the RS sample tap)	Example **Sample Code # 1b**
AR	Additional Repeat sample site	(additional tap representative of the water system)	Example **Sample Code # 1c**
RW	Raw Water sample site	(untreated source water)	Example **Sample Code # RW-01G, RW-01S etc.**
PT	Plant Tap sample site	(entry point-finished (treated) water sample tap)	Example **Sample Code # 10000, 10001, etc.**

Also attach a map or sketch of your water supply distribution system showing the locations of the bacteria sampling sites, wells, and storage tanks.

Public Water Supplier Signature: Roy A. Walker DATE: 01/09/13

For DEP/DWP use

Total # of bacteria samples required per 310 CMR 22.05 _____per _____.

Action: _____ Date: _____

DWP Name: _____Signature: _____

Corn Hill Condominiums
Truro, MA
PWSID# 4300027
Unit 19 002RS, 2aUR, 2bDR, 2cAR
Unit 8 1c AR
Wells
Unit 6 001 RS
Unit 17 1b DR
Unit 12 1a UR
Google earth
Imagery Date: 3/11/2012 42°00'11.81" N 70°04'47.97" W elev 111 ft eye alt 1233 ft