
NOVOMATIC - NOVOUNITY II

How to synchronize/update time Settings from DB Server

1. "STOP" DB server from NU2 system

Stop Server

The **Stop Server** button allows for stopping and restarting the Novo Unity Server.



After clicking the button, the following window is displayed:




Description:

STOP	Stops the Novo Unity Server program.
RESTART	Restarts the Novo Unity Server program.
CANCEL	Aborts the process and closes the window.

2. Exit the NU2 system application.
3. "CTRL + ALT + DELETE", Windows will be logged off. Click "LOG OFF"
4. Fill in below details at "Administrator Account" under DB Server.



Username: Administrator
Password: +432252606300



5. From there, you can change the time settings. Then Apply.. then OK.
6. After logging in as Administrator, NU2 system will launch automatically.
7. Log in again got go back to the Main Novo Unity Game



8. Request AM to log in again, and “STOP” the DB server again.
9. Check on the time system settings in the machines if its updated and it’s good to go.