CORONA
— RESORT & CASINO —


lot Technical Department

Ainsworth A600 RAM Clear Procedure

Technical Luke

January 1, 2025

DIP Switch number 1



1. Power off machine
2. Open logic door
3. Switch down DIP switch number 1
4. Power on machine




5. Waiting boot up


6. Reset DIP Switch 1




7. Press Red Button

8. Press "yes"









9. Chose type of touchscreen and Press **Next**


10. Set machine model is "High Boy" and Press **Next**






11. Select the market, location, currency and Press **Next**


12. Set date and time and Press **Next**






13. Serial Number of machine will auto generate then press **Next**


14. Set denomination according the Masterlist and Press **Next**






15. Select the Bet configuration and display type of currency and Press **Next**


16. Select accounting denom and Press **Next**






17. Select token value and Press **Next**


18. We don't use hopper so just Press **Next**






19. Select MEI for banknote acceptor and Press **Next**


20. Select type of printer is "TransAct" and set payout limit. Press **Next**





21. No setting just Press **Next**


22. Chose valiadation is "Secure Enhanced" and Press **Next**






23. Press Next

24. Press Next






25. Chose cashless transfer type is “AFT” and Press **Next**


26. Select GAT version and Press **Next**





27. Set limit and Press **Next**


28. Set handpay limit and Press **Next**






29. Set jackpot amount and Press **Next**


30. Set jackpot amount and Press **Next**





29. Set jackpot amount and Press **Next**


30. Set jackpot amount and Press **Next**





31. Press **Next**

32. Press **Next**



33. Check setting and Press Save

34. Wating machine reload.

35. Done