# RadiationPressureModel 5.1

Generated by Doxygen 1.8.5

Mon Jul 31 2023 11:41:56

## **Contents**

1	Mod	lule Inde	ex	1
	1.1	Module	es	1
2	Nam	nespace	Index	3
	2.1	Names	space List	3
3	Hier	archica	l Index	5
	3.1	Class I	Hierarchy	5
4	Data	Struct	ure Index	7
	4.1	Data S	tructures	7
5	File	Index		9
	5.1	File Lis	st	9
6	Mod	lule Doc	eumentation	11
	6.1	Models	<b>3</b>	11
		6.1.1	Detailed Description	11
	6.2	Interac	tions	12
		6.2.1	Detailed Description	12
	6.3	Radiat	ionPressure	13
		6.3.1	Detailed Description	14
		6.3.2	Macro Definition Documentation	14
			6.3.2.1 PATH	14
7	Nam	nespace	Documentation	15
	7.1	jeod N	amespace Reference	15
		7.1.1	Detailed Description	15
8	Data	Struct	ure Documentation	17
	8.1	jeod::F	latPlateRadiationFacet Class Reference	17
		8.1.1	Detailed Description	18
		8.1.2	Constructor & Destructor Documentation	18
			8.1.2.1 FlatPlateRadiationFacet	18

iv CONTENTS

		8.1.2.2	~FlatPlateRadiationFacet	18			
		8.1.2.3	FlatPlateRadiationFacet	18			
	8.1.3	Member	Function Documentation	18			
		8.1.3.1	define_facet	18			
		8.1.3.2	incident_radiation	19			
		8.1.3.3	initialize_geom	19			
		8.1.3.4	operator=	19			
		8.1.3.5	radiation_pressure	19			
	8.1.4	Friends A	And Related Function Documentation	19			
		8.1.4.1	init_attrjeodFlatPlateRadiationFacet	19			
		8.1.4.2	InputProcessor	20			
	8.1.5	Field Doo	cumentation	20			
		8.1.5.1	incident_flux_hat	20			
		8.1.5.2	normal	20			
		8.1.5.3	sin_theta	20			
8.2	jeod::F	latPlateRa	adiationFactory Class Reference	20			
	8.2.1	Detailed	Description	21			
	8.2.2	Construc	tor & Destructor Documentation	21			
		8.2.2.1	FlatPlateRadiationFactory	21			
		8.2.2.2	$\sim \! FlatPlateRadiationFactory \ \ldots \ $	21			
		8.2.2.3	FlatPlateRadiationFactory	21			
	8.2.3	Member	Function Documentation	21			
		8.2.3.1	create_facet	21			
		8.2.3.2	is_correct_factory	22			
		8.2.3.3	operator=	22			
	8.2.4	Friends A	And Related Function Documentation	22			
		8.2.4.1	init_attrjeodFlatPlateRadiationFactory	22			
		8.2.4.2	InputProcessor	22			
8.3	jeod::R	adiationBa	aseFacet Class Reference	22			
	8.3.1	3.1 Detailed Description					
	8.3.2	Construc	tor & Destructor Documentation	24			
		8.3.2.1	RadiationBaseFacet	24			
		8.3.2.2	~RadiationBaseFacet	24			
		8.3.2.3	RadiationBaseFacet	24			
	8.3.3	Member	Function Documentation	24			
		8.3.3.1	incident_radiation	24			
		8.3.3.2	initialize	24			
		8.3.3.3	initialize_runtime_values	24			
		8.3.3.4	interact_with_third_body	25			
		8.3.3.5	operator=	25			

CONTENTS

	8.3.4	Friends A	And Related Function Documentation	25
		8.3.4.1	init_attrjeodRadiationBaseFacet	25
		8.3.4.2	InputProcessor	25
	8.3.5	Field Doo	cumentation	25
		8.3.5.1	albedo	25
		8.3.5.2	albedo_IR	25
		8.3.5.3	albedo_vis	26
		8.3.5.4	areaxflux	26
		8.3.5.5	areaxflux_e	26
		8.3.5.6	cx_area	26
		8.3.5.7	diffuse	26
		8.3.5.8	F_absorption	26
		8.3.5.9	F_diffuse	27
		8.3.5.10	F_emission	27
		8.3.5.11	F_specular	27
		8.3.5.12	speed_of_light	27
		8.3.5.13	thermal	27
8.4	jeod::R	adiationDe	efaultSurface Class Reference	28
	8.4.1	Detailed	Description	29
	8.4.2	Construc	tor & Destructor Documentation	29
		8.4.2.1	RadiationDefaultSurface	29
		8.4.2.2	~RadiationDefaultSurface	29
		8.4.2.3	RadiationDefaultSurface	29
	8.4.3	Member	Function Documentation	29
		8.4.3.1	add_thermal_integrator_to	29
		8.4.3.2	incident_radiation	29
		8.4.3.3	initialize	30
		8.4.3.4	operator=	30
		8.4.3.5	set_name	30
		8.4.3.6	thermal_update	30
	8.4.4	Friends A	And Related Function Documentation	30
		8.4.4.1	init_attrjeodRadiationDefaultSurface	30
		8.4.4.2	InputProcessor	31
	8.4.5	Field Doo	cumentation	31
		8.4.5.1	name	31
		8.4.5.2	rad_coeff	31
		8.4.5.3	surface_area	31
		8.4.5.4	temperature	31
8.5	jeod::R		acet Class Reference	31
	8.5.1	Detailed	Description	33

vi CONTENTS

	8.5.2	Construc	ctor & Destructor Documentation	33
		8.5.2.1	RadiationFacet	33
		8.5.2.2	$\sim$ RadiationFacet	33
		8.5.2.3	RadiationFacet	33
	8.5.3	Member	Function Documentation	33
		8.5.3.1	define_facet_core	33
		8.5.3.2	get_thermal_integrator	33
		8.5.3.3	initialize	33
		8.5.3.4	initialize_geom	34
		8.5.3.5	operator=	34
		8.5.3.6	radiation_pressure	34
	8.5.4	Friends A	And Related Function Documentation	34
		8.5.4.1	init_attrjeodRadiationFacet	34
		8.5.4.2	InputProcessor	34
	8.5.5	Field Doo	cumentation	34
		8.5.5.1	center_pressure	34
		8.5.5.2	crot_to_cp	34
		8.5.5.3	two_thirds	35
8.6	jeod::R	adiationM	lessages Class Reference	35
	8.6.1	Detailed	Description	35
	8.6.2	Construc	ctor & Destructor Documentation	36
		8.6.2.1	RadiationMessages	36
		8.6.2.2	RadiationMessages	36
	8.6.3	Member	Function Documentation	36
		8.6.3.1	operator=	36
	8.6.4	Friends A	And Related Function Documentation	36
		8.6.4.1	init_attrjeodRadiationMessages	36
		8.6.4.2	InputProcessor	36
	8.6.5	Field Doo	cumentation	36
		8.6.5.1	incomplete_setup_error	36
		8.6.5.2	invalid_function_call	36
		8.6.5.3	invalid_setup_error	36
		8.6.5.4	operational_setup_error	37
		8.6.5.5	unknown_numerical_error	37
8.7	jeod::R	adiationPa	arams Class Reference	37
	8.7.1	Detailed	Description	38
	8.7.2	Construc	ctor & Destructor Documentation	38
		8.7.2.1	RadiationParams	38
		8.7.2.2	$\sim$ RadiationParams	38
		8.7.2.3	RadiationParams	39

CONTENTS vii

	8.7.3	Member	Function Documentation	39
		8.7.3.1	operator=	39
	8.7.4	Friends A	And Related Function Documentation	39
		8.7.4.1	init_attrjeodRadiationParams	39
		8.7.4.2	InputProcessor	39
	8.7.5	Field Doo	cumentation	39
		8.7.5.1	albedo	39
		8.7.5.2	diffuse	39
		8.7.5.3	thermal	39
8.8	jeod::R	adiationPr	ressure Class Reference	39
	8.8.1	Detailed	Description	41
	8.8.2	Construc	tor & Destructor Documentation	41
		8.8.2.1	RadiationPressure	41
		8.8.2.2	~RadiationPressure	41
		8.8.2.3	RadiationPressure	42
	8.8.3	Member	Function Documentation	42
		8.8.3.1	add_third_body	42
		8.8.3.2	find_third_body	42
		8.8.3.3	initialize	42
		8.8.3.4	initialize	42
		8.8.3.5	initialize_environment	44
		8.8.3.6	operator=	44
		8.8.3.7	set_calculate_forces	44
		8.8.3.8	set_third_body_active	44
		8.8.3.9	set_third_body_inactive	44
		8.8.3.10	third_body_adjustments	45
		8.8.3.11	update	45
		8.8.3.12	update_default_surface	45
		8.8.3.13	update_facet_surface	46
	8.8.4	Friends A	And Related Function Documentation	46
		8.8.4.1	init_attrjeodRadiationPressure	46
		8.8.4.2	InputProcessor	46
	8.8.5	Field Doo	cumentation	46
		8.8.5.1	active	46
		8.8.5.2	calculate_forces	46
		8.8.5.3	default_surface_ptr	46
		8.8.5.4	dyn_manager_ptr	46
		8.8.5.5	force	47
		8.8.5.6	illum_factor	47
		8.8.5.7	initialized	47

viii CONTENTS

		8.8.5.8	num_third_bodies	47
		8.8.5.9	source	47
		8.8.5.10	surface_ptr	47
		8.8.5.11	thermal	48
		8.8.5.12	third_bodies	48
		8.8.5.13	third_bodies_active	48
		8.8.5.14	torque	48
8.9	jeod::R	adiationSo	ource Class Reference	48
	8.9.1	Detailed	Description	50
	8.9.2	Member	Enumeration Documentation	50
		8.9.2.1	OldShadowGeometry	50
	8.9.3	Construc	tor & Destructor Documentation	50
		8.9.3.1	RadiationSource	50
		8.9.3.2	~RadiationSource	51
		8.9.3.3	RadiationSource	51
	8.9.4	Member	Function Documentation	51
		8.9.4.1	calculate_flux	51
		8.9.4.2	initialize	51
		8.9.4.3	operator=	51
		8.9.4.4	set_name	51
	8.9.5	Friends A	And Related Function Documentation	51
		8.9.5.1	init_attrjeodRadiationSource	51
		8.9.5.2	InputProcessor	51
	8.9.6	Field Doo	cumentation	52
		8.9.6.1	bodies_active	52
		8.9.6.2	d_source_to_cg	52
		8.9.6.3	flux_hat	52
		8.9.6.4	flux_inertial	52
		8.9.6.5	flux_mag	52
		8.9.6.6	flux_struc	52
		8.9.6.7	flux_struc_hat	53
		8.9.6.8	inertial_cg	53
		8.9.6.9	inertial_frame_ptr	53
		8.9.6.10	luminosity	53
		8.9.6.11	multiple_shadow_bodies	53
		8.9.6.12	name	53
		8.9.6.13	num_bodies	54
		8.9.6.14	radius	54
		8.9.6.15	shadow_geometry	54
		8.9.6.16	solar_luminosity	54

CONTENTS

	8.9.6.17	solar_radius	54
	8.9.6.18	source_to_cg	54
	8.9.6.19	source_to_struc_origin	55
	8.9.6.20	third_body	55
8.10 jeod	d::RadiationSเ	urface Class Reference	55
8.10	0.1 Detailed	Description	56
8.10	0.2 Construc	tor & Destructor Documentation	56
	8.10.2.1	RadiationSurface	56
	8.10.2.2	~RadiationSurface	57
	8.10.2.3	RadiationSurface	57
8.10	0.3 Member	Function Documentation	57
	8.10.3.1	accumulate_thermal_sources	57
	8.10.3.2	add_thermal_integrators_to	57
	8.10.3.3	allocate_array	57
	8.10.3.4	allocate_interaction_facet	57
	8.10.3.5	equalize_absorption_emission	58
	8.10.3.6	incident_radiation	58
	8.10.3.7	initialize	58
	8.10.3.8	initialize_runtime_values	58
	8.10.3.9	interact_with_third_body	58
	8.10.3.10	) operator=	59
	8.10.3.11	radiation_pressure	59
	8.10.3.12	2 thermal_integrator	59
8.10	0.4 Friends A	And Related Function Documentation	59
	8.10.4.1	init_attrjeodRadiationSurface	59
	8.10.4.2	InputProcessor	59
8.10	0.5 Field Doo	cumentation	59
	8.10.5.1	facets	59
	8.10.5.2	force	59
	8.10.5.3	ii_facet	60
	8.10.5.4	include_conduction	60
	8.10.5.5	num_facets	60
	8.10.5.6	thermal_conduction	60
	8.10.5.7	torque	60
8.11 jeod	d::RadiationSเ	urfaceFactory Class Reference	60
8.1	1.1 Detailed	Description	61
8.1	1.2 Construc	tor & Destructor Documentation	61
		RadiationSurfaceFactory	61
		~RadiationSurfaceFactory	61
	8.11.2.3	RadiationSurfaceFactory	62

CONTENTS

	8.11.3	Member F	function Documentation	62
		8.11.3.1	add_facet_params	62
		8.11.3.2	operator=	62
	8.11.4	Friends Ar	nd Related Function Documentation	62
		8.11.4.1	init_attrjeodRadiationSurfaceFactory	62
		8.11.4.2	InputProcessor	62
	8.11.5	Field Docu	umentation	62
		8.11.5.1	flat_plate_radiation_factory	62
8.12	jeod::R	adiationThi	irdBody Class Reference	62
	8.12.1	Detailed D	Description	65
	8.12.2	Member E	Enumeration Documentation	65
		8.12.2.1	ShadowGeometry	65
	8.12.3	Constructo	or & Destructor Documentation	65
		8.12.3.1	RadiationThirdBody	65
		8.12.3.2	$\sim$ RadiationThirdBody	65
		8.12.3.3	RadiationThirdBody	65
	8.12.4	Member F	Function Documentation	65
		8.12.4.1	accumulate_rad_flux	65
		8.12.4.2	accumulate_refl_flux	65
		8.12.4.3	calculate_shadow	66
		8.12.4.4	convert_shadow_from_int	66
		8.12.4.5	generate_alpha	66
		8.12.4.6	get_added_to_model	66
		8.12.4.7	initialize	67
		8.12.4.8	is_interactive	67
		8.12.4.9	operator=	67
		8.12.4.10	process_third_body	67
		8.12.4.11	set_added_to_model	67
		8.12.4.12	set_name	68
		8.12.4.13	test_for_state_update	68
		8.12.4.14	update_third_body_state	68
	8.12.5	Friends Ar	nd Related Function Documentation	68
		8.12.5.1	init_attrjeodRadiationThirdBody	68
		8.12.5.2	InputProcessor	68
	8.12.6	Field Docu	umentation	68
		8.12.6.1	active	68
		8.12.6.2	added_to_model	69
		8.12.6.3	d_source_to_third	69
		8.12.6.4	force_state_update	69
		8.12.6.5	illum_factor	69

CONTENTS xi

		8.12.6.6 initialized	69
		8.12.6.7 last_update_time	69
		8.12.6.8 local_frame_ptr	70
		8.12.6.9 name	70
		8.12.6.10 output_flux	70
		8.12.6.11 planet_link	70
		8.12.6.12 primary_source_ptr	70
		8.12.6.13 r_minus	70
		8.12.6.14 r_par	71
		8.12.6.15 r_perp	71
		8.12.6.16 r_plus	71
		8.12.6.17 r_ratio	71
		8.12.6.18 radius	71
		8.12.6.19 shadow_geometry	71
		8.12.6.20 source_to_third_hat_inrtl	72
		8.12.6.21 source_to_third_inrtl	72
		8.12.6.22 third_to_cg_inrtl	72
		8.12.6.23 update_interval	72
9	File I	Documentation	73
•	9.1		73
	0.1		73
	9.2		73
	0.2		74
	9.3		74
	0.0		74
	9.4	flat plate radiation factory.hh File Reference	74
			75
	9.5	•	75
			75
	9.6	radiation_base_facet.hh File Reference	75
			76
	9.7	radiation_default_surface.cc File Reference	76
			76
	9.8		76
		radiation_default_surface.hh File Reference	
			77
	9.9	9.8.1 Detailed Description	77 77
	9.9	9.8.1 Detailed Description	
		9.8.1       Detailed Description         radiation_facet.cc File Reference          9.9.1       Detailed Description	77
		9.8.1 Detailed Description	77 77

xii CONTENTS

9.11	radiation_messages.cc File Reference	78
	9.11.1 Detailed Description	78
9.12	radiation_messages.hh File Reference	78
	9.12.1 Detailed Description	78
9.13	radiation_params.cc File Reference	79
	9.13.1 Detailed Description	79
9.14	radiation_params.hh File Reference	79
	9.14.1 Detailed Description	79
9.15	radiation_pressure.cc File Reference	79
	9.15.1 Detailed Description	80
9.16	radiation_pressure.hh File Reference	80
	9.16.1 Detailed Description	80
9.17	radiation_pressuredefault_surface.cc File Reference	81
	9.17.1 Detailed Description	81
9.18	radiation_pressuresurface_model.cc File Reference	81
	9.18.1 Detailed Description	81
9.19	radiation_source.cc File Reference	81
	9.19.1 Detailed Description	82
9.20	radiation_source.hh File Reference	82
	9.20.1 Detailed Description	82
9.21	radiation_surface.cc File Reference	82
	9.21.1 Detailed Description	83
9.22	radiation_surface.hh File Reference	83
	9.22.1 Detailed Description	83
9.23	radiation_surface_factory.cc File Reference	84
	9.23.1 Detailed Description	84
9.24	radiation_surface_factory.hh File Reference	84
	9.24.1 Detailed Description	84
9.25	radiation_third_body.cc File Reference	84
	9.25.1 Detailed Description	85
9.26	radiation_third_body.hh File Reference	85
	9.26.1 Detailed Description	85

Index

86

## **Module Index**

### 1.1 Modules

11	:_	_	1: _4		-11	modules:
пеге	15	a	IISt	OI	all	modules.

Models	 	 11
Interactions	 	 12
RadiationPressu	 	 13

2 **Module Index** 

# Namespace Index

2.1	Namespace List
Here	is a list of all namespaces with brief descriptions:
je	od

Namespace Index

## **Hierarchical Index**

### 3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

FacetParams	
jeod::RadiationParams	37
nteractionFacet	
jeod::RadiationFacet	31
jeod::FlatPlateRadiationFacet	17
nteractionFacetFactory	
jeod::FlatPlateRadiationFactory	20
nteractionSurface	
jeod::RadiationSurface	55
nteractionSurfaceFactory	
jeod::RadiationSurfaceFactory	
eod::RadiationBaseFacet	22
jeod::RadiationDefaultSurface	28
jeod::RadiationFacet	31
eod::RadiationMessages	35
eod::RadiationPressure	39
eod::RadiationSource	48
eod::RadiationThirdBody	62

6 **Hierarchical Index** 

## **Data Structure Index**

### 4.1 Data Structures

Here are the data structures with brief descriptions:

jeod::FlatPlateRadiationFacet	
A flat plate facet to be used for radiation interaction	17
jeod::FlatPlateRadiationFactory	
The factory for building flat plate radiation facets	20
jeod::RadiationBaseFacet	
Generic type of facet for radiation pressure	22
jeod::RadiationDefaultSurface	
The default spherical surface for radiation pressure	28
jeod::RadiationFacet	
Generic type of facet for radiation pressure	31
jeod::RadiationMessages	
Provides error messages	35
jeod::RadiationParams	
Provides a parameter list to each facet, based on the facet material properties	37
jeod::RadiationPressure	
Radiation pressure top-level definition	39
jeod::RadiationSource	
Provides information on the source of the incident radiation	48
jeod::RadiationSurface	
The surface of the vehicle that interacts with the incident flux	55
jeod::RadiationSurfaceFactory	
The factory for creating Radiation Surfaces	60
jeod::RadiationThirdBody	
Provide information on bodies that may cause shadowing or reflected illumination	62

8 Data Structure Index

## File Index

### 5.1 File List

Here is a list of all files with brief descriptions:

flat_plate	e_radiation_facet.cc	
	Define member functions for class FlatPlateRadiationFacet	73
flat plate	e radiation facet.hh	
	Individual facets for use with rad environment interaction models	73
flat plate	e_radiation_factory.cc	
	Factory that creates a FlatPlateRadiationFacet, from a facet model	74
flat_plate	e_radiation_factory.hh	
	Factory that creates an interaction facet, for a specific environment interaction model, from a	
	facet model	74
radiation	_base_facet.cc	
	Define member functions for class RadiationBaseFacet	75
radiation	_base_facet.hh	
	Individual facets for use with radiation environment interaction models	75
radiation	_default_surface.cc	
	Default surface for use with Radiation Pressure interaction model	76
radiation	_default_surface.hh	
	Individual facets for use with radiation environment interaction models	76
radiation	_facet.cc	
	Individual facets for use with Radiation Pressure interaction models	77
radiation	_facet.hh	
	Individual facets for use with radiation environment interaction models	77
radiation	_messages.cc	
	Implement the class RadiationMessages	78
radiation	_messages.hh	
	Define the class RadiationMessages, the class that specifies the message IDs used in the Radi-	
	ation model	78
radiation	_params.cc	
	A virtual base class for radiation facet parameters, used to create interaction facets for radiation	
	in the InteractionSurfaceFactorys	79
radiation	_params.hh	
	A virtual base class for radiation facet parameters, used to create interaction facets for radiation	
	in the InteractionSurfaceFactorys	79
radiation	_pressure.cc	
	Calculation of force and torque due to radiation pressure	79
radiation	_pressure.hh	
	Radiation pressure top-level definition	80
radiation	_pressuredefault_surface.cc	
	Calculation of force and torque due to radiation pressure	81

10 File Index

radiation_pressuresurface_model.cc	
Calculation of force and torque due to radiation pressure	81
radiation_source.cc	
Definition of methods associated with Primary Sources	81
radiation_source.hh	
Radiation pressure parameter and variable definitions	82
radiation_surface.cc	
Vehicle surface model for Radiation Pressure model	82
radiation_surface.hh	
Vehicle surface model for general environment interaction models	83
radiation_surface_factory.cc	
Factory that creates an interaction surface, for a specific environment interaction model, from a	
surface model	84
radiation_surface_factory.hh	
Factory that creates an interaction surface, for a specific environment interaction model, from a	
surface model	84
radiation_third_body.cc	
Provides the functionality associated with RadiationThirdBodys	84
radiation_third_body.hh	
Define the class RadiationThirdBody	85

## **Module Documentation**

6.1 Models

Modules

- Interactions
- 6.1.1 Detailed Description

12 Module Documentation

### 6.2 Interactions

#### **Modules**

RadiationPressure

### 6.2.1 Detailed Description

6.3 RadiationPressure 13

#### 6.3 RadiationPressure

#### **Files**

· file flat\_plate\_radiation\_facet.hh

Individual facets for use with rad environment interaction models.

· file flat plate radiation factory.hh

Factory that creates an interaction facet, for a specific environment interaction model, from a facet model.

file radiation\_base\_facet.hh

Individual facets for use with radiation environment interaction models.

· file radiation default surface.hh

Individual facets for use with radiation environment interaction models.

· file radiation\_facet.hh

Individual facets for use with radiation environment interaction models.

· file radiation messages.hh

Define the class RadiationMessages, the class that specifies the message IDs used in the Radiation model.

· file radiation\_params.hh

A virtual base class for radiation facet parameters, used to create interaction facets for radiation in the Interaction-SurfaceFactorys.

· file radiation\_pressure.hh

Radiation pressure top-level definition.

· file radiation\_source.hh

Radiation pressure parameter and variable definitions.

· file radiation\_surface.hh

Vehicle surface model for general environment interaction models.

· file radiation surface factory.hh

Factory that creates an interaction surface, for a specific environment interaction model, from a surface model.

• file radiation\_third\_body.hh

Define the class RadiationThirdBody.

· file flat plate radiation facet.cc

Define member functions for class FlatPlateRadiationFacet.

file flat\_plate\_radiation\_factory.cc

Factory that creates a FlatPlateRadiationFacet, from a facet model.

· file radiation base facet.cc

Define member functions for class RadiationBaseFacet.

• file radiation\_default\_surface.cc

Default surface for use with Radiation Pressure interaction model.

· file radiation facet.cc

Individual facets for use with Radiation Pressure interaction models.

file radiation\_messages.cc

Implement the class RadiationMessages.

file radiation\_params.cc

A virtual base class for radiation facet parameters, used to create interaction facets for radiation in the Interaction-SurfaceFactorys.

· file radiation pressure.cc

Calculation of force and torque due to radiation pressure.

• file radiation\_pressure\_\_default\_surface.cc

Calculation of force and torque due to radiation pressure.

• file radiation\_pressure\_\_surface\_model.cc

Calculation of force and torque due to radiation pressure.

• file radiation\_source.cc

14 Module Documentation

Definition of methods associated with Primary Sources.

• file radiation\_surface.cc

Vehicle surface model for Radiation Pressure model.

• file radiation\_surface\_factory.cc

Factory that creates an interaction surface, for a specific environment interaction model, from a surface model.

• file radiation\_third\_body.cc

Provides the functionality associated with RadiationThirdBodys.

#### **Namespaces**

jeod

Namespace jeod.

#### **Macros**

- #define PATH "interactions/radiation\_pressure/"
- 6.3.1 Detailed Description
- 6.3.2 Macro Definition Documentation
- 6.3.2.1 #define PATH "interactions/radiation\_pressure/"

Definition at line 38 of file radiation\_messages.cc.

## **Namespace Documentation**

#### 7.1 jeod Namespace Reference

Namespace jeod.

#### **Data Structures**

· class FlatPlateRadiationFacet

A flat plate facet to be used for radiation interaction.

· class FlatPlateRadiationFactory

The factory for building flat plate radiation facets.

· class RadiationBaseFacet

Generic type of facet for radiation pressure.

· class RadiationDefaultSurface

The default spherical surface for radiation pressure.

class RadiationFacet

Generic type of facet for radiation pressure.

class RadiationMessages

Provides error messages.

• class RadiationParams

Provides a parameter list to each facet, based on the facet material properties.

• class RadiationPressure

Radiation pressure top-level definition.

· class RadiationSource

Provides information on the source of the incident radiation.

class RadiationSurface

The surface of the vehicle that interacts with the incident flux.

class RadiationSurfaceFactory

The factory for creating Radiation Surfaces.

class RadiationThirdBody

Provide information on bodies that may cause shadowing or reflected illumination.

#### 7.1.1 Detailed Description

Namespace jeod.

Names	pace	Docur	ment	ation


### **Data Structure Documentation**

#### 8.1 jeod::FlatPlateRadiationFacet Class Reference

A flat plate facet to be used for radiation interaction.

```
#include <flat_plate_radiation_facet.hh>
```

Inheritance diagram for jeod::FlatPlateRadiationFacet:



#### **Public Member Functions**

FlatPlateRadiationFacet ()

 ${\it Construct\ a\ Flat PlateRadiation Facet.}$ 

 $\bullet \ \sim \! \mathsf{FlatPlateRadiationFacet} \ () \ \mathsf{override}$ 

Destructor for FlatPlateRadiationFacet.

void incident\_radiation (const double flux\_mag, const double flux\_struct\_hat[3], const bool calculate\_forces)
 override

Calculation of force and torque due to radiation pressure.

void initialize\_geom (double center\_grav[3]) override

Initializes the Facet for use in the model.

void define\_facet (FlatPlate \*flat\_plate)

Defines the facet data values.

· void radiation\_pressure (void) override

Calculates the radiative emission force, accumulated force, and torque acting on a facet.

#### **Data Fields**

• double \* normal

Unit vector normal to the plate surface, pointing outward (structural frame).

double incident\_flux\_hat [3]

Temporary value.

#### **Private Member Functions**

- FlatPlateRadiationFacet & operator= (const FlatPlateRadiationFacet &rhs)
- FlatPlateRadiationFacet (const FlatPlateRadiationFacet &rhs)

#### **Private Attributes**

· double sin\_theta

Theta is the angle between the plate and the radiation vector.

#### **Friends**

- · class InputProcessor
- void init attrjeod FlatPlateRadiationFacet ()

#### **Additional Inherited Members**

#### 8.1.1 Detailed Description

A flat plate facet to be used for radiation interaction.

Definition at line 86 of file flat\_plate\_radiation\_facet.hh.

#### 8.1.2 Constructor & Destructor Documentation

8.1.2.1 jeod::FlatPlateRadiationFacet::FlatPlateRadiationFacet ( void )

Construct a FlatPlateRadiationFacet.

Definition at line 55 of file flat\_plate\_radiation\_facet.cc.

**8.1.2.2** jeod::FlatPlateRadiationFacet::~FlatPlateRadiationFacet ( void ) [override]

Destructor for FlatPlateRadiationFacet.

Definition at line 218 of file flat\_plate\_radiation\_facet.cc.

8.1.2.3 jeod::FlatPlateRadiationFacet::FlatPlateRadiationFacet ( const FlatPlateRadiationFacet & rhs ) [private]

#### 8.1.3 Member Function Documentation

8.1.3.1 void jeod::FlatPlateRadiationFacet::define\_facet ( FlatPlate \* flat\_plate )

Defines the facet data values.

**Parameters** 

	in	flat_plate	pointer to the flat plate object
--	----	------------	----------------------------------

Definition at line 70 of file flat\_plate\_radiation\_facet.cc.

References jeod::RadiationFacet::center\_pressure, and normal.

 $Referenced\ by\ jeod::FlatPlateRadiationFactory::create\_facet().$ 

8.1.3.2 void jeod::FlatPlateRadiationFacet::incident\_radiation ( const double flux\_mag, const double flux\_struct\_hat[3], const bool calculate\_forces ) [override], [virtual]

Calculation of force and torque due to radiation pressure.

**Assumptions and Limitations** 

Only called when flux\_mag > 0

#### **Parameters**

	in	flux_mag	incident flux (per unit area)
			Units: N/m
ĺ	in	flux_struct_hat	the flux unit vector in structural frame
ſ	in	calculate_forces	on/off flag for whether to calculate forces.

Implements jeod::RadiationBaseFacet.

Definition at line 114 of file flat\_plate\_radiation\_facet.cc.

References jeod::RadiationBaseFacet::albedo, jeod::RadiationBaseFacet::areaxflux, jeod::RadiationBaseFacet::areaxflux\_e, jeod::RadiationBaseFacet::cx\_area, jeod::RadiationBaseFacet::diffuse, jeod::RadiationBaseFacet::F\_absorption, jeod::RadiationBaseFacet::F\_diffuse, jeod::RadiationBaseFacet::F\_specular, normal, sin\_theta, jeod::RadiationBaseFacet::speed\_of\_light, jeod::RadiationBaseFacet::thermal, and jeod::RadiationFacet::two\_thirds.

**8.1.3.3** void jeod::FlatPlateRadiationFacet::initialize\_geom ( double center\_grav[3] ) [override], [virtual]

Initializes the Facet for use in the model.

#### **Parameters**

in	center_grav	center of gravity position
		Units: M

Implements jeod::RadiationFacet.

Definition at line 92 of file flat\_plate\_radiation\_facet.cc.

References jeod::RadiationFacet::center\_pressure, jeod::RadiationFacet::crot\_to\_cp, jeod::RadiationFacet::initialize(), and jeod::RadiationBaseFacet::thermal.

- 8.1.3.4 FlatPlateRadiationFacet& jeod::FlatPlateRadiationFacet::operator=( const FlatPlateRadiationFacet & rhs )
  [private]
- 8.1.3.5 void jeod::FlatPlateRadiationFacet::radiation pressure(void) [override], [virtual]

Calculates the radiative emission force, accumulated force, and torque acting on a facet.

Implements jeod::RadiationFacet.

Definition at line 177 of file flat\_plate\_radiation\_facet.cc.

References jeod::RadiationFacet::crot\_to\_cp, jeod::RadiationBaseFacet::F\_absorption, jeod::RadiationBaseFacet::F\_diffuse, jeod::RadiationBaseFacet::F\_emission, jeod::RadiationBaseFacet::F\_specular, normal, jeod::RadiationBaseFacet::speed\_of\_light, jeod::RadiationBaseFacet::thermal, jeod::RadiationFacet::two\_thirds, and jeod::RadiationMessages::unknown\_numerical\_error.

#### 8.1.4 Friends And Related Function Documentation

**8.1.4.1 void init\_attrjeod\_\_FlatPlateRadiationFacet()** [friend]

**8.1.4.2 friend class InputProcessor** [friend]

Definition at line 88 of file flat\_plate\_radiation\_facet.hh.

#### 8.1.5 Field Documentation

8.1.5.1 double jeod::FlatPlateRadiationFacet::incident\_flux\_hat[3]

Temporary value.

trick units(-)

Definition at line 104 of file flat\_plate\_radiation\_facet.hh.

8.1.5.2 double\* jeod::FlatPlateRadiationFacet::normal

Unit vector normal to the plate surface, pointing outward (structural frame).

once the radiation surface is initialized, it points to the normal found in FlatPlatetrick\_units(-)

Definition at line 99 of file flat plate radiation facet.hh.

Referenced by define\_facet(), incident\_radiation(), and radiation\_pressure().

**8.1.5.3** double jeod::FlatPlateRadiationFacet::sin\_theta [private]

Theta is the angle between the plate and the radiation vector.

trick\_units(-)

Definition at line 110 of file flat\_plate\_radiation\_facet.hh.

Referenced by incident\_radiation().

The documentation for this class was generated from the following files:


- flat\_plate\_radiation\_facet.hh
- flat\_plate\_radiation\_facet.cc

#### 8.2 jeod::FlatPlateRadiationFactory Class Reference

The factory for building flat plate radiation facets.

```
#include <flat_plate_radiation_factory.hh>
```

Inheritance diagram for jeod::FlatPlateRadiationFactory:



#### **Public Member Functions**

- FlatPlateRadiationFactory ()
  - Constructor for FlatPlateRadiationFactory.
- $\sim$ FlatPlateRadiationFactory () override

Destructor for FlatPlateRadiationFactory.

• InteractionFacet \* create\_facet (Facet \*facet, FacetParams \*params) override

Records the data for the Flat Plate Radiation Facet.

• bool is\_correct\_factory (Facet \*facet) override

Tests to ensure that the factory can function on the facet as intended.

#### **Private Member Functions**

- FlatPlateRadiationFactory & operator= (const FlatPlateRadiationFactory &rhs)
- FlatPlateRadiationFactory (const FlatPlateRadiationFactory &rhs)

#### **Friends**

- · class InputProcessor
- void init\_attrjeod\_\_FlatPlateRadiationFactory ()

#### 8.2.1 Detailed Description

The factory for building flat plate radiation facets.

Definition at line 85 of file flat\_plate\_radiation\_factory.hh.

#### 8.2.2 Constructor & Destructor Documentation

8.2.2.1 jeod::FlatPlateRadiationFactory::FlatPlateRadiationFactory (void )

Constructor for FlatPlateRadiationFactory.

Definition at line 63 of file flat\_plate\_radiation\_factory.cc.

```
8.2.2.2 jeod::FlatPlateRadiationFactory::~FlatPlateRadiationFactory ( void ) [override]
```

Destructor for FlatPlateRadiationFactory.

Definition at line 154 of file flat\_plate\_radiation\_factory.cc.

```
8.2.2.3 jeod::FlatPlateRadiationFactory::FlatPlateRadiationFactory ( const FlatPlateRadiationFactory & rhs ) [private]
```

#### 8.2.3 Member Function Documentation

```
8.2.3.1 InteractionFacet * jeod::FlatPlateRadiationFactory::create_facet ( Facet * facet, FacetParams * params ) [override]
```

Records the data for the Flat Plate Radiation Facet.

#### Returns

pointer to the interaction facet that this function creates.

#### **Parameters**

in	facet	pointer to the facet
in	params	pointer to the set of parameters for the facet.

Definition at line 77 of file flat\_plate\_radiation\_factory.cc.

References jeod::FlatPlateRadiationFacet::define\_facet(), and jeod::RadiationMessages::invalid\_setup\_error.

**8.2.3.2** bool jeod::FlatPlateRadiationFactory::is\_correct\_factory ( Facet \* facet ) [override]

Tests to ensure that the factory can function on the facet as intended.

#### Returns

Boolean, is this the correct factory?

#### **Parameters**

in	facet	pointer to the facet being manipulated by the factory
----	-------	---

Definition at line 136 of file flat\_plate\_radiation\_factory.cc.

8.2.3.3 FlatPlateRadiationFactory& jeod::FlatPlateRadiationFactory::operator= ( const FlatPlateRadiationFactory & rhs ) [private]

#### 8.2.4 Friends And Related Function Documentation

- **8.2.4.1 void init\_attrjeod\_\_FlatPlateRadiationFactory( )** [friend]
- **8.2.4.2 friend class InputProcessor** [friend]

Definition at line 87 of file flat\_plate\_radiation\_factory.hh.

The documentation for this class was generated from the following files:


- · flat\_plate\_radiation\_factory.hh
- flat\_plate\_radiation\_factory.cc

#### 8.3 jeod::RadiationBaseFacet Class Reference

Generic type of facet for radiation pressure.

#include <radiation\_base\_facet.hh>

Inheritance diagram for jeod::RadiationBaseFacet:



#### **Public Member Functions**

RadiationBaseFacet ()

Construct a RadiationBaseFacet.

virtual ∼RadiationBaseFacet ()

Destructor for RadiationBaseFacet.

virtual void initialize (void)

initializes the base surface

virtual void interact with third body (RadiationThirdBody \*third body, const bool calc forces)

Calculation of force, torques and irradiance due to ThirdBody flux.

virtual void initialize\_runtime\_values (void)

To initialize the values during each update run.

virtual void incident\_radiation (const double flux\_mag, const double flux\_hat[3], const bool calc\_forc)=0
 Calculates the effect on the facet of the incident radiation.

#### **Data Fields**

· double albedo

Usable value of albedo, set to either albedo\_IR or albedo\_vis, depending on situation.

· double albedo vis

Fraction of incident visible radiation that is immediately reflected.

· double albedo\_IR

Fraction of incident IR radiation that is immediately reflected.

· double diffuse

Fraction of reflected radiation that is reflected diffusely (balance reflected specularly)

• ThermalFacetRider thermal

thermal characteristics of the facet.

double cx\_area

cross-sectional area projected perpendicular to the radiation vector.

double areaxflux

product of momentum flux and cross-sectional area (cx\_area).

· double areaxflux e

product of energy flux and cross-sectional area

• double F\_absorption [3]

Force due to photon absorption from ONLY ONE source.

double F\_specular [3]

Force due to photon specular reflection from ONLY ONE source.

double F\_diffuse [3]

Force due to photon diffuse reflection from ONLY ONE source.

• double F emission [3]

Force due to photon (thermal) emission.

#### **Static Protected Attributes**

static const double speed\_of\_light = 299792458.0
 Speed of light in vacuum.

#### **Private Member Functions**

- RadiationBaseFacet & operator= (const RadiationBaseFacet &rhs)
- RadiationBaseFacet (const RadiationBaseFacet &rhs)

#### **Friends**

- · class InputProcessor
- void init\_attrjeod\_\_RadiationBaseFacet ()

#### 8.3.1 Detailed Description

Generic type of facet for radiation pressure.

Definition at line 86 of file radiation\_base\_facet.hh.

#### 8.3.2 Constructor & Destructor Documentation

8.3.2.1 jeod::RadiationBaseFacet::RadiationBaseFacet (void)

Construct a RadiationBaseFacet.

Definition at line 56 of file radiation\_base\_facet.cc.

**8.3.2.2** jeod::RadiationBaseFacet::~RadiationBaseFacet(void) [virtual]

Destructor for RadiationBaseFacet.

Definition at line 156 of file radiation\_base\_facet.cc.

**8.3.2.3** jeod::RadiationBaseFacet::RadiationBaseFacet (const RadiationBaseFacet & rhs) [private]

#### 8.3.3 Member Function Documentation

8.3.3.1 virtual void jeod::RadiationBaseFacet::incident\_radiation ( const double flux\_mag, const double flux\_hat[3], const bool calc\_forc ) [pure virtual]

Calculates the effect on the facet of the incident radiation.

#### **Parameters**

in	flux_mag	Magnitude of the incident flux
in	flux_hat	unit vector associated with the incident flux vector
in	calc_forc	true/false, do forces get calculated

 $Implemented\ in\ jeod:: Radiation Default Surface,\ and\ jeod:: Flat Plate Radiation Facet.$ 

Referenced by jeod::RadiationSurface::incident\_radiation().

**8.3.3.2 void jeod::RadiationBaseFacet::initialize ( void )** [virtual]

initializes the base surface

Reimplemented in jeod::RadiationDefaultSurface, and jeod::RadiationFacet.

Definition at line 76 of file radiation\_base\_facet.cc.

References albedo, albedo\_IR, albedo\_vis, and jeod::RadiationMessages::invalid\_setup\_error.

Referenced by jeod::RadiationFacet::initialize(), and jeod::RadiationDefaultSurface::initialize().

8.3.3.3 void jeod::RadiationBaseFacet::initialize\_runtime\_values( void ) [virtual]

To initialize the values during each update run.

Definition at line 143 of file radiation\_base\_facet.cc.

References F absorption, F diffuse, F specular, and thermal.

Referenced by jeod::RadiationSurface::initialize\_runtime\_values(), and jeod::RadiationPressure::update\_default\_surface().

8.3.3.4 void jeod::RadiationBaseFacet::interact\_with\_third\_body ( RadiationThirdBody \* third\_body\_ptr, const bool calculate\_forces ) [virtual]

Calculation of force, torques and irradiance due to ThirdBody flux.

#### **Parameters**

in,out	third_body_ptr	Third body that emits radiation
in	calculate_forces	Calculate forces on this facet if true.

Definition at line 121 of file radiation base facet.cc.

References jeod::RadiationThirdBody::accumulate\_rad\_flux(), jeod::RadiationThirdBody::accumulate\_refl\_flux(), albedo, albedo\_IR, and albedo\_vis.

Referenced by jeod::RadiationSurface::interact\_with\_third\_body(), and jeod::RadiationPressure::update\_default\_surface().

8.3.3.5 RadiationBaseFacet& jeod::RadiationBaseFacet::operator= ( const RadiationBaseFacet & rhs )

[private]

# 8.3.4 Friends And Related Function Documentation

- **8.3.4.1** void init\_attrjeod\_\_RadiationBaseFacet() [friend]
- **8.3.4.2 friend class InputProcessor** [friend]

Definition at line 88 of file radiation\_base\_facet.hh.

# 8.3.5 Field Documentation

### 8.3.5.1 double jeod::RadiationBaseFacet::albedo

Usable value of albedo, set to either albedo\_IR or albedo\_vis, depending on situation.

trick units(-)

Definition at line 98 of file radiation\_base\_facet.hh.

Referenced by jeod::RadiationFacet::define\_facet\_core(), jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), jeod::RadiationFacet::initialize(), jeod::RadiationDefaultSurface::initialize(), interact\_with\_third\_body(), and jeod::RadiationDefaultSurface::RadiationDefaultSurface().

# 8.3.5.2 double jeod::RadiationBaseFacet::albedo\_IR

Fraction of incident IR radiation that is immediately reflected.

trick\_units(-)

Definition at line 108 of file radiation\_base\_facet.hh.

Referenced by jeod::RadiationFacet::initialize(), initialize(), and interact\_with\_third\_body().

#### 8.3.5.3 double jeod::RadiationBaseFacet::albedo\_vis

Fraction of incident visible radiation that is immediately reflected.

trick units(-)

Definition at line 103 of file radiation base facet.hh.

Referenced by jeod::RadiationFacet::initialize(), initialize(), and interact\_with\_third\_body().

# 8.3.5.4 double jeod::RadiationBaseFacet::areaxflux

product of momentum flux and cross-sectional area (cx area).

Highly variable.trick\_units(-)

Definition at line 138 of file radiation base facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), and jeod::RadiationDefaultSurface::RadiationDefaultSurface().

### 8.3.5.5 double jeod::RadiationBaseFacet::areaxflux\_e

product of energy flux and cross-sectional area

trick units(-)

Definition at line 143 of file radiation\_base\_facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), and jeod::RadiationDefaultSurface::RadiationDefaultSurface().

### 8.3.5.6 double jeod::RadiationBaseFacet::cx\_area

cross-sectional area projected perpendicular to the radiation vector.

For facets that have an orientation, this is intended to be a variable value, dependent upon the orientation. For spherical surfaces, this can be set at initialization.trick\_units(m2)

Definition at line 129 of file radiation\_base\_facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), jeod::RadiationDefaultSurface::Initialize(), and jeod::RadiationDefaultSurface::RadiationDefaultSurface().

#### 8.3.5.7 double jeod::RadiationBaseFacet::diffuse

Fraction of reflected radiation that is reflected diffusely (balance reflected specularly)

trick\_units(-)

Definition at line 114 of file radiation\_base\_facet.hh.

Referenced by jeod::RadiationFacet::define\_facet\_core(), jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), jeod::RadiationFacet::initialize(), jeod::RadiationDefaultSurface::RadiationDefaultSurface().

# $8.3.5.8 \quad double\ jeod:: Radiation Base Facet:: F\_absorption [3]$

Force due to photon absorption from ONLY ONE source.

trick\_units(-)

Definition at line 148 of file radiation\_base\_facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), initialize\_runtime\_values(), jeod::FlatPlateRadiationFacet::radiation\_pressure(), jeod::RadiationDefaultSurface(), and jeod::RadiationPressure::update\_default\_surface().

8.3.5.9 double jeod::RadiationBaseFacet::F\_diffuse[3]

Force due to photon diffuse reflection from ONLY ONE source.

trick units(-)

Definition at line 158 of file radiation\_base\_facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), initialize\_runtime\_values(), jeod::FlatPlateRadiationFacet::radiation\_pressure(), jeod::RadiationDefaultSurface::RadiationDefaultSurface(), and jeod::RadiationPressure::update\_default\_surface().

8.3.5.10 double jeod::RadiationBaseFacet::F\_emission[3]

Force due to photon (thermal) emission.

trick\_units(-)

Definition at line 163 of file radiation base facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::radiation\_pressure(), and jeod::RadiationDefaultSurface::RadiationDefaultSurface().

8.3.5.11 double jeod::RadiationBaseFacet::F\_specular[3]

Force due to photon specular reflection from ONLY ONE source.

trick units(-)

Definition at line 153 of file radiation base facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), initialize\_runtime\_values(), jeod::FlatPlateRadiationFacet::radiation\_pressure(), jeod::RadiationDefaultSurface(), and jeod::RadiationPressure::update\_default\_surface().

**8.3.5.12** const double jeod::RadiationBaseFacet::speed\_of\_light = 299792458.0 [static], [protected]

Speed of light in vacuum.

trick io(\*o) trick units(m/s)

Definition at line 171 of file radiation base facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), jeod::RadiationDefaultSurface::incident\_radiation(), and jeod::FlatPlateRadiationFacet::radiation\_pressure().

8.3.5.13 ThermalFacetRider jeod::RadiationBaseFacet::thermal

thermal characteristics of the facet.

trick\_units(-)

Definition at line 119 of file radiation\_base\_facet.hh.

Referenced by jeod::RadiationSurface::accumulate\_thermal\_sources(), jeod::RadiationDefaultSurface::add\_thermal\_integrator\_to(), jeod::RadiationFacet::define\_facet\_core(), jeod::RadiationSurface::equalize\_absorption\_emission(), jeod::RadiationFacet::get\_thermal\_integrator(), jeod::FlatPlateRadiationFacet::incident\_radiation(),

jeod::RadiationDefaultSurface::incident\_radiation(), jeod::RadiationFacet::initialize(), jeod::RadiationSurface::initialize(), jeod::RadiationDefaultSurface::initialize(), jeod::FlatPlateRadiationFacet::initialize\_geom(), initialize\_runtime\_values(), jeod::FlatPlateRadiationFacet::radiation\_pressure(), jeod::RadiationSurface::thermal\_integrator(), and jeod::RadiationDefaultSurface::thermal\_update().

The documentation for this class was generated from the following files:


- · radiation base facet.hh
- · radiation\_base\_facet.cc

# 8.4 jeod::RadiationDefaultSurface Class Reference

The default spherical surface for radiation pressure.

```
#include <radiation_default_surface.hh>
```

Inheritance diagram for jeod::RadiationDefaultSurface:



# **Public Member Functions**

· RadiationDefaultSurface ()

Constructor for RadiationDefaultSurface.

• ~RadiationDefaultSurface () override

Destructor for RadiationDefaultSurface.

• void initialize (void) override

initializes the default surface

 void incident\_radiation (const double flux\_mag, const double flux\_struc\_hat[3], const bool calculate\_forces) override

Calculation of force and torque due to radiation pressure.

void thermal\_update (void)

Test for necessity of maintaining thermal updates, and performs them as necessary.

void add\_thermal\_integrator\_to (DynBody \*dyn\_body)

Adds the thermal integrator of this surface to the integration group of the DynBody.

void set\_name (std::string name\_in)

Setter for the name.

### **Data Fields**

· double rad\_coeff

The radiation-equivalent of a drag coefficient.

· double temperature

The value of the surface kinetic temperature.

std::string name

The name of the surface.

· double surface area

surface area of the default sphere.

# **Private Member Functions**

- RadiationDefaultSurface & operator= (const RadiationDefaultSurface &rhs)
- RadiationDefaultSurface (const RadiationDefaultSurface &rhs)

#### **Friends**

- · class InputProcessor
- · void init attrieod RadiationDefaultSurface ()

#### **Additional Inherited Members**

# 8.4.1 Detailed Description

The default spherical surface for radiation pressure.

Definition at line 89 of file radiation\_default\_surface.hh.

#### 8.4.2 Constructor & Destructor Documentation

8.4.2.1 jeod::RadiationDefaultSurface::RadiationDefaultSurface (void)

Constructor for RadiationDefaultSurface.

Definition at line 65 of file radiation default surface.cc.

References jeod::RadiationBaseFacet::albedo, jeod::RadiationBaseFacet::areaxflux, jeod::RadiationBaseFacet::areaxflux\_e, jeod::RadiationBaseFacet::cx\_area, jeod::RadiationBaseFacet::diffuse, jeod::RadiationBaseFacet::F\_absorption, jeod::RadiationBaseFacet::F\_emission, jeod::RadiationBaseFacet::F\_specular, rad\_coeff, surface\_area, and temperature.

**8.4.2.2** jeod::RadiationDefaultSurface::~RadiationDefaultSurface(void) [override]

Destructor for RadiationDefaultSurface.

Definition at line 299 of file radiation\_default\_surface.cc.

 $\textbf{8.4.2.3} \quad \textbf{jeod::RadiationDefaultSurface::RadiationDefaultSurface ( \ const \ RadiationDefaultSurface \& \textit{rhs} \ ) \quad \texttt{[private]}$ 

# 8.4.3 Member Function Documentation

8.4.3.1 void jeod::RadiationDefaultSurface::add\_thermal\_integrator\_to (  $DynBody*dyn\_body$  )

Adds the thermal integrator of this surface to the integration group of the DynBody.

# Parameters

in,out	dyn_body	Body associated with this thermal object.

Definition at line 289 of file radiation\_default\_surface.cc.

References jeod::RadiationBaseFacet::thermal.

8.4.3.2 void jeod::RadiationDefaultSurface::incident\_radiation ( const double flux\_mag, const double flux\_struc\_hat[3], const bool calculate\_forces ) [override], [virtual]

Calculation of force and torque due to radiation pressure.

#### **Assumptions and Limitations**

- · Assumes that flux magnitude is positive.
- · Will only be called if flux magnitude is positive.
- · Assumes spherical surface.

#### **Parameters**

in	flux_mag	the magnitude of the incident flux
in	flux_struc_hat	the unit vector in structural frame for the flux vector.
in	calculate_forces	boolean indicating whether to calculate forces.

Implements jeod::RadiationBaseFacet.

Definition at line 218 of file radiation\_default\_surface.cc.

References jeod::RadiationBaseFacet::albedo, jeod::RadiationBaseFacet::areaxflux, jeod::RadiationBaseFacet::areaxflux\_e, jeod::RadiationBaseFacet::cx\_area, jeod::RadiationBaseFacet::diffuse, jeod::RadiationBaseFacet::F\_absorption, jeod::RadiationBaseFacet::F\_geod::RadiationBaseFacet::F\_specular, jeod::RadiationBaseFacet::speed of light, and jeod::RadiationBaseFacet::thermal.

Referenced by jeod::RadiationPressure::update\_default\_surface().

**8.4.3.3** void jeod::RadiationDefaultSurface::initialize (void ) [override], [virtual]

initializes the default surface

Reimplemented from jeod::RadiationBaseFacet.

Definition at line 89 of file radiation default surface.cc.

References jeod::RadiationBaseFacet::albedo, jeod::RadiationBaseFacet::cx\_area, jeod::RadiationBaseFacet::diffuse, jeod::RadiationBaseFacet::initialize(), jeod::RadiationMessages::invalid\_setup\_error, jeod::RadiationMessages::operational\_setup\_error, rad\_coeff, surface\_area, temperature, and jeod::RadiationBaseFacet::thermal.

Referenced by jeod::RadiationPressure::initialize().

8.4.3.4 RadiationDefaultSurface& jeod::RadiationDefaultSurface::operator=( const RadiationDefaultSurface & rhs )
[private]

8.4.3.5 void jeod::RadiationDefaultSurface::set\_name( std::string name\_in ) [inline]

Setter for the name.

Definition at line 160 of file radiation\_default\_surface.hh.

8.4.3.6 void jeod::RadiationDefaultSurface::thermal\_update (void)

Test for necessity of maintaining thermal updates, and performs them as necessary.

Definition at line 270 of file radiation\_default\_surface.cc.

References temperature, and jeod::RadiationBaseFacet::thermal.

Referenced by jeod::RadiationPressure::update\_default\_surface().

# 8.4.4 Friends And Related Function Documentation

**8.4.4.1 void init\_attrjeod\_\_RadiationDefaultSurface( )** [friend]

**8.4.4.2** friend class InputProcessor [friend]

Definition at line 91 of file radiation\_default\_surface.hh.

# 8.4.5 Field Documentation

8.4.5.1 std::string jeod::RadiationDefaultSurface::name

The name of the surface.

This is optional.trick units(-)

Definition at line 119 of file radiation\_default\_surface.hh.

8.4.5.2 double jeod::RadiationDefaultSurface::rad\_coeff

The radiation-equivalent of a drag coefficient.

It is the value by which the area must be multiplied in order to generate the same force if the reflecting surface were considered a perfectly absorbing surface. For a sphere, this has a value between 1.0 (perfectly absorbing, or perfect specular reflection) to 1.4444 (all diffuse reflection). Specify either: rad\_coeff OR (albedo AND diffuse). NOTE 1 - this value is used at initialization only; changes to its value mid-simulation cannot be effected. NOTE 2 - the values albedo and diffuse are inherited from RadiationBaseFacet.trick\_units(-)

Definition at line 109 of file radiation\_default\_surface.hh.

Referenced by initialize(), and RadiationDefaultSurface().

8.4.5.3 double jeod::RadiationDefaultSurface::surface\_area

surface area of the default sphere.

trick units(m2)

Definition at line 129 of file radiation\_default\_surface.hh.

Referenced by initialize(), and RadiationDefaultSurface().

8.4.5.4 double jeod::RadiationDefaultSurface::temperature

The value of the surface kinetic temperature.

trick units(K)

Definition at line 114 of file radiation\_default\_surface.hh.

Referenced by initialize(), RadiationDefaultSurface(), and thermal\_update().

The documentation for this class was generated from the following files:


- · radiation\_default\_surface.hh
- · radiation default surface.cc

# 8.5 jeod::RadiationFacet Class Reference

Generic type of facet for radiation pressure.

#include <radiation\_facet.hh>

Inheritance diagram for jeod::RadiationFacet:



#### **Public Member Functions**

• RadiationFacet ()

Constructor for Radiationfacet.

∼RadiationFacet () override

Destructor for RadiationFacet.

virtual void radiation\_pressure ()=0

Calculates the effect of radiation pressure on the facet.

• virtual void initialize\_geom (double cg[3])=0

Initialize the facet geometry.

• void initialize () override

Run sanity checks on input variables.

• void define\_facet\_core (Facet \*facet, const ThermalFacetRider &facet\_thermal, RadiationParams \*params)

Defines the inherent facet values.

ThermalIntegrableObject & get\_thermal\_integrator ()

Get the integrator for thermal characteristics.

# **Data Fields**

• double crot\_to\_cp [3]

position of center of pressure w.r.t.

• double \* center\_pressure

Center of pressure (in structural frame).

# **Static Protected Attributes**

static const double two\_thirds = 2.0 / 3.0
 quite literally, 2/3.

# **Private Member Functions**

- RadiationFacet & operator= (const RadiationFacet &rhs)
- RadiationFacet (const RadiationFacet &rhs)

# **Friends**

- class InputProcessor
- void init\_attrjeod\_\_RadiationFacet ()

# 8.5.1 Detailed Description

Generic type of facet for radiation pressure.

Definition at line 87 of file radiation facet.hh.

### 8.5.2 Constructor & Destructor Documentation

8.5.2.1 jeod::RadiationFacet::RadiationFacet ( void )

Constructor for Radiationfacet.

Definition at line 59 of file radiation\_facet.cc.

References center\_pressure, and crot\_to\_cp.

**8.5.2.2** jeod::RadiationFacet::~RadiationFacet(void) [override]

Destructor for RadiationFacet.

Definition at line 121 of file radiation facet.cc.

**8.5.2.3** jeod::RadiationFacet::RadiationFacet ( const RadiationFacet & rhs ) [private]

# 8.5.3 Member Function Documentation

8.5.3.1 void jeod::RadiationFacet::define\_facet\_core ( Facet \* facet, const ThermalFacetRider & facet\_thermal, RadiationParams \* params )

Defines the inherent facet values.

#### **Parameters**

ĺ	in	facet	pointer to the facet
	in	facet_thermal	reference to the thermal components of the facet.
	in	params	pointer to the list of material parameters for the facet.

Definition at line 100 of file radiation\_facet.cc.

References jeod::RadiationParams::albedo, jeod::RadiationBaseFacet::albedo, jeod::RadiationParams::diffuse, jeod::RadiationBaseFacet::diffuse, jeod::RadiationParams::thermal, and jeod::RadiationBaseFacet::thermal.

**8.5.3.2** ThermalIntegrableObject& jeod::RadiationFacet::get\_thermal\_integrator( ) [inline]

Get the integrator for thermal characteristics.

Returns

Integrable object that integrates temperature.

Definition at line 154 of file radiation\_facet.hh.

References jeod::RadiationBaseFacet::thermal.

**8.5.3.3 void jeod::RadiationFacet::initialize ( void )** [override], [virtual]

Run sanity checks on input variables.

Reimplemented from jeod::RadiationBaseFacet.

Definition at line 70 of file radiation\_facet.cc.

References jeod::RadiationBaseFacet::albedo, jeod::RadiationBaseFacet::albedo\_IR, jeod::RadiationBaseFacet::albedo\_vis, jeod::RadiationBaseFacet::diffuse, jeod::RadiationBaseFacet::initialize(), jeod::RadiationMessages::invalid\_setup\_error, and jeod::RadiationBaseFacet::thermal.

Referenced by jeod::FlatPlateRadiationFacet::initialize\_geom().

**8.5.3.4** virtual void jeod::RadiationFacet::initialize\_geom ( double cg[3] ) [pure virtual]

Initialize the facet geometry.

**Parameters** 

```
cg Center of mass.
```

Implemented in jeod::FlatPlateRadiationFacet.

Referenced by jeod::RadiationSurface::initialize().

```
8.5.3.5 RadiationFacet&jeod::RadiationFacet::operator=(const RadiationFacet&rhs) [private]
```

```
8.5.3.6 virtual void jeod::RadiationFacet::radiation_pressure() [pure virtual]
```

Calculates the effect of radiation pressure on the facet.

Implemented in jeod::FlatPlateRadiationFacet.

Referenced by jeod::RadiationSurface::radiation\_pressure().

# 8.5.4 Friends And Related Function Documentation

```
8.5.4.1 void init_attrjeod__RadiationFacet() [friend]
```

**8.5.4.2** friend class InputProcessor [friend]

Definition at line 89 of file radiation facet.hh.

# 8.5.5 Field Documentation

8.5.5.1 double\* jeod::RadiationFacet::center\_pressure

Center of pressure (in structural frame).

Potentially variable, depending on the topology of the facet. For a flat plate facet, this just points to the position found in FlatPlatetrick units(m)

Definition at line 108 of file radiation facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::define\_facet(), jeod::FlatPlateRadiationFacet::initialize\_geom(), and RadiationFacet().

# 8.5.5.2 double jeod::RadiationFacet::crot\_to\_cp[3]

position of center of pressure w.r.t.

center of rotation (usually center of mass, or center of gravity), expressed in structural reference frame. Potentially variable, depending on the topology of the facet and the configuration of the vehicle.trick\_units(m)

Definition at line 101 of file radiation\_facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::initialize\_geom(), jeod::FlatPlateRadiationFacet::radiation\_pressure(), and RadiationFacet().

**8.5.5.3** const double jeod::RadiationFacet::two\_thirds = 2.0/3.0 [static], [protected]

quite literally, 2/3.

Occurs frequently with diffuse reflection and emission, so it is calculated once.trick\_io(\*o) trick\_units(-)

Definition at line 118 of file radiation facet.hh.

Referenced by jeod::FlatPlateRadiationFacet::incident\_radiation(), and jeod::FlatPlateRadiationFacet::radiation\_pressure().

The documentation for this class was generated from the following files:

- · radiation\_facet.hh
- · radiation\_facet.cc

# 8.6 jeod::RadiationMessages Class Reference

Provides error messages.

```
#include <radiation_messages.hh>
```

# **Static Public Attributes**

• static char const \* incomplete setup error

The setup was not fully defined.

• static char const \* invalid\_setup\_error

The setup is invalid.

static char const \* operational\_setup\_error

Something internal went wrong in the setup methods without obvious user error.

• static char const \* invalid\_function\_call

A function was called before it was fully implemented.

• static char const \* unknown\_numerical\_error

Something went horribly wrong.

# **Private Member Functions**

- RadiationMessages (void)
- RadiationMessages (const RadiationMessages &)
- RadiationMessages & operator= (const RadiationMessages &)

# **Friends**

- · class InputProcessor
- void init\_attrjeod\_\_RadiationMessages ()

# 8.6.1 Detailed Description

Provides error messages.

Definition at line 87 of file radiation\_messages.hh.

```
8.6.2 Constructor & Destructor Documentation
```

```
8.6.2.1 jeod::RadiationMessages::RadiationMessages ( void ) [private]
```

- **8.6.2.2** jeod::RadiationMessages::RadiationMessages ( const RadiationMessages & ) [private]
- 8.6.3 Member Function Documentation
- **8.6.3.1** RadiationMessages& jeod::RadiationMessages::operator=( const RadiationMessages & ) [private]
- 8.6.4 Friends And Related Function Documentation

```
8.6.4.1 void init_attrjeod__RadiationMessages() [friend]
```

**8.6.4.2 friend class InputProcessor** [friend]

Definition at line 90 of file radiation messages.hh.

#### 8.6.5 Field Documentation

```
8.6.5.1 char const * jeod::RadiationMessages::incomplete_setup_error [static]
```

#### Initial value:

```
"interactions/radiation_pressure/" "incomplete_setup_error"
```

The setup was not fully defined.

trick\_units(-)

Definition at line 99 of file radiation\_messages.hh.

 $Referenced\ by\ jeod:: Radiation Pressure:: add\_third\_body(),\ and\ jeod:: Radiation Source:: initialize().$ 

```
\textbf{8.6.5.2} \quad \textbf{char const} * \textbf{jeod::RadiationMessages::invalid\_function\_call} \quad \texttt{[static]}
```

#### Initial value:

```
"interactions/radiation_pressure/" "invalid_function_call"
```

A function was called before it was fully implemented.

trick\_units(-)

Definition at line 112 of file radiation\_messages.hh.

Referenced by jeod::RadiationPressure::find\_third\_body(), jeod::RadiationPressure::set\_third\_body\_active(), and jeod::RadiationPressure::set\_third\_body\_inactive().

**8.6.5.3 char const** \* jeod::RadiationMessages::invalid\_setup\_error [static]

### Initial value:

```
"interactions/radiation_pressure/" "invalid_setup_error"
```

The setup is invalid.

trick\_units(-)

Definition at line 103 of file radiation\_messages.hh.

Referenced by jeod::RadiationSurfaceFactory::add\_facet\_params(), jeod::RadiationPressure::add\_third\_body(), jeod::RadiationSurface::allocate\_interaction\_facet(), jeod::RadiationThirdBody::calculate\_shadow(), jeod::RadiationThirdBody::calculate\_shadow(), jeod::RadiationThirdBody::create\_facet(), jeod::RadiationFactory::create\_facet(), jeod::RadiationFacet::initialize(), jeod::RadiationDefaultSurface::initialize(), jeod::RadiationThirdBody::process\_third\_body(), and jeod::RadiationThirdBody::update\_third\_body\_state().

**8.6.5.4** char const \* jeod::RadiationMessages::operational\_setup\_error [static]

### Initial value:

```
"interactions/radiation_pressure/" "operational_setup_error"
```

Something internal went wrong in the setup methods without obvious user error.

trick units(-)

Definition at line 108 of file radiation\_messages.hh.

Referenced by jeod::RadiationSurface::allocate\_array(), jeod::RadiationSurface::allocate\_interaction\_facet(), jeod::RadiationSurface::initialize(), and jeod::RadiationThirdBody::process\_third\_body().

**8.6.5.5** char const \* jeod::RadiationMessages::unknown\_numerical\_error [static]

# Initial value:

```
"interactions/radiation_pressure/" "unknown_numerical_error"
```

Something went horribly wrong.

trick\_units(-)

Definition at line 117 of file radiation\_messages.hh.

 $Referenced\ by\ jeod::FlatPlateRadiationFacet::radiation\_pressure().$ 

The documentation for this class was generated from the following files:


- · radiation\_messages.hh
- · radiation\_messages.cc

# 8.7 jeod::RadiationParams Class Reference

Provides a parameter list to each facet, based on the facet material properties.

```
#include <radiation_params.hh>
```

Inheritance diagram for jeod::RadiationParams:



# **Public Member Functions**

• RadiationParams ()

Constructor for RadiationParams.

∼RadiationParams () override

Destructor for RadiationParams.

# **Data Fields**

· double albedo

Fraction of incident radiation that is immediately reflected.

· double diffuse

Fraction of reflected radiation that is reflected diffusely (balance reflected specularly)

· ThermalParams thermal

Additional thermal parameters.

# **Private Member Functions**

- RadiationParams & operator= (const RadiationParams &rhs)
- · RadiationParams (const RadiationParams &rhs)

# Friends

- · class InputProcessor
- void init\_attrjeod\_\_RadiationParams ()

# 8.7.1 Detailed Description

Provides a parameter list to each facet, based on the facet material properties.

Definition at line 83 of file radiation\_params.hh.

# 8.7.2 Constructor & Destructor Documentation

8.7.2.1 jeod::RadiationParams::RadiationParams ( void )

Constructor for RadiationParams.

Definition at line 43 of file radiation\_params.cc.

References albedo, and diffuse.

**8.7.2.2** jeod::RadiationParams::~RadiationParams(void) [override]

Destructor for RadiationParams.

Definition at line 53 of file radiation\_params.cc.

```
8.7.2.3 jeod::RadiationParams::RadiationParams ( const RadiationParams & rhs ) [private]
```

# 8.7.3 Member Function Documentation

**8.7.3.1** RadiationParams& jeod::RadiationParams::operator=(const RadiationParams & rhs) [private]

# 8.7.4 Friends And Related Function Documentation

```
8.7.4.1 void init_attrjeod__RadiationParams() [friend]
```

**8.7.4.2 friend class InputProcessor** [friend]

Definition at line 85 of file radiation\_params.hh.

#### 8.7.5 Field Documentation

8.7.5.1 double jeod::RadiationParams::albedo

Fraction of incident radiation that is immediately reflected.

trick units(-)

Definition at line 93 of file radiation\_params.hh.

Referenced by jeod::RadiationFacet::define\_facet\_core(), and RadiationParams().

# 8.7.5.2 double jeod::RadiationParams::diffuse

Fraction of reflected radiation that is reflected diffusely (balance reflected specularly)

trick\_units(-)

Definition at line 99 of file radiation params.hh.

Referenced by jeod::RadiationFacet::define\_facet\_core(), and RadiationParams().

# 8.7.5.3 ThermalParams jeod::RadiationParams::thermal

Additional thermal parameters.

trick\_units(-)

Definition at line 104 of file radiation\_params.hh.

Referenced by jeod::RadiationFacet::define\_facet\_core().

The documentation for this class was generated from the following files:

- radiation\_params.hh
- · radiation\_params.cc

# 8.8 jeod::RadiationPressure Class Reference

Radiation pressure top-level definition.

```
#include <radiation_pressure.hh>
```

# **Public Member Functions**

• RadiationPressure ()

Constructor for RadiationPressure.

• virtual  $\sim$ RadiationPressure ()

Destructor for RadiationPressure.

void initialize (DynManager &dyn\_manager, RadiationSurface \*surf\_ptr, double center\_grav[3])

Initialize the radiation pressure model when using a RadiationSurface (i.e.

void initialize (DynManager &dyn\_manager, RadiationDefaultSurface \*surf\_ptr)

Initialize the radiation pressure model when using a RadiationDefaultSurface (i.e.

• void update (RefFrame &vehicle\_structural\_frame, double center\_grav[3], double scale\_factor, double time)

Updates the model at each time step.

void add\_third\_body (RadiationThirdBody \*third\_body\_ptr)

Adds a third body to the vector storage of third bodies.

void set\_third\_body\_active (const char \*third\_body\_name)

Sets a Third Body to be active when it previously was not.

void set\_third\_body\_inactive (const char \*third\_body\_name)

Sets a Third Body to be inactive when it previously was not.

void set\_calculate\_forces (bool calc\_forces)

Sets the value calculate\_forces.

# **Data Fields**

· bool active

Is radiation pressure desired?

• double force [3]

Net force due to radiation.

• double torque [3]

Net torque due to radiation.

double illum\_factor

fraction of primary flux that is not eclipsed

• RadiationSource source

Collection of data for radiation source.

• ThermalModelRider thermal

Rider to allow dynamic thermal variation on facets in this model.

### **Protected Member Functions**

void update\_default\_surface (void)

Used to update the model when the surface is a default surface.

void update\_facet\_surface (void)

Used to update the model when the surface comprises facets.

void initialize\_environment (DynManager \*dyn\_mgr\_ptr)

Initializes the source and third bodies.

· void third body adjustments (double time, RefFrame &vehicle structural frame)

Used to modify the flux for shadowing.

• int find third body (const char \*third body name)

Finds the index of a third body based on its name.

# **Protected Attributes**

· bool initialized

Has model been initialized?

· bool calculate forces

Flag to indicate whether forces and torques should be calculated.

· bool third bodies active

Flag indicates whether there are any of the third bodies currently active.

· unsigned int num third bodies

Number of ThirdBodies available.

JeodPointerVector

< RadiationThirdBody >::type third\_bodies

Planetary bodies that provide shadowing or indirect, reflected, illumination.

RadiationSurface \* surface ptr

The surface over which the radiation pressure will be collected.

RadiationDefaultSurface \* default surface ptr

If no surface is defined, use a DefaultSurface; this is the pointer to that default surface,.

DynManager \* dyn\_manager\_ptr

Pointer to the Dynamics Manager.

#### **Private Member Functions**

- RadiationPressure (const RadiationPressure &)
- RadiationPressure & operator= (const RadiationPressure &)

# **Friends**

- · class InputProcessor
- void init\_attrjeod\_\_RadiationPressure ()

# 8.8.1 Detailed Description

Radiation pressure top-level definition.

Definition at line 93 of file radiation\_pressure.hh.

# 8.8.2 Constructor & Destructor Documentation

8.8.2.1 jeod::RadiationPressure::RadiationPressure (void)

Constructor for RadiationPressure.

Definition at line 68 of file radiation\_pressure.cc.

References active, calculate\_forces, default\_surface\_ptr, dyn\_manager\_ptr, force, illum\_factor, initialized, num\_third bodies, surface ptr, third bodies, third bodies active, and torque.

8.8.2.2 jeod::RadiationPressure:: $\sim$ RadiationPressure ( void ) [virtual]

Destructor for RadiationPressure.

Definition at line 394 of file radiation\_pressure.cc.

References third\_bodies.

8.8.2.3 jeod::RadiationPressure::RadiationPressure ( const RadiationPressure & ) [private]

# 8.8.3 Member Function Documentation

8.8.3.1 void jeod::RadiationPressure::add\_third\_body ( RadiationThirdBody \* third\_body\_ptr )

Adds a third body to the vector storage of third bodies.

### **Parameters**

		maintainte ThindDade.
ın	third_body_ptr	pointer to ThirdBody

Definition at line 183 of file radiation\_pressure.cc.

References jeod::RadiationThirdBody::active, dyn\_manager\_ptr, jeod::RadiationThirdBody::get\_added\_to\_model(), jeod::RadiationMessages::incomplete\_setup\_error, jeod::RadiationThirdBody::initialize(), initialized, jeod::RadiationMessages::invalid\_setup\_error, jeod::RadiationThirdBody::name, num\_third\_bodies, jeod::RadiationThirdBody::set\_added\_to\_model(), third\_bodies, and third\_bodies\_active.

Referenced by initialize().

8.8.3.2 int jeod::RadiationPressure::find third body ( const char \* third body name ) [protected]

Finds the index of a third body based on its name.

#### Returns

void

#### **Parameters**

in	third_body	Name of ThirdBody
	name	

Definition at line 358 of file radiation\_pressure.cc.

References jeod::RadiationMessages::invalid function call, num third bodies, and third bodies.

Referenced by set third body active(), and set third body inactive().

8.8.3.3 void jeod::RadiationPressure::initialize ( DynManager & dyn\_mgr, RadiationSurface \* surf\_ptr, double center\_grav[3] )

Initialize the radiation pressure model when using a RadiationSurface (i.e.

with facets).

### **Parameters**

in	dyn_mgr	The dynamics manager
in	surf_ptr	pointer to the radiation surface
in	center_grav	position of center of mass
		Units: M

Definition at line 75 of file radiation\_pressure\_\_surface\_model.cc.

References add\_third\_body(), dyn\_manager\_ptr, jeod::RadiationSurface::initialize(), initialize\_environment(), jeod::RadiationSource::num\_bodies, jeod::RadiationSource::shadow\_geometry, source, surface\_ptr, thermal, third\_bodies, and jeod::RadiationSource::third\_body.

8.8.3.4 void jeod::RadiationPressure::initialize ( DynManager & dyn\_mgr, RadiationDefaultSurface \* surf\_ptr )

Initialize the radiation pressure model when using a RadiationDefaultSurface (i.e.

spherical, uniform properties.)

#### **Parameters**

in	dyn_mgr	The dynamics manager
in	surf_ptr	pointer to the radiation surface

Definition at line 71 of file radiation pressure default surface.cc.

References add\_third\_body(), default\_surface\_ptr, dyn\_manager\_ptr, jeod::RadiationDefaultSurface::initialize(), initialize\_environment(), jeod::RadiationSource::num\_bodies, jeod::RadiationSource::shadow\_geometry, source, third bodies, and jeod::RadiationSource::third body.

**8.8.3.5** void jeod::RadiationPressure::initialize\_environment( DynManager \* dyn\_mgr\_ptr ) [protected]

Initializes the source and third bodies.

#### **Parameters**

ſ	in	dyn_mgr_ptr	The dynamics manager

Definition at line 93 of file radiation pressure.cc.

References jeod::RadiationSource::initialize(), initialized, num\_third\_bodies, source, and third\_bodies.

Referenced by initialize().

- **8.8.3.6** RadiationPressure& jeod::RadiationPressure::operator=( const RadiationPressure & ) [private]
- 8.8.3.7 void jeod::RadiationPressure::set\_calculate\_forces ( bool value )

Sets the value calculate forces.

### **Parameters**

	·	
in	value	whether forces are needed

Definition at line 379 of file radiation pressure.cc.

References calculate\_forces, force, and torque.

8.8.3.8 void jeod::RadiationPressure::set\_third\_body\_active ( const char \* third\_body\_name )

Sets a Third Body to be active when it previously was not.

### **Parameters**

i	[]	third_body	Name of ThirdBody
		name	

Definition at line 280 of file radiation pressure.cc.

 $References\ active,\ dyn\_manager\_ptr,\ find\_third\_body(),\ jeod::RadiationMessages::invalid\_function\_call,\ third\_bodies,\ and\ third\_bodies\_active.$ 

8.8.3.9 void jeod::RadiationPressure::set\_third\_body\_inactive ( const char \* third\_body\_name )

Sets a Third Body to be inactive when it previously was not.

**Parameters** 

in	third_body	Name of ThirdBody
	name	

Definition at line 317 of file radiation pressure.cc.

References active, dyn\_manager\_ptr, find\_third\_body(), jeod::RadiationMessages::invalid\_function\_call, num\_third\_bodies, third\_bodies, and third\_bodies\_active.

8.8.3.10 void jeod::RadiationPressure::third\_body\_adjustments ( double real\_time, RefFrame & veh\_struc\_frame )

[protected]

Used to modify the flux for shadowing.

#### **Parameters**

in	real_time	The current time, e.g. TAI or UT1.
		Units: s
in	veh_struc_frame	Structure frame of vehicle

Definition at line 159 of file radiation\_pressure.cc.

References active, jeod::RadiationSource::flux\_inertial, jeod::RadiationSource::flux\_mag, jeod::RadiationSource::flux\_struc, illum\_factor, num\_third\_bodies, source, and third\_bodies.

Referenced by update().

8.8.3.11 void jeod::RadiationPressure::update ( RefFrame & veh\_struc\_frame, double center\_grav[3], double scale\_factor, double real\_time )

Updates the model at each time step.

#### **Parameters**

in	veh_struc_frame	The vehicle structural reference frame.
in	center_grav	position of center of mass
		Units: M
in	scale_factor	the scale between the simulator time and the dynamic time.
in	real_time	The current time, e.g. TAI or UT1.
		Units: s

Definition at line 114 of file radiation\_pressure.cc.

References active, jeod::RadiationSource::calculate\_flux(), source, surface\_ptr, third\_bodies\_active, third\_body\_adjustments(), update\_default\_surface(), and update\_facet\_surface().

8.8.3.12 void jeod::RadiationPressure::update\_default\_surface( void ) [protected]

Used to update the model when the surface is a default surface.

Definition at line 96 of file radiation\_pressure\_\_default\_surface.cc.

References active, calculate\_forces, default\_surface\_ptr, jeod::RadiationBaseFacet::F\_absorption, jeod::RadiationBaseFacet::F\_diffuse, jeod::RadiationBaseFacet::F\_specular, jeod::RadiationSource::flux\_mag, jeod::RadiationBaseFacet::initialize\_runtime\_values(), jeod::RadiationBaseFacet::initialize\_runtime\_values(), jeod::RadiationBaseFacet::initialize\_runtime\_values(), ipid::RadiationBaseFacet::initialize\_runtime\_values(), ipid::RadiationBaseFacet:

Referenced by update().

**8.8.3.13** void jeod::RadiationPressure::update\_facet\_surface( void ) [protected]

Used to update the model when the surface comprises facets.

Definition at line 111 of file radiation pressure surface model.cc.

References active, calculate\_forces, jeod::RadiationSurface::equalize\_absorption\_emission(), jeod::RadiationSource::flux\_mag, jeod::RadiationSource::flux\_struc\_hat, force, jeod::RadiationSurface::force, jeod::RadiationSurface::incident\_radiation(), jeod::RadiationSurface::initialize\_runtime\_values(), jeod::RadiationSurface::interact\_with\_third\_body(), num\_third\_bodies, jeod::RadiationSurface::radiation\_pressure(), source, surface\_ptr, thermal, third\_bodies, torque, and jeod::RadiationSurface::torque.

Referenced by update().

#### 8.8.4 Friends And Related Function Documentation

**8.8.4.1 void init\_attrjeod\_\_RadiationPressure()** [friend]

**8.8.4.2** friend class InputProcessor [friend]

Definition at line 95 of file radiation pressure.hh.

#### 8.8.5 Field Documentation

8.8.5.1 bool jeod::RadiationPressure::active

Is radiation pressure desired?

trick\_units(-)

Definition at line 103 of file radiation\_pressure.hh.

Referenced by RadiationPressure(), set\_third\_body\_active(), set\_third\_body\_inactive(), third\_body\_adjustments(), update(), update default surface(), and update facet surface().

**8.8.5.2** bool jeod::RadiationPressure::calculate\_forces [protected]

Flag to indicate whether forces and torques should be calculated.

trick units(-)

Definition at line 140 of file radiation\_pressure.hh.

Referenced by RadiationPressure(), set\_calculate\_forces(), update\_default\_surface(), and update\_facet\_surface().

**8.8.5.3 RadiationDefaultSurface**\* jeod::RadiationPressure::default\_surface\_ptr [protected]

If no surface is defined, use a DefaultSurface; this is the pointer to that default surface,.

trick units(-)

Definition at line 170 of file radiation\_pressure.hh.

Referenced by initialize(), RadiationPressure(), and update\_default\_surface().

**8.8.5.4 DynManager**\* jeod::RadiationPressure::dyn\_manager\_ptr [protected]

Pointer to the Dynamics Manager.

trick\_units(-)

Definition at line 175 of file radiation\_pressure.hh.

Referenced by add\_third\_body(), initialize(), RadiationPressure(), set\_third\_body\_active(), and set\_third\_body\_inactive().

8.8.5.5 double jeod::RadiationPressure::force[3]

Net force due to radiation.

trick units(N)

Definition at line 108 of file radiation pressure.hh.

Referenced by RadiationPressure(), set\_calculate\_forces(), update\_default\_surface(), and update\_facet\_surface().

8.8.5.6 double jeod::RadiationPressure::illum\_factor

fraction of primary flux that is not eclipsed

trick\_units(-)

Definition at line 118 of file radiation\_pressure.hh.

Referenced by RadiationPressure(), and third\_body\_adjustments().

**8.8.5.7 bool jeod::RadiationPressure::initialized** [protected]

Has model been initialized?

trick units(-)

Definition at line 135 of file radiation\_pressure.hh.

Referenced by add third body(), initialize environment(), and RadiationPressure().

**8.8.5.8 unsigned int jeod::RadiationPressure::num\_third\_bodies** [protected]

Number of ThirdBodies available.

trick\_units(count)

Definition at line 151 of file radiation\_pressure.hh.

Referenced by add\_third\_body(), find\_third\_body(), initialize\_environment(), RadiationPressure(), set\_third\_body\_inactive(), third\_body\_adjustments(), update\_default\_surface(), and update\_facet\_surface().

8.8.5.9 RadiationSource jeod::RadiationPressure::source

Collection of data for radiation source.

trick\_units(-)

Definition at line 123 of file radiation pressure.hh.

Referenced by initialize(), initialize\_environment(), third\_body\_adjustments(), update(), update\_default\_surface(), and update\_facet\_surface().

**8.8.5.10 RadiationSurface**\* jeod::RadiationPressure::surface\_ptr [protected]

The surface over which the radiation pressure will be collected.

If this is NULL, use the default radiation surface (which is a whole separate entity from a RadiationSurface.trick\_-units(-)

Definition at line 164 of file radiation\_pressure.hh.

Referenced by initialize(), RadiationPressure(), update(), and update facet surface().

#### 8.8.5.11 ThermalModelRider jeod::RadiationPressure::thermal

Rider to allow dynamic thermal variation on facets in this model.

trick\_units(-)

Definition at line 128 of file radiation pressure.hh.

Referenced by initialize(), and update\_facet\_surface().

# **8.8.5.12** JeodPointerVector < RadiationThirdBody >::type jeod::RadiationPressure::third\_bodies [protected]

Planetary bodies that provide shadowing or indirect, reflected, illumination.

trick\_io(\*\*)

Definition at line 157 of file radiation\_pressure.hh.

Referenced by add\_third\_body(), find\_third\_body(), initialize(), initialize\_environment(), RadiationPressure(), set\_third\_body\_active(), set\_third\_body\_inactive(), third\_body\_adjustments(), update\_default\_surface(), update\_facet\_surface(), and  $\sim$ RadiationPressure().

#### **8.8.5.13** bool jeod::RadiationPressure::third\_bodies\_active [protected]

Flag indicates whether there are any of the third bodies currently active.

trick\_units(-)

Definition at line 146 of file radiation pressure.hh.

Referenced by add\_third\_body(), RadiationPressure(), set\_third\_body\_active(), set\_third\_body\_inactive(), and update().

# 8.8.5.14 double jeod::RadiationPressure::torque[3]

Net torque due to radiation.

trick units(N\*m)

Definition at line 113 of file radiation\_pressure.hh.

Referenced by RadiationPressure(), set calculate forces(), update default surface(), and update facet surface().

The documentation for this class was generated from the following files:

- · radiation\_pressure.hh
- radiation\_pressure.cc
- radiation\_pressure\_\_default\_surface.cc
- radiation\_pressure\_\_surface\_model.cc

# 8.9 jeod::RadiationSource Class Reference

Provides information on the source of the incident radiation.

#include <radiation\_source.hh>

# **Public Types**

 enum OldShadowGeometry { Cylindrical = 0, Cyl = 1, Conical = 2, Con = 3 } distinguishes between conical and cylindrical shadowing.

# **Public Member Functions**

• RadiationSource ()

Constructor for RadiationSource.

virtual ∼RadiationSource ()

destructor for RadiationSource

virtual void initialize (DynManager \*dyn\_manager\_ptr)

Initializes the source object for use in the Radiation Pressure model.

virtual void calculate\_flux (RefFrame &veh\_struc\_frame, const double center\_grav[3])

calculates the flux vector from the vehicle's position.

void set\_name (std::string name\_in)

Setter for the name.

# **Data Fields**

· const double solar luminosity

Solar Luminosity.

· const double solar\_radius

Mean solar radius.

std::string name

The name of the source of the illumination (usually Sun)

• double flux\_hat [3]

(inertial) unit vector associated with primary radiative flux.

· double flux mag

magnitude of principle radiative flux vector

• double d\_source\_to\_cg

distance from source to vehicle cg.

· double luminosity

Luminosity of primary source.

double radius

Radius of primary source.

• double flux\_inertial [3]

(N/M/s) Power per unit area in the inertial reference frame

double flux\_struc [3]

(N/M\*s) Power per unit area in the vehicle structural reference frame

• double flux\_struc\_hat [3]

Unit vector representing flux vector in the vehicle structural reference frame.

double inertial\_cg [3]

vehicle cg position w.r.t vehicle strucural origin, expressed in inertial RF.

• double source to cg [3]

vehicle cg position relative to the source

• double source\_to\_struc\_origin [3]

vehicle struc frame origin position relative to source.

· bool multiple shadow bodies

flags that more than one body are casting shadows on the vehicle.

RefFrame \* inertial\_frame\_ptr

the inertial reference frame associated with this source

· bool bodies active

can there be 3rd-body interference, either shadowing or reflection.

• unsigned int num\_bodies

number of ThirdBodies available.

RadiationThirdBody \*\* third\_body

Planetary bodies that provide shadowing or indirect, reflected, illumination.

OldShadowGeometry shadow\_geometry

Flag indicating cylindrical / conical shadow geometry.

#### **Private Member Functions**

- RadiationSource (const RadiationSource &)
- RadiationSource & operator= (const RadiationSource &)

#### **Friends**

- · class InputProcessor
- · void init attrjeod RadiationSource ()

# 8.9.1 Detailed Description

Provides information on the source of the incident radiation.

Definition at line 92 of file radiation\_source.hh.

# 8.9.2 Member Enumeration Documentation

# 8.9.2.1 enum jeod::RadiationSource::OldShadowGeometry

distinguishes between conical and cylindrical shadowing.

NOTE this is provided for backward-compatibility and should not be used.

# Enumerator

Cylindrical planet casts a cylindrical shadow

Cyl planet casts a cylindrical shadow

Conical planet casts a conical shadow

Con planet casts a conical shadow

Definition at line 209 of file radiation\_source.hh.

# 8.9.3 Constructor & Destructor Documentation

# 8.9.3.1 jeod::RadiationSource::RadiationSource ( void )

Constructor for RadiationSource.

Definition at line 64 of file radiation\_source.cc.

References d\_source\_to\_cg, flux\_hat, flux\_inertial, flux\_mag, flux\_struc, flux\_struc\_hat, inertial\_cg, inertial\_frame\_ptr, luminosity, multiple\_shadow\_bodies, radius, solar\_luminosity, solar\_radius, source\_to\_cg, and source\_to\_struc\_origin.

8.9.3.2 jeod::RadiationSource::~RadiationSource(void) [virtual]

destructor for RadiationSource

Definition at line 189 of file radiation source.cc.

8.9.3.3 jeod::RadiationSource::RadiationSource & ) [private]

#### 8.9.4 Member Function Documentation

8.9.4.1 void jeod::RadiationSource::calculate\_flux ( RefFrame & veh\_struc\_frame, const double center\_gravity[3] )

[virtual]

calculates the flux vector from the vehicle's position.

#### **Parameters**

in	veh_struc_frame	the vehicle structural reference frame
in	center_gravity	position of the center of mass
		Units: M

Definition at line 102 of file radiation\_source.cc.

References d\_source\_to\_cg, flux\_hat, flux\_inertial, flux\_mag, flux\_struc, flux\_struc\_hat, inertial\_cg, inertial\_frame-ptr, luminosity, source to cg, and source to struc origin.

Referenced by jeod::RadiationPressure::update().

**8.9.4.2** void jeod::RadiationSource::initialize ( DynManager \* dyn\_mgr\_ptr ) [virtual]

Initializes the source object for use in the Radiation Pressure model.

# **Parameters**

in	dyn_mgr_ptr	pointer to the dynamics manager

Definition at line 166 of file radiation\_source.cc.

References jeod::RadiationMessages::incomplete\_setup\_error, inertial\_frame\_ptr, and name.

Referenced by jeod::RadiationPressure::initialize environment().

8.9.4.3 RadiationSource& jeod::RadiationSource::operator=( const RadiationSource & ) [private]

8.9.4.4 void jeod::RadiationSource::set\_name ( std::string name\_in ) [inline]

Setter for the name.

Definition at line 235 of file radiation\_source.hh.

References name.

#### 8.9.5 Friends And Related Function Documentation

**8.9.5.1 void init\_attrjeod\_\_RadiationSource()** [friend]

8.9.5.2 friend class InputProcessor [friend]

Definition at line 93 of file radiation\_source.hh.

# 8.9.6 Field Documentation

8.9.6.1 bool jeod::RadiationSource::bodies\_active

can there be 3rd-body interference, either shadowing or reflection.

trick\_units(-)

Definition at line 191 of file radiation\_source.hh.

8.9.6.2 double jeod::RadiationSource::d\_source\_to\_cg

distance from source to vehicle cg.

trick\_units(m)

Definition at line 127 of file radiation\_source.hh.

Referenced by calculate\_flux(), jeod::RadiationThirdBody::calculate\_shadow(), and RadiationSource().

8.9.6.3 double jeod::RadiationSource::flux\_hat[3]

(inertial) unit vector associated with primary radiative flux.

trick\_units(-)

Definition at line 116 of file radiation\_source.hh.

Referenced by calculate flux(), and RadiationSource().

8.9.6.4 double jeod::RadiationSource::flux\_inertial[3]

(N/M/s) Power per unit area in the inertial reference frame

trick\_units(-)

Definition at line 142 of file radiation source.hh.

Referenced by calculate\_flux(), RadiationSource(), and jeod::RadiationPressure::third\_body\_adjustments().

8.9.6.5 double jeod::RadiationSource::flux\_mag

magnitude of principle radiative flux vector

trick\_units(N/m2)

Definition at line 121 of file radiation source.hh.

Referenced by calculate\_flux(), RadiationSource(), jeod::RadiationPressure::third\_body\_adjustments(), jeod::RadiationPressure::update\_default\_surface(), and jeod::RadiationPressure::update\_facet\_surface().

8.9.6.6 double jeod::RadiationSource::flux\_struc[3]

(N/M\*s) Power per unit area in the vehicle structural reference frame

trick\_units(-)

Definition at line 147 of file radiation source.hh.

Referenced by calculate\_flux(), RadiationSource(), and jeod::RadiationPressure::third\_body\_adjustments().

8.9.6.7 double jeod::RadiationSource::flux\_struc\_hat[3]

Unit vector representing flux vector in the vehicle structural reference frame.

trick\_units(-)

Definition at line 153 of file radiation source.hh.

Referenced by calculate\_flux(), RadiationSource(), jeod::RadiationPressure::update\_default\_surface(), and jeod::RadiationPressure::update\_facet\_surface().

8.9.6.8 double jeod::RadiationSource::inertial\_cg[3]

vehicle cg position w.r.t vehicle strucural origin, expressed in inertial RF.

trick\_units(m)

Definition at line 159 of file radiation\_source.hh.

Referenced by calculate flux(), and RadiationSource().

8.9.6.9 RefFrame\* jeod::RadiationSource::inertial\_frame\_ptr

the inertial reference frame associated with this source

trick units(-)

Definition at line 179 of file radiation\_source.hh.

Referenced by calculate\_flux(), initialize(), jeod::RadiationThirdBody::initialize(), RadiationSource(), and jeod::RadiationThirdBody::update\_third\_body\_state().

8.9.6.10 double jeod::RadiationSource::luminosity

Luminosity of primary source.

trick\_units(-)

Definition at line 132 of file radiation\_source.hh.

Referenced by calculate flux(), and RadiationSource().

8.9.6.11 bool jeod::RadiationSource::multiple\_shadow\_bodies

flags that more than one body are casting shadows on the vehicle.

trick units(-)

Definition at line 174 of file radiation\_source.hh.

Referenced by RadiationSource().

8.9.6.12 std::string jeod::RadiationSource::name

The name of the source of the illumination (usually Sun)

trick\_units(-)

Definition at line 111 of file radiation source.hh.

Referenced by initialize(), and set\_name().

8.9.6.13 unsigned int jeod::RadiationSource::num\_bodies

number of ThirdBodies available.

trick units(count)

Definition at line 196 of file radiation\_source.hh.

Referenced by jeod::RadiationPressure::initialize().

8.9.6.14 double jeod::RadiationSource::radius

Radius of primary source.

trick units(m)

Definition at line 137 of file radiation\_source.hh.

Referenced by jeod::RadiationThirdBody::calculate\_shadow(), jeod::RadiationThirdBody::initialize(), and Radiation-Source().

8.9.6.15 OldShadowGeometry jeod::RadiationSource::shadow\_geometry

Flag indicating cylindrical / conical shadow geometry.

trick\_units(-)

Definition at line 219 of file radiation source.hh.

Referenced by jeod::RadiationPressure::initialize().

8.9.6.16 const double jeod::RadiationSource::solar\_luminosity

Solar Luminosity.

trick\_units(-)

Definition at line 101 of file radiation\_source.hh.

Referenced by RadiationSource().

8.9.6.17 const double jeod::RadiationSource::solar\_radius

Mean solar radius.

trick\_units(m)

Definition at line 106 of file radiation\_source.hh.

Referenced by RadiationSource().

8.9.6.18 double jeod::RadiationSource::source\_to\_cg[3]

vehicle cg position relative to the source

trick\_units(m)

Definition at line 164 of file radiation\_source.hh.

Referenced by calculate\_flux(), jeod::RadiationThirdBody::calculate\_shadow(), and RadiationSource().

8.9.6.19 double jeod::RadiationSource::source\_to\_struc\_origin[3]

vehicle struc frame origin position relative to source.

trick\_units(m)

Definition at line 169 of file radiation source.hh.

Referenced by calculate\_flux(), and RadiationSource().

8.9.6.20 RadiationThirdBody\*\* jeod::RadiationSource::third\_body

Planetary bodies that provide shadowing or indirect, reflected, illumination.

trick\_units(-)

Definition at line 202 of file radiation\_source.hh.

Referenced by jeod::RadiationPressure::initialize().

The documentation for this class was generated from the following files:


- radiation\_source.hh
- · radiation\_source.cc

# 8.10 jeod::RadiationSurface Class Reference

The surface of the vehicle that interacts with the incident flux.

#include <radiation\_surface.hh>

Inheritance diagram for jeod::RadiationSurface:



### **Public Member Functions**

• RadiationSurface ()

Constructor for RadiationSurface.

∼RadiationSurface () override

Destructor for RadiationSurface.

void initialize (double center\_grav[3])

Initializes the radiation surface.

• void allocate\_array (unsigned int size) override

Allocates memory for an array of radiation facets.

void allocate\_interaction\_facet (Facet \*facet, InteractionFacetFactory \*factory, FacetParams \*params, unsigned int index) override

Turns facet memory into radiaiton facet memory.

void initialize\_runtime\_values (void)

To initialize the values during each update run.

- void incident radiation (double flux mag, const double flux struc hat[3], bool calculate forces)
  - systematically calls the method to calculate the interaction on each facet.
- void interact\_with\_third\_body (RadiationThirdBody \*third\_body\_ptr, const bool calculate\_forces)

systematically calls the method to calculate the interaction of each facet with ThirdBody flux.

void accumulate\_thermal\_sources (void) override

systematically calls the method to accumulate thermal sources on each facet.

· void thermal integrator (void) override

systematically calls the method to integrate the temperature variation for each facet.

void equalize\_absorption\_emission (void)

systematically calls the method to ensure that the same for each facet.

void radiation\_pressure (void)

systematically calls the method to wrap up the radiation pressure calculation on each facet and accumulate forces and torques over all facets.

void add\_thermal\_integrators\_to (DynBody \*dyn\_body)

To attach thermal integrators from each facet to the integration group of a DynBody.

# **Data Fields**

RadiationFacet \*\* facets

Array of pointers to the Radiation Facets.

· unsigned int num\_facets

number of facets in this surface.

· bool include conduction

Flag to instruct model to include conduction between plates in the thermal calculation.

double \*\* thermal conduction

Conductivity values (Watts per Kelvin) between facets.

• double force [3]

Force resulting from all radiative interactions.

• double torque [3]

Torque resulting from all radiative interactions.

· unsigned int ii facet

Simple counter, used repeatedly.

# **Private Member Functions**

- RadiationSurface & operator= (const RadiationSurface &rhs)
- · RadiationSurface (const RadiationSurface &rhs)

# Friends

- class InputProcessor
- void init\_attrjeod\_\_RadiationSurface ()

# 8.10.1 Detailed Description

The surface of the vehicle that interacts with the incident flux.

Definition at line 89 of file radiation\_surface.hh.

# 8.10.2 Constructor & Destructor Documentation

8.10.2.1 jeod::RadiationSurface::RadiationSurface ( void )

Constructor for RadiationSurface.

Definition at line 65 of file radiation\_surface.cc.

**8.10.2.2** jeod::RadiationSurface::~RadiationSurface ( void ) [override]

Destructor for RadiationSurface.

Definition at line 374 of file radiation surface.cc.

References facets, ii\_facet, and num\_facets.

**8.10.2.3** jeod::RadiationSurface::RadiationSurface ( const RadiationSurface & rhs ) [private]

# 8.10.3 Member Function Documentation

**8.10.3.1 void jeod::RadiationSurface::accumulate\_thermal\_sources ( void )** [override]

systematically calls the method to accumulate thermal sources on each facet.

Definition at line 276 of file radiation surface.cc.

References facets, ii\_facet, num\_facets, and jeod::RadiationBaseFacet::thermal.

8.10.3.2 void jeod::RadiationSurface::add\_thermal\_integrators\_to ( DynBody \* dyn\_body )

To attach thermal integrators from each facet to the integration group of a DynBody.

#### **Parameters**

in,out	dyn_body	Body to which integrators are to be added.
--------	----------	--

Definition at line 363 of file radiation\_surface.cc.

8.10.3.3 void jeod::RadiationSurface::allocate\_array( unsigned int size ) [override]

Allocates memory for an array of radiation facets.

### Parameters

in	size	Size of array

Definition at line 140 of file radiation\_surface.cc.

 $References\ facets,\ ii\_facet,\ num\_facets,\ and\ jeod::Radiation Messages::operational\_setup\_error.$ 

8.10.3.4 void jeod::RadiationSurface::allocate\_interaction\_facet ( Facet \* facet, InteractionFacetFactory \* factory, FacetParams \* params, unsigned int index ) [override]

Turns facet memory into radiation facet memory.

# **Parameters**

in	facet	pointer to the facet
in	factory	pointer to the facet factory
in	params	pointer to the generic facet parameter.
in	index	index value in the facet list.

Definition at line 174 of file radiation surface.cc.

References facets, jeod::RadiationMessages::invalid\_setup\_error, num\_facets, and jeod::RadiationMessages::operational\_setup\_error.

8.10.3.5 void jeod::RadiationSurface::equalize\_absorption\_emission ( void )

systematically calls the method to ensure that the same for each facet.

Definition at line 311 of file radiation\_surface.cc.

References facets, ii facet, num facets, and jeod::RadiationBaseFacet::thermal.

Referenced by jeod::RadiationPressure::update\_facet\_surface().

8.10.3.6 void jeod::RadiationSurface::incident\_radiation ( double flux\_mag, const double flux\_struc\_hat[3], bool calculate\_forces )

systematically calls the method to calculate the interaction on each facet.

#### **Parameters**

	in	flux_mag	Magnitude of incident flux
Ī	in	flux_struc_hat	unit vector of incident flux
	in	calculate_forces	boolean indicating whether to calculate forces.

Definition at line 239 of file radiation\_surface.cc.

References facets, ii\_facet, jeod::RadiationBaseFacet::incident\_radiation(), and num\_facets.

Referenced by jeod::RadiationPressure::update facet surface().

8.10.3.7 void jeod::RadiationSurface::initialize ( double center\_grav[3] )

Initializes the radiation surface.

#### **Parameters**

in	center_grav	position of center of mass
		Units: M

Definition at line 85 of file radiation surface.cc.

References facets, ii\_facet, jeod::RadiationFacet::initialize\_geom(), jeod::RadiationMessages::invalid\_setup\_error, num\_facets, jeod::RadiationMessages::operational\_setup\_error, and jeod::RadiationBaseFacet::thermal.

Referenced by jeod::RadiationPressure::initialize().

8.10.3.8 void jeod::RadiationSurface::initialize\_runtime\_values ( void )

To initialize the values during each update run.

Definition at line 347 of file radiation surface.cc.

References facets, ii\_facet, jeod::RadiationBaseFacet::initialize\_runtime\_values(), and num\_facets.

Referenced by jeod::RadiationPressure::update\_facet\_surface().

8.10.3.9 void jeod::RadiationSurface::interact\_with\_third\_body ( RadiationThirdBody \* third\_body\_ptr, const bool calculate\_forces )

systematically calls the method to calculate the interaction of each facet with ThirdBody flux.

# **Parameters**

in,out	third_body_ptr	Third body that emits radiation.
in	calculate_forces	Calculate forces on the surface if true.

Definition at line 261 of file radiation surface.cc.

References facets, ii\_facet, jeod::RadiationBaseFacet::interact\_with\_third\_body(), and num\_facets.

Referenced by jeod::RadiationPressure::update\_facet\_surface().

**8.10.3.10** RadiationSurface& jeod::RadiationSurface::operator=( const RadiationSurface & rhs) [private]

8.10.3.11 void jeod::RadiationSurface::radiation\_pressure ( void )

systematically calls the method to wrap up the radiation pressure calculation on each facet and accumulate forces and torques over all facets.

Definition at line 326 of file radiation surface.cc.

References facets, force, ii\_facet, num\_facets, jeod::RadiationFacet::radiation\_pressure(), and torque.

Referenced by jeod::RadiationPressure::update facet surface().

**8.10.3.12 void jeod::RadiationSurface::thermal\_integrator(void)** [override]

systematically calls the method to integrate the temperature variation for each facet.

Definition at line 291 of file radiation surface.cc.

References facets, ii\_facet, num\_facets, and jeod::RadiationBaseFacet::thermal.

# 8.10.4 Friends And Related Function Documentation

**8.10.4.1 void init\_attrjeod\_\_RadiationSurface( )** [friend]

**8.10.4.2** friend class InputProcessor [friend]

Definition at line 91 of file radiation surface.hh.

# 8.10.5 Field Documentation

#### 8.10.5.1 RadiationFacet\*\* jeod::RadiationSurface::facets

Array of pointers to the Radiation Facets.

trick units(-)

Definition at line 98 of file radiation\_surface.hh.

Referenced by accumulate\_thermal\_sources(), allocate\_array(), allocate\_interaction\_facet(), equalize\_absorption\_emission(), incident\_radiation(), initialize(), initialize\_runtime\_values(), interact\_with\_third\_body(), radiation\_pressure(), thermal\_integrator(), and  $\sim$ RadiationSurface().

8.10.5.2 double jeod::RadiationSurface::force[3]

Force resulting from all radiative interactions.

trick\_units(-)

Definition at line 122 of file radiation surface.hh.

Referenced by radiation\_pressure(), and jeod::RadiationPressure::update\_facet\_surface().

8.10.5.3 unsigned int jeod::RadiationSurface::ii\_facet

Simple counter, used repeatedly.

trick units(-)

Definition at line 132 of file radiation surface.hh.

Referenced by accumulate\_thermal\_sources(), allocate\_array(), equalize\_absorption\_emission(), incident\_radiation(), initialize(), initialize\_runtime\_values(), interact\_with\_third\_body(), radiation\_pressure(), thermal\_integrator(), and ~RadiationSurface().

8.10.5.4 bool jeod::RadiationSurface::include\_conduction

Flag to instruct model to include conduction between plates in the thermal calculation.

Requires a thermal conduction matrix.trick units(-)

Definition at line 109 of file radiation\_surface.hh.

8.10.5.5 unsigned int jeod::RadiationSurface::num\_facets

number of facets in this surface.

trick units(-)

Definition at line 103 of file radiation\_surface.hh.

Referenced by accumulate\_thermal\_sources(), allocate\_array(), allocate\_interaction\_facet(), equalize\_absorption\_emission(), incident\_radiation(), initialize(), initialize\_runtime\_values(), interact\_with\_third\_body(), radiation\_pressure(), thermal\_integrator(), and ~RadiationSurface().

8.10.5.6 double\*\* jeod::RadiationSurface::thermal\_conduction

Conductivity values (Watts per Kelvin) between facets.

Assumed symmetric, only the values [small][large] will be considered (e.g. thermal\_conduction[2][3] gives the conduction between facets 2 and 3, whereas thermal\_conduction[3][2] will never be seen.trick\_units(-)

Definition at line 117 of file radiation surface.hh.

8.10.5.7 double jeod::RadiationSurface::torque[3]

Torque resulting from all radiative interactions.

trick units(-)

Definition at line 127 of file radiation\_surface.hh.

Referenced by radiation\_pressure(), and jeod::RadiationPressure::update\_facet\_surface().

The documentation for this class was generated from the following files:


- · radiation surface.hh
- radiation\_surface.cc

# 8.11 jeod::RadiationSurfaceFactory Class Reference

The factory for creating Radiation Surfaces.

#include <radiation\_surface\_factory.hh>

Inheritance diagram for jeod::RadiationSurfaceFactory:



#### **Public Member Functions**

· RadiationSurfaceFactory ()

Constructor.

~RadiationSurfaceFactory () override

Destructor.

• void add\_facet\_params (FacetParams \*to\_add) override

Add a set of radiation parameters to those available to Radiation Surface.

#### **Protected Attributes**

FlatPlateRadiationFactory flat\_plate\_radiation\_factory

The factory to build flat plate thermal facets.

#### **Private Member Functions**

- RadiationSurfaceFactory & operator= (const RadiationSurfaceFactory &rhs)
- RadiationSurfaceFactory (const RadiationSurfaceFactory &rhs)

#### **Friends**

- · class InputProcessor
- void init\_attrjeod\_\_RadiationSurfaceFactory ()

# 8.11.1 Detailed Description

The factory for creating Radiation Surfaces.

Definition at line 85 of file radiation\_surface\_factory.hh.

# 8.11.2 Constructor & Destructor Documentation

8.11.2.1 jeod::RadiationSurfaceFactory::RadiationSurfaceFactory ( void )

Constructor.

Definition at line 55 of file radiation\_surface\_factory.cc.

References flat\_plate\_radiation\_factory.

**8.11.2.2** jeod::RadiationSurfaceFactory::~RadiationSurfaceFactory(void) [override]

Destructor.

Definition at line 99 of file radiation\_surface\_factory.cc.

8.11.2.3 jeod::RadiationSurfaceFactory::RadiationSurfaceFactory ( const RadiationSurfaceFactory & rhs )
[private]

#### 8.11.3 Member Function Documentation

8.11.3.1 void jeod::RadiationSurfaceFactory::add\_facet\_params ( FacetParams \* to\_add ) [override]

Add a set of radiation parameters to those available to Radiation Surface.

#### **Parameters**

2	to odd	pointer to the parameter list to add
ΤIJ	to_add	pointer to the parameter list to add.

Definition at line 69 of file radiation\_surface\_factory.cc.

References jeod::RadiationMessages::invalid\_setup\_error.

8.11.3.2 RadiationSurfaceFactory& jeod::RadiationSurfaceFactory::operator=( const RadiationSurfaceFactory & rhs ) [private]

#### 8.11.4 Friends And Related Function Documentation

```
8.11.4.1 void init_attrjeod__RadiationSurfaceFactory() [friend]
```

**8.11.4.2** friend class InputProcessor [friend]

Definition at line 87 of file radiation\_surface\_factory.hh.

#### 8.11.5 Field Documentation

**8.11.5.1 FlatPlateRadiationFactory jeod::RadiationSurfaceFactory::flat\_plate\_radiation\_factory** [protected]

The factory to build flat plate thermal facets.

trick\_units(-)

Definition at line 111 of file radiation\_surface\_factory.hh.

Referenced by RadiationSurfaceFactory().

The documentation for this class was generated from the following files:

- radiation\_surface\_factory.hh
- radiation\_surface\_factory.cc

# 8.12 jeod::RadiationThirdBody Class Reference

Provide information on bodies that may cause shadowing or reflected illumination.

```
#include <radiation_third_body.hh>
```

# **Public Types**

• enum ShadowGeometry { Cylindrical = 0, Cyl = 1, Conical = 2, Con = 3 }

distinguishes between conical and cylindrical shadowing

#### **Public Member Functions**

· RadiationThirdBody ()

Constructor.

- virtual ∼RadiationThirdBody ()
- virtual void initialize (DynManager \*dyn\_mgr\_ptr)

initializes the third body

void calculate\_shadow (void)

Calculates the effect of shadowing by a third body.

void convert shadow from int (int geometry)

convert from the old style framework in which the shadow geometry was owned by the RadiationSource (same for all third bodies) to the new style framework where the geometry is owned by each ThirdBody

• virtual double process third body (double real time, RefFrame &veh struc frame)

Primary executable for handling the Third Body effects.

• void set\_name (std::string name\_in)

Setter for the name.

virtual void accumulate\_refl\_flux (RadiationBaseFacet \*veh\_surf\_elem, bool calculate\_forces)

To provide base class null implementation.

virtual void accumulate rad flux (RadiationBaseFacet \*veh surf elem, bool calculate forces)

To provide base class null implementation.

· virtual bool is\_interactive ()

Identifies this class as one that does not produce a radiaiton field.

bool get\_added\_to\_model ()

Returns information on whether the body has already been used in one RadiationPressure model.

void set\_added\_to\_model (bool value)

Sets the added to model value.

# **Data Fields**

• RadiationSource \* primary\_source\_ptr

Pointer to the primary illumination source.

ShadowGeometry shadow\_geometry

Flag indicating cylindrical / conical shadow geometry.

bool force\_state\_update

Flag to indicate whether to enforce an update to the third-body body-state.

std::string name

Name of planet.

· bool active

Model on/off flag.

· double update\_interval

Time interval between third body state updates.

double radius

Radius of RadiationThirdBody.

double output\_flux [3]

Calculated value.

• RefFrame \* local frame ptr

Pointer to the local reference frame, for determining position of this object.

#### **Protected Member Functions**

double generate\_alpha (double rho\_adj, double delta)

generate\_alpha( rho\_adj, delta: generates an approximate alpha-value given a relative disk size and fraction of maximum possible eclipse

bool test\_for\_state\_update (double time)

Tests for necessity of updating third body state, and calls appropriate update method (polymorphic) if needed.

virtual bool update\_third\_body\_state (void)

Updates the state of the Third Body.

# **Protected Attributes**

· bool added to model

Flag to indicate whether body has already been added to a model.

bool initialized

Flag to indicate that initialization has been complete.

· double illum factor

Value between 0 and 1 representing the fraction of possible flux that is actually incident after shadowing effects.

• double last\_update\_time

Time at which the third body state was last updated.

Planet \* planet link

Pointer to the associated Planet object.

· double r plus

The value (radius + R\_source)

• double r minus

The value (radius - R\_source)

· double r\_ratio

The ratio (radius / R\_source)

double r par

Component of vector from RadiationThirdBody to vehicle that is parallel to vector from primary source to Radiation-ThirdBody.

double r\_perp

Component of vector from RadiationThirdBody to vehicle that is perpendicular to vector from primary source to RadiationThirdBody.

• double third\_to\_cg\_inrtl [3]

Vector from RadiationThirdBody to vehicle center of gravity, in inertial RF.

double source\_to\_third\_inrtl [3]

Vector from the primary source to the RadiationThirdBody in inertial RF.

double d\_source\_to\_third

Magnitude of source\_to\_third.

double source\_to\_third\_hat\_inrtl [3]

Unit vector of source\_to\_third.

# **Private Member Functions**

- RadiationThirdBody (const RadiationThirdBody &)
- RadiationThirdBody & operator= (const RadiationThirdBody &)

# Friends

- · class InputProcessor
- void init\_attrjeod\_\_RadiationThirdBody ()

# 8.12.1 Detailed Description

Provide information on bodies that may cause shadowing or reflected illumination.

Definition at line 84 of file radiation\_third\_body.hh.

#### 8.12.2 Member Enumeration Documentation

#### 8.12.2.1 enum jeod::RadiationThirdBody::ShadowGeometry

distinguishes between conical and cylindrical shadowing

#### Enumerator

Cylindrical planet casts a cylindrical shadow

Cyl planet casts a cylindrical shadow

Conical planet casts a conical shadow

Con planet casts a conical shadow

Definition at line 92 of file radiation\_third\_body.hh.

#### 8.12.3 Constructor & Destructor Documentation

8.12.3.1 jeod::RadiationThirdBody::RadiationThirdBody ( )

#### Constructor.

Definition at line 57 of file radiation\_third\_body.cc.

References output\_flux, source\_to\_third\_hat\_inrtl, source\_to\_third\_inrtl, and third\_to\_cg\_inrtl.

```
8.12.3.2 virtual jeod::RadiationThirdBody::~RadiationThirdBody( ) [inline], [virtual]
```

Definition at line 238 of file radiation\_third\_body.hh.

**8.12.3.3** jeod::RadiationThirdBody::RadiationThirdBody ( const RadiationThirdBody & ) [private]

#### 8.12.4 Member Function Documentation

8.12.4.1 virtual void jeod::RadiationThirdBody::accumulate\_rad\_flux ( RadiationBaseFacet \* veh\_surf\_elem, bool calculate\_forces ) [inline], [virtual]

To provide base class null implementation.

#### **Parameters**

veh_surf_elem	The facet of the vehicle.
calculate_forces	pass-through flag.

Definition at line 272 of file radiation\_third\_body.hh.

Referenced by jeod::RadiationBaseFacet::interact\_with\_third\_body().

8.12.4.2 virtual void jeod::RadiationThirdBody::accumulate\_refl\_flux ( RadiationBaseFacet \* veh\_surf\_elem, bool calculate\_forces ) [inline], [virtual]

To provide base class null implementation.

#### **Parameters**

veh_sı	urf_elem	The facet of the vehicle.
calculate	e_forces	pass-through flag.

Definition at line 264 of file radiation\_third\_body.hh.

Referenced by jeod::RadiationBaseFacet::interact\_with\_third\_body().

8.12.4.3 void jeod::RadiationThirdBody::calculate\_shadow (void)

Calculates the effect of shadowing by a third body.

NOTE - This method is intended to be an internal call so should be protected However, doing so would be a change to the API. Delay for JEOD4.0.

Definition at line 210 of file radiation\_third\_body.cc.

References active, Con, Conical, Cyl, Cylindrical, jeod::RadiationSource::d\_source\_to\_cg, d\_source\_to\_third, generate\_alpha(), illum\_factor, initialized, jeod::RadiationMessages::invalid\_setup\_error, name, primary\_source\_ptr, r\_minus, r\_par, r\_perp, r\_plus, r\_ratio, radius, jeod::RadiationSource::radius, shadow\_geometry, jeod::RadiationSource::source\_to\_cg, source\_to\_third\_hat\_inrtl, source\_to\_third\_inrtl, and third\_to\_cg\_inrtl.

Referenced by process\_third\_body().

8.12.4.4 void jeod::RadiationThirdBody::convert\_shadow\_from\_int ( int old\_shadow\_geometry )

convert from the old style framework in which the shadow geometry was owned by the RadiationSource (same for all third bodies) to the new style framework where the geometry is owned by each ThirdBody

#### **Parameters**

in	old_shadow	integer representation of the shadow geometry enumeration.
	geometry	

Definition at line 413 of file radiation\_third\_body.cc.

References jeod::RadiationMessages::invalid setup error, and shadow geometry.

8.12.4.5 double jeod::RadiationThirdBody::generate alpha ( double rho\_adj, double delta ) [protected]

generate\_alpha( rho\_adj, delta: generates an approximate alpha-value given a relative disk size and fraction of maximum possible eclipse

# Parameters

in	rho_adj	relative disk size
in	delta	fraction of eclipse achieved.

Definition at line 380 of file radiation third body.cc.

Referenced by calculate\_shadow().

**8.12.4.6** bool jeod::RadiationThirdBody::get\_added\_to\_model( ) [inline]

Returns information on whether the body has already been used in one RadiationPressure model.

Protects against multiple use of one ThirdBody instance.

Returns

added\_to\_model

Definition at line 287 of file radiation\_third\_body.hh.

References added\_to\_model.

Referenced by jeod::RadiationPressure::add\_third\_body().

**8.12.4.7** void jeod::RadiationThirdBody::initialize ( DynManager \* dyn\_mgr\_ptr ) [virtual]

initializes the third body

#### **Parameters**

in	dyn_mgr_ptr	pointer to the dynamics manager
	, – • –	, ,

Definition at line 92 of file radiation third body.cc.

References active, jeod::RadiationSource::inertial\_frame\_ptr, initialized, jeod::RadiationMessages::invalid\_setup\_error, local\_frame\_ptr, name, planet\_link, primary\_source\_ptr, r\_minus, r\_plus, r\_ratio, radius, and jeod::Radiation-Source::radius.

Referenced by jeod::RadiationPressure::add third body().

8.12.4.8 virtual bool jeod::RadiationThirdBody::is\_interactive( ) [inline], [virtual]

Identifies this class as one that does not produce a radiaiton field.

Returns

false

Definition at line 279 of file radiation\_third\_body.hh.

**8.12.4.9** RadiationThirdBody&jeod::RadiationThirdBody::operator=(const RadiationThirdBody&) [private]

8.12.4.10 double jeod::RadiationThirdBody::process\_third\_body ( double real\_time, RefFrame & veh\_struc\_frame )

[virtual]

Primary executable for handling the Third Body effects.

Returns

shading fraction

#### **Parameters**

in	real_time	Current time.
		Units: s
in	veh struc frame	Unused.

Definition at line 435 of file radiation\_third\_body.cc.

References active, calculate\_shadow(), illum\_factor, initialized, jeod::RadiationMessages::invalid\_setup\_error, name, jeod::RadiationMessages::operational\_setup\_error, and test\_for\_state\_update().

**8.12.4.11** void jeod::RadiationThirdBody::set\_added\_to\_model( bool value ) [inline]

Sets the added\_to\_model value.

#### **Parameters**

value	New value
-------	-----------

Definition at line 293 of file radiation\_third\_body.hh.

References added to model.

Referenced by jeod::RadiationPressure::add\_third\_body().

**8.12.4.12** void jeod::RadiationThirdBody::set\_name ( std::string name\_in ) [inline]

Setter for the name.

Definition at line 254 of file radiation third body.hh.

References name.

8.12.4.13 bool jeod::RadiationThirdBody::test\_for\_state\_update ( double real\_time ) [protected]

Tests for necessity of updating third body state, and calls appropriate update method (polymorphic) if needed.

#### **Parameters**

in	real_time	Current time
		Units: s

Definition at line 478 of file radiation\_third\_body.cc.

References force\_state\_update, last\_update\_time, update\_interval, and update\_third\_body\_state().

Referenced by process third body().

**8.12.4.14** bool jeod::RadiationThirdBody::update\_third\_body\_state ( void ) [protected], [virtual]

Updates the state of the Third Body.

Because the ThirdBody may be associated with multiple vehicles, and because its state typically changes much more slowly than the vehicle anyway, it is not always necessary to update the ThirdBodyState.

Definition at line 502 of file radiation third body.cc.

References active, d\_source\_to\_third, jeod::RadiationSource::inertial\_frame\_ptr, jeod::RadiationMessages::invalid\_setup\_error, local\_frame\_ptr, name, primary\_source\_ptr, source\_to\_third\_hat\_inrtl, and source\_to\_third\_inrtl.

Referenced by test for state update().

#### 8.12.5 Friends And Related Function Documentation

**8.12.5.1 void init\_attrjeod\_\_RadiationThirdBody( )** [friend]

**8.12.5.2 friend class InputProcessor** [friend]

Definition at line 86 of file radiation\_third\_body.hh.

# 8.12.6 Field Documentation

8.12.6.1 bool jeod::RadiationThirdBody::active

Model on/off flag.

trick\_units(-)

Definition at line 124 of file radiation\_third\_body.hh.

Referenced by jeod::RadiationPressure::add\_third\_body(), calculate\_shadow(), initialize(), process\_third\_body(), and update\_third\_body\_state().

**8.12.6.2** bool jeod::RadiationThirdBody::added\_to\_model [protected]

Flag to indicate whether body has already been added to a model.

trick units(-)

Definition at line 156 of file radiation\_third\_body.hh.

Referenced by get\_added\_to\_model(), and set\_added\_to\_model().

**8.12.6.3** double jeod::RadiationThirdBody::d\_source\_to\_third [protected]

Magnitude of source to third.

trick\_units(m)

Definition at line 226 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), and update\_third\_body\_state().

8.12.6.4 bool jeod::RadiationThirdBody::force\_state\_update

Flag to indicate whether to enforce an update to the third-body body-state.

Default: true Self-resets to false after each use.trick\_units(-)

Definition at line 114 of file radiation\_third\_body.hh.

Referenced by test\_for\_state\_update().

**8.12.6.5** double jeod::RadiationThirdBody::illum\_factor [protected]

Value between 0 and 1 representing the fraction of possible flux that is actually incident after shadowing effects.

trick\_units(-)

Definition at line 167 of file radiation\_third\_body.hh.

 $Referenced \ by \ calculate\_shadow(), \ and \ process\_third\_body().$ 

**8.12.6.6 bool jeod::RadiationThirdBody::initialized** [protected]

Flag to indicate that initialization has been complete.

trick units(-)

Definition at line 161 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), initialize(), and process\_third\_body().

**8.12.6.7 double jeod::RadiationThirdBody::last\_update\_time** [protected]

Time at which the third body state was last updated.

trick\_units(s)

Definition at line 172 of file radiation\_third\_body.hh.

Referenced by test\_for\_state\_update().

8.12.6.8 RefFrame\* jeod::RadiationThirdBody::local\_frame\_ptr

Pointer to the local reference frame, for determining position of this object.

trick\_units(-)

Definition at line 147 of file radiation\_third\_body.hh.

Referenced by initialize(), and update\_third\_body\_state().

8.12.6.9 std::string jeod::RadiationThirdBody::name

Name of planet.

trick units(-)

Definition at line 119 of file radiation\_third\_body.hh.

Referenced by jeod::RadiationPressure::add\_third\_body(), calculate\_shadow(), initialize(), process\_third\_body(), set\_name(), and update\_third\_body\_state().

8.12.6.10 double jeod::RadiationThirdBody::output\_flux[3]

Calculated value.

Set only in derived class RadiationReflectingThirdBody.trick\_units(-)

Definition at line 141 of file radiation\_third\_body.hh.

Referenced by RadiationThirdBody().

**8.12.6.11** Planet\* jeod::RadiationThirdBody::planet\_link [protected]

Pointer to the associated Planet object.

trick\_units(-)

Definition at line 178 of file radiation\_third\_body.hh.

Referenced by initialize().

8.12.6.12 RadiationSource\* jeod::RadiationThirdBody::primary\_source\_ptr

Pointer to the primary illumination source.

trick\_units(-)

Definition at line 102 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), initialize(), and update\_third\_body\_state().

**8.12.6.13** double jeod::RadiationThirdBody::r\_minus [protected]

The value (radius - R\_source)

trick\_units(-)

Definition at line 188 of file radiation third body.hh.

Referenced by calculate\_shadow(), and initialize().

```
8.12.6.14 double jeod::RadiationThirdBody::r_par [protected]
```

Component of vector from RadiationThirdBody to vehicle that is parallel to vector from primary source to RadiationThirdBody.

trick\_units(m)

Definition at line 201 of file radiation third body.hh.

Referenced by calculate\_shadow().

**8.12.6.15** double jeod::RadiationThirdBody::r\_perp [protected]

Component of vector from RadiationThirdBody to vehicle that is perpendicular to vector from primary source to RadiationThirdBody.

trick units(-)

Definition at line 207 of file radiation third body.hh.

Referenced by calculate\_shadow().

**8.12.6.16** double jeod::RadiationThirdBody::r\_plus [protected]

The value (radius + R source)

trick\_units(-)

Definition at line 183 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), and initialize().

**8.12.6.17** double jeod::RadiationThirdBody::r\_ratio [protected]

The ratio (radius / R source)

trick\_units(-)

Definition at line 193 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), and initialize().

8.12.6.18 double jeod::RadiationThirdBody::radius

Radius of RadiationThirdBody.

Note - this is set automatically if RTB is a planet, but must be set manually if RTB is a DynBody.trick\_units(m)

Definition at line 135 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), and initialize().

8.12.6.19 ShadowGeometry jeod::RadiationThirdBody::shadow\_geometry

Flag indicating cylindrical / conical shadow geometry.

trick\_units(-)

Definition at line 107 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), and convert\_shadow\_from\_int().

**8.12.6.20** double jeod::RadiationThirdBody::source\_to\_third\_hat\_inrtl[3] [protected]

Unit vector of source\_to\_third.

trick\_units(-)

Definition at line 231 of file radiation third body.hh.

Referenced by calculate\_shadow(), RadiationThirdBody(), and update\_third\_body\_state().

**8.12.6.21** double jeod::RadiationThirdBody::source\_to\_third\_inrtl[3] [protected]

Vector from the primary source to the RadiationThirdBody in inertial RF.

trick\_units(m)

Definition at line 221 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), RadiationThirdBody(), and update\_third\_body\_state().

**8.12.6.22** double jeod::RadiationThirdBody::third\_to\_cg\_inrtl[3] [protected]

Vector from RadiationThirdBody to vehicle center of gravity, in inertial RF.

trick\_units(m)

Definition at line 213 of file radiation\_third\_body.hh.

Referenced by calculate\_shadow(), and RadiationThirdBody().

8.12.6.23 double jeod::RadiationThirdBody::update\_interval

Time interval between third body state updates.

trick\_units(s)

Definition at line 129 of file radiation third body.hh.

Referenced by test\_for\_state\_update().

The documentation for this class was generated from the following files:

- · radiation\_third\_body.hh
- radiation\_third\_body.cc

# **Chapter 9**

# **File Documentation**

# 9.1 flat\_plate\_radiation\_facet.cc File Reference

Define member functions for class FlatPlateRadiationFacet.

```
#include "utils/math/include/vector3.hh"
#include "utils/message/include/message_handler.hh"
#include "utils/surface_model/include/flat_plate.hh"
#include "../include/flat_plate_radiation_facet.hh"
#include "../include/radiation_messages.hh"
#include "../include/radiation_third_body.hh"
```

# **Namespaces**

• jeod

Namespace jeod.

# 9.1.1 Detailed Description

Define member functions for class FlatPlateRadiationFacet.

Definition in file flat\_plate\_radiation\_facet.cc.

# 9.2 flat\_plate\_radiation\_facet.hh File Reference

Individual facets for use with rad environment interaction models.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "radiation_facet.hh"
```

#### **Data Structures**

• class jeod::FlatPlateRadiationFacet

A flat plate facet to be used for radiation interaction.

74 File Documentation

# **Namespaces**

• jeod

Namespace jeod.

# 9.2.1 Detailed Description

Individual facets for use with rad environment interaction models.

Definition in file flat\_plate\_radiation\_facet.hh.

# 9.3 flat\_plate\_radiation\_factory.cc File Reference

Factory that creates a FlatPlateRadiationFacet, from a facet model.

```
#include <cstddef>
#include <typeinfo>
#include "utils/surface_model/include/flat_plate_thermal.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/flat_plate_radiation_factory.hh"
#include "../include/radiation_params.hh"
#include "../include/flat_plate_radiation_facet.hh"
#include "../include/radiation_messages.hh"
```

# **Namespaces**

jeod

Namespace jeod.

#### 9.3.1 Detailed Description

Factory that creates a FlatPlateRadiationFacet, from a facet model.

Definition in file flat\_plate\_radiation\_factory.cc.

# 9.4 flat\_plate\_radiation\_factory.hh File Reference

Factory that creates an interaction facet, for a specific environment interaction model, from a facet model.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_facet_factory.hh"
#include "flat_plate_radiation_facet.hh"
```

#### **Data Structures**

· class jeod::FlatPlateRadiationFactory

The factory for building flat plate radiation facets.

# **Namespaces**

jeod

Namespace jeod.

#### 9.4.1 Detailed Description

Factory that creates an interaction facet, for a specific environment interaction model, from a facet model. Definition in file flat\_plate\_radiation\_factory.hh.

# 9.5 radiation\_base\_facet.cc File Reference

Define member functions for class RadiationBaseFacet.

```
#include "utils/math/include/vector3.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/radiation_base_facet.hh"
#include "../include/radiation_messages.hh"
#include "../include/radiation_third_body.hh"
```

# **Namespaces**

jeod

Namespace jeod.

# 9.5.1 Detailed Description

Define member functions for class RadiationBaseFacet.

Definition in file radiation\_base\_facet.cc.

# 9.6 radiation base facet.hh File Reference

Individual facets for use with radiation environment interaction models.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_facet.hh"
#include "interactions/thermal_rider/include/thermal_facet_rider.hh"
```

#### **Data Structures**

• class jeod::RadiationBaseFacet

Generic type of facet for radiation pressure.

# **Namespaces**

jeod

Namespace jeod.

76 File Documentation

# 9.6.1 Detailed Description

Individual facets for use with radiation environment interaction models.

Definition in file radiation\_base\_facet.hh.

# 9.7 radiation\_default\_surface.cc File Reference

Default surface for use with Radiation Pressure interaction model.

```
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "interactions/thermal_rider/include/thermal_facet_rider.hh"
#include "utils/math/include/vector3.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/radiation_default_surface.hh"
#include "../include/radiation_messages.hh"
#include "../include/radiation_third_body.hh"
```

# **Namespaces**

jeod

Namespace jeod.

#### 9.7.1 Detailed Description

Default surface for use with Radiation Pressure interaction model.

Definition in file radiation\_default\_surface.cc.

# 9.8 radiation default surface.hh File Reference

Individual facets for use with radiation environment interaction models.

```
#include <string>
#include <utility>
#include "utils/sim_interface/include/jeod_class.hh"
#include "interactions/thermal_rider/include/thermal_facet_rider.hh"
#include "radiation_base_facet.hh"
```

# **Data Structures**

class jeod::RadiationDefaultSurface

The default spherical surface for radiation pressure.

#### **Namespaces**

· jeod

Namespace jeod.

# 9.8.1 Detailed Description

Individual facets for use with radiation environment interaction models.

Definition in file radiation default surface.hh.

# 9.9 radiation\_facet.cc File Reference

Individual facets for use with Radiation Pressure interaction models.

```
#include "utils/math/include/vector3.hh"
#include "utils/surface_model/include/facet.hh"
#include "interactions/thermal_rider/include/thermal_facet_rider.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/radiation_facet.hh"
#include "../include/radiation_params.hh"
#include "../include/radiation_messages.hh"
```

# **Namespaces**

jeod

Namespace jeod.

#### 9.9.1 Detailed Description

Individual facets for use with Radiation Pressure interaction models.

Definition in file radiation\_facet.cc.

# 9.10 radiation facet.hh File Reference

Individual facets for use with radiation environment interaction models.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_facet.hh"
#include "interactions/thermal_rider/include/thermal_facet_rider.hh"
#include "radiation_base_facet.hh"
#include "utils/surface_model/include/facet.hh"
```

# **Data Structures**

class jeod::RadiationFacet

Generic type of facet for radiation pressure.

#### **Namespaces**

jeod

Namespace jeod.

78 File Documentation

# 9.10.1 Detailed Description

Individual facets for use with radiation environment interaction models.

Definition in file radiation\_facet.hh.

# 9.11 radiation\_messages.cc File Reference

Implement the class RadiationMessages.

```
#include "../include/radiation_messages.hh"
```

# **Namespaces**

jeod

Namespace jeod.

#### **Macros**

• #define PATH "interactions/radiation pressure/"

# 9.11.1 Detailed Description

Implement the class RadiationMessages.

Definition in file radiation\_messages.cc.

# 9.12 radiation\_messages.hh File Reference

Define the class RadiationMessages, the class that specifies the message IDs used in the Radiation model.

```
#include "utils/sim_interface/include/jeod_class.hh"
```

#### **Data Structures**

class jeod::RadiationMessages

Provides error messages.

# **Namespaces**

• jeod

Namespace jeod.

# 9.12.1 Detailed Description

Define the class RadiationMessages, the class that specifies the message IDs used in the Radiation model. Definition in file radiation\_messages.hh.

# 9.13 radiation\_params.cc File Reference

A virtual base class for radiation facet parameters, used to create interaction facets for radiation in the Interaction-SurfaceFactorys.

```
#include "../include/radiation_params.hh"
```

# **Namespaces**

· jeod

Namespace jeod.

#### 9.13.1 Detailed Description

A virtual base class for radiation facet parameters, used to create interaction facets for radiation in the Interaction-SurfaceFactorys.

Definition in file radiation\_params.cc.

# 9.14 radiation\_params.hh File Reference

A virtual base class for radiation facet parameters, used to create interaction facets for radiation in the Interaction-SurfaceFactorys.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "interactions/thermal_rider/include/thermal_params.hh"
#include "utils/surface_model/include/facet_params.hh"
```

#### **Data Structures**

· class jeod::RadiationParams

Provides a parameter list to each facet, based on the facet material properties.

# **Namespaces**

• jeod

Namespace jeod.

#### 9.14.1 Detailed Description

A virtual base class for radiation facet parameters, used to create interaction facets for radiation in the Interaction-SurfaceFactorys.

Definition in file radiation\_params.hh.

# 9.15 radiation\_pressure.cc File Reference

Calculation of force and torque due to radiation pressure.

80 File Documentation

```
#include <cstddef>
#include "dynamics/dyn_manager/include/dyn_manager.hh"
#include "utils/math/include/vector3.hh"
#include "utils/message/include/message_handler.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "interactions/thermal_rider/include/thermal_facet_rider.hh"
#include "../include/radiation_pressure.hh"
#include "../include/radiation_third_body.hh"
#include "../include/radiation_source.hh"
#include "../include/radiation_messages.hh"
```

# **Namespaces**

· jeod

Namespace jeod.

# 9.15.1 Detailed Description

Calculation of force and torque due to radiation pressure.

Definition in file radiation\_pressure.cc.

# 9.16 radiation\_pressure.hh File Reference

Radiation pressure top-level definition.

```
#include "utils/container/include/pointer_vector.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "interactions/thermal_rider/include/thermal_model_rider.hh"
#include "radiation_source.hh"
#include "radiation_surface.hh"
#include "radiation_default_surface.hh"
```

# **Data Structures**

· class jeod::RadiationPressure

Radiation pressure top-level definition.

# **Namespaces**

jeod

Namespace jeod.

# 9.16.1 Detailed Description

Radiation pressure top-level definition.

Definition in file radiation\_pressure.hh.

# 9.17 radiation\_pressure\_\_default\_surface.cc File Reference

Calculation of force and torque due to radiation pressure.

```
#include "dynamics/dyn_manager/include/dyn_manager.hh"
#include "utils/math/include/vector3.hh"
#include "interactions/thermal_rider/include/thermal_model_rider.hh"
#include "../include/radiation_pressure.hh"
#include "../include/radiation_default_surface.hh"
#include "../include/radiation_third_body.hh"
#include "../include/radiation_source.hh"
```

# **Namespaces**

· jeod

Namespace jeod.

# 9.17.1 Detailed Description

Calculation of force and torque due to radiation pressure.

Definition in file radiation\_pressure\_\_default\_surface.cc.

# 9.18 radiation\_pressure\_\_surface\_model.cc File Reference

Calculation of force and torque due to radiation pressure.

```
#include "dynamics/dyn_manager/include/dyn_manager.hh"
#include "utils/math/include/vector3.hh"
#include "interactions/thermal_rider/include/thermal_model_rider.hh"
#include "../include/radiation_pressure.hh"
#include "../include/radiation_surface.hh"
#include "../include/radiation_third_body.hh"
#include "../include/radiation_source.hh"
```

# **Namespaces**

jeod

Namespace jeod.

# 9.18.1 Detailed Description

Calculation of force and torque due to radiation pressure.

Definition in file radiation\_pressure\_\_surface\_model.cc.

# 9.19 radiation source.cc File Reference

Definition of methods associated with Primary Sources.

82 File Documentation

```
#include <cstddef>
#include "dynamics/dyn_manager/include/dyn_manager.hh"
#include "utils/math/include/vector3.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "utils/message/include/message_handler.hh"
#include "environment/planet/include/planet.hh"
#include "utils/ref_frames/include/ref_frame.hh"
#include "../include/radiation_source.hh"
#include "../include/radiation_messages.hh"
```

#### Namespaces

jeod

Namespace jeod.

# 9.19.1 Detailed Description

Definition of methods associated with Primary Sources.

Definition in file radiation\_source.cc.

# 9.20 radiation\_source.hh File Reference

Radiation pressure parameter and variable definitions.

```
#include <string>
#include <utility>
#include "utils/sim_interface/include/jeod_class.hh"
```

#### **Data Structures**

· class jeod::RadiationSource

Provides information on the source of the incident radiation.

# **Namespaces**

jeod

Namespace jeod.

# 9.20.1 Detailed Description

Radiation pressure parameter and variable definitions.

Definition in file radiation\_source.hh.

# 9.21 radiation surface.cc File Reference

Vehicle surface model for Radiation Pressure model.

```
#include <cstddef>
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "utils/math/include/vector3.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "utils/message/include/message_handler.hh"
#include "utils/surface_model/include/interaction_facet_factory.hh"
#include "utils/surface_model/include/interaction_facet.hh"
#include "utils/surface_model/include/facet.hh"
#include "../include/radiation_facet.hh"
#include "../include/radiation_surface.hh"
#include "../include/radiation_surface.hh"
#include "../include/radiation_messages.hh"
```

# **Namespaces**

· jeod

Namespace jeod.

# 9.21.1 Detailed Description

Vehicle surface model for Radiation Pressure model.

Definition in file radiation surface.cc.

# 9.22 radiation surface.hh File Reference

Vehicle surface model for general environment interaction models.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_surface.hh"
#include "radiation_facet.hh"
```

#### **Data Structures**

· class jeod::RadiationSurface

The surface of the vehicle that interacts with the incident flux.

# **Namespaces**

ieod

Namespace jeod.

#### 9.22.1 Detailed Description

Vehicle surface model for general environment interaction models.

Definition in file radiation\_surface.hh.

84 File Documentation

# 9.23 radiation\_surface\_factory.cc File Reference

Factory that creates an interaction surface, for a specific environment interaction model, from a surface model.

```
#include <cstddef>
#include "utils/message/include/message_handler.hh"
#include "../include/radiation_surface_factory.hh"
#include "../include/radiation_params.hh"
#include "../include/radiation_messages.hh"
```

#### **Namespaces**

• jeod

Namespace jeod.

# 9.23.1 Detailed Description

Factory that creates an interaction surface, for a specific environment interaction model, from a surface model. Definition in file radiation\_surface\_factory.cc.

# 9.24 radiation\_surface\_factory.hh File Reference

Factory that creates an interaction surface, for a specific environment interaction model, from a surface model.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_surface_factory.hh"
#include "flat_plate_radiation_factory.hh"
```

#### **Data Structures**

· class jeod::RadiationSurfaceFactory

The factory for creating Radiation Surfaces.

# **Namespaces**

jeod

Namespace jeod.

# 9.24.1 Detailed Description

Factory that creates an interaction surface, for a specific environment interaction model, from a surface model. Definition in file radiation\_surface\_factory.hh.

# 9.25 radiation\_third\_body.cc File Reference

Provides the functionality associated with RadiationThirdBodys.

```
#include <cstddef>
#include "dynamics/dyn_manager/include/dyn_manager.hh"
#include "environment/planet/include/planet.hh"
#include "utils/math/include/vector3.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/radiation_third_body.hh"
#include "../include/radiation_source.hh"
#include "../include/radiation_messages.hh"
```

# **Namespaces**

• jeod

Namespace jeod.

#### 9.25.1 Detailed Description

Provides the functionality associated with RadiationThirdBodys.

Definition in file radiation\_third\_body.cc.

# 9.26 radiation\_third\_body.hh File Reference

# Define the class RadiationThirdBody.

```
#include <string>
#include <utility>
#include "utils/sim_interface/include/jeod_class.hh"
```

# **Data Structures**

· class jeod::RadiationThirdBody

Provide information on bodies that may cause shadowing or reflected illumination.

#### **Namespaces**

jeod

Namespace jeod.

# 9.26.1 Detailed Description

Define the class RadiationThirdBody.

Definition in file radiation\_third\_body.hh.

# Index

$\sim$ FlatPlateRadiationFacet	jeod::RadiationSurface, 57
jeod::FlatPlateRadiationFacet, 18	allocate_interaction_facet
$\sim$ FlatPlateRadiationFactory	jeod::RadiationSurface, 57
jeod::FlatPlateRadiationFactory, 21	areaxflux
$\sim$ RadiationBaseFacet	jeod::RadiationBaseFacet, 26
jeod::RadiationBaseFacet, 24	areaxflux e
~RadiationDefaultSurface	jeod::RadiationBaseFacet, 26
jeod::RadiationDefaultSurface, 29	•
~RadiationFacet	bodies_active
jeod::RadiationFacet, 33	jeod::RadiationSource, 52
~RadiationParams	
jeod::RadiationParams, 38	calculate_flux
~RadiationPressure	jeod::RadiationSource, 51
jeod::RadiationPressure, 41	calculate_forces
~RadiationSource	jeod::RadiationPressure, 46
jeod::RadiationSource, 50	calculate_shadow
~RadiationSurface	jeod::RadiationThirdBody, 66
jeod::RadiationSurface, 56	center pressure
~RadiationSurfaceFactory	jeod::RadiationFacet, 34
jeod::RadiationSurfaceFactory, 61	Con
~RadiationThirdBody	jeod::RadiationSource, 50
jeod::RadiationThirdBody, 65	jeod::RadiationThirdBody, 65
jeod idalation midbody, 00	Conical
accumulate_rad_flux	jeod::RadiationSource, 50
jeod::RadiationThirdBody, 65	jeod::RadiationThirdBody, 65
accumulate_refl_flux	convert_shadow_from_int
jeod::RadiationThirdBody, 65	jeod::RadiationThirdBody, 66
accumulate_thermal_sources	create facet
jeod::RadiationSurface, 57	jeod::FlatPlateRadiationFactory, 2
active	crot_to_cp
jeod::RadiationPressure, 46	jeod::RadiationFacet, 34
jeod::RadiationThirdBody, 68	cx area
add_facet_params	jeod::RadiationBaseFacet, 26
jeod::RadiationSurfaceFactory, 62	Cyl
add_thermal_integrator_to	jeod::RadiationSource, 50
jeod::RadiationDefaultSurface, 29	
add thermal integrators to	jeod::RadiationThirdBody, 65
jeod::RadiationSurface, 57	Cylindrical
	jeod::RadiationSource, 50
add_third_body	jeod::RadiationThirdBody, 65
jeod::RadiationPressure, 42	d course to as
added_to_model	d_source_to_cg
jeod::RadiationThirdBody, 69	jeod::RadiationSource, 52
albedo	d_source_to_third
jeod::RadiationBaseFacet, 25	jeod::RadiationThirdBody, 69
jeod::RadiationParams, 39	default_surface_ptr
albedo_IR	jeod::RadiationPressure, 46
jeod::RadiationBaseFacet, 25	define_facet
albedo_vis	jeod::FlatPlateRadiationFacet, 18
jeod::RadiationBaseFacet, 25	define_facet_core
allocate_array	jeod::RadiationFacet, 33

diffuse	incident_flux_hat
jeod::RadiationBaseFacet, 26	jeod::FlatPlateRadiationFacet, 20
jeod::RadiationParams, 39	incident_radiation
dyn_manager_ptr	jeod::FlatPlateRadiationFacet, 18
jeod::RadiationPressure, 46	jeod::RadiationBaseFacet, 24
	jeod::RadiationDefaultSurface, 29
equalize_absorption_emission	jeod::RadiationSurface, 58
jeod::RadiationSurface, 57	include_conduction
	jeod::RadiationSurface, 60
F_absorption	incomplete_setup_error
jeod::RadiationBaseFacet, 26	jeod::RadiationMessages, 36
F_diffuse	inertial_cg
jeod::RadiationBaseFacet, 27	jeod::RadiationSource, 53
F_emission	inertial_frame_ptr
jeod::RadiationBaseFacet, 27	jeod::RadiationSource, 53
F_specular	init_attrjeodFlatPlateRadiationFacet
jeod::RadiationBaseFacet, 27	jeod::FlatPlateRadiationFacet, 19
facets	init_attrjeodFlatPlateRadiationFactory
jeod::RadiationSurface, 59	jeod::FlatPlateRadiationFactory, 22
find_third_body	init_attrjeodRadiationBaseFacet
jeod::RadiationPressure, 42	jeod::RadiationBaseFacet, 25
flat_plate_radiation_facet.cc, 73	init_attrjeodRadiationDefaultSurface
flat_plate_radiation_facet.hh, 73	jeod::RadiationDefaultSurface, 30
flat_plate_radiation_factory	init attrjeod RadiationFacet
jeod::RadiationSurfaceFactory, 62	jeod::RadiationFacet, 34
flat_plate_radiation_factory.cc, 74	init_attrjeodRadiationMessages
flat_plate_radiation_factory.hh, 74	jeod::RadiationMessages, 36
FlatPlateRadiationFacet	init_attrjeodRadiationParams
jeod::FlatPlateRadiationFacet, 18	jeod::RadiationParams, 39
FlatPlateRadiationFactory	init_attrjeodRadiationPressure
jeod::FlatPlateRadiationFactory, 21	jeod::RadiationPressure, 46
flux_hat	init_attrjeodRadiationSource
jeod::RadiationSource, 52	jeod::RadiationSource, 51
flux_inertial	init_attrjeodRadiationSurface
jeod::RadiationSource, 52	jeod::RadiationSurface, 59
flux_mag	init_attrjeodRadiationSurfaceFactory
jeod::RadiationSource, 52	jeod::RadiationSurfaceFactory, 62
flux_struc	init_attrjeodRadiationThirdBody
jeod::RadiationSource, 52	jeod::RadiationThirdBody, 68
flux_struc_hat	initialize
jeod::RadiationSource, 52	jeod::RadiationBaseFacet, 24
force	jeod::RadiationDefaultSurface, 30
jeod::RadiationPressure, 47	jeod::RadiationFacet, 33
jeod::RadiationSurface, 59	jeod::RadiationPressure, 42
force_state_update	jeod::RadiationSource, 51
jeod::RadiationThirdBody, 69	jeod::RadiationSurface, 58
generate_alpha	jeod::RadiationThirdBody, 67
jeod::RadiationThirdBody, 66	initialize_environment
get_added_to_model	jeod::RadiationPressure, 44
jeod::RadiationThirdBody, 66	initialize geom
get_thermal_integrator	jeod::FlatPlateRadiationFacet, 19
jeod::RadiationFacet, 33	jeod::RadiationFacet, 34
jeoui iadiatiotii acet, oo	initialize_runtime_values
ii facet	jeod::RadiationBaseFacet, 24
jeod::RadiationSurface, 59	jeod::RadiationSurface, 58
illum factor	initialized
jeod::RadiationPressure, 47	jeod::RadiationPressure, 47
jeod::RadiationThirdBody, 69	jeod::RadiationThirdBody, 69
josain ladialion i i ili abody, oo	joodin laalalloittiinabody, oo

InputProcessor	$\sim$ RadiationBaseFacet, 24
jeod::FlatPlateRadiationFacet, 19	albedo, 25
jeod::FlatPlateRadiationFactory, 22	albedo_IR, 25
jeod::RadiationBaseFacet, 25	albedo_vis, 25
jeod::RadiationDefaultSurface, 30	areaxflux, 26
jeod::RadiationFacet, 34	areaxflux e, 26
jeod::RadiationMessages, 36	cx_area, 26
jeod::RadiationParams, 39	diffuse, 26
jeod::RadiationPressure, 46	F_absorption, 26
jeod::RadiationSource, 51	F_diffuse, 27
jeod::RadiationSurface, 59	F_emission, 27
jeod::RadiationSurfaceFactory, 62	F_specular, 27
jeod::RadiationThirdBody, 68	incident_radiation, 24
interact_with_third_body	init_attrjeodRadiationBaseFacet, 25
jeod::RadiationBaseFacet, 25	initialize, 24
jeod::RadiationSurface, 58	initialize_runtime_values, 24
Interactions, 12	InputProcessor, 25
invalid_function_call	interact_with_third_body, 25
jeod::RadiationMessages, 36	operator=, 25
invalid_setup_error	RadiationBaseFacet, 24
jeod::RadiationMessages, 36	speed of light, 27
is_correct_factory	thermal, 27
jeod::FlatPlateRadiationFactory, 22	jeod::RadiationDefaultSurface, 28
is interactive	~RadiationDefaultSurface, 29
jeod::RadiationThirdBody, 67	add_thermal_integrator_to, 29
	incident_radiation, 29
jeod, 15	init_attrjeodRadiationDefaultSurface, 30
jeod::RadiationSource	initialize, 30
Con, 50	InputProcessor, 30
Conical, 50	·
Cyl, 50	name, 31
Cylindrical, 50	operator=, 30
jeod::RadiationThirdBody	rad_coeff, 31
Con, 65	RadiationDefaultSurface, 29
Conical, 65	set_name, 30
Cyl, 65	surface_area, 31
Cylindrical, 65	temperature, 31
jeod::FlatPlateRadiationFacet, 17	thermal_update, 30
$\sim$ FlatPlateRadiationFacet, 18	jeod::RadiationFacet, 31
define_facet, 18	~RadiationFacet, 33
FlatPlateRadiationFacet, 18	center_pressure, 34
incident_flux_hat, 20	crot_to_cp, 34
incident_radiation, 18	define_facet_core, 33
init_attrjeodFlatPlateRadiationFacet, 19	get_thermal_integrator, 33
initialize_geom, 19	init_attrjeodRadiationFacet, 34
InputProcessor, 19	initialize, 33
normal, 20	initialize_geom, 34
operator=, 19	InputProcessor, 34
radiation_pressure, 19	operator=, 34
sin_theta, 20	radiation_pressure, 34
jeod::FlatPlateRadiationFactory, 20	RadiationFacet, 33
$\sim$ FlatPlateRadiationFactory, 21	two_thirds, 35
create_facet, 21	jeod::RadiationMessages, 35
FlatPlateRadiationFactory, 21	incomplete_setup_error, 36
init_attrjeodFlatPlateRadiationFactory, 22	init_attrjeodRadiationMessages, 36
InputProcessor, 22	InputProcessor, 36
is_correct_factory, 22	invalid_function_call, 36
operator=, 22	invalid_setup_error, 36
jeod::RadiationBaseFacet, 22	operational_setup_error, 37

	operator=, 36		luminosity, 53
	RadiationMessages, 36		multiple_shadow_bodies, 53
	unknown_numerical_error, 37		name, 53
jeod:	:RadiationParams, 37		num_bodies, 53
	$\sim$ RadiationParams, 38		OldShadowGeometry, 50
	albedo, 39		operator=, 51
	diffuse, 39		RadiationSource, 50, 51
	init_attrjeodRadiationParams, 39		radius, 54
	InputProcessor, 39		set_name, 51
	operator=, 39		shadow_geometry, 54
	RadiationParams, 38		solar_luminosity, 54
	thermal, 39		solar_radius, 54
-	:RadiationPressure, 39		source_to_cg, 54
	$\sim$ RadiationPressure, 41		source_to_struc_origin, 54
	active, 46		third_body, 55
	add_third_body, 42	jeod	::RadiationSurface, 55
	calculate_forces, 46		$\sim$ RadiationSurface, 56
	default_surface_ptr, 46		accumulate_thermal_sources, 57
	dyn_manager_ptr, 46		add_thermal_integrators_to, 57
	find_third_body, 42		allocate_array, 57
	force, 47		allocate_interaction_facet, 57
	illum_factor, 47		equalize_absorption_emission, 57
	init_attrjeodRadiationPressure, 46		facets, 59
	initialize, 42		force, 59
	initialize_environment, 44		ii_facet, 59
	initialized, 47		incident_radiation, 58
	InputProcessor, 46		include_conduction, 60
	num_third_bodies, 47		init_attrjeodRadiationSurface, 59
	operator=, 44		initialize, 58
	RadiationPressure, 41		initialize_runtime_values, 58
	set_calculate_forces, 44		InputProcessor, 59
	set_third_body_active, 44		interact_with_third_body, 58
	set_third_body_inactive, 44		num_facets, 60
	source, 47		operator=, 59
	surface_ptr, 47		radiation_pressure, 59
	thermal, 48		RadiationSurface, 56, 57
	third_bodies, 48		thermal_conduction, 60
	third_bodies_active, 48		thermal_integrator, 59
	third_body_adjustments, 45		torque, 60
	torque, 48	jeod	::RadiationSurfaceFactory, 60
	update, 45		~RadiationSurfaceFactory, 61
	update_default_surface, 45		add_facet_params, 62
	update_facet_surface, 45		flat_plate_radiation_factory, 62
-	:RadiationSource, 48		init_attrjeodRadiationSurfaceFactory, 62
	~RadiationSource, 50		InputProcessor, 62
	bodies_active, 52		operator=, 62
	calculate_flux, 51		RadiationSurfaceFactory, 61
	d_source_to_cg, 52	jeod	::RadiationThirdBody, 62
	flux_hat, 52		~RadiationThirdBody, 65
	flux_inertial, 52		accumulate_rad_flux, 65
	flux_mag, 52		accumulate_refl_flux, 65
	flux_struc, 52		active, 68
	flux_struc_hat, 52		added_to_model, 69
	inertial_cg, 53		calculate_shadow, 66
	inertial_frame_ptr, 53		convert_shadow_from_int, 66
	init_attrjeodRadiationSource, 51		d_source_to_third, 69
	initialize, 51		force_state_update, 69
	InputProcessor, 51		generate_alpha, 66

get_added_to_model, 66	operational_setup_error
illum_factor, 69	jeod::RadiationMessages, 37
init_attrjeodRadiationThirdBody, 68	operator=
initialize, 67	jeod::FlatPlateRadiationFacet, 19
initialized, 69	jeod::FlatPlateRadiationFactory, 22
InputProcessor, 68	jeod::RadiationBaseFacet, 25
is_interactive, 67	jeod::RadiationDefaultSurface, 30
last_update_time, 69	jeod::RadiationFacet, 34
local_frame_ptr, 69	jeod::RadiationMessages, 36
name, 70	jeod::RadiationParams, 39
operator=, 67	jeod::RadiationPressure, 44
•	jeod::RadiationSource, 51
output_flux, 70	
planet_link, 70	jeod::RadiationSurface, 59
primary_source_ptr, 70	jeod::RadiationSurfaceFactory, 62
process_third_body, 67	jeod::RadiationThirdBody, 67
r_minus, 70	output_flux
r_par, 70	jeod::RadiationThirdBody, 70
r_perp, 71	DATU
r_plus, 71	PATH
r_ratio, 71	RadiationPressure, 14
RadiationThirdBody, 65	planet_link
radius, 71	jeod::RadiationThirdBody, 70
set_added_to_model, 67	primary_source_ptr
set_name, 68	jeod::RadiationThirdBody, 70
shadow_geometry, 71	process_third_body
ShadowGeometry, 65	jeod::RadiationThirdBody, 67
source_to_third_hat_inrtl, 71	
source_to_third_inrtl, 72	r_minus
test_for_state_update, 68	jeod::RadiationThirdBody, 70
third_to_cg_inrtl, 72	r_par
update_interval, 72	jeod::RadiationThirdBody, 70
update_third_body_state, 68	r_perp
apadio_tima_body_ctate, 00	jeod::RadiationThirdBody, 71
last_update_time	r_plus
jeod::RadiationThirdBody, 69	jeod::RadiationThirdBody, 71
local frame ptr	r_ratio
jeod::RadiationThirdBody, 69	jeod::RadiationThirdBody, 71
luminosity	rad_coeff
-	jeod::RadiationDefaultSurface, 31
jeod::RadiationSource, 53	radiation_base_facet.cc, 75
Models, 11	radiation_base_facet.hh, 75
multiple_shadow_bodies	radiation_default_surface.cc, 76
• — —	radiation_default_surface.hh, 76
jeod::RadiationSource, 53	radiation_facet.cc, 77
nama	radiation_facet.hh, 77
name	radiation_messages.cc, 78
jeod::RadiationDefaultSurface, 31	_ ·
jeod::RadiationSource, 53	radiation_messages.hh, 78
jeod::RadiationThirdBody, 70	radiation_params.cc, 79
normal	radiation_params.hh, 79
jeod::FlatPlateRadiationFacet, 20	radiation_pressure
num_bodies	jeod::FlatPlateRadiationFacet, 19
jeod::RadiationSource, 53	jeod::RadiationFacet, 34
num_facets	jeod::RadiationSurface, 59
jeod::RadiationSurface, 60	radiation_pressure.cc, 79
num_third_bodies	radiation_pressure.hh, 80
jeod::RadiationPressure, 47	radiation_pressuredefault_surface.cc, 8
	radiation_pressuresurface_model.cc, 8
OldShadowGeometry	radiation_source.cc, 81
jeod::RadiationSource, 50	radiation_source.hh, 82

radiation_surface.cc, 82	jeod::RadiationSource, 54			
radiation_surface.hh, 83	source_to_third_hat_inrtl			
radiation_surface_factory.cc, 84	jeod::RadiationThirdBody, 71			
radiation_surface_factory.hh, 84	source_to_third_inrtl			
radiation_third_body.cc, 84	jeod::RadiationThirdBody, 72			
radiation_third_body.hh, 85	speed_of_light			
RadiationBaseFacet	jeod::RadiationBaseFacet, 27			
jeod::RadiationBaseFacet, 24	surface area			
RadiationDefaultSurface	jeod::RadiationDefaultSurface, 31			
jeod::RadiationDefaultSurface, 29	surface_ptr			
RadiationFacet	jeod::RadiationPressure, 47			
jeod::RadiationFacet, 33	tomporatura			
RadiationMessages	temperature			
jeod::RadiationMessages, 36	jeod::RadiationDefaultSurface, 31			
RadiationParams	test_for_state_update			
jeod::RadiationParams, 38	jeod::RadiationThirdBody, 68			
RadiationPressure, 13	thermal			
jeod::RadiationPressure, 41	jeod::RadiationBaseFacet, 27			
PATH, 14	jeod::RadiationParams, 39			
RadiationSource	jeod::RadiationPressure, 48			
jeod::RadiationSource, 50, 51	thermal_conduction			
RadiationSurface	jeod::RadiationSurface, 60			
jeod::RadiationSurface, 56, 57	thermal integrator			
RadiationSurfaceFactory	jeod::RadiationSurface, 59			
jeod::RadiationSurfaceFactory, 61	thermal update			
	jeod::RadiationDefaultSurface, 30			
RadiationThirdBody	third bodies			
jeod::RadiationThirdBody, 65	<del>_</del>			
radius	jeod::RadiationPressure, 48			
jeod::RadiationSource, 54	third_bodies_active			
jeod::RadiationThirdBody, 71	jeod::RadiationPressure, 48			
	third_body			
set_added_to_model	jeod::RadiationSource, 55			
jeod::RadiationThirdBody, 67	third_body_adjustments			
set_calculate_forces	jeod::RadiationPressure, 45			
jeod::RadiationPressure, 44	third_to_cg_inrtl			
set_name	jeod::RadiationThirdBody, 72			
jeod::RadiationDefaultSurface, 30	torque			
jeod::RadiationSource, 51	jeod::RadiationPressure, 48			
jeod::RadiationThirdBody, 68	jeod::RadiationSurface, 60			
set_third_body_active	two thirds			
jeod::RadiationPressure, 44	jeod::RadiationFacet, 35			
set_third_body_inactive	jood tadiationi assi, so			
jeod::RadiationPressure, 44	unknown_numerical_error			
shadow_geometry	jeod::RadiationMessages, 37			
_ ·	update			
jeod::RadiationSource, 54	•			
jeod::RadiationThirdBody, 71	jeod::RadiationPressure, 45			
ShadowGeometry	update_default_surface			
jeod::RadiationThirdBody, 65	jeod::RadiationPressure, 45			
sin_theta	update_facet_surface			
jeod::FlatPlateRadiationFacet, 20	jeod::RadiationPressure, 45			
solar_luminosity	update_interval			
jeod::RadiationSource, 54	jeod::RadiationThirdBody, 72			
solar_radius	update_third_body_state			
jeod::RadiationSource, 54	jeod::RadiationThirdBody, 68			
source	•			
jeod::RadiationPressure, 47				
source_to_cg				
jeod::RadiationSource, 54				
-				
source_to_struc_origin				