OrientationModel 5.1

Generated by Doxygen 1.8.5

Mon Jul 31 2023 11:43:03

Contents

1	Mod	ule Index	1
	1.1	Modules	1
2	Nam	espace Index	3
	2.1	Namespace List	3
3	Data	Structure Index	5
	3.1	Data Structures	5
4	File	Index	7
	4.1	File List	7
5	Mod	ule Documentation	9
	5.1	Models	9
		5.1.1 Detailed Description	9
	5.2	Utils	10
		5.2.1 Detailed Description	10
	5.3	Orientation	11
		5.3.1 Detailed Description	11
6	Nam	espace Documentation	13
	6.1	jeod Namespace Reference	13
		6.1.1 Detailed Description	13
		6.1.2 Variable Documentation	13
		6.1.2.1 Euler_info	13
7	Data	Structure Documentation	15
	7.1	jeod::EulerInfo Struct Reference	15
		7.1.1 Detailed Description	15
		7.1.2 Field Documentation	15
		7.1.2.1 alternate_x	15
		7.1.2.2 alternate_z	16
		7.1.2.3 indices	16
		7124 is aerodynamics sequence	16

iv CONTENTS

		7.1.2.5	is_even_permutation	16
7.2	jeod::C	Orientation	Class Reference	16
	7.2.1	Detailed	Description	19
	7.2.2	Member	Enumeration Documentation	20
		7.2.2.1	DataSource	20
		7.2.2.2	EulerSequence	20
	7.2.3	Construc	tor & Destructor Documentation	21
		7.2.3.1	Orientation	21
		7.2.3.2	Orientation	21
		7.2.3.3	Orientation	21
		7.2.3.4	Orientation	21
		7.2.3.5	Orientation	21
		7.2.3.6	\sim Orientation	22
	7.2.4	Member	Function Documentation	22
		7.2.4.1	clear_euler_sequence	22
		7.2.4.2	compute_all_products	22
		7.2.4.3	compute_eigen_rotation	22
		7.2.4.4	compute_eigen_rotation_from_matrix	22
		7.2.4.5	compute_eigen_rotation_from_matrix	23
		7.2.4.6	compute_euler_angles	24
		7.2.4.7	compute_euler_angles_from_matrix	24
		7.2.4.8	compute_euler_angles_from_matrix	25
		7.2.4.9	compute_matrix_from_eigen_rotation	25
		7.2.4.10	compute_matrix_from_eigen_rotation	26
		7.2.4.11	compute_matrix_from_euler_angles	26
		7.2.4.12	compute_matrix_from_euler_angles	26
		7.2.4.13	compute_quaternion	26
		7.2.4.14	compute_quaternion_from_euler_angles	27
		7.2.4.15	compute_quaternion_from_euler_angles	27
		7.2.4.16	compute_transform	27
		7.2.4.17	compute_transformation_and_quaternion	27
		7.2.4.18	get_eigen_rotation	27
		7.2.4.19	get_euler_angles	28
		7.2.4.20	get_euler_angles	28
		7.2.4.21	get_euler_sequence	28
		7.2.4.22	get_quaternion	28
		7.2.4.23	get_transform	28
		7.2.4.24	mark_input_as_available	29
		7.2.4.25	reset	29
		7.2.4.26	set_eigen_rotation	29

CONTENTS

		7.2.4.27	set_euler_angles	29
		7.2.4.28	set_euler_angles	30
		7.2.4.29	set_euler_sequence	30
		7.2.4.30	set_quaternion	30
		7.2.4.31	set_transform	30
	7.2.5	Friends A	And Related Function Documentation	31
		7.2.5.1	init_attrjeodOrientation	31
		7.2.5.2	InputProcessor	31
	7.2.6	Field Doo	cumentation	31
		7.2.6.1	data_source	31
		7.2.6.2	eigen_angle	31
		7.2.6.3	eigen_axis	31
		7.2.6.4	euler_angles	31
		7.2.6.5	euler_sequence	31
		7.2.6.6	gimbal_lock_threshold	32
		7.2.6.7	have_eigen_rotation	32
		7.2.6.8	have_euler_angles	32
		7.2.6.9	have_quaternion	32
		7.2.6.10	have_transformation	32
		7.2.6.11	quat	33
		7.2.6.12	trans	33
7.3	jeod::O	rientation	Messages Class Reference	33
	7.3.1	Detailed	Description	34
	7.3.2	Construc	tor & Destructor Documentation	34
		7.3.2.1	OrientationMessages	34
		7.3.2.2	OrientationMessages	34
	7.3.3	Member	Function Documentation	34
		7.3.3.1	operator=	34
	7.3.4	Friends A	And Related Function Documentation	34
		7.3.4.1	init_attrjeodOrientationMessages	34
		7.3.4.2	InputProcessor	34
	7.3.5	Field Doo	cumentation	34
		7.3.5.1	invalid_data	34
		7.3.5.2	invalid_enum	34
		7.3.5.3	invalid_request	34
Eilo	Dogume	entation		37
8.1			File Reference	37 37
0.1	8.1.1		Description	37
8.2			File Reference	37
٥.۷	eulel_a	angico.co F	IIIO TIOIOTOTO CONTRA C	37

8

vi CONTENTS

Index			41
	8.6.1	Detailed Description	40
8.6	orienta	tion_messages.hh File Reference	39
		8.5.2.1 MAKE_ORIENTATION_MESSAGE_CODE	39
	8.5.2	Macro Definition Documentation	39
	8.5.1	Detailed Description	39
8.5	orienta	tion_messages.cc File Reference	39
	8.4.1	Detailed Description	39
8.4	orienta	tion.hh File Reference	38
	8.3.1	Detailed Description	38
8.3	orienta	tion.cc File Reference	38
	8.2.1	Detailed Description	38

Module Index

1.1 Modules

Here is a list of all modules:			
Models	 	 	 9
Utils	 	 	 10
Orientation			11

2 **Module Index**

Namespace Index

2.1	Namespace List	
Here	e is a list of all namespaces with brief descriptions:	

eod					
	Namespace jeod	 	 	 	13

Namespace Index

Data Structure Index

3.1 Data Structures

Here are the data structures with brief descriptions:

jeod::EulerInfo	
Contains data needed to construct a transformation matrix given a sequence of Euler angles and	
to extract a sequence of Euler angles from a matrix	15
jeod::Orientation	
Specifies the orientiation of one reference frame with respect to another	16
jeod::OrientationMessages	
Declares messages associated with the orientation model	33

6 Data Structure Index

File Index

4.1 File List

Here is a list of all files with brief descriptions:

eigen_rotation.cc	
Define Orientation methods related to computing single axis rotations	37
euler_angles.cc	
Define Orientation methods related to computing Euler angles	37
orientation.cc	
Define methods for the NewOrientation class	38
orientation.hh	
Define the Orientation class	38
orientation_messages.cc	
Implement the class OrientationMessages	39
orientation_messages.hh	
Define the class OrientationMessages, the class that specifies the message IDs used in the	
orientation model	39

8 File Index

Module Documentation

5.1 Models

Modules

• Utils

5.1.1 Detailed Description

10 Module Documentation

5.2 Utils

Modules

Orientation

5.2.1 Detailed Description

5.3 Orientation

5.3 Orientation

Files

· file orientation.hh

Define the Orientation class.

· file orientation_messages.hh

Define the class OrientationMessages, the class that specifies the message IDs used in the orientation model.

• file eigen_rotation.cc

Define Orientation methods related to computing single axis rotations.

• file euler_angles.cc

Define Orientation methods related to computing Euler angles.

· file orientation.cc

Define methods for the NewOrientation class.

• file orientation_messages.cc

Implement the class OrientationMessages.

Namespaces

• jeod

Namespace jeod.

5.3.1 Detailed Description

12 **Module Documentation**

Namespace Documentation

6.1 jeod Namespace Reference

Namespace jeod.

Data Structures

class Orientation

Specifies the orientiation of one reference frame with respect to another.

class OrientationMessages

Declares messages associated with the orientation model.

struct EulerInfo

Contains data needed to construct a transformation matrix given a sequence of Euler angles and to extract a sequence of Euler angles from a matrix.

Variables

• static const EulerInfo Euler_info [12]

Contains twelve EulerInfo objects, one per each of the JEOD Euler sequences.

6.1.1 Detailed Description

Namespace jeod.

6.1.2 Variable Documentation

6.1.2.1 const EulerInfo jeod::Euler_info[12] [static]

Initial value:

```
= {
    { {0, 1, 2}, 0, 2, true, true },
    { {0, 2, 1}, 0, 1, false, true },
    { {1, 2, 0}, 1, 0, true, true },
    { {1, 0, 2}, 1, 2, false, true },
    { {2, 0, 1}, 2, 1, true, true },
    { {2, 1, 0}, 2, 0, false, true },
    { {0, 1, 0}, 2, 2, true, false },
    { {0, 2, 0}, 1, 1, false, false },
    { {1, 2, 1}, 0, 0, true, false },
}
```

```
{ {1, 0, 1}, 2, 2, false, false }, { {2, 0, 2}, 1, 1, true, false }, { {2, 1, 2}, 0, 0, false, false }
```

Contains twelve EulerInfo objects, one per each of the JEOD Euler sequences.

The elements are arranged per the values of the Orientation::EulerSequence enumeration items.

Definition at line 98 of file euler_angles.cc.

Referenced by jeod::Orientation::compute_euler_angles_from_matrix(), jeod::Orientation::compute_matrix_from_euler_angles(), and jeod::Orientation::compute_quaternion_from_euler_angles().

Data Structure Documentation

7.1 jeod::EulerInfo Struct Reference

Contains data needed to construct a transformation matrix given a sequence of Euler angles and to extract a sequence of Euler angles from a matrix.

Data Fields

• unsigned int indices [3]

The axes about which the rotations are performed in the order in which the rotations are performed, with X=0, Y=1, Z=2.

unsigned int alternate_x

The initial element of the sequence for aerodynamics sequences, but the index of the omitted axis for astronomical sequences.

unsigned int alternate_z

The final element of the sequence for aerodynamics sequences, but the index of the omitted axis for astronomical sequences.

· bool is_even_permutation

Indicates whether the 3-axis rotation sequence generated by replacing the final element of the sequence with the one axis not specified by the first two elements of the sequence is an even (true) permutation or odd permutation (false) of XYZ.

· bool is aerodynamics sequence

True if the sequence is an aerodynamics sequence such as XYZ; false for an astronomical sequence such as ZXZ.

7.1.1 Detailed Description

Contains data needed to construct a transformation matrix given a sequence of Euler angles and to extract a sequence of Euler angles from a matrix.

See Orientation::compute_euler_angles_from_matrix for details.

Definition at line 51 of file euler_angles.cc.

7.1.2 Field Documentation

7.1.2.1 unsigned int jeod::EulerInfo::alternate_x

The initial element of the sequence for aerodynamics sequences, but the index of the omitted axis for astronomical sequences.

For example, the omitted axis in a ZXZ sequence is Y=1.trick_units(-)

Definition at line 65 of file euler angles.cc.

Referenced by jeod::Orientation::compute_euler_angles_from_matrix().

7.1.2.2 unsigned int jeod::EulerInfo::alternate_z

The final element of the sequence for aerodynamics sequences, but the index of the omitted axis for astronomical sequences.

trick_units(-)

Definition at line 71 of file euler angles.cc.

Referenced by jeod::Orientation::compute_euler_angles_from_matrix().

7.1.2.3 unsigned int jeod::EulerInfo::indices[3]

The axes about which the rotations are performed in the order in which the rotations are performed, with X=0, Y=1, Z=2.

For example, an XYZ or roll pitch yaw sequence is {0,1,2} while a ZXZ sequence is {2,0,2}.trick_units(-)

Definition at line 58 of file euler_angles.cc.

Referenced by jeod::Orientation::compute_euler_angles_from_matrix(), jeod::Orientation::compute_matrix_from_euler angles(), and jeod::Orientation::compute quaternion from euler angles().

7.1.2.4 bool jeod::EulerInfo::is_aerodynamics_sequence

True if the sequence is an aerodynamics sequence such as XYZ; false for an astronomical sequence such as ZXZ. trick_units(-)

Definition at line 89 of file euler_angles.cc.

Referenced by jeod::Orientation::compute_euler_angles_from_matrix().

7.1.2.5 bool jeod::EulerInfo::is_even_permutation

Indicates whether the 3-axis rotation sequence generated by replacing the final element of the sequence with the one axis not specified by the first two elements of the sequence is an even (true) permutation or odd permutation (false) of XYZ.

The alternative 3-axis sequence is identical to the original sequence in the case of aerodynamics sequences. The astronomical ZXZ sequence becomes ZXY via this replacement rule. Since ZXY is an even permutation of XYZ, the is_even_permutation member for a ZXZ sequence is true.trick_units(-)

Definition at line 83 of file euler_angles.cc.

Referenced by jeod::Orientation::compute_euler_angles_from_matrix().

The documentation for this struct was generated from the following file:

· euler angles.cc

7.2 jeod::Orientation Class Reference

Specifies the orientiation of one reference frame with respect to another.

#include <orientation.hh>

Public Types

```
    enum DataSource {
        InputNone = -1, InputMatrix = 0, InputQuaternion = 1, InputEigenRotation = 2,
        InputEulerRotation = 3 }
        Specifies which representation has been input by the user.
    enum EulerSequence {
        NoSequence = -1, EulerXYZ = 0, EulerXZY = 1, EulerYZX = 2,
        EulerYXZ = 3, EulerZXY = 4, EulerZYX = 5, EulerXYX = 6,
        EulerXZX = 7, EulerYZY = 8, EulerYXY = 9, EulerZXZ = 10,
        EulerZYZ = 11, Roll_Pitch_Yaw = 0, Roll_Yaw_Pitch = 1, Pitch_Yaw_Roll = 2,
        Pitch_Roll_Yaw = 3, Yaw_Roll_Pitch = 4, Yaw_Pitch_Roll = 5, RollPitchYaw = 0,
        RollYawPitch = 1, PitchYawRoll = 2, PitchRollYaw = 3, YawRollPitch = 4,
        YawPitchRoll = 5 }
```

Identifies which type of Euler sequence has been specified.

Public Member Functions

· Orientation (void)

Construct an Orientation instance.

• Orientation (const double trans in[3][3])

Construct an Orientation instance from a transformation matrix.

Orientation (const Quaternion &quat_in)

Construct an Orientation instance from a Quaternion.

• Orientation (double eigen_angle_in, const double eigen_axis[3])

Construct an Orientation instance from an eigen rotation.

Orientation (EulerSequence sequence_in, const double angles_in[3])

Construct an Orientation instance from an Euler rotation.

virtual ∼Orientation (void)

Destruct an Orientation instance.

virtual void reset (void)

Forget that we have any data.

virtual void compute_transform (void)

Compute the transformation matrix from the source.

virtual void compute_quaternion (void)

Compute the left transformation quaternion from the source.

virtual void compute_eigen_rotation (void)

Compute the eigen rotation from the source.

· virtual void compute euler angles (void)

Compute the eigen rotation from the source.

virtual void compute_all_products (void)

Compute all represented charts on SO3 from the specified source.

· virtual void compute transformation and quaternion (void)

Compute the transformation matrix and quaternion.

void set_quaternion (const Quaternion &quat)

Reset the instance with a new quaternion.

void get quaternion (Quaternion &quat)

Accessor for the left transformation quaternion.

• void set_transform (const double trans[3][3])

Reset the instance with a new matrix.

void get_transform (double trans[3][3])

Accessor for the transformation matrix.

void set_eigen_rotation (double eigen_angle, const double eigen_axis[3])

Reset the instance with a new eigen rotation.

void get_eigen_rotation (double *eigen_angle, double eigen_axis[3])

Accessor for the eigen rotation.

· void set_euler_angles (EulerSequence sequence, const double angles[3])

Reset the instance with a new Euler rotation.

void set_euler_angles (const double angles[3])

Reset the instance with a new Euler rotation.

• void get_euler_angles (EulerSequence *sequence, double angles[3])

Accessor for the Euler angles.

void get_euler_angles (double angles[3])

Accessor for the Euler angles.

• EulerSequence get_euler_sequence (void)

Accessor for the Euler sequence data member.

void set_euler_sequence (EulerSequence sequence)

Set the euler_sequence data member.

• void clear_euler_sequence (void)

Reset the euler_sequence data member.

Static Public Member Functions

static void compute_quaternion_from_euler_angles (EulerSequence sequence, const double angles[3],
 Quaternion &quat)

Compute the left transformation quaternion from the Euler sequence.

 static void compute_matrix_from_euler_angles (EulerSequence sequence, const double angles[3], double trans[3][3])

Compute the transformation matrix from the Euler sequence.

 static void compute_euler_angles_from_matrix (const double trans[3][3], EulerSequence sequence, double angles[3])

Extract an Euler sequence from the transformation matrix.

• static void compute_matrix_from_eigen_rotation (double eigen_angle, const double eigen_axis[3], double trans[3][3])

Compute the transformation matrix from the eigen rotation.

• static void compute_eigen_rotation_from_matrix (const double trans[3][3], double *eigen_angle, double eigen_axis[3])

Compute the eigen rotation from the transformation matrix.

Data Fields

• DataSource data_source

Orientation data source – specifies whether the user has provided as input an Euler rotation, a transformation matrix, or a left transformation quaternion.

EulerSequence euler_sequence

The Euler rotation sequence corresponding to euler_angles.

• double euler angles [3]

Euler angles corresponding to rotation sequence euler_sequence.

double trans [3][3]

Transformation matrix.

· Quaternion quat

Left transformation unit quaternion.

double eigen_angle

Single axis rotation angle.

• double eigen_axis [3]

Single axis rotation axis unit vector.

Protected Member Functions

void mark_input_as_available ()

Mark the item specified by the data_source as available.

void compute_quaternion_from_euler_angles (void)

Compute the left transformation quaternion that corresponds to the provided Euler rotation sequence.

void compute_matrix_from_euler_angles (void)

Compute the transformation matrix that corresponds to the provided Euler rotation sequence.

void compute_euler_angles_from_matrix (void)

Compute an Euler rotation sequence that corresponds to the provided transformation matrix.

void compute_matrix_from_eigen_rotation (void)

Compute the transformation matrix that corresponds to the provided eigen rotation.

void compute_eigen_rotation_from_matrix (void)

Compute a eigen rotation that corresponds to the provided transformation matrix.

Protected Attributes

bool have transformation

True if transformation matrix has been set/computed.

· bool have_quaternion_

True if quaternion has been set/computed.

· bool have_eigen_rotation_

True if eigen rotation has been set/computed.

bool have_euler_angles_

True if an Euler rotation has been set/computed.

Static Protected Attributes

• static double gimbal_lock_threshold = 1e-13

Threshold for detecting gimbal lock in compute_euler_angles_from_matrix.

Friends

- class InputProcessor
- void init_attrjeod__Orientation ()

7.2.1 Detailed Description

Specifies the orientiation of one reference frame with respect to another.

There are many competing charts on the rotation group. This class provides means for representing rotations as Euler rotations, transformation matrices, left transformation quaternions, and eigen rotations. The class also provides mechanisms for converting these representations into the alternative representations.

Definition at line 81 of file orientation.hh.

7.2.2 Member Enumeration Documentation

7.2.2.1 enum jeod::Orientation::DataSource

Specifies which representation has been input by the user.

Enumerator

InputNone No source specified.

InputMatrix Transformation matrices supplied by user.

InputQuaternion Quaternions supplied by user.

InputEigenRotation Single axis rotation supplied by user.

InputEulerRotation Euler sequence and angles supplied by user.

Definition at line 91 of file orientation.hh.

7.2.2.2 enum jeod::Orientation::EulerSequence

Identifies which type of Euler sequence has been specified.

Enumerator

```
NoSequence No sequence specified.
EulerXYZ XYX sequence (roll pitch yaw)
EulerXZY XZY sequence (roll yaw pitch)
EulerYZX YZX sequence (pitch yaw roll)
EulerYXZ YXZ sequence (pitch roll yaw)
EulerZXY ZXY sequence (yaw roll pitch)
EulerZYX ZYX sequence (yaw pitch roll)
EulerXYX XYX sequence.
EulerXZX XZX sequence.
EulerYZY YZY sequence.
EulerYXY YXY sequence.
EulerZXZ The canonical ZXZ Euler sequence.
EulerZYZ ZYZ sequence.
Roll_Pitch_Yaw XYX sequence (roll pitch yaw)
Roll_Yaw_Pitch XZY sequence (roll yaw pitch)
Pitch_Yaw_Roll YZX sequence (pitch yaw roll)
Pitch_Roll_Yaw YXZ sequence (pitch roll yaw)
Yaw_Roll_Pitch ZXY sequence (yaw roll pitch)
Yaw_Pitch_Roll ZYX sequence (yaw pitch roll)
RollPitchYaw XYX sequence (roll pitch yaw)
RollYawPitch XZY sequence (roll yaw pitch)
PitchYawRoll YZX sequence (pitch yaw roll)
PitchRollYaw YXZ sequence (pitch roll yaw)
YawRollPitch ZXY sequence (yaw roll pitch)
YawPitchRoll ZYX sequence (yaw pitch roll)
```

Definition at line 103 of file orientation.hh.

7.2.3 Constructor & Destructor Documentation

7.2.3.1 jeod::Orientation::Orientation (void)

Construct an Orientation instance.

All data products are marked as unavailable, the two enum values are set to invalid values, and the composite elements are set to their default values.

Definition at line 69 of file orientation.cc.

References eigen_axis, euler_angles, and trans.

7.2.3.2 jeod::Orientation::Orientation (const double trans_in[3][3]) [explicit]

Construct an Orientation instance from a transformation matrix.

Parameters

in	trans_in	Transformation matrix

Definition at line 94 of file orientation.cc.

References eigen_axis, euler_angles, and trans.

7.2.3.3 jeod::Orientation::Orientation (const Quaternion & quat_in) [explicit]

Construct an Orientation instance from a Quaternion.

Parameters

in	quat_in	Quaternion
----	---------	------------

Definition at line 120 of file orientation.cc.

References eigen axis, euler angles, and trans.

7.2.3.4 jeod::Orientation::Orientation (double eigen angle in, const double eigen axis in[3]) [explicit]

Construct an Orientation instance from an eigen rotation.

Parameters

in	eigen_angle_in	Rotation angle
		Units: r
in	eigen axis in	Rotation axis, unit vector

Definition at line 146 of file orientation.cc.

References eigen_axis, euler_angles, and trans.

7.2.3.5 jeod::Orientation::Orientation (EulerSequence sequence_in, const double angles_in[3]) [explicit]

Construct an Orientation instance from an Euler rotation.

Parameters

in	sequence_in	Euler sequence
in	angles_in	Euler angles
		Units: r

Definition at line 174 of file orientation.cc.

References eigen_axis, euler_angles, and trans.

7.2.3.6 jeod::Orientation::~Orientation (void) [virtual]

Destruct an Orientation instance.

This is intentionally null; this class doesn't allocate resources.

Definition at line 201 of file orientation.cc.

7.2.4 Member Function Documentation

7.2.4.1 void jeod::Orientation::clear_euler_sequence (void)

Reset the euler_sequence data member.

Issues arise if the data source is the Euler rotation sequence. The resolution is to preserve the existing input elsewhere.

Definition at line 906 of file orientation.cc.

References compute_matrix_from_euler_angles(), compute_quaternion_from_euler_angles(), data_source, euler_sequence, have_euler_angles_, have_quaternion_, have_transformation_, InputEulerRotation, InputMatrix, and NoSequence.

Referenced by set_euler_sequence().

7.2.4.2 void jeod::Orientation::compute_all_products (void) [virtual]

Compute all represented charts on SO3 from the specified source.

Definition at line 552 of file orientation.cc.

References compute_eigen_rotation(), compute_euler_angles(), compute_quaternion(), and compute_transform().

7.2.4.3 void jeod::Orientation::compute_eigen_rotation(void) [virtual]

Compute the eigen rotation from the source.

Definition at line 425 of file orientation.cc.

References compute_eigen_rotation_from_matrix(), compute_matrix_from_euler_angles(), data_source, eigen_angle, eigen_axis, have_eigen_rotation_, have_transformation_, InputEigenRotation, InputEulerRotation, InputMatrix, InputNone, InputQuaternion, mark_input_as_available(), and quat.

Referenced by compute_all_products(), and get_eigen_rotation().

7.2.4.4 void jeod::Orientation::compute_eigen_rotation_from_matrix (const double trans[3][3], double * eigen_angle, double eigen_axis[3]) [static]

Compute the eigen rotation from the transformation matrix.

There are several alternate expressions for computing the eigen rotation from a matrix, all of which are equivalent in infinite precision arithmetic. The use of finite precision arithmetic means that care must be taken in choosing the algorithm to be used. The starting point is the generic expression

$$T_{ij} = \cos\phi \, \delta_{ij} + (1 - \cos\phi) \, \hat{u}_i \hat{u}_j + \varepsilon_{ijk} \sin\phi \, \hat{u}_k$$

From this, the trace of the matrix and the difference between and sum of pairs of off-diagonal elements are

$$tr(T) = 2\cos\phi + 1$$

$$T_{ij} - T_{ji} = 2\varepsilon_{ijk}\sin\phi \,\hat{u}_k$$

$$T_{ij} + T_{ji} = 2(1 - \cos\phi) \,\hat{u}_i\hat{u}_j$$

Method 1

One approach to determining the eigen rotation involves the construction of a vector of differences between pairs of off-diagonal elements of the transformation matrix,

$$d_k = T_{ij} - T_{ji} = 2\sin\phi \,\hat{u}_k$$

where (i,j,k) is an even permutation of (0,1,2). With this,

$$\phi = \arcsin\left(\frac{||\mathbf{d}||}{2}\right)$$

$$\hat{\mathbf{u}} = \frac{\mathbf{d}}{||\mathbf{d}||}$$

Note that the above of the inverse sine will restrict the rotation angle to be between 0 and 90 degrees. Special processing is needed when the rotation angle is between 90 and 180 degrees. Note also that the symmetric difference vector will be identically zero if the rotation angle is 0 or 180 degrees and will be very small for rotation angles close to 0 or 180 degrees. The precision loss for rotation angles near 0 and 180 degrees means the individual components of the eigen axis will not be as precise with this approach compared to alternatives.

Method 2

The diagonal elements of the matrix yields another method for determining the single axis rotation angle and the rotation axis:

$$\phi = \arccos\left(\frac{\operatorname{tr}(T) - 1}{2}\right)$$

$$|\hat{u}_i| = \sqrt{\frac{T_{ii} - \cos\phi}{1 - \cos\phi}}$$

Note that this approach determines the magnitudes but not the signs of the components of the eigen axis vector. Because this method is based on the inverse cosine, the calculated phi angle will be less precise than that obtained by method 1 for angles near 0 or 180 degrees. The unit vector however will be more accurate than that obtained from method 1 for small rotation angles.

Method 3

Yet another alternative for computing components of the eigen axis is to use the sum of pairs of off-diagonal elements of the transformation metrix,

$$T_{ij} + T_{ji} = 2(1 - \cos \phi) \hat{u}_i \hat{u}_j$$

$$T_{ik} + T_{ki} = 2(1 - \cos \phi) \hat{u}_i \hat{u}_k$$

This enables the calculation of two components of the unit vector. One component needs to be computed by one of the two previous methods.

Assumptions and Limitations

• The matrix is a proper transformation matrix.

Parameters

in	trans	Transformation matrix
out	eigen_angle	Resultant rotation angle
		Units: r
out	eigen_axis	Resultant rotation axis

Definition at line 203 of file eigen rotation.cc.

7.2.4.5 void jeod::Orientation::compute_eigen_rotation_from_matrix(void) [inline], [protected]

Compute a eigen rotation that corresponds to the provided transformation matrix.

Definition at line 358 of file orientation.hh.

References eigen angle, eigen axis, and trans.

Referenced by compute_eigen_rotation().

7.2.4.6 void jeod::Orientation::compute_euler_angles (void) [virtual]

Compute the eigen rotation from the source.

Definition at line 481 of file orientation.cc.

References compute_euler_angles_from_matrix(), compute_matrix_from_eigen_rotation(), data_source, euler_sequence, EulerXYZ, EulerZYZ, have_euler_angles_, have_transformation_, InputEigenRotation, InputEuler-Rotation, InputMatrix, InputNone, InputQuaternion, jeod::OrientationMessages::invalid_enum, mark_input_as_available(), quat, and trans.

Referenced by compute all products(), and get euler angles().

7.2.4.7 void jeod::Orientation::compute_euler_angles_from_matrix (const double trans[3][3], EulerSequence euler_sequence, double euler_angles[3]) [static]

Extract an Euler sequence from the transformation matrix.

A transformation matrix constructed from an XYZ Euler sequence is of the form

$$\begin{bmatrix} \cos \psi \cos \theta & \cdots & \cdots \\ -\sin \psi \cos \theta & \cdots & \cdots \\ \sin \theta & -\cos \theta \sin \phi & \cos \theta \cos \phi \end{bmatrix}$$

Note that the [2][0] element of the matrix depends on theta only. The other two elements of the leftmost column are simple terms that depend on theta and psi only, and the other two elements of the bottommost row are simple terms that depend on theta and phi only. Those five elements are the key to extracting an XYZ Euler sequence from a transformation matrix. The same principle applies to all twelve of the Euler sequences: Five key elements contain all of the information needed to extract the desired sequence. The location and form of those key elements of course depends on the sequence.

A problem arises in the above when cos(theta) is zero, or nearly so. This situation is called 'gimbal lock'. Those four elements used to determine phi and psi are zero or nearly so. Fortunately That ugly stuff isn't so ugly in the case of gimbal lock. Once again looking at the matrix generated from an XYZ Euler sequence, when theta=pi/2 the matrix becomes

$$\begin{bmatrix} 0 & \sin(\phi + \psi) & -\cos(\phi + \psi) \\ 0 & \cos(\phi + \psi) & \sin(\phi + \psi) \\ 1 & 0 & 0 \end{bmatrix}$$

In this case there no way to determine both phi and psi; all that can be determined is their sum. One way to overcome this problem is to arbitrarily set one of those angles to an arbitrary value such as zero. That is the approach used in this method. This arbitrary setting enables an XYZ Euler sequence to be extracted from the matrix even in the case of gimbal lock. The same principle once again applies to all twelve sequences.

In summary, for a transformation matrix corresponding to an XYZ sequence,

- The [2][0] element of the matrix specifies theta.
- The [1][0] and [0][0] elements of the matrix specify psi.
- The [2][1] and [2][2] elements of the matrix specify phi. These psi and phi values are valid only when gimbal lock is not present.
- The [1][2] and [1][1] elements of the matrix specify phi in the case of gimbal lock.

Extending this analysis to the remaining eleven sequences provides the essential information needed to extract the desired Euler angles from a transformation matrix. This information is captured in the EulerInfo array Euler_info defined at the head of this file. With a reference info to the appropriate element of this array,

- The [info.indices[2]][info.indices[0]] element of the matrix specifies the angle theta.
- The [info.indices[1]][info.indices[0]] and [info.alternate_x][info.indices[0]] elements of the matrix specify the angle psi when gimbal lock is not present.
- The [info.indices[2]][info.indices[1]] and [info.indices[2]][info.alternate_z] elements of the matrix specify the angle phi when gimbal lock is not present.
- The [info.indices[1]][info.alternate_z] and [info.indices[1]][info.indices[1]] elements of the matrix specify angle phi when gimbal lock is present.

Assumptions and Limitations

- To within numerical accuracy, the transformation matrix in the Orientation object is a proper transformation matrix:
 - The magnitude of each row and column vector is nearly one.
 - The inner product of any two different rows / two different columns of the matrix nearly zero.
 - The determinant of the matrix is nearly one.
 - An element whose value is outside the range [-1,1] is only slightly outside that range and the deviation is numerical.

Parameters

in	trans	Transformation matrix
in	euler_sequence	Euler sequence
out	euler_angles	Resultant Euler angles
		Units: r

Definition at line 305 of file euler_angles.cc.

References jeod::EulerInfo::alternate_x, jeod::EulerInfo::alternate_z, jeod::Euler_info, euler_sequence, EulerXYZ, EulerZYZ, gimbal_lock_threshold, jeod::EulerInfo::indices, jeod::OrientationMessages::invalid_enum, jeod::EulerInfo::is_aerodynamics_sequence, and jeod::EulerInfo::is_even_permutation.

7.2.4.8 void jeod::Orientation::compute_euler_angles_from_matrix(void) [inline], [protected]

Compute an Euler rotation sequence that corresponds to the provided transformation matrix.

Definition at line 330 of file orientation.hh.

References euler_angles, euler_sequence, and trans.

Referenced by compute_euler_angles().

7.2.4.9 void jeod::Orientation::compute_matrix_from_eigen_rotation (double eigen_angle, const double eigen_axis[3], double trans[3][3]) [static]

Compute the transformation matrix from the eigen rotation.

Given a rotation by an angle ϕ about an axis $\hat{\mathbf{u}}$, the [i][j] element of the transformation matrix is given by

$$T_{ij} = \cos\phi \, \delta_{ij} + (1 - \cos\phi) \, \hat{u}_i \hat{u}_j + \varepsilon_{ijk} \sin\phi \, \hat{u}_k$$

where

- δ_{ij} is the Kronecker delta,
- $k ext{ is } (i+j) ext{ mod } 3$, and
- ε_{ijk} is the Levi-Civita symbol taken with respect to (0,1,2).

Assumptions and Limitations

The eigen axis is a unit vector.

Parameters

in	eigen_angle	Rotation angle
		Units: r
in	eigen_axis	Rotation axis, unit vector
out	trans	Resultant transformation matrix

Definition at line 82 of file eigen_rotation.cc.

7.2.4.10 void jeod::Orientation::compute_matrix_from_eigen_rotation(void) [inline], [protected]

Compute the transformation matrix that corresponds to the provided eigen rotation.

Definition at line 344 of file orientation.hh.

References eigen_angle, eigen_axis, and trans.

Referenced by compute_euler_angles(), and compute_transform().

7.2.4.11 void jeod::Orientation::compute_matrix_from_euler_angles (EulerSequence euler_sequence, const double euler_angles[3], double trans[3][3]) [static]

Compute the transformation matrix from the Euler sequence.

The matrix is formed by generating a sequence of three simple transformation matrices corresponding to the three rotations. The composite transformation matrix is the reverse-order product of these three simple matrices.

Parameters

in	euler_sequence	Euler sequence
in	euler_angles	Euler angles
		Units: r
out	trans	Resultant transformation matrix

Definition at line 171 of file euler_angles.cc.

References jeod::Euler_info, euler_sequence, EulerXYZ, EulerZYZ, jeod::EulerInfo::indices, and jeod::Orientation-Messages::invalid_enum.

7.2.4.12 void jeod::Orientation::compute_matrix_from_euler_angles (void) [inline], [protected]

Compute the transformation matrix that corresponds to the provided Euler rotation sequence.

Definition at line 316 of file orientation.hh.

References euler_angles, euler_sequence, and trans.

Referenced by clear euler sequence(), compute eigen rotation(), and compute transform().

 $\textbf{7.2.4.13} \quad \textbf{void jeod::Orientation::compute_quaternion (void)} \quad [\texttt{virtual}]$

Compute the left transformation quaternion from the source.

Definition at line 373 of file orientation.cc.

References compute_quaternion_from_euler_angles(), data_source, eigen_angle, eigen_axis, have_quaternion_, InputEigenRotation, InputEulerRotation, InputMatrix, InputNone, InputQuaternion, mark_input_as_available(), quat, and trans.

Referenced by compute_all_products(), compute_transformation_and_quaternion(), and get_quaternion().

7.2.4.14 void jeod::Orientation::compute_quaternion_from_euler_angles (EulerSequence euler_sequence, const double euler_angles[3], Quaternion & quat) [static]

Compute the left transformation quaternion from the Euler sequence.

The quaternion is formed by generating a sequence of three simple quaternions corresponding to the three rotations. The composite quaternion is the reverse-order product of these three simple quaternions.

Parameters

in	euler_sequence	Euler sequence
in	euler_angles	Euler angles
		Units: r
out	quat	Resultant quaternion

Definition at line 126 of file euler_angles.cc.

References jeod::Euler_info, euler_sequence, EulerXYZ, EulerZYZ, jeod::EulerInfo::indices, and jeod::Orientation-Messages::invalid_enum.

7.2.4.15 void jeod::Orientation::compute_quaternion_from_euler_angles (void) [inline], [protected]

Compute the left transformation quaternion that corresponds to the provided Euler rotation sequence.

Definition at line 302 of file orientation.hh.

References euler_angles, euler_sequence, and quat.

Referenced by clear_euler_sequence(), and compute_quaternion().

7.2.4.16 void jeod::Orientation::compute_transform (void) [virtual]

Compute the transformation matrix from the source.

Definition at line 321 of file orientation.cc.

References compute_matrix_from_eigen_rotation(), compute_matrix_from_euler_angles(), data_source, have_transformation_, InputEigenRotation, InputEulerRotation, InputMatrix, InputNone, InputQuaternion, mark_input_as_available(), quat, and trans.

Referenced by compute_all_products(), compute_transformation_and_quaternion(), and get_transform().

7.2.4.17 void jeod::Orientation::compute_transformation_and_quaternion(void) [virtual]

Compute the transformation matrix and quaternion.

Definition at line 569 of file orientation.cc.

References compute_quaternion(), and compute_transform().

7.2.4.18 void jeod::Orientation::get_eigen_rotation (double * eigen_angle_out, double eigen_axis_out[3])

Accessor for the eigen rotation.

Parameters

ſ	011+	oigen angle out	Copy of the single axis rotation angle
	out	eigen_angle_out	Copy of the single axis rotation angle
			Units: r

-			
ſ			
- 1	out	eiden axis olit	Copy of the single axis rotation axis
	Ouc	orgon_axib_bat	Copy of the single axis retation axis

Definition at line 647 of file orientation.cc.

References compute_eigen_rotation(), eigen_angle, eigen_axis, and have_eigen_rotation_.

7.2.4.19 void jeod::Orientation::get_euler_angles (EulerSequence * sequence, double angles[3])

Accessor for the Euler angles.

Parameters

out	sequence	Copy of the Euler sequence
out	angles	Copy of the Euler angles
		Units: r

Definition at line 673 of file orientation.cc.

References compute_euler_angles(), euler_angles, euler_sequence, and have_euler_angles_.

7.2.4.20 void jeod::Orientation::get_euler_angles (double angles[3])

Accessor for the Euler angles.

Parameters

out	angles	Copy of the Euler angles
		Units: r

Definition at line 698 of file orientation.cc.

References compute_euler_angles(), euler_angles, and have_euler_angles_.

7.2.4.21 Orientation::EulerSequence jeod::Orientation::get_euler_sequence (void)

Accessor for the Euler sequence data member.

Returns

Euler sequence data member

Definition at line 721 of file orientation.cc.

References euler sequence.

7.2.4.22 void jeod::Orientation::get_quaternion (Quaternion & quat_out)

Accessor for the left transformation quaternion.

Parameters

out	quat_out	Copy of the quaternion

Definition at line 623 of file orientation.cc.

References compute_quaternion(), have_quaternion_, and quat.

7.2.4.23 void jeod::Orientation::get_transform (double trans_out[3][3])

Accessor for the transformation matrix.

Parameters

out	trans_out	Copy of the transformation matrix
-----	-----------	-----------------------------------

Definition at line 600 of file orientation.cc.

References compute transform(), have transformation, and trans.

7.2.4.24 void jeod::Orientation::mark_input_as_available (void) [protected]

Mark the item specified by the data_source as available.

Note that this method doesn't compute any products.

Assumptions and Limitations

• The data_source member datum is valid.

Definition at line 246 of file orientation.cc.

References data_source, have_eigen_rotation_, have_euler_angles_, have_quaternion_, have_transformation_, InputEigenRotation, InputEulerRotation, InputMatrix, InputNone, InputQuaternion, and jeod::OrientationMessages::invalid enum.

Referenced by compute_eigen_rotation(), compute_euler_angles(), compute_quaternion(), and compute_transform().

7.2.4.25 void jeod::Orientation::reset (void) [virtual]

Forget that we have any data.

Note that this method does not reset the euler_sequence member; that is intentional.

Definition at line 227 of file orientation.cc.

References data_source, have_eigen_rotation_, have_euler_angles_, have_quaternion_, have_transformation_, and InputNone.

Referenced by set_eigen_rotation(), set_euler_angles(), set_quaternion(), and set_transform().

7.2.4.26 void jeod::Orientation::set_eigen_rotation (double eigen_angle_in, const double eigen_axis_in[3])

Reset the instance with a new eigen rotation.

Parameters

in	eigen_angle_in	New single axis rotation angle
in	eigen_axis_in	New single axis rotation axis

Definition at line 783 of file orientation.cc.

References data_source, eigen_angle, eigen_axis, have_eigen_rotation_, InputEigenRotation, and reset().

7.2.4.27 void jeod::Orientation::set_euler_angles (EulerSequence sequence, const double angles[3])

Reset the instance with a new Euler rotation.

Parameters

in	sequence	New Euler sequence
in	angles	New Euler angles
		Units: r

Definition at line 804 of file orientation.cc.

References data_source, euler_angles, euler_sequence, EulerXYZ, EulerZYZ, have_euler_angles_, InputEuler-Rotation, jeod::OrientationMessages::invalid enum, and reset().

7.2.4.28 void jeod::Orientation::set_euler_angles (const double angles[3])

Reset the instance with a new Euler rotation.

Assumptions and Limitations

• The euler_sequence data member must have previously been set to a valid value.

Parameters

in	angles	New Euler angles
		Units: r

Definition at line 840 of file orientation.cc.

References data_source, euler_angles, euler_sequence, EulerXYZ, EulerZYZ, have_euler_angles_, InputEuler-Rotation, jeod::OrientationMessages::invalid_enum, and reset().

7.2.4.29 void jeod::Orientation::set_euler_sequence (EulerSequence sequence)

Set the euler_sequence data member.

Parameters

in	sequence	New Euler sequence

Definition at line 872 of file orientation.cc.

References clear_euler_sequence(), euler_sequence, EulerXYZ, EulerZYZ, have_euler_angles_, and jeod::-OrientationMessages::invalid_enum.

7.2.4.30 void jeod::Orientation::set_quaternion (const Quaternion & quat_in)

Reset the instance with a new quaternion.

Parameters

in	quat_in	New quaternion

Definition at line 764 of file orientation.cc.

References data_source, have_quaternion_, InputQuaternion, quat, and reset().

7.2.4.31 void jeod::Orientation::set_transform (const double trans_in[3][3])

Reset the instance with a new matrix.

Parameters

in	trans_in	New transformation matrix

Definition at line 746 of file orientation.cc.

References data_source, have_transformation_, InputMatrix, reset(), and trans.

7.2.5 Friends And Related Function Documentation

```
7.2.5.1 void init_attrjeod__Orientation( ) [friend]
```

7.2.5.2 friend class InputProcessor [friend]

Definition at line 83 of file orientation.hh.

7.2.6 Field Documentation

7.2.6.1 DataSource jeod::Orientation::data_source

Orientation data source – specifies whether the user has provided as input an Euler rotation, a transformation matrix, or a left transformation quaternion.

trick_units(-)

Definition at line 239 of file orientation.hh.

Referenced by clear_euler_sequence(), compute_eigen_rotation(), compute_euler_angles(), compute_quaternion(), compute_transform(), mark_input_as_available(), reset(), set_eigen_rotation(), set_euler_angles(), set_quaternion(), and set_transform().

7.2.6.2 double jeod::Orientation::eigen_angle

Single axis rotation angle.

trick_units(rad)

Definition at line 265 of file orientation.hh.

Referenced by compute_eigen_rotation(), compute_eigen_rotation_from_matrix(), compute_matrix_from_eigen_rotation(), compute_quaternion(), get_eigen_rotation(), and set_eigen_rotation().

7.2.6.3 double jeod::Orientation::eigen_axis[3]

Single axis rotation axis unit vector.

trick units(-)

Definition at line 270 of file orientation.hh.

Referenced by compute_eigen_rotation(), compute_eigen_rotation_from_matrix(), compute_matrix_from_eigen_rotation(), compute_quaternion(), get_eigen_rotation(), Orientation(), and set_eigen_rotation().

7.2.6.4 double jeod::Orientation::euler_angles[3]

Euler angles corresponding to rotation sequence euler_sequence.

The elements are stored in the order specified by that sequence.trick units(rad)

Definition at line 250 of file orientation.hh.

Referenced by compute_euler_angles_from_matrix(), compute_matrix_from_euler_angles(), compute_quaternion_from_euler_angles(), get_euler_angles(), Orientation(), and set_euler_angles().

7.2.6.5 EulerSequence jeod::Orientation::euler_sequence

The Euler rotation sequence corresponding to euler_angles.

trick units(-)

Definition at line 244 of file orientation.hh.

Referenced by clear_euler_sequence(), compute_euler_angles(), compute_euler_angles_from_matrix(), compute_matrix_from_euler_angles(), compute_quaternion_from_euler_angles(), get_euler_angles(), get_euler_sequence(), set_euler_angles(), and set_euler_sequence().

7.2.6.6 double jeod::Orientation::gimbal_lock_threshold = 1e-13 [static], [protected]

Threshold for detecting gimbal lock in compute euler angles from matrix.

The threshold for determining whether a gimbal lock condition exists.

trick_units(-)

Gimbal lock occurs when sin(theta) (aerodynamics Euler sequences) or cos(theta) (astronomical sequences) is very close to -1 or +1. This static variable quantifies the meaning of 'very close'.

Definition at line 144 of file orientation.hh.

Referenced by compute_euler_angles_from_matrix().

7.2.6.7 bool jeod::Orientation::have_eigen_rotation [protected]

True if eigen rotation has been set/computed.

trick units(-)

Definition at line 287 of file orientation.hh.

Referenced by compute_eigen_rotation(), get_eigen_rotation(), mark_input_as_available(), reset(), and set_eigen_rotation().

7.2.6.8 bool jeod::Orientation::have_euler_angles_ [protected]

True if an Euler rotation has been set/computed.

trick_units(-)

Definition at line 292 of file orientation.hh.

Referenced by clear_euler_sequence(), compute_euler_angles(), get_euler_angles(), mark_input_as_available(), reset(), set_euler_angles(), and set_euler_sequence().

7.2.6.9 bool jeod::Orientation::have_quaternion_ [protected]

True if quaternion has been set/computed.

trick_units(-)

Definition at line 282 of file orientation.hh.

Referenced by clear_euler_sequence(), compute_quaternion(), get_quaternion(), mark_input_as_available(), reset(), and set_quaternion().

7.2.6.10 bool jeod::Orientation::have_transformation_ [protected]

True if transformation matrix has been set/computed.

trick_units(-)

Definition at line 277 of file orientation.hh.

Referenced by clear_euler_sequence(), compute_eigen_rotation(), compute_euler_angles(), compute_transform(), get_transform(), mark_input_as_available(), reset(), and set_transform().

7.2.6.11 Quaternion jeod::Orientation::quat

Left transformation unit quaternion.

trick_units(-)

Definition at line 260 of file orientation.hh.

Referenced by compute_eigen_rotation(), compute_euler_angles(), compute_quaternion(), compute_quaternion_from_euler_angles(), compute_transform(), get_quaternion(), and set_quaternion().

7.2.6.12 double jeod::Orientation::trans[3][3]

Transformation matrix.

trick_units(-)

Definition at line 255 of file orientation.hh.

Referenced by compute_eigen_rotation_from_matrix(), compute_euler_angles(), compute_euler_angles_from_matrix(), compute_matrix_from_eigen_rotation(), compute_matrix_from_euler_angles(), compute_quaternion(), compute_transform(), get_transform(), Orientation(), and set_transform().

The documentation for this class was generated from the following files:

- · orientation.hh
- eigen_rotation.cc
- · euler_angles.cc
- orientation.cc

7.3 jeod::OrientationMessages Class Reference

Declares messages associated with the orientation model.

```
#include <orientation_messages.hh>
```

Static Public Attributes

- static char const * invalid_enum = "utils/orientation/" "invalid_enum"
 - Issued when a enum value is not one of the enumerated values.
- static char const * invalid_data = "utils/orientation/" "invalid_data"

Issued when an orientation specification is invalid.

static char const * invalid_request = "utils/orientation/" "invalid_request"

Issued when an requested is invalid.

Private Member Functions

- OrientationMessages (void)
- OrientationMessages (const OrientationMessages &)
- OrientationMessages & operator= (const OrientationMessages &)

Friends

- · class InputProcessor
- void init_attrjeod__OrientationMessages ()

7.3.1 Detailed Description

Declares messages associated with the orientation model.

Definition at line 83 of file orientation messages.hh.

7.3.2 Constructor & Destructor Documentation

- 7.3.2.1 jeod::OrientationMessages::OrientationMessages (void) [private]
- 7.3.2.2 jeod::OrientationMessages::OrientationMessages (const OrientationMessages &) [private]
- 7.3.3 Member Function Documentation
- 7.3.3.1 OrientationMessages& jeod::OrientationMessages::operator= (const OrientationMessages &) [private]
- 7.3.4 Friends And Related Function Documentation
- 7.3.4.1 void init_attrjeod__OrientationMessages() [friend]
- **7.3.4.2 friend class InputProcessor** [friend]

Definition at line 86 of file orientation_messages.hh.

7.3.5 Field Documentation

7.3.5.1 char const * jeod::OrientationMessages::invalid_data = "utils/orientation/" "invalid_data" [static]

Issued when an orientation specification is invalid.

trick_units(-)

Definition at line 100 of file orientation_messages.hh.

7.3.5.2 char const * jeod::OrientationMessages::invalid_enum = "utils/orientation/" "invalid_enum" [static]

Issued when a enum value is not one of the enumerated values.

trick_units(-)

Definition at line 95 of file orientation messages.hh.

Referenced by jeod::Orientation::compute_euler_angles(), jeod::Orientation::compute_euler_angles_from_matrix(), jeod::Orientation::compute_matrix_from_euler_angles(), jeod::Orientation::compute_quaternion_from_euler_angles(), jeod::Orientation::mark_input_as_available(), jeod::Orientation::set_euler_angles(), and jeod::Orientation::set_euler_angles().

7.3.5.3 char const * jeod::OrientationMessages::invalid_request = "utils/orientation/" "invalid_request" [static]

Issued when an requested is invalid.

trick_units(-)

Definition at line 105 of file orientation_messages.hh.

The documentation for this class was generated from the following files:

- orientation_messages.hh
- orientation_messages.cc



Chapter 8

File Documentation

8.1 eigen_rotation.cc File Reference

Define Orientation methods related to computing single axis rotations.

```
#include <cmath>
#include "utils/math/include/matrix3x3.hh"
#include "utils/math/include/vector3.hh"
#include "../include/orientation.hh"
```

Namespaces

• jeod

Namespace jeod.

8.1.1 Detailed Description

Define Orientation methods related to computing single axis rotations.

Definition in file eigen_rotation.cc.

8.2 euler_angles.cc File Reference

Define Orientation methods related to computing Euler angles.

```
#include <cmath>
#include "utils/math/include/matrix3x3.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/orientation.hh"
#include "../include/orientation_messages.hh"
```

Data Structures

• struct jeod::EulerInfo

Contains data needed to construct a transformation matrix given a sequence of Euler angles and to extract a sequence of Euler angles from a matrix.

38 File Documentation

Namespaces

jeod

Namespace jeod.

Variables

static const EulerInfo jeod::Euler_info [12]
 Contains twelve EulerInfo objects, one per each of the JEOD Euler sequences.

8.2.1 Detailed Description

Define Orientation methods related to computing Euler angles.

Definition in file euler_angles.cc.

8.3 orientation.cc File Reference

Define methods for the NewOrientation class.

```
#include <cmath>
#include "utils/math/include/matrix3x3.hh"
#include "utils/math/include/vector3.hh"
#include "utils/message/include/message_handler.hh"
#include "../include/orientation.hh"
#include "../include/orientation_messages.hh"
```

Namespaces

· jeod

Namespace jeod.

8.3.1 Detailed Description

Define methods for the NewOrientation class.

Definition in file orientation.cc.

8.4 orientation.hh File Reference

Define the Orientation class.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/quaternion/include/quat.hh"
```

Data Structures

class jeod::Orientation

Specifies the orientiation of one reference frame with respect to another.

Namespaces

jeod

Namespace jeod.

8.4.1 Detailed Description

Define the Orientation class.

Definition in file orientation.hh.

8.5 orientation_messages.cc File Reference

Implement the class OrientationMessages.

```
#include "utils/message/include/make_message_code.hh"
#include "../include/orientation_messages.hh"
```

Namespaces

jeod

Namespace jeod.

Macros

#define MAKE_ORIENTATION_MESSAGE_CODE(id) JEOD_MAKE_MESSAGE_CODE(Orientation-Messages, "utils/orientation/", id)

8.5.1 Detailed Description

Implement the class OrientationMessages.

Definition in file orientation_messages.cc.

8.5.2 Macro Definition Documentation

8.5.2.1 #define MAKE_ORIENTATION_MESSAGE_CODE(id) JEOD_MAKE_MESSAGE_CODE(OrientationMessages, "utils/orientation/", id)

Definition at line 38 of file orientation_messages.cc.

8.6 orientation_messages.hh File Reference

Define the class OrientationMessages, the class that specifies the message IDs used in the orientation model.

```
#include "utils/sim_interface/include/jeod_class.hh"
```

40 File Documentation

Data Structures

• class jeod::OrientationMessages

Declares messages associated with the orientation model.

Namespaces

• jeod

Namespace jeod.

8.6.1 Detailed Description

Define the class OrientationMessages, the class that specifies the message IDs used in the orientation model. Definition in file orientation_messages.hh.

Index

\sim Orientation	jeod::Orientation, 20
jeod::Orientation, 21	EulerYXY
	jeod::Orientation, 20
alternate x	EulerYXZ
jeod::EulerInfo, 15	jeod::Orientation, 20
alternate z	EulerYZX
-	
jeod::EulerInfo, 16	jeod::Orientation, 20
	EulerYZY
clear_euler_sequence	jeod::Orientation, 20
jeod::Orientation, 22	EulerZXY
compute_all_products	jeod::Orientation, 20
jeod::Orientation, 22	EulerZXZ
compute_eigen_rotation	jeod::Orientation, 20
jeod::Orientation, 22	EulerZYX
compute_eigen_rotation_from_matrix	
jeod::Orientation, 22, 23	jeod::Orientation, 20
-	EulerZYZ
compute_euler_angles	jeod::Orientation, 20
jeod::Orientation, 24	euler_angles
compute_euler_angles_from_matrix	jeod::Orientation, 31
jeod::Orientation, 24, 25	euler angles.cc, 37
compute_matrix_from_eigen_rotation	Euler info
jeod::Orientation, 25, 26	jeod, 13
compute_matrix_from_euler_angles	euler_sequence
jeod::Orientation, 26	
compute_quaternion	jeod::Orientation, 31
• — •	EulerSequence
jeod::Orientation, 26	jeod::Orientation, 20
compute_quaternion_from_euler_angles	
jeod::Orientation, 26, 27	get_eigen_rotation
compute_transform	jeod::Orientation, 27
jeod::Orientation, 27	get_euler_angles
compute_transformation_and_quaternion	jeod::Orientation, 28
jeod::Orientation, 27	get_euler_sequence
,	jeod::Orientation, 28
data source	get quaternion
jeod::Orientation, 31	- - ·
DataSource	jeod::Orientation, 28
	get_transform
jeod::Orientation, 20	jeod::Orientation, 28
	gimbal_lock_threshold
eigen_angle	jeod::Orientation, 32
jeod::Orientation, 31	
eigen_axis	have_eigen_rotation_
jeod::Orientation, 31	jeod::Orientation, 32
eigen_rotation.cc, 37	have_euler_angles_
EulerXYX	
	jeod::Orientation, 32
jeod::Orientation, 20	have_quaternion_
EulerXYZ	jeod::Orientation, 32
jeod::Orientation, 20	have_transformation_
EulerXZX	jeod::Orientation, 32
jeod::Orientation, 20	
EulerXZY	indices

42 INDEX

jeod::EulerInfo, 16	Yaw_Roll_Pitch, 20
init_attrjeodOrientation	YawPitchRoll, 20
jeod::Orientation, 31	YawRollPitch, 20
init_attrjeodOrientationMessages	jeod::EulerInfo, 15
jeod::OrientationMessages, 34	alternate_x, 15
InputEigenRotation	alternate_z, 16
jeod::Orientation, 20	indices, 16
InputEulerRotation	is_aerodynamics_sequence, 16
jeod::Orientation, 20	is_even_permutation, 16
InputMatrix	jeod::Orientation, 16
jeod::Orientation, 20	∼Orientation, 21
InputNone	clear euler sequence, 22
jeod::Orientation, 20	compute_all_products, 22
InputQuaternion	compute_eigen_rotation, 22
jeod::Orientation, 20	compute_eigen_rotation_from_matrix, 22, 23
InputProcessor	compute_euler_angles, 24
jeod::Orientation, 31	compute_euler_angles_from_matrix, 24, 25
jeod::OrientationMessages, 34	compute_matrix_from_eigen_rotation, 25, 26
invalid_data	. – – – – –
jeod::OrientationMessages, 34	compute_matrix_from_euler_angles, 26
invalid_enum	compute_quaternion, 26
jeod::OrientationMessages, 34	compute_quaternion_from_euler_angles, 26, 27
invalid_request	compute_transform, 27
jeod::OrientationMessages, 34	compute_transformation_and_quaternion, 27
is_aerodynamics_sequence	data_source, 31
jeod::EulerInfo, 16	DataSource, 20
is_even_permutation	eigen_angle, 31
	eigen_axis, 31
jeod::EulerInfo, 16	euler_angles, 31
jeod, 13	euler_sequence, 31
Euler_info, 13	EulerSequence, 20
jeod::Orientation	get_eigen_rotation, 27
EulerXYX, 20	get_euler_angles, 28
EulerXYZ, 20	get_euler_sequence, 28
EulerXZX, 20	get_quaternion, 28
EulerXZY, 20	get_transform, 28
EulerYXY, 20	gimbal_lock_threshold, 32
EulerYXZ, 20	have_eigen_rotation_, 32
EulerYZX, 20	have_euler_angles_, 32
EulerYZY, 20	have_quaternion_, 32
EulerZXY, 20	have_transformation_, 32
EulerZXZ, 20	init attrjeod Orientation, 31
EulerZYX, 20	InputProcessor, 31
EulerZYZ, 20	mark_input_as_available, 29
InputEigenRotation, 20	Orientation, 21
InputEulerRotation, 20	quat, 32
InputMatrix, 20	reset, 29
InputNone, 20	set eigen rotation, 29
InputQuaternion, 20	set_euler_angles, 29, 30
NoSequence, 20	set_euler_sequence, 30
Pitch_Roll_Yaw, 20	set_quaternion, 30
Pitch_Yaw_Roll, 20	set_transform, 30
PitchRollYaw, 20	trans, 33
PitchYawRoll, 20	jeod::OrientationMessages, 33
Roll_Pitch_Yaw, 20	init_attrjeodOrientationMessages, 34
Roll_Yaw_Pitch, 20	InputProcessor, 34
RollPitchYaw, 20	invalid_data, 34
RollYawPitch, 20	invalid_data, 54
Yaw_Pitch_Roll, 20	invalid_endin, 54 invalid_request, 34
14.1_1 1.011_1.011, 20	

operator=, 34 jeod::Orientation, 20 OrientationMessages, 34 mark_input_as_available YawPitchRoll jeod::Orientation, 29 Models, 9 YawRollPitch NoSequence jeod::Orientation, 20 operator= jeod::OrientationMessages, 34 Orientation, 11 jeod::Orientation, 21 orientation.cc, 38 orientation.hh, 38 orientation messages.cc, 39 orientation_messages.hh, 39 OrientationMessages jeod::OrientationMessages, 34 Pitch_Roll_Yaw jeod::Orientation, 20 Pitch_Yaw_Roll jeod::Orientation, 20 PitchRollYaw jeod::Orientation, 20 PitchYawRoll jeod::Orientation, 20 quat jeod::Orientation, 32 reset jeod::Orientation, 29 Roll Pitch Yaw jeod::Orientation, 20 Roll_Yaw_Pitch jeod::Orientation, 20 RollPitchYaw jeod::Orientation, 20 RollYawPitch jeod::Orientation, 20 set_eigen_rotation jeod::Orientation, 29 set euler angles jeod::Orientation, 29, 30 set_euler_sequence jeod::Orientation, 30 set_quaternion jeod::Orientation, 30 set_transform jeod::Orientation, 30 trans jeod::Orientation, 33 Utils, 10 Yaw_Pitch_Roll

Yaw_Roll_Pitch jeod::Orientation, 20 jeod::Orientation, 20 jeod::Orientation, 20