ContactModel 5.0

Generated by Doxygen 1.8.5

Wed Jun 1 2022 12:05:00

Contents

1 Module Index					
	1.1	Module	es	1	
2	Nam	nespace	Index	3	
	2.1	Names	space List	3	
3	Hier	archica	Index	5	
	3.1	Class	Hierarchy	5	
4	Data	Struct	ure Index	7	
	4.1	Data S	tructures	7	
5	File	Index		9	
	5.1	File Lis	st	9	
6	Mod	lule Doo	umentation	11	
	6.1	Model		11	
		6.1.1	Detailed Description	11	
	6.2	Interac	tions	12	
		6.2.1	Detailed Description	12	
	6.3	Contac	xt	13	
		6.3.1	Detailed Description	14	
		6.3.2	Macro Definition Documentation	14	
			6.3.2.1 PATH	14	
7	Nam	nespace	Documentation	15	
	7.1	jeod N	amespace Reference	15	
		7.1.1	Detailed Description	16	
8	Data	Struct	ure Documentation	17	
	8.1	jeod::C	contact Class Reference	17	
		8.1.1	Detailed Description	18	
		8.1.2	Constructor & Destructor Documentation	18	
			8.1.2.1 Contact	18	

iv CONTENTS

		8.1.2.2	~Contact	18
		8.1.2.3	Contact	18
	8.1.3	Member	Function Documentation	18
		8.1.3.1	check_contact	18
		8.1.3.2	find_interaction	19
		8.1.3.3	initialize_contact	19
		8.1.3.4	operator=	19
		8.1.3.5	register_contact	19
		8.1.3.6	register_contact	19
		8.1.3.7	register_contact	20
		8.1.3.8	register_contact	21
		8.1.3.9	register_interaction	21
		8.1.3.10	unique_pair	21
	8.1.4	Friends A	And Related Function Documentation	21
		8.1.4.1	init_attrjeodContact	21
		8.1.4.2	InputProcessor	22
	8.1.5	Field Doo	cumentation	22
		8.1.5.1	active	22
		8.1.5.2	contact_limit_factor	22
		8.1.5.3	contact_pairs	22
		8.1.5.4	dyn_manager	22
		8.1.5.5	pair_interactions	22
8.2	jeod::C	ontactFac	et Class Reference	23
	8.2.1	Detailed	Description	24
	8.2.2	Construc	ctor & Destructor Documentation	24
		8.2.2.1	ContactFacet	24
		8.2.2.2	~ContactFacet	24
		8.2.2.3	ContactFacet	24
	8.2.3	Member	Function Documentation	24
		8.2.3.1	calculate_torque	24
		8.2.3.2	create_pair	24
		8.2.3.3	create_pair	25
		8.2.3.4	create_vehicle_point	25
		8.2.3.5	get_name	25
		8.2.3.6	operator=	25
		8.2.3.7	set_max_dimension	25
	8.2.4	Friends A	And Related Function Documentation	25
		8.2.4.1	init_attrjeodContactFacet	25
		8.2.4.2	InputProcessor	25
	8.2.5	Field Doo	cumentation	25

CONTENTS

		8.2.5.1	active	25
		8.2.5.2	max_dimension	26
		8.2.5.3	normal	26
		8.2.5.4	position	26
		8.2.5.5	surface_type	26
		8.2.5.6	vehicle_body	26
		8.2.5.7	vehicle_point	27
8.3	jeod::C	ContactMe	ssages Class Reference	27
	8.3.1	Detailed	Description	27
	8.3.2	Construc	ctor & Destructor Documentation	28
		8.3.2.1	ContactMessages	28
		8.3.2.2	ContactMessages	28
	8.3.3	Member	Function Documentation	28
		8.3.3.1	operator=	28
	8.3.4	Friends A	And Related Function Documentation	28
		8.3.4.1	init_attrjeodContactMessages	28
		8.3.4.2	InputProcessor	28
	8.3.5	Field Do	cumentation	28
		8.3.5.1	initialization_error	28
		8.3.5.2	initialization_warns	28
		8.3.5.3	pre_initialization_error	28
		8.3.5.4	runtime_error	29
		8.3.5.5	runtime_inform	29
		8.3.5.6	runtime_warns	29
8.4	jeod::C	ontactPair	r Class Reference	29
	8.4.1	Detailed	Description	31
	8.4.2	Construc	ctor & Destructor Documentation	31
		8.4.2.1	ContactPair	31
		8.4.2.2	~ContactPair	31
		8.4.2.3	ContactPair	31
	8.4.3	Member	Function Documentation	31
		8.4.3.1	check_tree	31
		8.4.3.2	get_subject	31
		8.4.3.3	get_target	32
		8.4.3.4	in_contact	32
		8.4.3.5	in_range	32
		8.4.3.6	initialize_pair	32
		8.4.3.7	initialize_relstate	32
		8.4.3.8	is_active	33
		8.4.3.9	is_complete	33

vi CONTENTS

		8.4.3.10	operator=	33
	8.4.4	Friends An	nd Related Function Documentation	33
		8.4.4.1	init_attrjeodContactPair	33
		8.4.4.2	InputProcessor	33
	8.4.5	Field Docu	mentation	33
		8.4.5.1	interaction	33
		8.4.5.2	interaction_distance	33
		8.4.5.3	rel_state	34
		8.4.5.4	subject	34
		8.4.5.5	target	34
8.5	jeod::C	ContactParar	ms Class Reference	34
	8.5.1	Detailed D	escription	35
	8.5.2	Constructo	or & Destructor Documentation	35
		8.5.2.1	ContactParams	35
		8.5.2.2	~ContactParams	35
		8.5.2.3	ContactParams	35
	8.5.3	Member F	unction Documentation	35
		8.5.3.1	operator=	35
	8.5.4	Friends An	nd Related Function Documentation	35
		8.5.4.1	init_attrjeodContactParams	35
		8.5.4.2	InputProcessor	35
8.6	jeod::C	ContactSurfa	ce Class Reference	35
	8.6.1	Detailed D	escription	36
	8.6.2	Constructo	or & Destructor Documentation	37
		8.6.2.1	ContactSurface	37
		8.6.2.2	~ContactSurface	37
		8.6.2.3	ContactSurface	37
	8.6.3	Member F	unction Documentation	37
		8.6.3.1	allocate_array	37
		8.6.3.2	allocate_interaction_facet	37
		8.6.3.3	collect_forces_torques	37
		8.6.3.4	operator=	37
	8.6.4	Friends An	nd Related Function Documentation	38
		8.6.4.1	init_attrjeodContactSurface	38
		8.6.4.2	InputProcessor	38
	8.6.5		mentation	38
		8.6.5.1	contact_facets	38
		8.6.5.2	contact_force	38
		8.6.5.3	contact_torque	38
		8.6.5.4	facets_size	38

CONTENTS vii

jeod::C	ContactSurf	faceFactory Class Reference	38
8.7.1	Detailed I	Description	39
8.7.2	Construc	tor & Destructor Documentation	39
	8.7.2.1	ContactSurfaceFactory	39
	8.7.2.2	~ContactSurfaceFactory	40
	8.7.2.3	ContactSurfaceFactory	40
8.7.3	Member I	Function Documentation	40
	8.7.3.1	add_facet_params	40
	8.7.3.2	create_surface	40
	8.7.3.3	operator=	40
8.7.4	Friends A	And Related Function Documentation	40
	8.7.4.1	init_attrjeodContactSurfaceFactory	40
	8.7.4.2	InputProcessor	40
8.7.5	Field Doo	cumentation	40
	8.7.5.1	line_contact_facet_factory	40
	8.7.5.2	point_contact_facet_factory	41
jeod::C	ContactUtils	s Class Reference	41
8.8.1	Detailed I	Description	41
8.8.2	Member I	Function Documentation	41
	8.8.2.1	copy_const_char_to_char	41
	8.8.2.2	create_relstate_name	42
	8.8.2.3	dist_line_segments	42
jeod::L	ineContact	tFacet Class Reference	43
8.9.1	Detailed I	Description	44
8.9.2	Construc	tor & Destructor Documentation	44
	8.9.2.1	LineContactFacet	44
	8.9.2.2	~LineContactFacet	44
	8.9.2.3	LineContactFacet	44
8.9.3	Member I	Function Documentation	44
	8.9.3.1	calculate_contact_point	44
	8.9.3.2	calculate_torque	44
	8.9.3.3	create_pair	45
	8.9.3.4	create_pair	45
	8.9.3.5	operator=	45
	8.9.3.6	set_max_dimension	45
8.9.4	Friends A	And Related Function Documentation	45
	8.9.4.1	init_attrjeodLineContactFacet	45
	8.9.4.2	InputProcessor	45
8.9.5	Field Doo	cumentation	46
	8.9.5.1	length	46
	8.7.1 8.7.2 8.7.3 8.7.4 8.7.5 jeod::C 8.8.1 8.9.1 8.9.2 8.9.3	8.7.1 Detailed 8.7.2 Construct 8.7.2.1 8.7.2.2 8.7.2.3 8.7.3.1 8.7.3.2 8.7.3.3 8.7.4 Friends A 8.7.4.1 8.7.4.2 8.7.5 Field Doc 8.7.5.1 8.7.5.2 jeod::ContactUtils 8.8.1 Detailed 8.8.2 Member 8.8.2.1 8.8.2.2 8.8.2.3 jeod::LineContact 8.9.1 Detailed 8.9.2 Construct 8.9.1 Detailed 8.9.2 Construct 8.9.2.1 8.9.2.2 8.9.2.3 8.9.3.1 8.9.2.2 8.9.3.3 8.9.3.4 8.9.3.5 8.9.3.6 8.9.4 Friends A 8.9.4.1 8.9.4.2 8.9.5 Field Doc	8.7.2. Constructor & Destructor Documentation 8.7.2.1 ContactSurfaceFactory 8.7.2.2 ~ContactSurfaceFactory 8.7.3.3 Member Function Documentation 8.7.3.1 add_facet_params 8.7.3.2 create_surface 8.7.3.3 operator= 8.7.4.1 init_attrieodContactSurfaceFactory 8.7.4.2 InputProcessor 8.7.5.5 Field Documentation 8.7.5.1 line_contact_facet_factory 8.7.5.2 point_contact_facet_factory jeod::ContactUtils Class Reference 8.8.1 Detailed Description 8.8.2.1 copy_const_char_to_char 8.8.2.2 create_relate_name 8.8.2.3 dist_line_segments jeod::LineContactFacet Class Reference 8.9.1 Detailed Description 8.9.2 Constructor & Destructor Documentation 8.9.2.1 LineContactFacet 8.9.2.2 ~LineContactFacet 8.9.3.1 LineContactFacet 8.9.3.2 calculate_contact_point 8.9.3.3 create_pair 8.9.3.4 create_pair 8.9.3.5 operator= 8.9.3.6 set_max_dimension 8.9.4 Friends And Related Function Documentation 8.9.4.1 init_attrjeod_LineContactFacet 8.9.4.2 InputProcessor

viii CONTENTS

8.10	jeod::Li	neContactFacetFactory Class Reference	16
	8.10.1	Detailed Description	17
	8.10.2	Constructor & Destructor Documentation	17
		8.10.2.1 LineContactFacetFactory	17
		8.10.2.2 ~LineContactFacetFactory	17
		8.10.2.3 LineContactFacetFactory	17
	8.10.3	Member Function Documentation	17
		8.10.3.1 create_facet	17
		8.10.3.2 is_correct_factory	17
		8.10.3.3 operator=	18
	8.10.4	Friends And Related Function Documentation	18
		8.10.4.1 init_attrjeodLineContactFacetFactory	18
		8.10.4.2 InputProcessor	18
8.11	jeod::Li	neContactPair Class Reference	18
	8.11.1	Detailed Description	19
	8.11.2	Constructor & Destructor Documentation	19
		8.11.2.1 LineContactPair	19
		8.11.2.2 ~LineContactPair	19
		8.11.2.3 LineContactPair	19
	8.11.3	Member Function Documentation	19
		8.11.3.1 in_contact	19
		8.11.3.2 initialize_pair	19
		8.11.3.3 operator=	50
	8.11.4	Friends And Related Function Documentation	50
		8.11.4.1 init_attrjeodLineContactPair	50
		8.11.4.2 InputProcessor	50
	8.11.5	Field Documentation	50
		8.11.5.1 line_subject	50
		8.11.5.2 line_target	50
8.12	jeod::Li	nePointContactPair Class Reference	50
	8.12.1	Detailed Description	51
	8.12.2	Constructor & Destructor Documentation	51
		8.12.2.1 LinePointContactPair	51
		8.12.2.2 ~LinePointContactPair	52
		8.12.2.3 LinePointContactPair	52
	8.12.3	Member Function Documentation	52
		8.12.3.1 in_contact	52
		8.12.3.2 initialize_pair	52
		8.12.3.3 operator=	52
	8.12.4	Friends And Related Function Documentation	52

CONTENTS

		8.12.4.1	init_attrjeodLinePointContactPair	. 52
		8.12.4.2	InputProcessor	. 52
	8.12.5	Field Doo	cumentation	. 52
		8.12.5.1	line_subject	. 52
		8.12.5.2	point_target	. 53
8.13	jeod::Pa	airInteracti	ion Class Reference	. 53
	8.13.1	Detailed I	Description	. 54
	8.13.2	Construc	tor & Destructor Documentation	. 54
		8.13.2.1	PairInteraction	. 54
		8.13.2.2	~PairInteraction	. 54
		8.13.2.3	PairInteraction	. 54
	8.13.3	Member I	Function Documentation	. 54
		8.13.3.1	calculate_forces	. 54
		8.13.3.2	is_correct_interaction	. 54
		8.13.3.3	operator=	. 55
	8.13.4	Friends A	And Related Function Documentation	. 55
		8.13.4.1	init_attrjeodPairInteraction	. 55
		8.13.4.2	InputProcessor	. 55
	8.13.5	Field Doo	cumentation	. 55
		8.13.5.1	friction_mag	. 55
		8.13.5.2	params_1	. 55
		8.13.5.3	params_2	. 55
8.14	jeod::Po	ointContac	ctFacet Class Reference	. 56
	8.14.1	Detailed I	Description	. 57
	8.14.2	Construc	tor & Destructor Documentation	. 57
		8.14.2.1	PointContactFacet	. 57
		8.14.2.2	~PointContactFacet	. 57
		8.14.2.3	PointContactFacet	. 57
	8.14.3	Member I	Function Documentation	. 57
		8.14.3.1	calculate_contact_point	. 57
		8.14.3.2	calculate_torque	. 57
		8.14.3.3	create_pair	. 58
		8.14.3.4	create_pair	. 58
		8.14.3.5	operator=	. 58
		8.14.3.6	set_max_dimension	. 58
	8.14.4	Friends A	And Related Function Documentation	. 59
		8.14.4.1	init_attrjeodPointContactFacet	. 59
		8.14.4.2	InputProcessor	. 59
	8.14.5	Field Doo	cumentation	. 59
		8.14.5.1	contact_point	. 59

CONTENTS

		8.14.5.2 radius	59
8.15	jeod::Po	intContactFacetFactory Class Reference	59
	8.15.1	Detailed Description	60
	8.15.2	Constructor & Destructor Documentation	60
		8.15.2.1 PointContactFacetFactory	60
		8.15.2.2 ~PointContactFacetFactory	60
		8.15.2.3 PointContactFacetFactory	61
	8.15.3	Member Function Documentation	61
		8.15.3.1 create_facet	61
		8.15.3.2 is_correct_factory	61
		8.15.3.3 operator=	61
	8.15.4	Friends And Related Function Documentation	61
		8.15.4.1 init_attrjeodPointContactFacetFactory	61
		8.15.4.2 InputProcessor	61
8.16	jeod::Po	intContactPair Class Reference	62
	8.16.1	Detailed Description	62
	8.16.2	Constructor & Destructor Documentation	63
		8.16.2.1 PointContactPair	63
		8.16.2.2 ~PointContactPair	63
		8.16.2.3 PointContactPair	63
	8.16.3	Member Function Documentation	63
		8.16.3.1 in_contact	63
		8.16.3.2 initialize_pair	63
		8.16.3.3 operator=	63
	8.16.4	Friends And Related Function Documentation	63
		8.16.4.1 init_attrjeodPointContactPair	63
		8.16.4.2 InputProcessor	63
	8.16.5	Field Documentation	64
		8.16.5.1 point_subject	64
		8.16.5.2 point_target	64
8.17	jeod::S	oringPairInteraction Class Reference	64
	8.17.1	Detailed Description	65
	8.17.2	Constructor & Destructor Documentation	65
		8.17.2.1 SpringPairInteraction	65
		8.17.2.2 ~SpringPairInteraction	65
		8.17.2.3 SpringPairInteraction	65
	8.17.3	Member Function Documentation	65
		8.17.3.1 calculate_forces	65
		8.17.3.2 operator=	66
	8.17.4	Friends And Related Function Documentation	66

CONTENTS xi

		8.17.4.1 init_attrjeodSpringPairInteraction	66
		8.17.4.2 InputProcessor	66
		8.17.5 Field Documentation	66
		8.17.5.1 damping_b	66
		8.17.5.2 mu	66
		8.17.5.3 spring_k	66
9	File I	Documentation	67
•	9.1	class declarations.hh File Reference	67
	0.1	9.1.1 Detailed Description	67
	9.2	contact.cc File Reference	67
	0.2	9.2.1 Detailed Description	67
	9.3	contact.hh File Reference	68
	0.0	9.3.1 Detailed Description	68
	9.4	contact_facet.cc File Reference	68
	0.1	9.4.1 Detailed Description	69
	9.5	contact_facet.hh File Reference	69
	0.0	9.5.1 Detailed Description	69
	9.6	contact_messages.cc File Reference	69
	0.0	9.6.1 Detailed Description	70
	9.7	contact_messages.hh File Reference	70
	•	9.7.1 Detailed Description	70
	9.8	contact pair.cc File Reference	70
	0.0	9.8.1 Detailed Description	70
	9.9	contact_pair.hh File Reference	71
	0.0	9.9.1 Detailed Description	71
	9.10	contact_params.cc File Reference	71
	0	9.10.1 Detailed Description	71
	9.11	contact_params.hh File Reference	71
		9.11.1 Detailed Description	72
	9.12	contact surface.cc File Reference	72
		9.12.1 Detailed Description	72
	9.13	contact_surface.hh File Reference	72
		9.13.1 Detailed Description	73
	9.14	contact_surface_factory.cc File Reference	73
		9.14.1 Detailed Description	73
	9.15	contact_surface_factory.hh File Reference	73
		9.15.1 Detailed Description	74
	9.16	contact_utils.hh File Reference	74
			74

xii CONTENTS

9	9.17	contact_utils_inline.hh File Reference	74
		9.17.1 Detailed Description	75
9	9.18	line_contact_facet.cc File Reference	75
		9.18.1 Detailed Description	75
9	9.19	line_contact_facet.hh File Reference	75
		9.19.1 Detailed Description	76
9	9.20	line_contact_facet_factory.cc File Reference	76
		9.20.1 Detailed Description	76
9	9.21	line_contact_facet_factory.hh File Reference	76
		9.21.1 Detailed Description	77
9	.22	line_contact_pair.cc File Reference	77
		9.22.1 Detailed Description	77
9	9.23	line_contact_pair.hh File Reference	77
		9.23.1 Detailed Description	78
9	.24	line_point_contact_pair.cc File Reference	78
		9.24.1 Detailed Description	78
9	9.25	line_point_contact_pair.hh File Reference	78
		9.25.1 Detailed Description	79
9	9.26	pair_interaction.cc File Reference	79
		9.26.1 Detailed Description	79
9	9.27	pair_interaction.hh File Reference	79
		9.27.1 Detailed Description	79
9	9.28	point_contact_facet.cc File Reference	80
		9.28.1 Detailed Description	80
9	9.29	point_contact_facet.hh File Reference	80
		9.29.1 Detailed Description	81
g	9.30	point_contact_facet_factory.cc File Reference	81
		9.30.1 Detailed Description	81
g	9.31	point_contact_facet_factory.hh File Reference	81
		9.31.1 Detailed Description	82
9	9.32	point_contact_pair.cc File Reference	82
		9.32.1 Detailed Description	82
9	9.33	point_contact_pair.hh File Reference	82
		9.33.1 Detailed Description	83
9	9.34	spring_pair_interaction.cc File Reference	83
		9.34.1 Detailed Description	83
g	9.35	spring_pair_interaction.hh File Reference	83
		9.35.1 Detailed Description	83

Index 84

Module Index

1.1 Modules

Here	is	а	list	٥f	all	modules
11010	ıo	а	ΠOL	OI.	all	IIIOddics

Models	 																					11
Interactions										 											•	12
Contact	 						 			 										 		13

2 **Module Index**

Namespace Index

2.1	Namespace List
Here	is a list of all namespaces with brief descriptions:
je	od

Namespace Index

Hierarchical Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

eod::Contact	17
eod::ContactMessages	27
eod::ContactPair	29
jeod::LineContactPair	48
jeod::LinePointContactPair	5 0
jeod::PointContactPair	62
eod::ContactUtils	41
jeod::ContactParams	34
nteractionFacet	
jeod::ContactFacet	23
jeod::PointContactFacet	56
jeod::LineContactFacet	43
nteractionFacetFactory	
jeod::LineContactFacetFactory	46
jeod::PointContactFacetFactory	59
nteractionSurface	
jeod::ContactSurface	35
nteractionSurfaceFactory	
jeod::ContactSurfaceFactory	3 8
eod::PairInteraction	53
ieod::SpringPairInteraction	64

6 **Hierarchical Index**

Data Structure Index

4.1 Data Structures

Here are the data structures with brief descriptions:

jeod::Contact	
An base contact class for use in the surface model	17
jeod::ContactFacet	
An contact interaction specific facet for use in the surface model	23
jeod::ContactMessages	
Messages associated with use of the contact model	27
jeod::ContactPair	
An base contact pair class for use in the contact model	29
jeod::ContactParams	
A base class for all contact parameters used in the surface model	34
jeod::ContactSurface	
The contact specific interaction surface, for use with the surface model	35
jeod::ContactSurfaceFactory	0.0
The surface factory that creates an contact specific surface from a general surface	38
jeod::ContactUtils	41
Utility string and math functions for the contact model	4
The contact facet based on the distance to a single point, specifically the vehicle point	43
jeod::LineContactFacetFactory	70
Creates a PointContactFacet from an InteractionFacet	46
jeod::LineContactPair	
An point to point contact pair for use in the contact model	48
jeod::LinePointContactPair	
An point to point contact pair for use in the contact model	50
jeod::PairInteraction	
Simple spring contact parameters	53
jeod::PointContactFacet	
The contact facet based on the distance to a single point, specifically the vehicle point	56
jeod::PointContactFacetFactory	
Creates a PointContactFacet from an InteractionFacet	59
jeod::PointContactPair	
An point to point contact pair for use in the contact model	62
jeod::SpringPairInteraction	
Simple spring contact parameters	64

8 Data Structure Index

File Index

5.1 File List

Here is a list of all files with brief descriptions:

class_declarations.hh	
Forward declaration of classes defined in the contact model	67
contact.cc	
Base Contact for use with contact interaction model	67
contact.hh	
(Base class to for the contact manager for use with contact interaction model)	68
contact_facet.cc	
Define ContactFacet::create_vehicle_point	68
contact_facet.hh	
Individual facets for use with contact interaction models	69
contact_messages.cc	
Implement contact_messages	69
contact_messages.hh	
Contact message for message handling	70
contact_pair.cc	
ContactPair class for use with contact interaction model	70
contact_pair.hh	_
Base class for pair of contact facets for use with contact interaction model	71
contact_params.cc	
Contact parameters for use in the surface model	71
contact_params.hh	
A class for contact facet parameters, used to create interaction facets for contact in the	7-
InteractionSurfaceFactorys	71
contact_surface.cc Vehicle surface model for the contact interaction models	72
	12
contact_surface.hh Vehicle surface model for contact	72
contact surface factory.cc	12
Factory that creates an contact surface, from a surface model	73
contact surface factory.hh	7
Factory that creates an contact interaction surface from a surface model	73
contact utils.hh	, ,
This Model is used for utility rotines	74
contact utils inline.hh	•
Define ContactUtils::create_relstate_name, ContactUtils::copy_const_char_to_char	74
line_contact_facet.cc	-
Define LineContactEacet functions	75

10 File Index

line_contact_tacet.nn	
The contact facet based on the distance to a line segment centered on the vehicle point	75
line_contact_facet_factory.cc	
Factory that creates a LineContactFacetFactory from a Cylinder facet and a ContactParams	
object	76
line_contact_facet_factory.hh	
Creates a line contact facet from an cylinder facet	76
line_contact_pair.cc	
LineContactPair class for use with contact interaction model	77
line_contact_pair.hh	77
Class for a pair of line contact facets for use with contact interaction model	77
line_point_contact_pair.cc	78
LinePointContactPair class for use with contact interaction model	/0
line_point_contact_pair.hh	
Class for a pair of a line contact facet and a point contact facet for use with contact interaction	78
model	70
A class to define the interaction type for a pair of contact facets	79
pair_interaction.hh	73
A class to define the interaction type for a pair of contact facets	79
point contact facet.cc	, 0
Define PointContactFacet functions	80
point contact facet.hh	
The contact facet based on the distance to a single point, specifically the vehicle point	80
point contact facet factory.cc	
Factory that creates a PointContactFacet from a FlatPlateCircular facet and a ContactParams	
object	81
point_contact_facet_factory.hh	
Creates a point contact facet from an circular flat plate facet	81
point_contact_pair.cc	
ContactPair class for use with contact interaction model	82
point_contact_pair.hh	
Class for a pair of point contact facets for use with contact interaction model	82
spring_pair_interaction.cc	
Spring pair interaction for use in the contact model	83
spring_pair_interaction.hh	
A class for pair interactions based on a simple spring	83

Module Documentation

6.1 Models

Modules

- Interactions
- 6.1.1 Detailed Description

12 Module Documentation

6.2 Interactions

Modules

Contact

6.2.1 Detailed Description

6.3 Contact 13

6.3 Contact

Files

· file class declarations.hh

Forward declaration of classes defined in the contact model.

· file contact.hh

(Base class to for the contact manager for use with contact interaction model)

file contact_facet.hh

Individual facets for use with contact interaction models.

· file contact messages.hh

Contact message for message handling.

· file contact pair.hh

Base class for pair of contact facets for use with contact interaction model.

· file contact params.hh

A class for contact facet parameters, used to create interaction facets for contact in the InteractionSurfaceFactorys.

· file contact surface.hh

Vehicle surface model for contact.

· file contact surface factory.hh

Factory that creates an contact interaction surface from a surface model.

· file contact_utils.hh

This Model is used for utility rotines.

· file contact utils inline.hh

Define ContactUtils::create_relstate_name, ContactUtils::copy_const_char_to_char.

file line_contact_facet.hh

The contact facet based on the distance to a line segment centered on the vehicle point.

• file line_contact_facet_factory.hh

Creates a line contact facet from an cylinder facet.

• file line_contact_pair.hh

Class for a pair of line contact facets for use with contact interaction model.

· file line point contact pair.hh

Class for a pair of a line contact facet and a point contact facet for use with contact interaction model.

· file pair_interaction.hh

A class to define the interaction type for a pair of contact facets.

· file point_contact_facet.hh

The contact facet based on the distance to a single point, specifically the vehicle point.

file point_contact_facet_factory.hh

Creates a point contact facet from an circular flat plate facet.

· file point_contact_pair.hh

Class for a pair of point contact facets for use with contact interaction model.

• file spring_pair_interaction.hh

A class for pair interactions based on a simple spring.

· file contact.cc

Base Contact for use with contact interaction model.

· file contact facet.cc

Define ContactFacet::create_vehicle_point.

file contact_messages.cc

Implement contact_messages.

· file contact pair.cc

ContactPair class for use with contact interaction model.

file contact_params.cc

14 Module Documentation

contact parameters for use in the surface model

• file contact_surface.cc

Vehicle surface model for the contact interaction models.

• file contact_surface_factory.cc

Factory that creates an contact surface, from a surface model.

• file line_contact_facet.cc

Define LineContactFacet functions.

• file line_contact_facet_factory.cc

Factory that creates a LineContactFacetFactory from a Cylinder facet and a ContactParams object.

• file line_contact_pair.cc

LineContactPair class for use with contact interaction model.

• file line_point_contact_pair.cc

LinePointContactPair class for use with contact interaction model.

· file pair interaction.cc

A class to define the interaction type for a pair of contact facets.

file point_contact_facet.cc

Define PointContactFacet functions.

• file point_contact_facet_factory.cc

Factory that creates a PointContactFacet from a FlatPlateCircular facet and a ContactParams object.

• file point_contact_pair.cc

ContactPair class for use with contact interaction model.

• file spring_pair_interaction.cc

spring pair interaction for use in the contact model

Namespaces

jeod

Namespace jeod.

Macros

- #define PATH "interactions/contact"
- 6.3.1 Detailed Description
- 6.3.2 Macro Definition Documentation
- 6.3.2.1 #define PATH "interactions/contact"

Definition at line 37 of file contact_messages.cc.

Namespace Documentation

7.1 jeod Namespace Reference

Namespace jeod.

Data Structures

· class Contact

An base contact class for use in the surface model.

· class ContactFacet

An contact interaction specific facet for use in the surface model.

class ContactMessages

Messages associated with use of the contact model.

class ContactPair

An base contact pair class for use in the contact model.

· class ContactParams

A base class for all contact parameters used in the surface model.

class ContactSurface

The contact specific interaction surface, for use with the surface model.

· class ContactSurfaceFactory

The surface factory that creates an contact specific surface from a general surface.

class ContactUtils

Utility string and math functions for the contact model.

class LineContactFacet

The contact facet based on the distance to a single point, specifically the vehicle point.

class LineContactFacetFactory

Creates a PointContactFacet from an InteractionFacet.

class LineContactPair

An point to point contact pair for use in the contact model.

class LinePointContactPair

An point to point contact pair for use in the contact model.

· class PairInteraction

Simple spring contact parameters.

· class PointContactFacet

The contact facet based on the distance to a single point, specifically the vehicle point.

class PointContactFacetFactory

Creates a PointContactFacet from an InteractionFacet.

• class PointContactPair

An point to point contact pair for use in the contact model.

• class SpringPairInteraction

Simple spring contact parameters.

7.1.1 Detailed Description

Namespace jeod.

Data Structure Documentation

8.1 jeod::Contact Class Reference

An base contact class for use in the surface model.

```
#include <contact.hh>
```

Public Member Functions

· Contact ()

Default Constructor.

virtual ∼Contact ()

Destructor.

void register_contact (ContactFacet *facet)

Register one ContactFacet with all inclusive interactions with other registered ContactFacets.

void register_contact (ContactFacet **facets, unsigned int n_facets)

Register an array of ContactFacets with all inclusive interactions with other registered ContactFacets.

void register_contact (ContactFacet *facet1, ContactFacet *facet2)

Register two facets as a pair.

void register_contact (ContactFacet **facets1, unsigned int n_facets1, ContactFacet **facets2, unsigned int n_facets2)

Regiser to arrays of facets and create specific pairs between all of them.

void register_interaction (PairInteraction *interaction)

Register a pair interaction.

virtual PairInteraction * find_interaction (ContactParams *params_1, ContactParams *params_2)

find a PairInteraction baced on a set of ContactParams.

void initialize_contact (DynManager *manager)

Initialize ContactFacets and the mananger by cleaning up the pair list.

bool unique_pair (ContactFacet *facet_1, ContactFacet *facet_2)

Check to see if a pair of facets already exists.

void check_contact ()

iterate through contact pairs list then call the appropriate contact resolution functions

Data Fields

bool active

toggles contact on and off, true=on false=off

double contact_limit_factor

factor determines if contact is limited by a muliple of the maximum dimensions of the facets in a pair.

Protected Attributes

DynManager * dyn_manager

Pointer to the dyn_manager so relstates and be successfully initialized.

JeodPointerList< ContactPair >
 ::type contact_pairs

list of all possible pairings of contact facets registered with this contact class or derived class

- JeodPointerList
 - < PairInteraction >::type pair_interactions

list of all possible pair interaction types

Private Member Functions

- Contact & operator= (const Contact &rhs)
- Contact (const Contact &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__Contact ()

8.1.1 Detailed Description

An base contact class for use in the surface model.

Definition at line 56 of file contact.hh.

8.1.2 Constructor & Destructor Documentation

```
8.1.2.1 jeod::Contact::Contact ( void )
```

Default Constructor.

Definition at line 52 of file contact.cc.

References contact_pairs, and pair_interactions.

```
8.1.2.2 jeod::Contact::\simContact ( void ) [virtual]
```

Destructor.

Definition at line 69 of file contact.cc.

References contact_pairs, and pair_interactions.

```
8.1.2.3 jeod::Contact::Contact ( const Contact & rhs ) [private]
```

8.1.3 Member Function Documentation

8.1.3.1 void jeod::Contact::check_contact (void)

iterate through contact pairs list then call the appropriate contact resolution functions

Definition at line 97 of file contact.cc.

References active, and contact_pairs.

8.1.3.2 PairInteraction * jeod::Contact::find_interaction (ContactParams * params_1, ContactParams * params_2)

[virtual]

find a PairInteraction baced on a set of ContactParams.

Returns

pointer to a PairInteraction

Parameters

in	params_1	ContactParams from a ContactFacet
in	params_2	ContactParams from a ContactFacet

Definition at line 281 of file contact.cc.

References pair interactions.

Referenced by jeod::LineContactFacet::create_pair(), and jeod::PointContactFacet::create_pair().

8.1.3.3 void jeod::Contact::initialize_contact (DynManager * manager)

Initialize ContactFacets and the mananger by cleaning up the pair list.

Parameters

in,out	manager	Dynamics Manager

Definition at line 119 of file contact.cc.

References contact_pairs, jeod::ContactFacet::create_pair(), dyn_manager, jeod::ContactPair::get_subject(), jeod::ContactPair::initialize_relstate(), and unique_pair().

- 8.1.3.4 Contact& jeod::Contact::operator=(const Contact & rhs) [private]
- 8.1.3.5 void jeod::Contact::register_contact (ContactFacet * facet)

Register one ContactFacet with all inclusive interactions with other registered ContactFacets.

Parameters

in,out	facet	ContactFacet

Definition at line 178 of file contact.cc.

References contact_pairs, and jeod::ContactFacet::create_pair().

Referenced by register_contact().

8.1.3.6 void jeod::Contact::register_contact (ContactFacet ** facets, unsigned int nFacets)

Register an array of ContactFacets with all inclusive interactions with other registered ContactFacets.

Parameters

in,out	facets	array of ContactFacets
in	nFacets	number of ContactFacets in array

Definition at line 199 of file contact.cc.

References register_contact().

8.1.3.7 void jeod::Contact::register_contact (ContactFacet * facet1, ContactFacet * facet2)

Register two facets as a pair.

Parameters

in,out	facet1	Contact Facet 1
in,out	facet2	Contact Facet 2

Definition at line 217 of file contact.cc.

References contact_pairs, jeod::ContactFacet::create_pair(), and dyn_manager.

8.1.3.8 void jeod::Contact::register_contact (ContactFacet ** facets1, unsigned int nFacets1, ContactFacet ** facets2, unsigned int nFacets2)

Regiser to arrays of facets and create specific pairs between all of them.

Parameters

in,out	facets1	array of ContactFacets
in	nFacets1	number of ContactFacets in array
in,out	facets2	array of ContactFacets
in	nFacets2	number of ContactFacets in array

Definition at line 244 of file contact.cc.

References register_contact().

8.1.3.9 void jeod::Contact::register_interaction (PairInteraction * interaction)

Register a pair interaction.

Parameters

in	interaction	PairInteraction to add to list

Definition at line 266 of file contact.cc.

References pair_interactions.

8.1.3.10 bool jeod::Contact::unique_pair (ContactFacet * facet_1, ContactFacet * facet_2)

Check to see if a pair of facets already exists.

Returns

bool

Parameters

in	,out	facet_1	ContactFacet
in	,out	facet_2	ContactFacet

Definition at line 155 of file contact.cc.

References contact_pairs.

Referenced by initialize_contact().

8.1.4 Friends And Related Function Documentation

8.1.4.1 void init_attrjeod__Contact() [friend]

8.1.4.2 friend class InputProcessor [friend]

Definition at line 58 of file contact.hh.

8.1.5 Field Documentation

8.1.5.1 bool jeod::Contact::active

toggles contact on and off, true=on false=off

trick_units(-)

Definition at line 64 of file contact.hh.

Referenced by check_contact().

8.1.5.2 double jeod::Contact::contact_limit_factor

factor determines if contact is limited by a muliple of the maximum dimensions of the facets in a pair.

trick units(-)

Definition at line 70 of file contact.hh.

Referenced by jeod::LineContactFacet::create pair(), and jeod::PointContactFacet::create pair().

8.1.5.3 JeodPointerList < ContactPair > ::type jeod::Contact::contact_pairs [protected]

list of all possible pairings of contact facets registered with this contact class or derived class

trick_io(**)

Definition at line 129 of file contact.hh.

Referenced by check contact(), Contact(), initialize contact(), register contact(), unique pair(), and ~Contact().

8.1.5.4 DynManager* jeod::Contact::dyn_manager [protected]

Pointer to the dyn_manager so relstates and be successfully initialized.

trick units(-)

Definition at line 123 of file contact.hh.

Referenced by initialize_contact(), and register_contact().

8.1.5.5 JeodPointerList<PairInteraction>::type jeod::Contact::pair_interactions [protected]

list of all possible pair interaction types

trick_io(**)

Definition at line 134 of file contact.hh.

Referenced by Contact(), find_interaction(), register_interaction(), and ~Contact().

The documentation for this class was generated from the following files:


- · contact.hh
- contact.cc

8.2 jeod::ContactFacet Class Reference

An contact interaction specific facet for use in the surface model.

#include <contact_facet.hh>

Inheritance diagram for jeod::ContactFacet:



Public Member Functions

· ContactFacet ()

Default constructor.

virtual ∼ContactFacet ()

Destructor.

void create_vehicle_point (void)

Create a vehicle point to track the state information of the contact facet.

virtual void set max dimension (void)=0

Calculate the max dimension of the facet for range limit determination.

const char * get_name (void) const

Accessor for name.

virtual void calculate_torque (double *tmp_force)=0

Calculate the torque acting on the facet in the vehicle structural frame.

virtual ContactPair * create_pair (void)=0

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

virtual ContactPair * create_pair (ContactFacet *target, Contact *contact)=0

Overloaded functions that creates a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

Data Fields

· bool active

toggles this contact facet on and off, true=on false=off

ContactParams * surface_type

Stores the name of surface material that the facet is constructed of.

DynBody * vehicle body

DynBody associated with this facet for structural frame information.

• double max_dimension

maximum dimension of the contact facet for use in limiting pair in_contact calls

· double position [3]

position of the facet in vehicle structural frame.

double normal [3]

normal of the facet relative to the vehicle structural frame.

const BodyRefFrame * vehicle_point

Vehicle point for relstate calculations.

Private Member Functions

- ContactFacet & operator= (const ContactFacet &rhs)
- ContactFacet (const ContactFacet &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__ContactFacet ()

8.2.1 Detailed Description

An contact interaction specific facet for use in the surface model.

Definition at line 50 of file contact_facet.hh.

8.2.2 Constructor & Destructor Documentation

```
8.2.2.1 jeod::ContactFacet::ContactFacet ( void )
```

Default constructor.

Definition at line 49 of file contact_facet.cc.

References normal, and position.

```
8.2.2.2 jeod::ContactFacet::~ContactFacet(void) [virtual]
```

Destructor.

Definition at line 65 of file contact_facet.cc.

```
8.2.2.3 jeod::ContactFacet::ContactFacet ( const ContactFacet & rhs ) [private]
```

8.2.3 Member Function Documentation

```
8.2.3.1 virtual void jeod::ContactFacet::calculate_torque( double * tmp_force ) [pure virtual]
```

Calculate the torque acting on the facet in the vehicle structural frame.

Implemented in jeod::PointContactFacet, and jeod::LineContactFacet.

 $Referenced \ by \ jeod:: SpringPairInteraction:: calculate_forces().$

```
8.2.3.2 virtual ContactPair* jeod::ContactFacet::create_pair( void ) [pure virtual]
```

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

This function is called to create a pair that only contains a subject.

Implemented in jeod::PointContactFacet, and jeod::LineContactFacet.

Referenced by jeod::Contact::initialize_contact(), and jeod::Contact::register_contact().

```
8.2.3.3 virtual ContactPair* jeod::ContactFacet::create_pair ( ContactFacet * target, Contact * contact ) [pure virtual]
```

Overloaded functions that creates a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

This function is called when a subject and target are known.

Implemented in jeod::PointContactFacet, and jeod::LineContactFacet.

```
8.2.3.4 void jeod::ContactFacet::create_vehicle_point ( void )
```

Create a vehicle point to track the state information of the contact facet.

Create a vehicle point from the base facet position and orientation and store the created vehicle point in the contact facet.

Definition at line 78 of file contact_facet.cc.

References get_name(), normal, position, vehicle_body, and vehicle_point.

Referenced by jeod::LineContactFacetFactory::create_facet(), and jeod::PointContactFacetFactory::create_facet().

```
8.2.3.5 const char * jeod::ContactFacet::get_name( void ) const [inline]
```

Accessor for name.

Returns

Point name

Definition at line 153 of file contact_facet.hh.

Referenced by create_vehicle_point().

```
8.2.3.6 ContactFacet& jeod::ContactFacet::operator=( const ContactFacet & rhs ) [private]
```

```
8.2.3.7 virtual void jeod::ContactFacet::set_max_dimension( void ) [pure virtual]
```

Calculate the max dimension of the facet for range limit determination.

Implemented in jeod::PointContactFacet, and jeod::LineContactFacet.

8.2.4 Friends And Related Function Documentation

```
8.2.4.1 void init_attrjeod__ContactFacet( ) [friend]
```

8.2.4.2 friend class InputProcessor [friend]

Definition at line 52 of file contact facet.hh.

8.2.5 Field Documentation

8.2.5.1 bool jeod::ContactFacet::active

toggles this contact facet on and off, true=on false=off

trick_units(-)

Definition at line 58 of file contact facet.hh.

Referenced by jeod::ContactPair::is_active().

8.2.5.2 double jeod::ContactFacet::max_dimension

maximum dimension of the contact facet for use in limiting pair in_contact calls

trick units(m)

Definition at line 75 of file contact_facet.hh.

Referenced by jeod::LineContactFacet::create_pair(), jeod::PointContactFacet::create_pair(), jeod::LineContactFacet::set max dimension(), and jeod::PointContactFacet::set max dimension().

8.2.5.3 double jeod::ContactFacet::normal[3]

normal of the facet relative to the vehicle structural frame.

trick_units(-)

Definition at line 85 of file contact facet.hh.

Referenced by ContactFacet(), jeod::PointContactFacetFactory::create_facet(), jeod::LineContactFacetFactory::create_facet(), and create vehicle point().

8.2.5.4 double jeod::ContactFacet::position[3]

position of the facet in vehicle structural frame.

trick units(m)

Definition at line 80 of file contact facet.hh.

Referenced by ContactFacet(), $jeod::PointContactFacetFactory::create_facet()$, $jeod::LineContactFacetFactory::create_facet()$, and $create_vehicle_point()$.

8.2.5.5 ContactParams* jeod::ContactFacet::surface_type

Stores the name of surface material that the facet is constructed of.

This information is used to deturmine the contact parameters used when pairs are constructed.trick_units(-)

Definition at line 65 of file contact_facet.hh.

Referenced by jeod::LineContactFacetFactory::create_facet(), jeod::PointContactFacetFactory::create_facet(), jeod::LineContactFacet::create_pair(), and jeod::PointContactFacet::create_pair().

8.2.5.6 DynBody* jeod::ContactFacet::vehicle_body

DynBody associated with this facet for structural frame information.

trick_units(-)

Definition at line 70 of file contact_facet.hh.

Referenced by jeod::SpringPairInteraction::calculate_forces(), jeod::LineContactFacet::calculate_torque(), jeod::PointContactFacet::calculate_torque(), jeod::LineContactFacetFactory::create_facet(), jeod::PointContactFacetFactory::create_facet(), create_vehicle_point(), and jeod::ContactPair::initialize_relstate().

8.2.5.7 const BodyRefFrame* jeod::ContactFacet::vehicle_point

Vehicle point for relstate calculations.

trick_units(-)

Definition at line 90 of file contact facet.hh.

Referenced by jeod::SpringPairInteraction::calculate_forces(), jeod::LineContactFacet::calculate_torque(), jeod::PointContactFacet::calculate_torque(), create_vehicle_point(), jeod::PointContactPair::initialize_pair(), jeod::LineContactPair::initialize_pair(), and jeod::LinePointContactPair::initialize_pair().

The documentation for this class was generated from the following files:

- · contact_facet.hh
- · contact facet.cc

8.3 jeod::ContactMessages Class Reference

Messages associated with use of the contact model.

```
#include <contact_messages.hh>
```

Static Public Attributes

• static char const * initialization_error

Associated with errors during initialization of the contact model.

static char const * runtime_error

Associated with errors during the runtime of the contact model.

static char const * pre_initialization_error

Associated with errors during the setup of the system, before runtime.

• static char const * initialization_warns

Associated with warning during initialization of the contact model.

static char const * runtime_warns

Associated with warnings given at runtime.

• static char const * runtime_inform

Associated with information given at runtime.

Private Member Functions

- ContactMessages (void)
- ContactMessages (const ContactMessages &rhs)
- ContactMessages & operator= (const ContactMessages &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__ContactMessages ()

8.3.1 Detailed Description

Messages associated with use of the contact model.

Definition at line 50 of file contact_messages.hh.

8.3.2 Constructor & Destructor Documentation

```
8.3.2.1 jeod::ContactMessages::ContactMessages ( void ) [private]
```

- **8.3.2.2** jeod::ContactMessages::ContactMessages (const ContactMessages & rhs) [private]
- 8.3.3 Member Function Documentation
- 8.3.3.1 ContactMessages& jeod::ContactMessages::operator=(const ContactMessages & rhs) [private]
- 8.3.4 Friends And Related Function Documentation

```
8.3.4.1 void init_attrjeod__ContactMessages() [friend]
```

8.3.4.2 friend class InputProcessor [friend]

Definition at line 53 of file contact messages.hh.

8.3.5 Field Documentation

8.3.5.1 char const * jeod::ContactMessages::initialization_error [static]

Initial value:

```
"interactions/contact" "initialization_error"
```

Associated with errors during initialization of the contact model.

```
trick units(-)
```

Definition at line 64 of file contact_messages.hh.

Referenced by jeod::ContactSurface::allocate_array(), jeod::ContactSurface::allocate_interaction_facet(), jeod::ContactSurface::allocate_interaction_facet(), jeod::ContactFacetFactory::create_facet(), and jeod::ContactSurfaceFactory::create_surface().

```
8.3.5.2 char const * jeod::ContactMessages::initialization_warns [static]
```

Initial value:

```
"interactions/contact" "initialization_warns"
```

Associated with warning during initialization of the contact model.

```
trick units(-)
```

Definition at line 79 of file contact_messages.hh.

Referenced by jeod::LineContactFacet::create_pair(), and jeod::PointContactFacet::create_pair().

8.3.5.3 char const * jeod::ContactMessages::pre_initialization_error [static]

Initial value:

```
"interactions/contact" "pre_initialization_error"
```

Associated with errors during the setup of the system, before runtime.

```
trick units(-)
```

Definition at line 72 of file contact_messages.hh.

Referenced by jeod::ContactSurfaceFactory::add_facet_params().

8.3.5.4 char const * jeod::ContactMessages::runtime_error [static]

Initial value:

```
"interactions/contact" "runtime_error"
```

Associated with errors during the runtime of the contact model.

```
trick_units(-)
```

Definition at line 68 of file contact_messages.hh.

8.3.5.5 char const * jeod::ContactMessages::runtime_inform [static]

Initial value:

```
=
    "interactions/contact"    "runtime_warns"
```

Associated with information given at runtime.

```
trick_units(-)
```

Definition at line 90 of file contact_messages.hh.

8.3.5.6 char const * jeod::ContactMessages::runtime_warns [static]

Initial value:

```
"interactions/contact" "runtime_warns"
```

Associated with warnings given at runtime.

```
trick units(-)
```

Definition at line 83 of file contact_messages.hh.

The documentation for this class was generated from the following files:


- contact_messages.hh
- contact_messages.cc

8.4 jeod::ContactPair Class Reference

An base contact pair class for use in the contact model.

```
#include <contact_pair.hh>
```

Inheritance diagram for jeod::ContactPair:



Public Member Functions

· ContactPair ()

Default Constructor.

virtual ~ContactPair ()

Destructor.

• bool in_range ()

test whether the pair is in range for interaction

• bool is active ()

Determine if contact can occur between the two facets.

bool is_complete (void)

Determine if the pair has a target facet.

ContactFacet * get subject (void)

Determine if the pair has a target facet.

ContactFacet * get_target (void)

Determine if the pair has a target facet.

• virtual void in contact (void)=0

Virtual funtion to determine if the pair is in contact.

- virtual void initialize_pair (ContactFacet *subject_facet, ContactFacet *target_facet)=0
 - Initialize the contact pair by setting the subject, target, and creating the relstate if possible.
- virtual void initialize_relstate (DynManager *dyn_manager)

Initialize the relative state between the facets and register with the dynamics manager.

virtual bool check_tree ()

Make sure the two contact facets are not on the same mass tree.

Data Fields

• PairInteraction * interaction

Parameters that define the force calculation function between the subjec and target.

· double interaction_distance

rel_state distance at which in_contact should be called

Protected Attributes

• RelativeDerivedState rel_state

Current relative state between the subject and the target in the subject frame.

ContactFacet * subject

pointer to the contact facet that is the subject of the associated relative states.

ContactFacet * target

pointer to the contact facet that is the target of the associated relative states.

Private Member Functions

- ContactPair & operator= (const ContactPair &rhs)
- ContactPair (const ContactPair &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__ContactPair ()

8.4.1 Detailed Description

An base contact pair class for use in the contact model.

Definition at line 49 of file contact pair.hh.

8.4.2 Constructor & Destructor Documentation

```
8.4.2.1 jeod::ContactPair::ContactPair ( void )
```

Default Constructor.

Definition at line 45 of file contact_pair.cc.

```
8.4.2.2 jeod::ContactPair::~ContactPair(void) [virtual]
```

Destructor.

Definition at line 60 of file contact_pair.cc.

```
8.4.2.3 jeod::ContactPair::ContactPair ( const ContactPair & rhs ) [private]
```

8.4.3 Member Function Documentation

```
8.4.3.1 bool jeod::ContactPair::check_tree(void) [virtual]
```

Make sure the two contact facets are not on the same mass tree.

Returns

bool

Definition at line 136 of file contact_pair.cc.

References subject, and target.

Referenced by is_active().

8.4.3.2 ContactFacet * jeod::ContactPair::get_subject (void)

Determine if the pair has a target facet.

Returns

subject ContactFacet

Definition at line 114 of file contact_pair.cc.

References subject.

Referenced by jeod::Contact::initialize_contact().

8.4.3.3 ContactFacet * jeod::ContactPair::get_target (void)

Determine if the pair has a target facet.

Returns

target ContactFacet

Definition at line 125 of file contact_pair.cc.

References target.

8.4.3.4 virtual void jeod::ContactPair::in_contact(void) [pure virtual]

Virtual funtion to determine if the pair is in contact.

Contact depends on specific geometry so implementation has to wait for a derived class.

Implemented in jeod::LinePointContactPair, jeod::LineContactPair, and jeod::PointContactPair.

8.4.3.5 bool jeod::ContactPair::in_range (void)

test whether the pair is in range for interaction

Returns

bool

Definition at line 71 of file contact_pair.cc.

References interaction_distance, and rel_state.

8.4.3.6 virtual void jeod::ContactPair::initialize_pair (ContactFacet * subject_facet, ContactFacet * target_facet)

[pure virtual]

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Parameters

in,out	subject_facet	subject ContactFacet
in,out	target_facet	target ContactFacet

Implemented in jeod::LinePointContactPair, jeod::LineContactPair, and jeod::PointContactPair.

8.4.3.7 void jeod::ContactPair::initialize_relstate (DynManager * dyn_manager) [virtual]

Initialize the relative state between the facets and register with the dynamics manager.

Initialize the relstate using the DynManager provided by Contact class.

Parameters

in	dyn_manager	dynamics manager

Definition at line 158 of file contact_pair.cc.

References rel_state, subject, and jeod::ContactFacet::vehicle_body.

Referenced by jeod::Contact::initialize_contact().

```
8.4.3.8 bool jeod::ContactPair::is_active ( void )
Determine if contact can occur between the two facets.
Returns
      bool
Definition at line 86 of file contact_pair.cc.
References jeod::ContactFacet::active, check tree(), subject, and target.
8.4.3.9 bool jeod::ContactPair::is_complete ( void )
Determine if the pair has a target facet.
Returns
      bool
Definition at line 100 of file contact pair.cc.
References target.
8.4.3.10 ContactPair& jeod::ContactPair::operator=( const ContactPair & rhs ) [private]
8.4.4 Friends And Related Function Documentation
8.4.4.1 void init_attrjeod__ContactPair( ) [friend]
8.4.4.2 friend class InputProcessor [friend]
Definition at line 51 of file contact_pair.hh.
8.4.5 Field Documentation
8.4.5.1 PairInteraction* jeod::ContactPair::interaction
Parameters that define the force calculation function between the subjec and target.
trick_units(-)
Definition at line 57 of file contact_pair.hh.
Referenced by jeod::LineContactFacet::create_pair(), jeod::PointContactFacet::create_pair(), jeod::LineContact-
Pair::in_contact(), jeod::PointContactPair::in_contact(), and jeod::LinePointContactPair::in_contact().
8.4.5.2 double jeod::ContactPair::interaction_distance
rel_state distance at which in_contact should be called
trick units(m)
Definition at line 62 of file contact_pair.hh.
```

Referenced by jeod::LineContactFacet::create_pair(), jeod::PointContactFacet::create_pair(), and in_range().

8.4.5.3 RelativeDerivedState jeod::ContactPair::rel_state [protected]

Current relative state between the subject and the target in the subject frame.

trick units(-)

Definition at line 119 of file contact pair.hh.

Referenced by jeod::LineContactPair::in_contact(), jeod::PointContactPair::in_contact(), jeod::LinePointContactPair::in_contact(), jeod::LinePointContactPair::initialize_pair(), jeod::PointContactPair::initialize_pair(), jeod::LinePointContactPair::initialize_pair(), jeod::LinePointContactPair::LinePointContactPair::LinePointContactPair::LinePointContactPair::LinePointContactPair::LinePointContactP

8.4.5.4 ContactFacet* jeod::ContactPair::subject [protected]

pointer to the contact facet that is the subject of the associated relative states.

trick_units(-)

Definition at line 124 of file contact_pair.hh.

Referenced by check_tree(), get_subject(), jeod::LineContactPair::initialize_pair(), jeod::PointContactPair::initialize_pair(), jeod::LinePointContactPair::initialize_pair(), initialize_relstate(), and is_active().

8.4.5.5 ContactFacet* jeod::ContactPair::target [protected]

pointer to the contact facet that is the target of the associated relative states.

trick_units(-)

Definition at line 129 of file contact_pair.hh.

Referenced by check_tree(), get_target(), jeod::LineContactPair::initialize_pair(), jeod::PointContactPair::initialize_pair(), jeod::LinePointContactPair::initialize_pair(), is_active(), and is_complete().

The documentation for this class was generated from the following files:


- · contact pair.hh
- contact_pair.cc

8.5 jeod::ContactParams Class Reference

A base class for all contact parameters used in the surface model.

```
#include <contact_params.hh>
```

Inheritance diagram for jeod::ContactParams:



Public Member Functions

• ContactParams ()

Default Constructor.

virtual ∼ContactParams ()

Destructor.

Private Member Functions

- ContactParams & operator= (const ContactParams &rhs)
- ContactParams (const ContactParams &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__ContactParams ()

8.5.1 Detailed Description

A base class for all contact parameters used in the surface model.

Definition at line 46 of file contact_params.hh.

8.5.2 Constructor & Destructor Documentation

```
8.5.2.1 jeod::ContactParams::ContactParams ( void )
```

Default Constructor.

Definition at line 43 of file contact params.cc.

```
8.5.2.2 jeod::ContactParams::~ContactParams(void) [virtual]
```

Destructor.

Definition at line 54 of file contact_params.cc.

```
8.5.2.3 jeod::ContactParams::ContactParams ( const ContactParams & rhs ) [private]
```

8.5.3 Member Function Documentation

8.5.3.1 ContactParams& jeod::ContactParams::operator=(const ContactParams & rhs) [private]

8.5.4 Friends And Related Function Documentation

```
8.5.4.1 void init_attrjeod__ContactParams() [friend]
```

```
8.5.4.2 friend class InputProcessor [friend]
```

Definition at line 49 of file contact_params.hh.

The documentation for this class was generated from the following files:


- · contact_params.hh
- · contact_params.cc

8.6 jeod::ContactSurface Class Reference

The contact specific interaction surface, for use with the surface model.

```
#include <contact_surface.hh>
```

Inheritance diagram for jeod::ContactSurface:



Public Member Functions

· ContactSurface ()

Default Constructor.

virtual ∼ContactSurface ()

Destructor.

virtual void allocate_array (unsigned int size)

Allocates an array of ContactFacet pointers, of the size indicated by the input variable.

virtual void allocate_interaction_facet (Facet *facet, InteractionFacetFactory *factory, FacetParams *params, unsigned int index)

Creates an interaction facet or more accurately a contact facet from a basic facet and set of parameters.

virtual void collect_forces_torques (void)

collect the forces and torques from all the facets in this contact surface

Data Fields

ContactFacet ** contact_facets

An array of pointers to contact interaction facets.

• unsigned int facets_size

Size of the contact_facets array.

double contact_force [3]

Total Force due to contact, resulting from all plates combined.

• double contact_torque [3]

Total Torque due to contact, resulting from all plates combined.

Private Member Functions

- ContactSurface & operator= (const ContactSurface &rhs)
- ContactSurface (const ContactSurface &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__ContactSurface ()

8.6.1 Detailed Description

The contact specific interaction surface, for use with the surface model.

Definition at line 49 of file contact_surface.hh.

8.6.2 Constructor & Destructor Documentation

8.6.2.1 jeod::ContactSurface::ContactSurface (void)

Default Constructor.

Definition at line 59 of file contact_surface.cc.

8.6.2.2 jeod::ContactSurface::~ContactSurface(void) [virtual]

Destructor.

Definition at line 73 of file contact surface.cc.

References contact_facets, and facets_size.

8.6.2.3 jeod::ContactSurface::ContactSurface (const ContactSurface & rhs) [private]

8.6.3 Member Function Documentation

8.6.3.1 void jeod::ContactSurface::allocate_array (unsigned int size) [virtual]

Allocates an array of ContactFacet pointers, of the size indicated by the input variable.

Parameters

in	size	The size of the needed array
		Units: cnt:

Definition at line 99 of file contact_surface.cc.

References contact_facets, facets_size, and jeod::ContactMessages::initialization_error.

8.6.3.2 void jeod::ContactSurface::allocate_interaction_facet (Facet * facet, InteractionFacetFactory * factory, FacetParams * params, unsigned int index) [virtual]

Creates an interaction facet or more accurately a contact facet from a basic facet and set of parameters.

Parameters

in	facet	The basic facet used to create the interaction facet
in	factory	The factory used to create the interaction facet
in	params	The contact params used to create the interaction facet
in	index	Where the new interaction facet will be placed in the contact_facets array
		Units: cnt

Definition at line 137 of file contact_surface.cc.

References contact_facets, facets_size, and jeod::ContactMessages::initialization_error.

8.6.3.3 void jeod::ContactSurface::collect_forces_torques (void) [virtual]

collect the forces and torques from all the facets in this contact surface

Definition at line 214 of file contact surface.cc.

References contact_facets, contact_force, contact_torque, and facets_size.

8.6.3.4 ContactSurface& jeod::ContactSurface::operator=(const ContactSurface & rhs) [private]

8.6.4 Friends And Related Function Documentation

8.6.4.1 void init_attrjeod__ContactSurface() [friend]

8.6.4.2 friend class InputProcessor [friend]

Definition at line 52 of file contact surface.hh.

8.6.5 Field Documentation

8.6.5.1 ContactFacet** jeod::ContactSurface::contact_facets

An array of pointers to contact interaction facets.

trick_units(-)

Definition at line 65 of file contact_surface.hh.

 $Referenced \ by \ allocate_array(), \ allocate_interaction_facet(), \ collect_forces_torques(), \ and \ \sim ContactSurface().$

8.6.5.2 double jeod::ContactSurface::contact_force[3]

Total Force due to contact, resulting from all plates combined.

trick_units(N)

Definition at line 75 of file contact surface.hh.

Referenced by collect_forces_torques().

8.6.5.3 double jeod::ContactSurface::contact_torque[3]

Total Torque due to contact, resulting from all plates combined.

trick_units(N/m)

Definition at line 80 of file contact_surface.hh.

Referenced by collect_forces_torques().

8.6.5.4 unsigned int jeod::ContactSurface::facets_size

Size of the contact_facets array.

trick units(count)

Definition at line 70 of file contact_surface.hh.

Referenced by allocate_array(), allocate_interaction_facet(), collect_forces_torques(), and \sim ContactSurface().

The documentation for this class was generated from the following files:


- · contact surface.hh
- contact_surface.cc

8.7 jeod::ContactSurfaceFactory Class Reference

The surface factory that creates an contact specific surface from a general surface.

```
#include <contact_surface_factory.hh>
```

Inheritance diagram for jeod::ContactSurfaceFactory:



Public Member Functions

ContactSurfaceFactory ()

Default Constructor.

virtual ∼ContactSurfaceFactory ()

Destructor.

- virtual void create_surface (SurfaceModel *surface, InteractionSurface *inter_surface)
 - Creates an interaction surface, in the inter_surface parameter, from the given SurfaceModel.
- virtual void add_facet_params (FacetParams *to_add)

Add a named set of facet params to the surface factory.

Protected Attributes

PointContactFacetFactory point_contact_facet_factory

A factory that can create a point contact facet from a circular flat plate.

LineContactFacetFactory line_contact_facet_factory

A factory that can create a line contact facet from a cylinder.

Private Member Functions

- ContactSurfaceFactory & operator= (const ContactSurfaceFactory &rhs)
- ContactSurfaceFactory (const ContactSurfaceFactory &rhs)

Friends

- class InputProcessor
- void init_attrjeod__ContactSurfaceFactory ()

8.7.1 Detailed Description

The surface factory that creates an contact specific surface from a general surface.

Used with the surface model.

Definition at line 51 of file contact_surface_factory.hh.

8.7.2 Constructor & Destructor Documentation

8.7.2.1 jeod::ContactSurfaceFactory::ContactSurfaceFactory (void)

Default Constructor.

Definition at line 51 of file contact_surface_factory.cc.

References line_contact_facet_factory, and point_contact_facet_factory.

8.7.2.2 jeod::ContactSurfaceFactory::~ContactSurfaceFactory(void) [virtual]

Destructor.

Definition at line 65 of file contact surface factory.cc.

8.7.2.3 jeod::ContactSurfaceFactory::ContactSurfaceFactory (const ContactSurfaceFactory & rhs) [private]

8.7.3 Member Function Documentation

8.7.3.1 void jeod::ContactSurfaceFactory::add_facet_params (FacetParams * to_add) [virtual]

Add a named set of facet params to the surface factory.

Intended to be used when an contact specific surface is created, to convert a basic facet to an contact interaction facet. This MUST be a parameter inheriting from ContactParam, or the function will fail and send a failure message

Parameters

	in to_add	ın

Definition at line 203 of file contact surface factory.cc.

References jeod::ContactMessages::pre_initialization_error.

8.7.3.2 void jeod::ContactSurfaceFactory::create_surface (SurfaceModel * surface, InteractionSurface * inter_surface)

[virtual]

Creates an interaction surface, in the inter_surface parameter, from the given SurfaceModel.

The InteractionSurfaceFactory should contain all necessary InteractionFacetFactories and FacetParams already Parameters

in	surface	The surface model used to create the interaction surface
out	inter_surface	Where the interaction surface will be produced

Definition at line 84 of file contact_surface_factory.cc.

References jeod::ContactMessages::initialization_error.

- **8.7.3.3** ContactSurfaceFactory& jeod::ContactSurfaceFactory::operator=(const ContactSurfaceFactory & rhs) [private]
- 8.7.4 Friends And Related Function Documentation
- **8.7.4.1** void init_attrjeod__ContactSurfaceFactory() [friend]
- **8.7.4.2 friend class InputProcessor** [friend]

Definition at line 54 of file contact_surface_factory.hh.

8.7.5 Field Documentation

8.7.5.1 LineContactFacetFactory jeod::ContactSurfaceFactory::line_contact_facet_factory [protected]

A factory that can create a line contact facet from a cylinder.

trick_units(-)

Definition at line 87 of file contact_surface_factory.hh.

Referenced by ContactSurfaceFactory().

8.7.5.2 PointContactFacetFactory jeod::ContactSurfaceFactory::point_contact_facet_factory [protected]

A factory that can create a point contact facet from a circular flat plate.

trick units(-)

Definition at line 82 of file contact_surface_factory.hh.

Referenced by ContactSurfaceFactory().

The documentation for this class was generated from the following files:

- · contact_surface_factory.hh
- contact_surface_factory.cc

8.8 jeod::ContactUtils Class Reference

Utility string and math functions for the contact model.

```
#include <contact_utils.hh>
```

Static Public Member Functions

- static int create_relstate_name (char *name1, char *name2, char **out_str)

 create a name for a relstate out of two facet names
- static int copy_const_char_to_char (const char *in_str, char **out_str)

 create a name for a relstate out of two facet names
- static int dist_line_segments (double p1[3], double p2[3], double p3[3], double p4[3], double *pa, double *pb) calculate the closest points between two line segments

8.8.1 Detailed Description

Utility string and math functions for the contact model.

Definition at line 36 of file contact utils.hh.

8.8.2 Member Function Documentation

8.8.2.1 int jeod::ContactUtils::copy_const_char_to_char (const char * in_str, char ** out_str) [inline], [static]

create a name for a relstate out of two facet names

Returns

int

Parameters

in	in_str	const char input
in,out	out_str	char output

Definition at line 88 of file contact_utils_inline.hh.

Referenced by jeod::LineContactPair::initialize_pair(), jeod::PointContactPair::initialize_pair(), and jeod::LinePointContactPair::initialize_pair().

```
8.8.2.2 int jeod::ContactUtils::create_relstate_name ( char * name1, char * name2, char ** out_str ) [inline], [static]
```

create a name for a relstate out of two facet names

Returns

char**

Parameters

in	name1	name of first contact facet
in	name2	name of second contact facet
in,out	out_str	output name for the relstate

Definition at line 60 of file contact_utils_inline.hh.

8.8.2.3 int jeod::ContactUtils::dist_line_segments (double p1[3], double p2[3], double p3[3], double p4[3], double p3[3], double p4[3], double p3[3], double

calculate the closest points between two line segments

Returns

success

Parameters

in	р1	vector to one point of the first line seg
		Units: M
in	p2	vector to one point of the first line seg
		Units: M
in	рЗ	vector to one point of the second line seg
		Units: M
in	p4	vector to one point of the second line seg
		Units: M
out	ра	vector to close_point on line 1
		Units: M
out	pb	vector to close_point on line 2
		Units: M

Definition at line 122 of file contact_utils_inline.hh.

Referenced by jeod::LineContactPair::in_contact(), and jeod::LinePointContactPair::in_contact().

The documentation for this class was generated from the following files:


- · contact_utils.hh
- · contact_utils_inline.hh

8.9 jeod::LineContactFacet Class Reference

The contact facet based on the distance to a single point, specifically the vehicle point.

#include <line_contact_facet.hh>

Inheritance diagram for jeod::LineContactFacet:



Public Member Functions

LineContactFacet ()

Default constructor.

virtual ∼LineContactFacet ()

Destructor.

virtual ContactPair * create_pair ()

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

virtual ContactPair * create_pair (ContactFacet *target, Contact *contact)

Overloaded functions that creates a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

• virtual void set_max_dimension ()

calculate the max dimension of the facet for range limit determination.

virtual void calculate_torque (double *tmp_force)

Calculate the torque generated on the vehicle by the facet.

virtual void calculate_contact_point (double nvec[3])

Find the point on the surface that coorisponds to the closest point on line segments using the radius value.

Data Fields

• double length

length of the line along the vehicle point x axis.

Private Member Functions

- LineContactFacet & operator= (const LineContactFacet &rhs)
- LineContactFacet (const LineContactFacet &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__LineContactFacet ()

8.9.1 Detailed Description

The contact facet based on the distance to a single point, specifically the vehicle point.

In effect this represents a sphere.

Definition at line 51 of file line_contact_facet.hh.

8.9.2 Constructor & Destructor Documentation

8.9.2.1 jeod::LineContactFacet::LineContactFacet (void)

Default constructor.

Definition at line 53 of file line_contact_facet.cc.

References jeod::PointContactFacet::contact_point.

8.9.2.2 jeod::LineContactFacet:: \sim LineContactFacet (void) [virtual]

Destructor.

Definition at line 67 of file line_contact_facet.cc.

8.9.2.3 jeod::LineContactFacet::LineContactFacet (const LineContactFacet & rhs) [private]

8.9.3 Member Function Documentation

8.9.3.1 void jeod::LineContactFacet::calculate contact point (double nvec[3]) [virtual]

Find the point on the surface that coorisponds to the closest point on line segments using the radius value.

Parameters

in	nvec	vector between line points

Reimplemented from jeod::PointContactFacet.

Definition at line 173 of file line_contact_facet.cc.

References jeod::PointContactFacet::contact point, length, and jeod::PointContactFacet::radius.

Referenced by jeod::LineContactPair::in_contact(), and jeod::LinePointContactPair::in_contact().

8.9.3.2 void jeod::LineContactFacet::calculate_torque(double * *tmp_force***)** [virtual]

Calculate the torque generated on the vehicle by the facet.

Assumes that the force is in the vehicle structural frame, but that close_point is not.

Parameters

in	tmp_force	force from one contact interaction.
		Units: N

Reimplemented from jeod::PointContactFacet.

Definition at line 231 of file line_contact_facet.cc.

References jeod::PointContactFacet::contact_point, jeod::ContactFacet::vehicle_body, and jeod::ContactFacet::vehicle_point.

```
8.9.3.3 ContactPair * jeod::LineContactFacet::create_pair( void ) [virtual]
```

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

This function is called to create a pair that only contains a subject.

Returns

ContactPair that was created

Reimplemented from jeod::PointContactFacet.

Definition at line 83 of file line contact facet.cc.

References jeod::LineContactPair::initialize_pair().

```
8.9.3.4 ContactPair * jeod::LineContactFacet::create_pair ( ContactFacet * target, Contact * contact ) [virtual]
```

Overloaded functions that creates a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

This function is called when a subject and target are known.

Returns

ContactPair that was created

Parameters

in,out	target	target ContactFacet
in	contact	Contact object used to find the pair interaction

Reimplemented from jeod::PointContactFacet.

Definition at line 104 of file line_contact_facet.cc.

References jeod::Contact::contact_limit_factor, jeod::Contact::find_interaction(), jeod::ContactMessages::initialization_warns, jeod::LineContactPair::initialize_pair(), jeod::LinePointContactPair::initialize_pair(), jeod::ContactPair::interaction, jeod::ContactPair::interaction_distance, jeod::ContactFacet::max_dimension, and jeod::ContactFacet::surface_type.

```
8.9.3.5 LineContactFacet & jeod::LineContactFacet::operator=( const LineContactFacet & rhs ) [private]
```

```
8.9.3.6 void jeod::LineContactFacet::set_max_dimension(void) [virtual]
```

calculate the max dimension of the facet for range limit determination.

 $Reimplemented \ from \ jeod:: Point Contact Facet.$

Definition at line 218 of file line_contact_facet.cc.

References length, jeod::ContactFacet::max dimension, and jeod::PointContactFacet::radius.

 $Referenced \ by \ jeod:: Line Contact Facet Factory:: create_facet().$

8.9.4 Friends And Related Function Documentation

```
8.9.4.1 void init_attrjeod__LineContactFacet( ) [friend]
```

8.9.4.2 friend class InputProcessor [friend]

Definition at line 53 of file line_contact_facet.hh.

8.9.5 Field Documentation

8.9.5.1 double jeod::LineContactFacet::length

length of the line along the vehicle point x axis.

trick units(m)

Definition at line 59 of file line_contact_facet.hh.

Referenced by calculate_contact_point(), jeod::LineContactFacetFactory::create_facet(), jeod::LineContactPair::in-contact(), jeod::LinePointContactPair::in-contact(), and set max dimension().

The documentation for this class was generated from the following files:


- · line_contact_facet.hh
- line_contact_facet.cc

8.10 jeod::LineContactFacetFactory Class Reference

Creates a PointContactFacet from an InteractionFacet.

```
#include <line_contact_facet_factory.hh>
```

Inheritance diagram for jeod::LineContactFacetFactory:



Public Member Functions

LineContactFacetFactory ()

Default Constructor.

∼LineContactFacetFactory ()

Destructor.

• virtual InteractionFacet * create_facet (Facet *facet, FacetParams *params)

Create a PointContactFacet from a CircularFlatPlate facet and a ContactParams object.

virtual bool is_correct_factory (Facet *facet)

PointContactFacetFactory specific implementation of this function.

Private Member Functions

- LineContactFacetFactory & operator= (const LineContactFacetFactory &rhs)
- LineContactFacetFactory (const LineContactFacetFactory &rhs)

Friends

- class InputProcessor
- void init_attrjeod__LineContactFacetFactory ()

8.10.1 Detailed Description

Creates a PointContactFacet from an InteractionFacet.

Definition at line 50 of file line_contact_facet_factory.hh.

8.10.2 Constructor & Destructor Documentation

8.10.2.1 jeod::LineContactFacetFactory::LineContactFacetFactory (void)

Default Constructor.

Definition at line 54 of file line_contact_facet_factory.cc.

8.10.2.2 jeod::LineContactFacetFactory::~LineContactFacetFactory (void)

Destructor.

Definition at line 65 of file line_contact_facet_factory.cc.

8.10.2.3 jeod::LineContactFacetFactory::LineContactFacetFactory (const LineContactFacetFactory & rhs)
[private]

8.10.3 Member Function Documentation

```
8.10.3.1 InteractionFacet * jeod::LineContactFacetFactory::create_facet ( Facet * facet, FacetParams * params )

[virtual]
```

Create a PointContactFacet from a CircularFlatPlate facet and a ContactParams object.

Returns

The new EllipsoidContactFacet. Note that this is allocated and YOU are responsible for destroying it at the end!

Parameters

in	facet	The CircularFlatPlate. This MUST be a circular flat plate or the algorithm will
		send a failure message
in	params	ContactParams

Definition at line 83 of file line_contact_facet_factory.cc.

References jeod::ContactFacet::create_vehicle_point(), jeod::ContactMessages::initialization_error, jeod::Line-ContactFacet::length, jeod::ContactFacet::normal, jeod::ContactFacet::position, jeod::PointContactFacet::radius, jeod::LineContactFacet::set_max_dimension(), jeod::ContactFacet::surface_type, and jeod::ContactFacet::vehicle_body.

8.10.3.2 bool jeod::LineContactFacetFactory::is_correct_factory (Facet * facet) [virtual]

PointContactFacetFactory specific implementation of this function.

If the Facet is of type CircularFlatPlate, returns true. False otherwise

Returns

true if facet is a FlatPlateCircular, false otherwise

Parameters

×			
	in	facet	The facet to check

Definition at line 162 of file line_contact_facet_factory.cc.

8.10.3.3 LineContactFacetFactory&jeod::LineContactFacetFactory::operator=(const LineContactFacetFactory&rhs) [private]

8.10.4 Friends And Related Function Documentation

```
8.10.4.1 void init_attrjeod__LineContactFacetFactory() [friend]
```

8.10.4.2 friend class InputProcessor [friend]

Definition at line 53 of file line_contact_facet_factory.hh.

The documentation for this class was generated from the following files:

- · line_contact_facet_factory.hh
- · line_contact_facet_factory.cc

8.11 jeod::LineContactPair Class Reference

An point to point contact pair for use in the contact model.

```
#include <line_contact_pair.hh>
```

Inheritance diagram for jeod::LineContactPair:



Public Member Functions

LineContactPair ()

Default Constructor.

virtual ~LineContactPair ()

Destructor.

virtual void in_contact ()

Determine if contact has occurred between the facets of the pair.

• virtual void initialize_pair (ContactFacet *subject_facet, ContactFacet *target_facet)

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Data Fields

LineContactFacet * line_subject

pointer to the contact facet that is the subject of the associated relative states.

LineContactFacet * line_target

pointer to the contact facet that is the target of the associated relative states.

Private Member Functions

- LineContactPair & operator= (const LineContactPair &rhs)
- LineContactPair (const LineContactPair &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__LineContactPair ()

Additional Inherited Members

8.11.1 Detailed Description

An point to point contact pair for use in the contact model.

Definition at line 48 of file line_contact_pair.hh.

8.11.2 Constructor & Destructor Documentation

8.11.2.1 jeod::LineContactPair::LineContactPair (void)

Default Constructor.

Definition at line 48 of file line contact pair.cc.

```
8.11.2.2 jeod::LineContactPair::~LineContactPair ( void ) [virtual]
```

Destructor.

Definition at line 61 of file line_contact_pair.cc.

```
8.11.2.3 jeod::LineContactPair::LineContactPair ( const LineContactPair & rhs ) [private]
```

8.11.3 Member Function Documentation

```
8.11.3.1 void jeod::LineContactPair::in_contact( void ) [virtual]
```

Determine if contact has occurred between the facets of the pair.

Implements jeod::ContactPair.

Definition at line 71 of file line_contact_pair.cc.

References jeod::LineContactFacet::calculate_contact_point(), jeod::PairInteraction::calculate_forces(), jeod::Point-ContactFacet::contact_point, jeod::ContactUtils::dist_line_segments(), jeod::ContactPair::interaction, jeod::Line-ContactFacet::length, line_subject, line_target, and jeod::ContactPair::rel_state.

```
8.11.3.2 void jeod::LineContactPair::initialize_pair ( ContactFacet * subject_facet, ContactFacet * target_facet )

[virtual]
```

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Parameters

i	n,out	subject_facet	subject ContactFacet
i	n,out	target_facet	target ContactFacet

Implements jeod::ContactPair.

Definition at line 173 of file line_contact_pair.cc.

References jeod::ContactUtils::copy_const_char_to_char(), line_subject, line_target, jeod::ContactPair::rel_state, jeod::ContactPair::subject, jeod::ContactPair::target, and jeod::ContactFacet::vehicle point.

Referenced by jeod::LineContactFacet::create_pair().

8.11.3.3 LineContactPair& jeod::LineContactPair::operator=(const LineContactPair & rhs) [private]

8.11.4 Friends And Related Function Documentation

```
8.11.4.1 void init_attrjeod__LineContactPair( ) [friend]
```

8.11.4.2 friend class InputProcessor [friend]

Definition at line 50 of file line contact pair.hh.

8.11.5 Field Documentation

8.11.5.1 LineContactFacet* jeod::LineContactPair::line_subject

pointer to the contact facet that is the subject of the associated relative states.

trick units(-)

Definition at line 56 of file line_contact_pair.hh.

Referenced by in_contact(), and initialize_pair().

8.11.5.2 LineContactFacet* jeod::LineContactPair::line_target

pointer to the contact facet that is the target of the associated relative states.

trick_units(-)

Definition at line 61 of file line_contact_pair.hh.

Referenced by in_contact(), and initialize_pair().

The documentation for this class was generated from the following files:


- · line_contact_pair.hh
- · line_contact_pair.cc

8.12 jeod::LinePointContactPair Class Reference

An point to point contact pair for use in the contact model.

```
#include <line_point_contact_pair.hh>
```

 $Inheritance\ diagram\ for\ jeod:: Line Point Contact Pair:$



Public Member Functions

• LinePointContactPair ()

Default Constructor.

virtual ~LinePointContactPair ()

Destructor.

virtual void in_contact ()

Determine if contact has occurred between the facets of the pair.

virtual void initialize_pair (ContactFacet *subject_facet, ContactFacet *target_facet)

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Data Fields

LineContactFacet * line_subject

pointer to the contact facet that is the subject of the associated relative states.

PointContactFacet * point_target

pointer to the contact facet that is the target of the associated relative states.

Private Member Functions

- LinePointContactPair & operator= (const LineContactPair &rhs)
- LinePointContactPair (const LineContactPair &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__LinePointContactPair ()

Additional Inherited Members

8.12.1 Detailed Description

An point to point contact pair for use in the contact model.

Definition at line 49 of file line_point_contact_pair.hh.

8.12.2 Constructor & Destructor Documentation

8.12.2.1 jeod::LinePointContactPair::LinePointContactPair (void)

Default Constructor.

Definition at line 49 of file line_point_contact_pair.cc.

8.12.2.2 jeod::LinePointContactPair::~LinePointContactPair(void) [virtual]

Destructor.

Definition at line 62 of file line_point_contact_pair.cc.

8.12.2.3 jeod::LinePointContactPair::LinePointContactPair (const LineContactPair & rhs) [private]

8.12.3 Member Function Documentation

```
8.12.3.1 void jeod::LinePointContactPair::in_contact( void ) [virtual]
```

Determine if contact has occurred between the facets of the pair.

Implements jeod::ContactPair.

Definition at line 72 of file line_point_contact_pair.cc.

References jeod::LineContactFacet::calculate_contact_point(), jeod::PointContactFacet::calculate_contact_point(), jeod::PointContactFacet::contact_point, jeod::ContactUtils::dist_line_segments(), jeod::ContactPair::interaction, jeod::LineContactFacet::length, line_subject, point_target, and jeod::ContactPair::rel_state.

8.12.3.2 void jeod::LinePointContactPair::initialize_pair (ContactFacet * subject_facet, ContactFacet * target_facet)

[virtual]

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Parameters

in,out	subject_facet	subject ContactFacet
in,out	target_facet	target ContactFacet

Implements jeod::ContactPair.

Definition at line 158 of file line point contact pair.cc.

References jeod::ContactUtils::copy_const_char_to_char(), line_subject, point_target, jeod::ContactPair::rel_state, jeod::ContactPair::subject, jeod::ContactPair::target, and jeod::ContactFacet::vehicle point.

Referenced by jeod::LineContactFacet::create pair().

8.12.3.3 LinePointContactPair&jeod::LinePointContactPair::operator=(const LineContactPair & rhs) [private]

8.12.4 Friends And Related Function Documentation

```
8.12.4.1 void init_attrjeod__LinePointContactPair() [friend]
```

8.12.4.2 friend class InputProcessor [friend]

Definition at line 51 of file line_point_contact_pair.hh.

8.12.5 Field Documentation

8.12.5.1 LineContactFacet* jeod::LinePointContactPair::line_subject

pointer to the contact facet that is the subject of the associated relative states.

trick_units(-)

Definition at line 57 of file line_point_contact_pair.hh.

Referenced by in contact(), and initialize pair().

8.12.5.2 PointContactFacet* jeod::LinePointContactPair::point_target

pointer to the contact facet that is the target of the associated relative states.

trick units(-)

Definition at line 62 of file line_point_contact_pair.hh.

Referenced by in_contact(), and initialize_pair().

The documentation for this class was generated from the following files:


- · line_point_contact_pair.hh
- line_point_contact_pair.cc

8.13 jeod::PairInteraction Class Reference

Simple spring contact parameters.

```
#include <pair_interaction.hh>
```

Inheritance diagram for jeod::PairInteraction:



Public Member Functions

• PairInteraction ()

Default Constructor.

virtual ∼PairInteraction ()

Destructor.

• bool is_correct_interaction (ContactParams *subject_params, ContactParams *target_params)

Check a pair of contact params for a match to the ones defined for this pair_interaction.

 virtual void calculate_forces (ContactFacet *subject, ContactFacet *target, RelativeDerivedState *rel_state, double *penetration_vector, double *rel_velocity)=0

Pure virtual function that is defined to calculate forces on facets in contact.

Data Fields

• char * params_1

contact param type that defines this pair interaction.

char * params_2

contact param type that defines this pair interaction.

· double friction_mag

magnitude of the friction force on the contact surfaces.

Private Member Functions

- PairInteraction & operator= (const PairInteraction &rhs)
- PairInteraction (const PairInteraction &rhs)

Friends

- class InputProcessor
- void init_attrjeod__PairInteraction ()

8.13.1 Detailed Description

Simple spring contact parameters.

Definition at line 50 of file pair_interaction.hh.

8.13.2 Constructor & Destructor Documentation

8.13.2.1 jeod::PairInteraction::PairInteraction (void)

Default Constructor.

Definition at line 47 of file pair interaction.cc.

8.13.2.2 jeod::PairInteraction::~PairInteraction(void) [virtual]

Destructor.

Definition at line 61 of file pair_interaction.cc.

8.13.2.3 jeod::PairInteraction::PairInteraction (const PairInteraction & rhs) [private]

8.13.3 Member Function Documentation

8.13.3.1 virtual void jeod::PairInteraction::calculate_forces (ContactFacet * subject, ContactFacet * target,

RelativeDerivedState * rel_state, double * penetration_vector, double * rel_velocity) [pure virtual]

Pure virtual function that is defined to calculate forces on facets in contact.

Parameters

in,out	subject	subject of the relative state
in,out	target	target of the relative state
in	rel_state	relative state between subject and target in subject frame
in	penetration	vector that characterises the interpenetration of the subject and the target
	vector	
in	rel_velocity	relative velocity of the subject and the target in the subject frame

Implemented in jeod::SpringPairInteraction.

 $Referenced \ by \ jeod::LineContactPair::in_contact(), \ jeod::PointContactPair::in_contact(), \ and \ jeod::LinePointContactPair::in_contact().$

8.13.3.2 bool jeod::PairInteraction::is_correct_interaction (ContactParams * subject_params, ContactParams * target_params)

Check a pair of contact params for a match to the ones defined for this pair_interaction.

Returns

bool

Parameters

in	subject_params	parameters of the subject
in	target_params	parameters of the target

Definition at line 75 of file pair_interaction.cc.

References params_1, and params_2.

8.13.3.3 PairInteraction& jeod::PairInteraction::operator=(const PairInteraction & rhs) [private]

8.13.4 Friends And Related Function Documentation

```
8.13.4.1 void init_attrjeod__PairInteraction() [friend]
```

8.13.4.2 friend class InputProcessor [friend]

Definition at line 52 of file pair_interaction.hh.

8.13.5 Field Documentation

8.13.5.1 double jeod::PairInteraction::friction_mag

magnitude of the friction force on the contact surfaces.

trick_units(N)

Definition at line 68 of file pair interaction.hh.

 $Referenced\ by\ jeod::SpringPairInteraction::calculate_forces().$

8.13.5.2 char* jeod::PairInteraction::params_1

contact param type that defines this pair interaction.

trick_units(-)

Definition at line 59 of file pair_interaction.hh.

Referenced by is_correct_interaction().

8.13.5.3 char* jeod::PairInteraction::params_2

contact param type that defines this pair interaction.

trick_units(-)

Definition at line 63 of file pair_interaction.hh.

Referenced by is_correct_interaction().

The documentation for this class was generated from the following files:


- · pair_interaction.hh
- · pair_interaction.cc

8.14 jeod::PointContactFacet Class Reference

The contact facet based on the distance to a single point, specifically the vehicle point.

```
#include <point_contact_facet.hh>
```

Inheritance diagram for jeod::PointContactFacet:



Public Member Functions

· PointContactFacet ()

Default constructor.

virtual ~PointContactFacet ()

Destructor.

virtual ContactPair * create_pair ()

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

virtual ContactPair * create_pair (ContactFacet *target, Contact *contact)

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

virtual void set_max_dimension ()

calculate the max dimension of the facet for range limit determination.

virtual void calculate_contact_point (double nvec[3])

Use the relstate and radius of contact to calculate a contact point on this facet.

virtual void calculate_torque (double *tmp_force)

Calculate the torque generated on the vehicle by the facet.

Data Fields

· double radius

radius from the point at which contact takes place.

• double contact_point [3]

Contact point given in facet vehicle point frame, representing point on the point on the surface of a sphere of radius "radius" where contact has occured.

Private Member Functions

- PointContactFacet & operator= (const PointContactFacet &rhs)
- PointContactFacet (const PointContactFacet &rhs)

Friends

- class InputProcessor
- void init_attrjeod__PointContactFacet ()

8.14.1 Detailed Description

The contact facet based on the distance to a single point, specifically the vehicle point.

In effect this represents a sphere.

Definition at line 51 of file point_contact_facet.hh.

8.14.2 Constructor & Destructor Documentation

8.14.2.1 jeod::PointContactFacet::PointContactFacet (void)

Default constructor.

Definition at line 51 of file point_contact_facet.cc.

References contact point.

8.14.2.2 jeod::PointContactFacet::~PointContactFacet (void) [virtual]

Destructor.

Definition at line 64 of file point_contact_facet.cc.

8.14.2.3 jeod::PointContactFacet::PointContactFacet (const PointContactFacet & rhs) [private]

8.14.3 Member Function Documentation

8.14.3.1 void jeod::PointContactFacet::calculate_contact_point(double nvec[3]) [virtual]

Use the relstate and radius of contact to calculate a contact point on this facet.

Parameters

	in	nvec	direction vector between the two facets
_			

Reimplemented in jeod::LineContactFacet.

Definition at line 139 of file point_contact_facet.cc.

References contact_point, and radius.

Referenced by jeod::PointContactPair::in_contact(), and jeod::LinePointContactPair::in_contact().

8.14.3.2 void jeod::PointContactFacet::calculate_torque(double * tmp_force) [virtual]

Calculate the torque generated on the vehicle by the facet.

Assumes that the force is in the vehicle structural frame, but that close_point is not.

Parameters

in	tmp_force	force from one contact interaction.
		Units: N

Implements jeod::ContactFacet.

Reimplemented in jeod::LineContactFacet.

Definition at line 167 of file point_contact_facet.cc.

References contact_point, jeod::ContactFacet::vehicle_body, and jeod::ContactFacet::vehicle_point.

```
8.14.3.3 ContactPair * jeod::PointContactFacet::create_pair(void) [virtual]
```

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

This function is called to create a pair that only contains a subject.

Returns

ContactPair that was created

Implements jeod::ContactFacet.

Reimplemented in jeod::LineContactFacet.

Definition at line 80 of file point_contact_facet.cc.

References jeod::PointContactPair::initialize_pair().

```
8.14.3.4 ContactPair * jeod::PointContactFacet::create_pair ( ContactFacet * target, Contact * contact )

[virtual]
```

Overloaded functions that create a ContactPair and pass the address of it to the Contact class for addition to the list of pairs.

This function is called when a subject and target are known.

Returns

ContactPair that was created

Parameters

in,out	target	target ContactFacet
in	contact	Contact object used to find the pair interaction

Implements jeod::ContactFacet.

Reimplemented in jeod::LineContactFacet.

Definition at line 101 of file point_contact_facet.cc.

References jeod::Contact::contact_limit_factor, jeod::Contact::find_interaction(), jeod::ContactMessages::initialization_warns, jeod::PointContactPair::initialize_pair(), jeod::ContactPair::interaction, jeod::ContactPair::interaction_distance, jeod::ContactFacet::max_dimension, and jeod::ContactFacet::surface_type.

```
8.14.3.5 PointContactFacet& jeod::PointContactFacet::operator=( const PointContactFacet & rhs ) [private]
```

8.14.3.6 void jeod::PointContactFacet::set_max_dimension(void) [virtual]

calculate the max dimension of the facet for range limit determination.

Implements jeod::ContactFacet.

Reimplemented in jeod::LineContactFacet.

Definition at line 154 of file point contact facet.cc.

References jeod::ContactFacet::max_dimension, and radius.

Referenced by jeod::PointContactFacetFactory::create_facet().

8.14.4 Friends And Related Function Documentation

```
8.14.4.1 void init_attrjeod__PointContactFacet( ) [friend]
```

8.14.4.2 friend class InputProcessor [friend]

Definition at line 53 of file point_contact_facet.hh.

8.14.5 Field Documentation

8.14.5.1 double jeod::PointContactFacet::contact_point[3]

Contact point given in facet vehicle point frame, representing point on the point on the surface of a sphere of radius "radius" where contact has occured.

trick_units(m)

Definition at line 66 of file point_contact_facet.hh.

Referenced by jeod::LineContactFacet::calculate_contact_point(), calculate_contact_point(), jeod::LineContactFacet::calculate_torque(), jeod::LineContactPair::in_contact(), jeod::PointContactPair::in_contact(), jeod::LineContactFacet::LineContactFacet(), and PointContactFacet().

8.14.5.2 double jeod::PointContactFacet::radius

radius from the point at which contact takes place.

trick_units(m)

Definition at line 59 of file point_contact_facet.hh.

Referenced by jeod::LineContactFacet::calculate_contact_point(), calculate_contact_point(), jeod::PointContactFacetFactory::create_facet(), jeod::LineContactFacetFactory::create_facet(), jeod::PointContactPair::in_contact(), jeod::LineContactFacet::set max dimension(), and set max dimension().

The documentation for this class was generated from the following files:

- · point_contact_facet.hh
- · point_contact_facet.cc

8.15 jeod::PointContactFacetFactory Class Reference

Creates a PointContactFacet from an InteractionFacet.

```
#include <point_contact_facet_factory.hh>
```

Inheritance diagram for jeod::PointContactFacetFactory:



Public Member Functions

• PointContactFacetFactory ()

Default Constructor.

∼PointContactFacetFactory ()

Destructor.

• virtual InteractionFacet * create_facet (Facet *facet, FacetParams *params)

Create a PointContactFacet from a CircularFlatPlate facet and a ContactParams object.

virtual bool is correct factory (Facet *facet)

PointContactFacetFactory specific implementation of this function.

Private Member Functions

- PointContactFacetFactory & operator= (const PointContactFacetFactory &rhs)
- PointContactFacetFactory (const PointContactFacetFactory &rhs)

Friends

- class InputProcessor
- void init_attrjeod__PointContactFacetFactory ()

8.15.1 Detailed Description

Creates a PointContactFacet from an InteractionFacet.

Definition at line 50 of file point_contact_facet_factory.hh.

8.15.2 Constructor & Destructor Documentation

8.15.2.1 jeod::PointContactFacetFactory::PointContactFacetFactory (void)

Default Constructor.

Definition at line 54 of file point_contact_facet_factory.cc.

8.15.2.2 jeod::PointContactFacetFactory::~PointContactFacetFactory (void)

Destructor.

Definition at line 65 of file point_contact_facet_factory.cc.

8.15.2.3 jeod::PointContactFacetFactory::PointContactFacetFactory (const PointContactFacetFactory & rhs)
[private]

8.15.3 Member Function Documentation

8.15.3.1 InteractionFacet * jeod::PointContactFacetFactory::create_facet (Facet * facet, FacetParams * params) [virtual]

Create a PointContactFacet from a CircularFlatPlate facet and a ContactParams object.

Returns

The new EllipsoidContactFacet. Note that this is allocated and YOU are responsible for destroying it at the end!

Parameters

in	facet	The CircularFlatPlate. This MUST be a circular flat plate or the algorithm will
		send a failure message
in	params	ContactParams

Definition at line 83 of file point_contact_facet_factory.cc.

References jeod::ContactFacet::create_vehicle_point(), jeod::ContactMessages::initialization_error, jeod::ContactFacet::normal, jeod::ContactFacet::position, jeod::PointContactFacet::radius, jeod::PointContactFacet::set_max_dimension(), jeod::ContactFacet::surface_type, and jeod::ContactFacet::vehicle_body.

8.15.3.2 bool jeod::PointContactFacetFactory::is_correct_factory(Facet * facet) [virtual]

PointContactFacetFactory specific implementation of this function.

If the Facet is of type CircularFlatPlate, returns true. False otherwise

Returns

true if facet is a FlatPlateCircular, false otherwise

Parameters

in	facet	The facet to check

Definition at line 160 of file point_contact_facet_factory.cc.

- 8.15.3.3 PointContactFacetFactory&jeod::PointContactFacetFactory::operator=(const PointContactFacetFactory&rhs) [private]
- 8.15.4 Friends And Related Function Documentation
- **8.15.4.1 void init_attrjeod__PointContactFacetFactory()** [friend]
- **8.15.4.2** friend class InputProcessor [friend]

Definition at line 53 of file point_contact_facet_factory.hh.

The documentation for this class was generated from the following files:


- point_contact_facet_factory.hh
- point_contact_facet_factory.cc

8.16 jeod::PointContactPair Class Reference

An point to point contact pair for use in the contact model.

```
#include <point_contact_pair.hh>
```

Inheritance diagram for jeod::PointContactPair:



Public Member Functions

· PointContactPair ()

Default Constructor.

virtual ∼PointContactPair ()

Destructor.

• virtual void in contact ()

Determine if contact has occurred between the facets of the pair.

• virtual void initialize_pair (ContactFacet *subject_facet, ContactFacet *target_facet)

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Data Fields

PointContactFacet * point_subject

pointer to the point contact facet that is the subject of the associated relative states.

PointContactFacet * point_target

pointer to the point contact facet that is the target of the associated relative states.

Private Member Functions

- PointContactPair & operator= (const PointContactPair &rhs)
- PointContactPair (const PointContactPair &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__PointContactPair ()

Additional Inherited Members

8.16.1 Detailed Description

An point to point contact pair for use in the contact model.

Definition at line 48 of file point_contact_pair.hh.

8.16.2 Constructor & Destructor Documentation

8.16.2.1 jeod::PointContactPair::PointContactPair (void)

Default Constructor.

Definition at line 47 of file point_contact_pair.cc.

8.16.2.2 jeod::PointContactPair::~PointContactPair (void) [virtual]

Destructor.

Definition at line 60 of file point_contact_pair.cc.

8.16.2.3 jeod::PointContactPair::PointContactPair (const PointContactPair & rhs) [private]

8.16.3 Member Function Documentation

8.16.3.1 void jeod::PointContactPair::in_contact(void) [virtual]

Determine if contact has occurred between the facets of the pair.

Implements jeod::ContactPair.

Definition at line 70 of file point_contact_pair.cc.

References jeod::PointContactFacet::calculate_contact_point(), jeod::PairInteraction::calculate_forces(), jeod::PointContactFacet::contact_point, jeod::ContactPair::interaction, point_subject, point_target, jeod::PointContactFacet::radius, and jeod::ContactPair::rel_state.

8.16.3.2 void jeod::PointContactPair::initialize_pair (ContactFacet * subject_facet, ContactFacet * target_facet)

[virtual]

Initialize the contact pair by setting the subject, target, and creating the relstate if possible.

Parameters

in,out	subject_facet	subject ContactFacet
in,out	target facet	target ContactFacet

Implements jeod::ContactPair.

Definition at line 125 of file point_contact_pair.cc.

References jeod::ContactUtils::copy_const_char_to_char(), point_subject, point_target, jeod::ContactPair::rel_state, jeod::ContactPair::subject, jeod::ContactPair::target, and jeod::ContactFacet::vehicle_point.

Referenced by jeod::PointContactFacet::create_pair().

8.16.3.3 PointContactPair&jeod::PointContactPair::operator=(const PointContactPair & rhs) [private]

8.16.4 Friends And Related Function Documentation

8.16.4.1 void init_attrjeod__PointContactPair() [friend]

8.16.4.2 friend class InputProcessor [friend]

Definition at line 50 of file point_contact_pair.hh.

8.16.5 Field Documentation

8.16.5.1 PointContactFacet* jeod::PointContactPair::point_subject

pointer to the point contact facet that is the subject of the associated relative states.

trick_units(-)

Definition at line 56 of file point contact pair.hh.

Referenced by in_contact(), and initialize_pair().

8.16.5.2 PointContactFacet* jeod::PointContactPair::point_target

pointer to the point contact facet that is the target of the associated relative states.

trick units(-)

Definition at line 61 of file point_contact_pair.hh.

Referenced by in contact(), and initialize pair().

The documentation for this class was generated from the following files:


- point_contact_pair.hh
- point_contact_pair.cc

8.17 jeod::SpringPairInteraction Class Reference

Simple spring contact parameters.

#include <spring_pair_interaction.hh>

Inheritance diagram for jeod::SpringPairInteraction:



Public Member Functions

SpringPairInteraction ()

Default Constructor.

virtual ∼SpringPairInteraction ()

Destructor.

 virtual void calculate_forces (ContactFacet *subject, ContactFacet *target, RelativeDerivedState *rel_state, double *penetration_vector, double *rel_velocity)

force calculation for a simple spring based contact dynamics model, takes in geometry information from the appropriate ContactFacet::calculate_forces but doesn't know about specific type of ContactFacet

Data Fields

· double spring k

Spring stiffness constant.

double damping_b

Spring damping constant.

• double mu

Coefficent of friction.

Private Member Functions

- SpringPairInteraction & operator= (const SpringPairInteraction &rhs)
- SpringPairInteraction (const SpringPairInteraction &rhs)

Friends

- · class InputProcessor
- void init_attrjeod__SpringPairInteraction ()

8.17.1 Detailed Description

Simple spring contact parameters.

Definition at line 47 of file spring_pair_interaction.hh.

8.17.2 Constructor & Destructor Documentation

8.17.2.1 jeod::SpringPairInteraction::SpringPairInteraction (void)

Default Constructor.

Definition at line 51 of file spring_pair_interaction.cc.

 $\textbf{8.17.2.2} \quad \textbf{jeod::SpringPairInteraction::} \sim \textbf{SpringPairInteraction (void)} \quad [\texttt{virtual}]$

Destructor.

Definition at line 66 of file spring_pair_interaction.cc.

8.17.2.3 jeod::SpringPairInteraction::SpringPairInteraction & rhs) [private]

8.17.3 Member Function Documentation

8.17.3.1 void jeod::SpringPairInteraction::calculate_forces (ContactFacet * subject, ContactFacet * target, RelativeDerivedState * rel_state, double * penetration_vector, double * rel_velocity) [virtual]

force calculation for a simple spring based contact dynamics model, takes in geometry information from the appropriate ContactFacet::calculate_forces but doesn't know about specific type of ContactFacet

Parameters

in,out	subject	subject frame of the relative state
in,out	target	target frame of the relative state
in	rel_state	relative state between subject and target in subject frame
in	penetration	vector that characterises the interpenetration of the subject and the target
	vector	

in	rel_velocity	relative velocity of the subject and the target in the subject frame

Implements jeod::PairInteraction.

Definition at line 87 of file spring_pair_interaction.cc.

References jeod::ContactFacet::calculate_torque(), damping_b, jeod::PairInteraction::friction_mag, mu, spring_k, jeod::ContactFacet::vehicle_body, and jeod::ContactFacet::vehicle_point.

8.17.3.2 SpringPairInteraction& jeod::SpringPairInteraction::operator= (const SpringPairInteraction & *rhs*) [private]

8.17.4 Friends And Related Function Documentation

```
8.17.4.1 void init_attrjeod__SpringPairInteraction() [friend]
```

8.17.4.2 friend class InputProcessor [friend]

Definition at line 50 of file spring_pair_interaction.hh.

8.17.5 Field Documentation

8.17.5.1 double jeod::SpringPairInteraction::damping_b

Spring damping constant.

trick_units(N*s/m)

Definition at line 61 of file spring_pair_interaction.hh.

Referenced by calculate_forces().

8.17.5.2 double jeod::SpringPairInteraction::mu

Coefficent of friction.

trick_units(-)

Definition at line 66 of file spring_pair_interaction.hh.

Referenced by calculate_forces().

8.17.5.3 double jeod::SpringPairInteraction::spring_k

Spring stiffness constant.

 $trick_units(N/m)$

Definition at line 56 of file spring_pair_interaction.hh.

Referenced by calculate forces().

The documentation for this class was generated from the following files:

- spring_pair_interaction.hh
- spring_pair_interaction.cc

Chapter 9

File Documentation

9.1 class_declarations.hh File Reference

Forward declaration of classes defined in the contact model.

Namespaces

jeod

Namespace jeod.

9.1.1 Detailed Description

Forward declaration of classes defined in the contact model.

Definition in file class_declarations.hh.

9.2 contact.cc File Reference

Base Contact for use with contact interaction model.

```
#include "dynamics/mass/include/mass.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "utils/surface_model/include/facet.hh"
#include "../include/contact.hh"
#include "../include/contact_facet.hh"
#include "../include/contact_pair.hh"
#include "../include/pair_interaction.hh"
```

Namespaces

• jeod

Namespace jeod.

9.2.1 Detailed Description

Base Contact for use with contact interaction model.

Definition in file contact.cc.

9.3 contact.hh File Reference

(Base class to for the contact manager for use with contact interaction model)

```
#include <list>
#include "dynamics/dyn_manager/include/class_declarations.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/container/include/pointer_list.hh"
#include "class_declarations.hh"
#include "contact_facet.hh"
#include "contact_pair.hh"
#include "pair_interaction.hh"
```

Data Structures

· class jeod::Contact

An base contact class for use in the surface model.

Namespaces

· jeod

Namespace jeod.

9.3.1 Detailed Description

(Base class to for the contact manager for use with contact interaction model)

Definition in file contact.hh.

9.4 contact_facet.cc File Reference

Define ContactFacet::create_vehicle_point.

```
#include <cstddef>
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "dynamics/mass/include/mass_point_init.hh"
#include "utils/math/include/vector3.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "utils/surface_model/include/facet.hh"
#include "../include/contact_facet.hh"
#include "../include/contact_messages.hh"
#include "../include/contact_utils.hh"
```

Namespaces

jeod

Namespace jeod.

9.4.1 Detailed Description

Define ContactFacet::create_vehicle_point.

Definition in file contact_facet.cc.

9.5 contact_facet.hh File Reference

Individual facets for use with contact interaction models.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/facet.hh"
#include "utils/surface_model/include/interaction_facet.hh"
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "class_declarations.hh"
```

Data Structures

· class jeod::ContactFacet

An contact interaction specific facet for use in the surface model.

Namespaces

jeod

Namespace jeod.

9.5.1 Detailed Description

Individual facets for use with contact interaction models.

Definition in file contact_facet.hh.

9.6 contact_messages.cc File Reference

```
Implement contact_messages.
```

```
#include "../include/contact_messages.hh"
```

Namespaces

• jeod

Namespace jeod.

Macros

• #define PATH "interactions/contact"

9.6.1 Detailed Description

Implement contact_messages.

Definition in file contact_messages.cc.

9.7 contact_messages.hh File Reference

Contact message for message handling.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/message/include/message_handler.hh"
```

Data Structures

· class jeod::ContactMessages

Messages associated with use of the contact model.

Namespaces

jeod

Namespace jeod.

9.7.1 Detailed Description

Contact message for message handling.

Definition in file contact_messages.hh.

9.8 contact_pair.cc File Reference

ContactPair class for use with contact interaction model.

```
#include "utils/math/include/vector3.hh"
#include "dynamics/mass/include/mass.hh"
#include "../include/contact_pair.hh"
```

Namespaces

• jeod

Namespace jeod.

9.8.1 Detailed Description

ContactPair class for use with contact interaction model.

Definition in file contact_pair.cc.

9.9 contact_pair.hh File Reference

Base class for pair of contact facets for use with contact interaction model.

```
#include "dynamics/derived_state/include/relative_derived_state.hh"
#include "utils/sim_interface/include/jeod_class.hh"
#include "class_declarations.hh"
#include "contact_facet.hh"
```

Data Structures

· class jeod::ContactPair

An base contact pair class for use in the contact model.

Namespaces

jeod

Namespace jeod.

9.9.1 Detailed Description

Base class for pair of contact facets for use with contact interaction model.

Definition in file contact pair.hh.

9.10 contact_params.cc File Reference

contact parameters for use in the surface model

```
#include "utils/memory/include/jeod_alloc.hh"
#include "../include/contact_params.hh"
```

Namespaces

• jeod

Namespace jeod.

9.10.1 Detailed Description

contact parameters for use in the surface model

Definition in file contact_params.cc.

9.11 contact_params.hh File Reference

A class for contact facet parameters, used to create interaction facets for contact in the InteractionSurfaceFactorys.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/facet_params.hh"
```

Data Structures

· class jeod::ContactParams

A base class for all contact parameters used in the surface model.

Namespaces

jeod

Namespace jeod.

9.11.1 Detailed Description

A class for contact facet parameters, used to create interaction facets for contact in the InteractionSurfaceFactorys. Definition in file contact_params.hh.

9.12 contact surface.cc File Reference

Vehicle surface model for the contact interaction models.

Namespaces

jeod

Namespace jeod.

9.12.1 Detailed Description

Vehicle surface model for the contact interaction models.

Definition in file contact_surface.cc.

9.13 contact surface.hh File Reference

Vehicle surface model for contact.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_surface.hh"
#include "utils/surface_model/include/class_declarations.hh"
#include "contact_facet.hh"
```

Data Structures

· class jeod::ContactSurface

The contact specific interaction surface, for use with the surface model.

Namespaces

jeod

Namespace jeod.

9.13.1 Detailed Description

Vehicle surface model for contact.

Definition in file contact_surface.hh.

9.14 contact_surface_factory.cc File Reference

Factory that creates an contact surface, from a surface model.

```
#include <cstring>
#include "dynamics/mass/include/mass.hh"
#include "utils/surface_model/include/facet.hh"
#include "utils/surface_model/include/facet_params.hh"
#include "utils/surface_model/include/surface_model.hh"
#include "utils/surface_model/include/interaction_surface.hh"
#include "../include/contact_surface_factory.hh"
#include "../include/contact_messages.hh"
#include "../include/contact_params.hh"
```

Namespaces

jeod

Namespace jeod.

9.14.1 Detailed Description

Factory that creates an contact surface, from a surface model.

Definition in file contact_surface_factory.cc.

9.15 contact_surface_factory.hh File Reference

Factory that creates an contact interaction surface from a surface model.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/interaction_surface_factory.hh"
#include "utils/surface_model/include/class_declarations.hh"
#include "point_contact_facet_factory.hh"
#include "line_contact_facet_factory.hh"
```

Data Structures

· class jeod::ContactSurfaceFactory

The surface factory that creates an contact specific surface from a general surface.

Namespaces

• jeod

Namespace jeod.

9.15.1 Detailed Description

Factory that creates an contact interaction surface from a surface model.

Definition in file contact_surface_factory.hh.

9.16 contact_utils.hh File Reference

This Model is used for utility rotines.

```
#include "contact_utils_inline.hh"
```

Data Structures

class jeod::ContactUtils

Utility string and math functions for the contact model.

Namespaces

• jeod

Namespace jeod.

9.16.1 Detailed Description

This Model is used for utility rotines.

Definition in file contact utils.hh.

9.17 contact_utils_inline.hh File Reference

Define ContactUtils::create_relstate_name, ContactUtils::copy_const_char_to_char.

```
#include <cstring>
#include "utils/math/include/vector3.hh"
#include "contact_utils.hh"
#include "contact_messages.hh"
```

Namespaces

· jeod

Namespace jeod.

9.17.1 Detailed Description

Define ContactUtils::create relstate name, ContactUtils::copy const char to char.

Definition in file contact_utils_inline.hh.

9.18 line_contact_facet.cc File Reference

Define LineContactFacet functions.

```
#include <cmath>
#include "utils/math/include/vector3.hh"
#include "utils/math/include/matrix3x3.hh"
#include "utils/math/include/numerical.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "../include/contact_messages.hh"
#include "../include/contact_params.hh"
#include "../include/line_contact_facet.hh"
#include "../include/line_contact_pair.hh"
#include "../include/line_point_contact_pair.hh"
#include "../include/contact_utils.hh"
#include "../include/contact_hh"
```

Namespaces

• jeod

Namespace jeod.

9.18.1 Detailed Description

Define LineContactFacet functions.

Definition in file line_contact_facet.cc.

9.19 line_contact_facet.hh File Reference

The contact facet based on the distance to a line segment centered on the vehicle point.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "dynamics/derived_state/include/relative_derived_state.hh"
#include "class_declarations.hh"
#include "point_contact_facet.hh"
#include "line_contact_pair.hh"
#include "line_point_contact_pair.hh"
```

Data Structures

· class jeod::LineContactFacet

The contact facet based on the distance to a single point, specifically the vehicle point.

Namespaces

• jeod

Namespace jeod.

9.19.1 Detailed Description

The contact facet based on the distance to a line segment centered on the vehicle point. In effect this represents a cylinder with spherical ends.

Definition in file line contact facet.hh.

9.20 line_contact_facet_factory.cc File Reference

Factory that creates a LineContactFacetFactory from a Cylinder facet and a ContactParams object.

Namespaces

jeod

Namespace jeod.

9.20.1 Detailed Description

Factory that creates a LineContactFacetFactory from a Cylinder facet and a ContactParams object.

Definition in file line_contact_facet_factory.cc.

9.21 line_contact_facet_factory.hh File Reference

Creates a line contact facet from an cylinder facet.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/class_declarations.hh"
#include "utils/surface_model/include/interaction_facet.hh"
#include "utils/surface_model/include/interaction_facet_factory.hh"
#include "class_declarations.hh"
#include "line_contact_facet.hh"
```

Data Structures

class jeod::LineContactFacetFactory

Creates a PointContactFacet from an InteractionFacet.

Namespaces

jeod

Namespace jeod.

9.21.1 Detailed Description

Creates a line contact facet from an cylinder facet.

Definition in file line_contact_facet_factory.hh.

9.22 line_contact_pair.cc File Reference

LineContactPair class for use with contact interaction model.

```
#include "dynamics/mass/include/mass.hh"
#include "utils/named_item/include/named_item.hh"
#include "../include/line_contact_pair.hh"
#include "../include/line_contact_facet.hh"
#include "../include/pair_interaction.hh"
#include "../include/contact_utils.hh"
```

Namespaces

jeod

Namespace jeod.

9.22.1 Detailed Description

LineContactPair class for use with contact interaction model.

Definition in file line_contact_pair.cc.

9.23 line_contact_pair.hh File Reference

Class for a pair of line contact facets for use with contact interaction model.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "contact_pair.hh"
#include "class_declarations.hh"
```

Data Structures

class jeod::LineContactPair

An point to point contact pair for use in the contact model.

Namespaces

· jeod

Namespace jeod.

9.23.1 Detailed Description

Class for a pair of line contact facets for use with contact interaction model.

Definition in file line_contact_pair.hh.

9.24 line_point_contact_pair.cc File Reference

LinePointContactPair class for use with contact interaction model.

```
#include "dynamics/mass/include/mass.hh"
#include "utils/named_item/include/named_item.hh"
#include "../include/line_point_contact_pair.hh"
#include "../include/line_contact_facet.hh"
#include "../include/point_contact_facet.hh"
#include "../include/pair_interaction.hh"
#include "../include/contact_utils.hh"
```

Namespaces

jeod

Namespace jeod.

9.24.1 Detailed Description

LinePointContactPair class for use with contact interaction model.

Definition in file line_point_contact_pair.cc.

9.25 line_point_contact_pair.hh File Reference

Class for a pair of a line contact facet and a point contact facet for use with contact interaction model.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "contact_pair.hh"
#include "class_declarations.hh"
```

Data Structures

· class jeod::LinePointContactPair

An point to point contact pair for use in the contact model.

Namespaces

jeod

Namespace jeod.

9.25.1 Detailed Description

Class for a pair of a line contact facet and a point contact facet for use with contact interaction model.

Definition in file line_point_contact_pair.hh.

9.26 pair_interaction.cc File Reference

A class to define the interaction type for a pair of contact facets.

```
#include <cstring>
#include "../include/pair_interaction.hh"
#include "../include/contact_facet.hh"
#include "../include/contact_params.hh"
```

Namespaces

jeod

Namespace jeod.

9.26.1 Detailed Description

A class to define the interaction type for a pair of contact facets. This is a base class and derived classes define the force generation function when contact between facets occurs.

Definition in file pair_interaction.cc.

9.27 pair_interaction.hh File Reference

A class to define the interaction type for a pair of contact facets.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "dynamics/derived_state/include/class_declarations.hh"
#include "../include/class_declarations.hh"
```

Data Structures

· class jeod::PairInteraction

Simple spring contact parameters.

Namespaces

jeod

Namespace jeod.

9.27.1 Detailed Description

A class to define the interaction type for a pair of contact facets. This is a base class and derived classes define the force generation function when contact between facets occurs.

Definition in file pair_interaction.hh.

9.28 point_contact_facet.cc File Reference

Define PointContactFacet functions.

```
#include <cstring>
#include "utils/math/include/vector3.hh"
#include "utils/math/include/matrix3x3.hh"
#include "utils/math/include/numerical.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "../include/contact_messages.hh"
#include "../include/contact_params.hh"
#include "../include/point_contact_facet.hh"
#include "../include/point_contact_pair.hh"
#include "../include/contact_utils.hh"
#include "../include/contact.hh"
```

Namespaces

jeod

Namespace jeod.

9.28.1 Detailed Description

Define PointContactFacet functions.

Definition in file point_contact_facet.cc.

9.29 point_contact_facet.hh File Reference

The contact facet based on the distance to a single point, specifically the vehicle point.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "dynamics/derived_state/include/relative_derived_state.hh"
#include "class_declarations.hh"
#include "contact_facet.hh"
#include "point_contact_pair.hh"
```

Data Structures

class jeod::PointContactFacet

The contact facet based on the distance to a single point, specifically the vehicle point.

Namespaces

jeod

Namespace jeod.

9.29.1 Detailed Description

The contact facet based on the distance to a single point, specifically the vehicle point. In effect this represents a sphere.

Definition in file point_contact_facet.hh.

9.30 point_contact_facet_factory.cc File Reference

Factory that creates a PointContactFacet from a FlatPlateCircular facet and a ContactParams object.

```
#include <typeinfo>
#include <cstddef>
#include "utils/surface_model/include/flat_plate_circular.hh"
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "utils/memory/include/jeod_alloc.hh"
#include "../include/point_contact_facet_factory.hh"
#include "../include/point_contact_facet.hh"
#include "../include/contact_messages.hh"
#include "../include/contact_params.hh"
```

Namespaces

ieod

Namespace jeod.

9.30.1 Detailed Description

Factory that creates a PointContactFacet from a FlatPlateCircular facet and a ContactParams object.

Definition in file point contact facet factory.cc.

9.31 point_contact_facet_factory.hh File Reference

Creates a point contact facet from an circular flat plate facet.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "utils/surface_model/include/class_declarations.hh"
#include "utils/surface_model/include/interaction_facet.hh"
#include "utils/surface_model/include/interaction_facet_factory.hh"
#include "class_declarations.hh"
#include "point_contact_facet.hh"
```

Data Structures

class jeod::PointContactFacetFactory

Creates a PointContactFacet from an InteractionFacet.

Namespaces

jeod

Namespace jeod.

9.31.1 Detailed Description

Creates a point contact facet from an circular flat plate facet.

Definition in file point contact facet factory.hh.

9.32 point_contact_pair.cc File Reference

ContactPair class for use with contact interaction model.

```
#include "utils/named_item/include/named_item.hh"
#include "../include/point_contact_pair.hh"
#include "../include/point_contact_facet.hh"
#include "../include/pair_interaction.hh"
#include "../include/contact_utils.hh"
```

Namespaces

jeod

Namespace jeod.

9.32.1 Detailed Description

ContactPair class for use with contact interaction model.

Definition in file point_contact_pair.cc.

9.33 point_contact_pair.hh File Reference

Class for a pair of point contact facets for use with contact interaction model.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "contact_pair.hh"
#include "class_declarations.hh"
```

Data Structures

class jeod::PointContactPair

An point to point contact pair for use in the contact model.

Namespaces

• jeod

Namespace jeod.

9.33.1 Detailed Description

Class for a pair of point contact facets for use with contact interaction model.

Definition in file point_contact_pair.hh.

9.34 spring_pair_interaction.cc File Reference

spring pair interaction for use in the contact model

```
#include <cmath>
#include "utils/math/include/vector3.hh"
#include "dynamics/dyn_body/include/body_ref_frame.hh"
#include "dynamics/dyn_body/include/dyn_body.hh"
#include "dynamics/derived_state/include/relative_derived_state.hh"
#include "../include/spring_pair_interaction.hh"
#include "../include/contact_facet.hh"
```

Namespaces

jeod

Namespace jeod.

9.34.1 Detailed Description

spring pair interaction for use in the contact model

Definition in file spring pair interaction.cc.

9.35 spring_pair_interaction.hh File Reference

A class for pair interactions based on a simple spring.

```
#include "utils/sim_interface/include/jeod_class.hh"
#include "pair_interaction.hh"
```

Data Structures

• class jeod::SpringPairInteraction

Simple spring contact parameters.

Namespaces

· jeod

Namespace jeod.

9.35.1 Detailed Description

A class for pair interactions based on a simple spring.

Definition in file spring_pair_interaction.hh.

Index

\sim Contact	jeod::PointContactFacet, 57
jeod::Contact, 18	check_contact
\sim ContactFacet	jeod::Contact, 18
jeod::ContactFacet, 24	check_tree
\sim ContactPair	jeod::ContactPair, 31
jeod::ContactPair, 31	class_declarations.hh, 67
\sim ContactParams	collect_forces_torques
jeod::ContactParams, 35	jeod::ContactSurface, 37
\sim ContactSurface	Contact, 13
jeod::ContactSurface, 37	jeod::Contact, 18
\sim ContactSurfaceFactory	PATH, 14
jeod::ContactSurfaceFactory, 39	contact.cc, 67
\sim LineContactFacet	contact.hh, 68
jeod::LineContactFacet, 44	contact_facet.cc, 68
\sim LineContactFacetFactory	contact_facet.hh, 69
jeod::LineContactFacetFactory, 47	contact facets
\sim LineContactPair	jeod::ContactSurface, 38
jeod::LineContactPair, 49	contact force
\sim LinePointContactPair	jeod::ContactSurface, 38
jeod::LinePointContactPair, 51	contact_limit_factor
\sim PairInteraction	jeod::Contact, 22
jeod::PairInteraction, 54	contact_messages.cc, 69
\sim PointContactFacet	contact_messages.hh, 70
jeod::PointContactFacet, 57	contact_messages.mi, 70
~PointContactFacetFactory	contact_pair.cc, 70
jeod::PointContactFacetFactory, 60	_
~PointContactPair	contact_pairs
jeod::PointContactPair, 63	jeod::Contact, 22
~SpringPairInteraction	contact_params.cc, 71
jeod::SpringPairInteraction, 65	contact_params.hh, 71
	contact_point
active	jeod::PointContactFacet, 59
jeod::Contact, 22	contact_surface.cc, 72
jeod::ContactFacet, 25	contact_surface.hh, 72
add_facet_params	contact_surface_factory.cc, 73
jeod::ContactSurfaceFactory, 40	contact_surface_factory.hh, 73
allocate_array	contact_torque
jeod::ContactSurface, 37	jeod::ContactSurface, 38
allocate_interaction_facet	contact_utils.hh, 74
jeod::ContactSurface, 37	contact_utils_inline.hh, 74
,	ContactFacet
calculate_contact_point	jeod::ContactFacet, 24
jeod::LineContactFacet, 44	ContactMessages
jeod::PointContactFacet, 57	jeod::ContactMessages, 28
calculate forces	ContactPair
jeod::PairInteraction, 54	jeod::ContactPair, 31
jeod::SpringPairInteraction, 65	ContactParams
calculate_torque	jeod::ContactParams, 35
jeod::ContactFacet, 24	ContactSurface
jeod::LineContactFacet, 44	jeod::ContactSurface, 37
-	•

ContactSurfaceFactory	jeod::ContactSurfaceFactory, 40
jeod::ContactSurfaceFactory, 39, 40	init_attrjeodLineContactFacet
copy_const_char_to_char	jeod::LineContactFacet, 45
jeod::ContactUtils, 41	init_attrjeodLineContactFacetFactory
create_facet	jeod::LineContactFacetFactory, 48
jeod::LineContactFacetFactory, 47	init_attrjeodLineContactPair
jeod::PointContactFacetFactory, 61	jeod::LineContactPair, 50
create_pair	init_attrjeodLinePointContactPair
jeod::ContactFacet, 24, 25	jeod::LinePointContactPair, 52
jeod::LineContactFacet, 44, 45	init_attrjeodPairInteraction
jeod::PointContactFacet, 58	jeod::PairInteraction, 55
create_relstate_name	init_attrjeodPointContactFacet
jeod::ContactUtils, 42	jeod::PointContactFacet, 59
create_surface	init_attrjeodPointContactFacetFactory
jeod::ContactSurfaceFactory, 40	jeod::PointContactFacetFactory, 61
create_vehicle_point	init_attrjeodPointContactPair
jeod::ContactFacet, 25	jeod::PointContactPair, 63
	init_attrjeodSpringPairInteraction
damping_b	jeod::SpringPairInteraction, 66
jeod::SpringPairInteraction, 66	initialization_error
dist_line_segments	jeod::ContactMessages, 28
jeod::ContactUtils, 42	initialization warns
dyn_manager	jeod::ContactMessages, 28
jeod::Contact, 22	initialize contact
	jeod::Contact, 19
facets_size	initialize_pair
jeod::ContactSurface, 38	jeod::ContactPair, 32
find_interaction	jeod::LineContactPair, 49
jeod::Contact, 18	jeod::LinePointContactPair, 52
friction_mag	jeod::PointContactPair, 63
jeod::PairInteraction, 55	initialize_relstate
	jeod::ContactPair, 32
get_name	InputProcessor
jeod::ContactFacet, 25	jeod::Contact, 21
get_subject	jeod::Contact, 21 jeod::ContactFacet, 25
jeod::ContactPair, 31	jeod::ContactMessages, 28
get_target	-
jeod::ContactPair, 31	jeod::ContactPair, 33
	jeod::ContactParams, 35
in_contact	jeod::ContactSurface, 38 jeod::ContactSurfaceFactory, 40
jeod::ContactPair, 32	
jeod::LineContactPair, 49	jeod::LineContactFacet, 45
jeod::LinePointContactPair, 52	jeod::LineContactFacetFactory, 48
jeod::PointContactPair, 63	jeod::LineContactPair, 50
in_range	jeod::LinePointContactPair, 52
jeod::ContactPair, 32	jeod::PairInteraction, 55
init_attrjeodContact	jeod::PointContactFacet, 59
jeod::Contact, 21	jeod::PointContactFacetFactory, 61
init_attrjeodContactFacet	jeod::PointContactPair, 63
jeod::ContactFacet, 25	jeod::SpringPairInteraction, 66
init_attrjeodContactMessages	interaction
jeod::ContactMessages, 28	jeod::ContactPair, 33
init_attrjeodContactPair	interaction_distance
jeod::ContactPair, 33	jeod::ContactPair, 33
init_attrjeodContactParams	Interactions, 12
jeod::ContactParams, 35	is_active
init_attrjeodContactSurface	jeod::ContactPair, 32
jeod::ContactSurface, 38	is_complete
init_attrjeodContactSurfaceFactory	jeod::ContactPair, 33

is_correct_factory	in_contact, 32
jeod::LineContactFacetFactory, 47	in_range, 32
jeod::PointContactFacetFactory, 61	init_attrjeodContactPair, 33
is_correct_interaction	initialize_pair, 32
jeod::PairInteraction, 54	initialize_relstate, 32
jeod, 15	InputProcessor, 33
jeod::Contact, 17	interaction, 33
~Contact, 18	interaction_distance, 33
active, 22	is_active, 32
check_contact, 18	is_complete, 33
Contact, 18	operator=, 33
contact, 10 contact_limit_factor, 22	rel_state, 33
contact_nint_lactor, 22	subject, 34
dyn_manager, 22	target, 34
find_interaction, 18	jeod::ContactParams, 34
init_attrjeodContact, 21	\sim ContactParams, 35
initialize_contact, 19	ContactParams, 35
InputProcessor, 21	init_attrjeodContactParams, 35
operator=, 19	InputProcessor, 35
pair_interactions, 22	operator=, 35
register_contact, 19, 21	jeod::ContactSurface, 35
register interaction, 21	\sim ContactSurface, 37
unique_pair, 21	allocate_array, 37
jeod::ContactFacet, 23	allocate_interaction_facet, 37
~ContactFacet, 24	collect_forces_torques, 37
active, 25	contact_facets, 38
calculate_torque, 24	contact_force, 38
ContactFacet, 24	contact_torque, 38
create_pair, 24, 25	ContactSurface, 37
create_vehicle_point, 25	facets_size, 38
get_name, 25	init_attrjeodContactSurface, 38
init_attrjeodContactFacet, 25	InputProcessor, 38
InputProcessor, 25	operator=, 37
max_dimension, 26	jeod::ContactSurfaceFactory, 38
normal, 26	\sim ContactSurfaceFactory, 39
operator=, 25	add_facet_params, 40
position, 26	ContactSurfaceFactory, 39, 40
set max dimension, 25	create_surface, 40
surface_type, 26	init_attrjeodContactSurfaceFactory, 40
vehicle_body, 26	InputProcessor, 40
vehicle_point, 26	line_contact_facet_factory, 40
jeod::ContactMessages, 27	operator=, 40
ContactMessages, 28	point_contact_facet_factory, 41
init_attrjeodContactMessages, 28	jeod::ContactUtils, 41
initialization_error, 28	copy_const_char_to_char, 41
initialization warns, 28	create_relstate_name, 42
InputProcessor, 28	dist_line_segments, 42
operator=, 28	jeod::LineContactFacet, 43
pre_initialization_error, 28	~LineContactFacet, 44
runtime_error, 29	calculate_contact_point, 44
runtime_inform, 29	calculate_torque, 44
runtime_warns, 29	create_pair, 44, 45
jeod::ContactPair, 29	init_attrjeodLineContactFacet, 45
~ContactPair, 31	InputProcessor, 45
check_tree, 31	length, 46
ContactPair, 31	LineContactFacet, 44
get_subject, 31	operator=, 45
get_target, 31	set_max_dimension, 45
301_101.901, 01	ost_max_amonoion, to

jeod::LineContactFacetFactory, 46	PointContactFacetFactory, 60
~LineContactFacetFactory, 47	jeod::PointContactPair, 62
create_facet, 47	\sim PointContactPair, 63
init_attrjeodLineContactFacetFactory, 48	in_contact, 63
InputProcessor, 48	init_attrjeodPointContactPair, 63
is_correct_factory, 47	initialize_pair, 63
LineContactFacetFactory, 47	InputProcessor, 63
operator=, 48	operator=, 63
jeod::LineContactPair, 48	point_subject, 64
\sim LineContactPair, 49	point_target, 64
in_contact, 49	PointContactPair, 63
init_attrjeodLineContactPair, 50	jeod::SpringPairInteraction, 64
initialize_pair, 49	\sim SpringPairInteraction, 65
InputProcessor, 50	calculate_forces, 65
line_subject, 50	damping_b, 66
line_target, 50	init_attrjeodSpringPairInteraction, 66
LineContactPair, 49	InputProcessor, 66
operator=, 50	mu, 66
jeod::LinePointContactPair, 50	operator=, 66
~LinePointContactPair, 51	spring_k, 66
in contact, 52	SpringPairInteraction, 65
init attrjeod LinePointContactPair, 52	
initialize pair, 52	length
InputProcessor, 52	jeod::LineContactFacet, 46
line_subject, 52	line_contact_facet.cc, 75
LinePointContactPair, 51, 52	line_contact_facet.hh, 75
operator=, 52	line_contact_facet_factory
point_target, 53	jeod::ContactSurfaceFactory, 40
jeod::PairInteraction, 53	line_contact_facet_factory.cc, 76
~PairInteraction, 54	line_contact_facet_factory.hh, 76
	line_contact_pair.cc, 77
calculate_forces, 54	line_contact_pair.hh, 77
friction_mag, 55	line point contact pair.cc, 78
init_attrjeodPairInteraction, 55	line_point_contact_pair.hh, 78
InputProcessor, 55	line_subject
is_correct_interaction, 54	jeod::LineContactPair, 50
operator=, 55	jeod::LinePointContactPair, 52
PairInteraction, 54	line_target
params_1, 55	jeod::LineContactPair, 50
params_2, 55	LineContactFacet
jeod::PointContactFacet, 56	jeod::LineContactFacet, 44
∼PointContactFacet, 57	LineContactFacetFactory
calculate_contact_point, 57	jeod::LineContactFacetFactory, 47
calculate_torque, 57	LineContactPair
contact_point, 59	jeod::LineContactPair, 49
create_pair, 58	LinePointContactPair
<pre>init_attrjeodPointContactFacet, 59</pre>	jeod::LinePointContactPair, 51, 52
InputProcessor, 59	jeodEmer omtoomaan an, 51, 52
operator=, 58	max dimension
PointContactFacet, 57	jeod::ContactFacet, 26
radius, 59	Models, 11
set_max_dimension, 58	mu
jeod::PointContactFacetFactory, 59	jeod::SpringPairInteraction, 66
~PointContactFacetFactory, 60	jeodopringi dirinterdetion, oo
create_facet, 61	normal
init_attrjeodPointContactFacetFactory, 61	jeod::ContactFacet, 26
InputProcessor, 61	jeouoontacti acet, 20
is_correct_factory, 61	operator=
operator=, 61	jeod::Contact, 19
apolatoi –, VI	journa of tract, 10

jeod::ContactFacet, 25	jeod::ContactPair, 33
jeod::ContactMessages, 28	runtime_error
jeod::Contactwessages, 20	jeod::ContactMessages, 29
jeod::ContactParams, 35	runtime_inform
-	
jeod::ContactSurface, 37	jeod::ContactMessages, 29
jeod::ContactSurfaceFactory, 40	runtime_warns
jeod::LineContactFacet, 45	jeod::ContactMessages, 29
jeod::LineContactFacetFactory, 48	and many discounting
jeod::LineContactPair, 50	set_max_dimension
jeod::LinePointContactPair, 52	jeod::ContactFacet, 25
jeod::PairInteraction, 55	jeod::LineContactFacet, 45
jeod::PointContactFacet, 58	jeod::PointContactFacet, 58
jeod::PointContactFacetFactory, 61	spring_k
jeod::PointContactPair, 63	jeod::SpringPairInteraction, 66
jeod::SpringPairInteraction, 66	spring_pair_interaction.cc, 83
	spring_pair_interaction.hh, 83
PATH	SpringPairInteraction
Contact, 14	jeod::SpringPairInteraction, 65
pair interaction.cc, 79	subject
pair_interaction.hh, 79	jeod::ContactPair, 34
pair interactions	surface type
jeod::Contact, 22	jeod::ContactFacet, 26
PairInteraction	jedadomacii acci, 20
	target
jeod::PairInteraction, 54	jeod::ContactPair, 34
params_1	jedadomacii aii, 04
jeod::PairInteraction, 55	unique_pair
params_2	jeod::Contact, 21
jeod::PairInteraction, 55	jeodoomaci, 21
point_contact_facet.cc, 80	vehicle_body
point_contact_facet.hh, 80	jeod::ContactFacet, 26
point_contact_facet_factory	vehicle_point
jeod::ContactSurfaceFactory, 41	
point_contact_facet_factory.cc, 81	jeod::ContactFacet, 26
point_contact_facet_factory.hh, 81	
point_contact_pair.cc, 82	
point_contact_pair.hh, 82	
point_subject	
jeod::PointContactPair, 64	
point_target	
jeod::LinePointContactPair, 53	
jeod::PointContactPair, 64	
PointContactFacet	
jeod::PointContactFacet, 57	
PointContactFacetFactory	
jeod::PointContactFacetFactory, 60	
PointContactPair	
jeod::PointContactPair, 63	
position	
jeod::ContactFacet, 26	
pre_initialization_error	
jeod::ContactMessages, 28	
radius	
jeod::PointContactFacet, 59	
register_contact	
jeod::Contact, 19, 21	
register_interaction	
jeod::Contact, 21	
rel_state	