CONFIDENTIAL

Table of Contents

| 1. Overv | view | |
|----------|--------------------------------|----|
| 1.1 Ov | verview | |
| 1.2 Fu | unction | |
| 1.3 Re | eference | |
| 1.3.1 | Related Documents | |
| 1.4 No | otice | 2 |
| 1.5 Te | erminology | 2 |
| | | |
| 2. Opera | ating Environment | 3 |
| 2.1 Ha | ardware Environment | 3 |
| 2.2 Flo | lowchart | 4 |
| | | |
| 3. Comr | mand Specification | 5 |
| 3.1 CF | PLD help command | 5 |
| 3.1.1 | Synopsis | 5 |
| 3.1.2 | Description | 5 |
| 3.1.3 | Command option | 5 |
| 3.1.4 | Notice | |
| 3.2 CF | PLD list command | 5 |
| 3.2.1 | Synopsis | 5 |
| 3.2.2 | Description | 5 |
| 3.2.3 | Command option | 5 |
| 3.2.4 | Notice | 5 |
| 3.3 CF | PLD change serial command | |
| 3.3.1 | Synopsis | 6 |
| 3.3.2 | Description | 6 |
| 3.3.3 | Command option | 6 |
| 3.3.4 | Notice | |
| 3.4 CF | PLD read command | 7 |
| 3.4.1 | Synopsis | 7 |
| 3.4.2 | Description | 7 |
| 3.4.3 | Command option | |
| 3.4.4 | Notice | |
| 3.5 CF | PLD write command | 8 |
| 3.5.1 | Synopsis | 8 |
| 3.5.2 | Description | 8 |
| 3.5.3 | Command option | |
| 3.5.4 | Notice | |
| | PLD write non-volatile command | 9 |
| 3.6.1 | Synopsis | |
| 3.6.2 | Description | |
| 3.6.3 | Command option | |
| 3.6.4 | Notice | 9 |
| 4 T | | |
| _ | ration | |
| | older Structure | |
| | ardware Connection | |
| | astallation Procedure | |
| 4.3.1 | Dependency software, library | |
| 4.3.2 | CPLD control tool | 17 |

CONFIDENTIAL

| 5. Sample log | 18 |
|---------------|----|
|---------------|----|