Make a little DIAL





Mini tube (from airplane) it will fit perfect on the rotary encoder.

Original top view:





DIAL

Now polish the top on waterproof paper nr. 100 and then on nr. 180. Then polish with water on nr. 180 and Brass polish until it is shining.