Nets joined by label(s): refs auto-assigned
Generated by tools/gen_master.py from master_section_spec.md v0.5

Sheet /	
File: master_sched.sch	
Title: **Master section — goa Console**	Rev: 0.5
Size: User	Date: 2026-10-19
KiCad 8.0.x	Id: 1/1

POWER ENTRY (7-pin XLR NC7MD-LX on the rear panel, two 5 A contacts per rail, 18 AWG to this terminal: +-17 V PSU)

MAIN OUTPUTS: DRV134 -> 10U NP in the Sense loop -> mute relay (NO) -> XLR mate, pin 2 hot

DISTRIBUTION (PTC per wing per rail, 1.6 A hold, 72 V; local branches VA audio, VP phones, VM meters, VL logic)

POWER-ON MUTE: rails > -14 V for ~2 s closes all five relays; either rail low opens them at once

AUX MASTER 5: OPA1656 sum (22K || 100p) + re-invert, level, buffer, DRV134 out, AFL

AUX MASTER 6: OPA1656 sum (22K || 100p) + re-invert, level, buffer, DRV134 out, AFL

EXT INPUT (2-track / DAW) and MIX / EXT monitor select (SW latched = EXT)

GROUND CANCEL BUFFER (feeds every re-inverter; summing amps use the raw GCANCEL line)

MIX L: summing amp (GCANCEL-referenced), re-inverter, master insert

MIX R: summing amp (GCANCEL-referenced), re-inverter, master insert

MASTER FADER (dual 100 mm A10K, pin 1 = GNDA) + post-amps +10 dB

MONO: inverting sum of POST L+R, re-inverter

CONTROL ROOM: C/ROOM dual A10K, followers, DRV134, mute relays, TRS outs

HEADPHONES: PHONES dual A10K, OPA1612 + LME49600 composite (+9.9 dB), 2R2 out, PHONESGND

REMOTE METER HEADER (for a meter bridge)

METER L: full-wave rectifier, precision peak / average, follower (TL072), 2 dB ladder, 2 x 10-LED strings

METER R: full-wave rectifier, precision peak / average, follower (TL072), 2 dB ladder, 2 x 10-LED strings

PFL / AFL: OPA1656 sum (22K || 100p) + re-invert, SOLO LEVEL, follower

PFL SWITCHER: series J112 (Beta ED2780 sh.1) -> CR5 L/R followers

PFL DETECT (1.5 V per press vs 0.74 V), complementary ramps, rude-solo flasher

MOTHERLOOM (master in the center: CN1 = left wing, CN2 = right wing; Delta pinout)