

Smart-Home Pre-Wiring Checklist

If you're building or renovating, the cabling and conduits you lay **before plastering** decide what automation is possible — and at what cost. Use this room-by-room checklist with your architect/electrician at the MEP stage.

★ **The #1 rule:** insist on a **neutral wire at every switch point**. It's what most homes lack and what every smart switch/keypad needs — retrofitting it later means breaking walls.

When to involve us

At the **electrical & MEP drawing stage** — **before any conduiting**. We overlay automation onto your drawings (device placement, conduit runs, back-box schedule) so the wiring is right the first time.

Room-by-room

Every room

- Neutral at every switch box
- Deep back-boxes (45–60 mm) for keypads
- 1× Cat6 to keypad/control location

Living / Media

- 2–4× Cat6 (TV, AV, AP)
- Speaker cable to ceiling (5.1 / Atmos)
- Conduit for projector + motorized screen
- Curtain-motor power + conduit at windows

Bedrooms

- Keypad back-box at bedside + door
- Curtain/blind motor power at windows
- AC indoor-unit control wiring
- 1× Cat6

Kitchen / Utility

- Appliance & exhaust control points
- Water-leak sensor conduit

Bathrooms

- Leak sensor + exhaust automation wiring
- Mirror-defogger / geyser control point

Main door / Entry

- Video-doorbell cabling + Cat6
- Smart-lock power & conduit

Gate / Outdoor

- Gate-motor power + conduit
- CCTV Cat6 home-runs to each camera
- Facade / landscape lighting conduits

Network rack

- Central low-voltage cabinet location
- All Cat6 home-run here + power + ventilation

Electrical panel / DB

- Space for automation DB & actuators
- Dedicated circuits for AV, network, motors

Cabling quick-spec

Use	Cable / spec
Data & control (cameras, keypads, AP, control bus)	Cat6 (or Cat6A) home-run
In-ceiling / multi-room audio	14–16 AWG speaker cable

Curtain / blind / gate motors	2–3 core + earth, motor-rated
Conduit (switch / keypad runs)	20–25 mm, with pull-string
Keypad back-boxes	Deep, 45–60 mm

Send us your floor plans and we'll mark up the wiring free — growmoresolutions.com/solutions/for-architects