Unit 5.2: More on the Qualitative and Quantitative Response of First- and Second-Order Poles

Contents

- Acknowledgements
- Agenda
- Quantitative behaviour of real poles
- Natural frequency
- Analysis of a second-order system
- Step-response of a second-order system
- · Useful quantifiers that result from step response
- Exercises 16
- Summary
- Further exploration
- Still to come
- References
- Footnotes

Follow along at cpjobling.github.io/eg-150- textbook/poles_and_zeros/second_order_properties




Acknowledgements

The notes for this unit have been influenced by the MATLAB LiveScript **PoleZeroAnalysis.mlx** from the MathWorks curriculum module <u>Transfer Function Analysis of Dynamic Systems</u> [Allie, 2024]. You will find some useful interactive applications with which you can explore the concepts presented here. Some of these will be deomostrated in the lecture.

The examples have been inspired by the recording of the second half of the video recording of Stephen Boyd's 1999 lecture 10 (delivered at Stanford University) which itself is based on Qualitative properties of signals & Laplace transforms [Boyd, 1993].

You can watch the video on YouTube here:



Agenda

- Quantitative behaviour of real poles
- Natural frequency
- Step-response of a second-order system
- Useful quantifiers that result from step response
- Exercises 16

Quantitative behaviour of real poles

In <u>Qualitative properties of terms</u> we stated that a response term that corresponds to a real pole $s = \sigma$ will result in a growing expontial if $\sigma > 0$ and a decaying exponential if $\sigma < 0$.

We didn't quantify these effects, so it is useful to do so here.

Rate of exponential growth

Given that the rational polynomial F(s) representing the Laplace transfer of a signal or system has a pole $s=\sigma$, one of the terms in the partial fraction expansion will be

$$rac{r_{\sigma}}{s-\sigma}$$

reconstruction of the contract of

The corresponding term in f(t) will be $r_{\sigma}e^{\sigma t}$.

This will be a growing exponential for which the *doubling time* is a useful measure of the growth rate.

Given that at time t=0, $r_{\sigma}e^{0}=r_{\sigma}$, the doubling time T is the time for which

$$egin{align} r_{\sigma}e^{\sigma T}&=2r_{\sigma}\ e^{\sigma T}&=2\ \sigma T&=\log_e2\ T&=rac{\log_e2}{\sigma}&=rac{0.693147180559945}{\sigma}pproxrac{0.7}{\sigma}. \end{align}$$

Example 7

Plot the response of the pole

$$\frac{10}{s - 0.1}$$


and confirm that the doubling time is around 7 seconds.

Solution to example 7

Done in MATLAB

```
format compact
clear variables
t = linspace(0,15,100);
sigma = 0.1;
% Doubling time
T = log(2)/sigma;
% Plot
plot(t,10*exp(sigma*t)),ylim([0,50]),grid
% Plot and label lines: first doubling
line([T,T],[0,20],'Color','r','LineStyle','--')
line([0,T],[20,20],'Color','r','LineStyle','--')
hold on
plot(T,20,'o')
text(3,22,'First doubling')
% Plot and label lines: second doubling
plot(2*T,40,'o')
line([2*T,2*T],[0,40],'Color','g','LineStyle','--')
```

```
% Label graph
title('Exponential growth'),
ylabel('f(t) = 10*exp(-0.1*t)'),xlabel('Time t [s]')
hold off
```



Given that $\sigma=0.1$, the doubling time $T\approx 0.7/\sigma=7$ s. The initial value is 10 at t=0 s. It has doubled to 20 at $t\approx 7$ s, and has doubled again to 40 at $t\approx 14$.

We have added the exact solutions to the plot.

The MATLAB code to reproduce this result is given in **∠** example7.mlx

Rate of exponential decay

If F(s) has a pole $s=-\sigma$, one of the terms in the partial fraction expansion will be

$$rac{r_{\sigma}}{s+\sigma}$$

where r_{σ} is the residue of the pole.

The corresponding term in f(t) will be $r_{\sigma}e^{-\sigma t}$.

This will be a decaying exponential for which the time constant $au=1/|\sigma|$ is a useful

Putting the time constant into the response equation

$$r_{\sigma}e^{-\sigma au} = r_{\sigma}e^{-1} = 0.367879441171442r_{\sigma} \approx 0.37r_{\sigma}.$$

Thus the response reaches around 37% of it's initial value in $au=1/|\sigma|$ s.

Another measure of decay that is sometimes used is the value of t for which the response reaches 1% of its initial value.

$$egin{aligned} 0.01r_{\sigma} &= r_{\sigma}e^{-t/ au} \ 0.01 &= e^{-t/ au} \ \log_e(0.01) &= -t/ au \ t_{1\%} &pprox 4.6 au \end{aligned}$$

Example 8

The current in the RC circuit shown in Fig. 41 has the transform

$$i(t) = rac{1/RC}{s+1/RC}$$

If $R=1~{\rm M}\Omega$ and $C=10~\mu{\rm F}$, determine:

- (a) The initial current i(0).
- (b) The time constant τ .
- (c) The time at which the current decays to 1% of i(0).

Solution to example 8

(a) The initial current is given by [1]


$$\lim_{s o\infty}sI(s)=\lim_{s o\infty}srac{1/RC}{s+1/RC}=1/RC.$$

Given the component values of R and C, i(0)=1/RC=100 mA.

(c) The time at which the current decays to 1% of i(0) is 46 s.

MATLAB confirmation

```
t = linspace(0,50,100);
R = 1e6; C = 10e-6;
sigma = -1/(R*C);
% Time constant and initial current
tau = 1/abs(sigma); i0 = 1/(R*C);
% Plot
plot(t,i0*exp(sigma*t)),grid
% Plot and label lines: time constant
line([tau,tau],[0,i0*exp(-1)],'Color','r','LineStyle','--')
line([0,tau],[i0*exp(-1),i0*exp(-1)],'Color','r','LineStyle','--')
text(tau+1,i0*exp(-1), 'Time constant: 37% of i0 in 10 seconds')
hold on
plot(tau, i0*exp(-1), 'o')
% Plot and label lines: 1% point
line([4.6*tau,4.6*tau],[0,0.01*i0],'Color','g','LineStyle','--')
line([0,4.6*tau],[0.01*i0,0.01*i0],'Color','g','LineStyle','--')
plot(4.6*tau,0.01*i0,'o')
text(32,0.01*i0+0.005,'1% of initial current in 46 seconds')
% Label graph
title('Exponential decay of current in an RC circuit'),
ylabel('Current i(t) [A]'),xlabel('Time t [s]')
hold off
```



The MATLAB code to reproduce this result is given in \angle example8.mlx

Natural frequency

The locations of the poles in the s-plane determine the natural oscillation frequencies present in the system.

Consider a pole in the complex plane illustrated in Fig. 79




Fig. 79 Phase ϕ and magnitude r of pole p shown in the complex plane

- The natural (undamped) frequency (in rad/s) contributed by a pole p is the pole magnitude, r=|p|.
- The phase, $\phi = \arg p$, determines the relative strength of the oscillatory component.

Analysis of a second-order system

Second-order systems with a pair of conjugate poles and no zeros are useful for illustrating the natural frequency response analytically. It is helpful to write this type of system in the form:

$$G(s) = rac{K}{s^2 + 2\zeta \omega_n s + \omega_n^2}$$

where

- *K* is the gain coefficient
- ζ is the damping ratio already introduced in Complex poles: Damping ratio \zeta and quality factor Q
- and ω_n is the (undamped) natural frequency.

These parameters are helpful for drawing a connection between the natural response of the

system will be analytically computed and related to the natural response of the system.

Pole analysis

The poles of the system occur when the denominator is zero:

$$p_{1,2} = -\zeta \omega_n \pm \omega_n \sqrt{\zeta^2 - 1}$$

For simplicity, consider $\zeta \in [0,1)$. In this case, the poles are

$$p_{1,2} = -\zeta \omega_n \pm j \omega_n \sqrt{1-\zeta^2}$$

As stated above, the natural frequency is defined as the magnitude of the pole. The magnitude is computed as:

$$\sqrt{\mathbf{Re}^2 + \mathbf{Im}^2}$$

Using the definitions illustrated in Fig. 76, ${\bf Re}=-\sigma=-\zeta\omega_n$ and ${\bf Im}=\omega=\omega_n\sqrt{1-\zeta^2}$, so :

$$|p| = \sqrt{\sigma^2 + \omega^2}$$

$$= \sqrt{(-\zeta\omega_n)^2 + (\pm\omega_n\sqrt{1-\zeta^2})^2}$$

$$= \sqrt{\zeta^2\omega_n^2 + \omega_n^2(1-\zeta^2)}$$

$$= |\omega_n|$$

This illustrates why this form of the equation is used: the natural frequency is the parameter ω_n .

The damping ratio ζ determines the relative strength of the exponential part of the response.

As $\zeta \to 1$, the complex part of the pole tends to zero, implying less oscillatory and stronger exponential behavior.

For stable systems, that implies greater damping.

The gain coefficient K affects the magnitude of the response, not the time-dependent

Natural response

The impulse response of a system H(s) is also called the *natural response*. The natural response y(t) is computed by taking the inverse Laplace transform of

$$rac{Y(s)}{X(s)} = rac{Y(s)}{1} = rac{K}{s^2 + 2\zeta\omega_n s + \omega_n^2}$$

because the impulse $x(t)=\delta(t)$ has a Laplace transform 1. You can find the response's analytic form by referring to a table or using the MATLAB ilaplace function.

```
syms s t zeta omega_n K Y(s) y(t)
assume(t > 0)
Y(s) = K/(s^2 + 2*zeta*omega_n*s + omega_n^2)
```

```
Y(s) =
```

```
K/(omega_n^2 + 2*zeta*omega_n*s + s^2)
```

```
y(t) = ilaplace(Y); % The impulse response in the time domain
```

Gives the result

$$y(t) = \frac{K e^{-\zeta \omega_n t} \sin \left(\omega_n t \sqrt{1 - \zeta^2}\right)}{\omega_n \sqrt{1 - \zeta^2}}$$
(60)

Notice that the impulse response is a product of an exponential and sine function. From these functions observe that:

- The sine function frequency (in rads/s) is $\omega_n \sqrt{1-\zeta^2}$. If the damping $\zeta=0$, then the frequency is ω_n . This is the reason ω_n is often referred to as the *undamped natural frequency*.
- The rate of decay of the exponential damping function is $\zeta \omega_n$.
- ullet The gain parameter K only contributes as a constant multiplier to the magnitude of the response.

Step-response of a second-order system

The step response of a system H(s) is often computed. The step response $y_s(t)$ is determined by taking the inverse Laplace transform of

$$Y(s) = rac{1}{s}igg(rac{\omega_n^2}{s^2 + 2\zeta\omega_n s + \omega_n^2}igg)$$

because the step function $x(t)=u_0(t)$ has a Laplace transform 1/s. You can find the response's analytic form by taking partial fraction expansion of Y(s) and then referring to a table of Laplace transforms.

Here we will state, without proof, that the step response will be

$$y_s(t) = \left(1 - e^{-\sigma t} \left(\cos\left(\omega t\right) + \frac{\sigma}{\omega}\sin\left(\omega t\right)\right)\right) u_o(t)$$
 (61)

where:

- $\omega=\omega_n\sqrt{1-\zeta^2}$ is the imaginary part of the system's complex pole pair, sometimes called the *damped natural frequency*
- $\sigma = \zeta \omega_n$ is the magnitide of the real part of the system's complex pole pair
- $\phi = an^{-1} \zeta/(1-\zeta^2)$ is the phase shift.

Note

The proof requires us to complete the square in the denominator of the term with the complex roots

$$\left(s^2+2\zeta\omega_n+\omega_n^2
ight)=\left(s+\zeta\omega_n
ight)^2+\left(\omega_n^2\left(1-\zeta^2
ight)
ight)$$

Then take the PFE of the terms assuming that the complex poles will yield terms:

$$r_{1}\frac{s+\zeta\omega_{n}}{\left(s+\zeta\omega_{n}\right)^{2}+\left(\omega_{n}\sqrt{1-\zeta^{2}}\right)^{2}}+r_{2}\frac{\omega_{n}\sqrt{1-\zeta^{2}}}{\left(s+\zeta\omega_{n}\right)^{2}+\left(\omega_{n}\sqrt{1-\zeta^{2}}\right)^{2}} \quad (62)$$

Making the substitutions $\sigma=\zeta\omega_n$ and $\omega=\omega_n\sqrt{1-\zeta^2}$ we can simplify (62) to

$$r_1 \frac{s+\sigma}{\left(s+\sigma\right)^2 + \omega^2} + r_2 \frac{\omega}{\left(s+\sigma\right)^2 + \omega^2} \tag{63}$$

The step-response terms will then be

$$r_1 e^{-\sigma t} \sin(\omega t) + r_2 e^{-\sigma t} \cos(\omega t)$$

Having computed the residues r_1 and r_2 the sine and cosine terms can be combined to give the final $e^{-\sigma t}\cos(\omega t + \phi)$ expression.

Example 9

Determine the step response for a second order system with $\omega_n=10$ rad/s and $\zeta=0.5$. Confirm your result using (61) and the **tf** and **step** functions.

Solution to example 9

Analytical solution using the symbolic math toolbox

```
syms Y_s(s) y_s(t)
zeta = 0.5; omega_n = 10;
X(s) = 1/s;
H(s) = omega_n^2/(s^2 + 2*zeta*omega_n*s + omega_n^2);
```

$$Y_s(s) = \frac{100}{s(s^2 + 10s + 100)} \tag{64}$$


```
% step response
y_s(t) = ilaplace(Y_s(s));
```

Gives the result

$$y_s(t) = 1 - e^{-5t} \left(\cos\left(5\sqrt{3}t\right) + \frac{\sqrt{3}\sin\left(5\sqrt{3}t\right)}{3} \right) \tag{65}$$

Plot the solution

```
fplot(y_s(t)*heaviside(t),[0,1.2]),ylim([0,1.2]),grid
xlabel('Time (seconds)'),ylabel('y_s(t)'),...
title('Step Response: Determined analytically')
```




Confirming the result with (61) we get:

```
sigma = zeta*omega_n;
omega = omega_n*sqrt(1 - zeta^2);
```

```
t = linspace(0,1.2,100);
yst = (1 - exp(-sigma*t).*(cos(omega*t)+(sigma/omega)*sin(omega*t)));
```

Plot the result

```
plot(t,yst),grid,...
xlabel('Time (seconds)'),ylabel('y_s(t)'),...
title('Step Response: Computed with formula')
```



Using the tf and step functions we get:

```
num = omega_n^2; den = [1 2*zeta*omega_n,omega_n^2];
Hs = tf(num,den)
```


```
Hs =
```

```
100
```

```
s^2 + 10 s + 100
```

Continuous-time transfer function.

```
step(Hs),title('Step Response: Computed with tf function')
```



The MATLAB code to reproduce this result is given in \angle example 9.mlx

Useful quantifiers that result from step response

The relationship between the pole locations and the step response are summarized in Fig. 80 [2]




Fig. 80 Relationship between poles and step response

Knowledge of the location of the poles and their damping ratio and natural frequency are useful for qualtitaive analysis of the response of a complex pole pair. There are also a number of parameters that quantively define the features of the step response which we may be interested in. These are shown in the right-hand picture of <u>Fig. 81</u>. Knowledge of the poles allows us to predict the step response. But also, usefully for many design problems, knowledge of the step response allows us to predict the location of the poles.

We will explore these ideas in the following sections.

Poles

The location of the system poles is important and can be obtained by factorizing the denominator of H(s) either symbolically or numerically. There is also a handy function ${\tt pole}$ which will take these values from a transfer function.

We will illustrate these with the example used in Example 9.

First we set up the system function H(s)

```
syms s t
zeta = 0.5; omega_n = 10;
H = omega_n^2/(s^2 + 2*zeta*omega_n*s + omega_n^2)
```

```
H =
```

```
100/(s^2 + 10*s + 100)
```

Find the poles symbolically

```
[num,den] = numden(H);
sym_poles = factor(den,'FactorMode','full') % FactorMode needed to reduce qual
```

```
sym_poles =
```

```
[s + 5 + 3^{(1/2)}*5i, s + 5 - 3^{(1/2)}*5i]
```

Factors interpreted as

$$\left(s+5+j5\sqrt{3}
ight)\left(s+5-j5\sqrt{3}
ight)$$

Now find the poles numerically

```
% Convert symbolic polynomials to numeric polynomials
n = sym2poly(num); d = sym2poly(den);
```

```
% Compute the roots
num_poles = roots(d)
```

```
num_poles =
-5.0000 + 8.6603i
-5.0000 - 8.6603i
```

Finally from the transfer function model

```
Hs = tf(n,d);
```

```
poles = pole(Hs)
```

```
poles =
-5.0000 + 8.6603i
-5.0000 - 8.6603i
```

Damping ratio and natural frequencies

These are most conveniently obtained from the transfer function using the damp function.

```
[wn,z] = damp(Hs)
```

```
wn =
10.0000
10.0000
```

```
z = 0.5000
0.5000
```

The function damp can also return the poles

```
[wn,z,p] = damp(Hs)
```

```
wn =
10.0000
10.0000
```

```
z = 0.5000
0.5000
```

```
p =
-5.0000 + 8.6603i
-5.0000 - 8.6603i
```

Rise-tme

The *rise time* T_r is a measure of the speed of response of a system. It is usually taken to be the time taken to transition from 10% to 90% of the final value in the initial rise of the response. It is shown in Fig. 81.

The rise-time depends on ω_n but its actual value is also dependent on the damping ratio ζ so we rely on a calibration curve such as that shown in Fig. 81.





Fig. 81 Damping ratio as a function of normalised rise-time for a second-order underdamped response

For the problem being considered $\zeta=0.5$, so $\omega_n T_rpprox 1.65$ giving

$$T_r pprox rac{1.65}{\omega_n} = rac{1.65}{10} = 0.165 \, \mathrm{s}.$$

step(Hs),line([0,0.1],[0.1,0.1]),line([0,0.25],[0.9,0.9])




Settling time

The settling time T_s is defined as the time taken for the peaks of the oscillations in the step response to be bounded by some arbitrary limit. In Fig. 81 the bounds have been set to 2%.

The actual setting time is related to the real part of the poles and, for this case,

$$2\%T_spproxrac{4}{\zeta\omega_n}$$

For our example



The value looks about right!

Peak overshoot

The peak overshoot is a measure of damping in a system and is the height of the first peak ($C_{\rm max}$ in Fig. 81). It is usually quoted as a percentage of the final value.

$$\% ext{OS} = \exp \left(rac{-\zeta \pi}{\sqrt{1-\zeta^2}}
ight) imes 100$$


If we know the peak overshoot, we can calculate the damping ratio ζ using the formula:

$$\zeta = rac{-\log_e\left(\% ext{OS}/100
ight)}{\sqrt{\pi^2 + \log_e^2\left(\% ext{OS}/100
ight)}}$$

For our example

```
POS = 16.3034
```

```
step(Hs),line([0,1.2],[1.16304,1.16304])
```



Reverse formula check

```
z = -\log(POS/100)/sqrt(pi^2 + \log(POS/100)^2)
```

```
z = 0.5000
```


Peak time

We sometimes compute the peak time T_p , which is the time at which the first peak occurs. It depends on the damped natural frequency:

$$T_p = rac{\pi}{\omega_d} = rac{\pi}{\omega_n \sqrt{1-\zeta^2}}$$

For our example

```
step(Hs),line([Tp,Tp],[0,1.16304])
```



List all properties

MATLAB provides a useful function <u>stepinfo</u> that computes a step response for a system and takes measurements of the response to summarize the useful quantitative data defined above as well as a few more quantities.

```
stepinfo(Hs)
```

```
ans =
  struct with fields:

    RiseTime: 0.1639
TransientTime: 0.8076
SettlingTime: 0.8076
SettlingMin: 0.9315
SettlingMax: 1.1629
    Overshoot: 16.2929
Undershoot: 0
    Peak: 1.1629
PeakTime: 0.3592
```

You should compare the values computed with the approximations given in this section.

Exercises 16

Exercise 16.1

A signal or system response f(t) contains the terms

$$\cdots - e^{-2t} - 0.1t^2 \cos(3t+5) \cdots$$
 (66)

- (a) How many poles are there in F(s)?
- (b) What is the nature of the response due to the terms given in (66)?
- (c) Which are the dominant poles?

Exercise 16.2

A system has poles $s=0,\ 1\pm j,\ -1,\ -2\pm j2,\ -3$ and zeros at $s=-1.5,\ -3\pm j3.$


- (a) Give the transfer function F(s)=b(s)/a(a)
- (b) Plot the poles on a pole zero map
- (c) Give the time constant τ , doubling time T, damping ratio ζ , angle θ , natural frequency ω_n , and quality factor Q as appropriate for each pole or pole pair.
- (d) How do the zeros affect the response f(t)?
- (e) Which is the dominant pole?
- (f) Will the system be stable or unstable?


Partial solution to Exercise 16.2

The poles and zeros can be entered into MATLAB

```
z = [-1.5; -3 - 3j; -3 + 3j];
p = [0; 1 + j; 1 - j; -1; -2 + 2j; -2 - 2j; -3];
% Define a transfer function in zero-pole-gain form
Fs = zpk(z,p,1)
```


```
Fs =
```





Bonus: the step response is

step(Fs)



Skip to main content

Exercise 16.3: Spring-Mass-Damper System

You can analyze a mass-spring-damper system (Fig. 82) by looking at the poles of its transfer function.




Fig. 82 Diagram of a spring-mass-damper system

Consider a mass-spring-damper that

- is dynamically forced by an arbitrary function
- has zero initial conditions: x(0)=0 and $x^{\prime}(0)=0$

The position transfer function is

$$G(s)=rac{X(s)}{U(s)}=rac{1}{ms^2+cs+k}$$

(a) Write the mass-spring-damper transfer function in the form

$$G(s) = rac{K}{s^2 + 2 \zeta \omega_n s + \omega_n^2}$$

and solve for the expressions of the gain K, damping ratio ζ , and natural frequency ω_n in terms of the mass-spring-damper parameters. Write your answers using the symbolic variables c, m, and k.

```
% Use these symbolic variables
syms m c k
% Replace the NaNs with your expressions
K = NaN;
omega_n = NaN;
zeta = NaN;
```

- (b) Solve for the symbolic expressions of the poles of G in terms of the mass-spring-damper parameters m, c, and k. Store the expressions below in pplus and pminus where pplus stores the positive root.
- (c) Plot the step response of the system G starting with k=m=1 and c=0. Note the values of the poles, damping ratio, and natural frequency obtained. Observe the stepresponse parameters obtained using <code>sysinfo</code>. Adjust the values of k, m and c and comment on the effects on the step response observed.

Summary

Take aways

Real pole $s=\sigma$:

- Growth rate: $\sigma > 0$, the exponential signal doubles every $T \approx 0.7/\sigma$ s.
- Time constant: $\sigma<0$, the exponential signal decays to 37% of it's original value in $\tau=1/\sigma$ s. The exponential signal reaches 1% of it's original value in $t\approx4.6\tau$ s.

Complex pole pair $s=-\sigma\pm j\omega$:

• Representation of denominator:

$$(s+\sigma+j\omega_n)(s-\sigma+j\omega)=s^2+2\sigma s+\left(\sigma^2+\omega_n^2
ight)$$

- Natural frequency: $\omega_n = \sqrt{\sigma^2 + \omega^2}$
- Damping ratio: $\zeta = -\sigma/\sqrt{\sigma^2 + \omega^2}$

Standard second-order system transfer function

• Transfer function:

$$G(s) = rac{K}{s^2 + 2\zeta \omega_n s + \omega_n^2}$$

• Poles: $p_{1,2} = -\zeta \omega_n \pm j \omega_n \sqrt{1-\zeta^2}$

Performance parameters for second-order system

- Rise time: T_r is estimated from graph of normalized rise-time $\omega_n T_r$ v ζ shown in Fig. 81.
- 2% Setting time: $T_s pprox 4/\sigma$
- ullet Percentage overshoot: $\% \mathrm{OS} = \exp\left(-\zeta \pi/\sqrt{1-\zeta^2}
 ight) imes 100$
- $\bullet \ \ \text{Peak time:} \ T_p=\pi/\omega$

Useful MATLAB commands

- ullet (tf): defines a system as a transfer function n(s)/d(s)
- step: plots the step response of a system
- (pole): lists the poles of a system
- damp: lists the natural frequency and damping ratios of the poles of a system
- stepinfo: lists the properties of the step response of a system

Further exploration

If you have access to MATLAB (desktop of online), you can install the MATLAB curriculum module <u>Transfer Function Analysis of Dynamic Systems</u> [Allie, 2024] and further explore the concepts given here. The MATLAB Live Script **PoleZeroAnalysis.mlx** provides some interactive tools that enable you to interactively explore second order system response and includes the impact of *zeros* which we have not covered here.

Still to come

We will the conclude this module by considering frequency response analysis of signals and systems defined by rational polynomials in s.

References

[All24](1,2) Chad Allie. Transfer function analysis of dynamic systems. 2024. Retrieved April 3, 2024. URL: MathWorks-Teaching-Resources/Transfer-Function-Analysis-of-Dynamic-Systems.

[Boy93] Stephen Boyd. Ee-102: introduction to signals and systems. 1993. Retrieved April 3, 2024. URL: https://web.stanford.edu/~boyd/ee102/.

Footnotes

- [1] This is easily determined from $f(t)|_{t o 0} = rac{1}{RC} e^{-t/RC} ig|_{t o 0} = 1/RC.$
- [2] In the diagram we use a slightly changed notation: $\omega_d = \omega$ is the damped natural frequency given by the imaginary part of the pole and $\sigma_d = \sigma$ is the real part of the pole.

Previous

Unit 5.1: Qualitative Properties

of Signals and Transfer

functions

Vext
Unit 6: Frequency Response >
Analysis