Unit 2.1: Signals and Classification of Signals

Contents

- Subjects to be covered
- Continuous-Time Signals
- Discrete-Time Signals
- Analogue and Digital Signals
- Real and Complex Signals
- Deterministic and Random Signals
- Even and Odd Signals
- Examples 1
- Summary
- Next Time
- References

This section is based on Section 1.2 of [Hsu, 2020].

Follow along at cpjobling.github.io/eg-150-textbook/signals_and_systems/signals



A *signal* is a function representing a physical quality of variable, and typically it contains information about the behaviour or nature of the phenomenon.

For instance, in an *RC* circuit the signal may represent the voltage across the capacitor or the current flowing in the resistor.

- Mathematically, a signal is represented as a function of an independent variable, t.
- Usually *t* represents time.
- Thus a signal is denoted by x(t).

Subjects to be covered

- Continuous-Time Signals
- Discrete-Time Signals
- More on discrete-time signals
- Analogue and Digital Signals
- Real and Complex Signals
- Deterministic and Random Signals
- From and Odd Cianala

Continuous-Time Signals

A signal x(t) is a *continuous-time* (CT) signal if t is a continuous variable. For an example of a continuous-time signal, please see Fig. 10.




Fig. 10 Graphical representation of a continuous-time signal

Discrete-Time Signals

If t is a discrete variable—that is, x(t) is defined at discrete times—then x(t) is a discrete-time (DT) signal. For an example of a discrete-time signal, please see Fig. 11.





Fig. 11 Graphical representation of a discrete-time signal

Since a discrete-time signal is defined at discrete times, a discrete-time is often defined as a sequence of numbers, donated by x[n], where n is an integer (mathematically: $n \in \mathbb{Z}$).


Because discrete-time signals are defined as sequences, it is easy to define and plot a sequence in MATLAB. For example, to redraw <u>Graphical representation of a discrete-time</u> signal, execute the following code.



More on discrete-time signals

A discrete-time signal x[n] may represent a phenomenon for which the independent variable is inherently discrete: e.g. daily stock market average prices.

E.g. FTSE 100 (Fig. 12)



Skip to main content

Sampled data

In electronic engineering, we mostly use discrete-time signals to represent the *sampling* of continuous-time signals.

For example, a discrete-time signal x[n] may be obtained by $\mathit{sampling}$ a continuous-time signal x(t) such as

$$x(t_0), x(t_1), x(t_2), \ldots, x(t_n), \ldots$$

or in a shorter form as

$$x[0],x[1],x[2],\ldots,x[n],\ldots$$

$$x_0, x_1, x_2, \ldots, x_n, \ldots$$

where

$$x_n = x[n] = x(t_n)$$

The x_n 's are called *samples* and the time interval between them is called the *sampling* interval.



ADCs and sampling

In the EG-151 Microcontroller's course the analogue to digital converter (ADC) that you used in one of the experiments sampled the votage on the wiper of the potentiometer to a binary number in the range 0-1023.

Uniform sampling

When the sampling intervals are equal (uniform sampling), then

$$x_n = x[n] = x(nT_s)$$

where the constant T_s is the sampling interval.

There is much more about discrete-time signals in Chapter 1 of [Hsu, 2020] but we will leave it here for now.

We will return to the study of discrete-time signals and discrete-time systems in EG-247 Signals and Systems next year.

Analogue and Digital Signals

If a continuous-time signal x(t) can take on any value in the continuous interval (a, b), where a may be $-\infty$ and b may be $+\infty$, then the continuous-time signal x(t) is called an analogue signal.

If a discrete-time signal x[n] can take on only a finite number of distinct values, then we call this signal a digital signal.

In modern electronics, most physical phenomena which we wish to deal are represented by analogue signals. But more often than not these days, we will process such data by sampling the signals and converting them into digital signals.

💄 Digital signals

The output of an ADC is not a continuous signal. Instead there will be 2^N-1 integer values (where N is the number of *bits* used for the ADC). If the range maximum voltage supplied to an ADC is 5V, what is the quantization level, in volts, of each step?

Real and Complex Signals

A signal x(t) is a real signal if its value if a real number, and a signal x(t) is a complex signal if its value is a complex number.

A general complex signal is a signal x(t) is a function of the form

$$x(t) = x_1(t) + jx_2(t)$$

Skip to main content

where $x_1(t)$ and $x_2(t)$ are real signals and $j=\sqrt{-1}$.

Note that t could represent either a comtinuous or a discrete variable.

We won't see any examples of complex signals in this course.


Deterministic and Random Signals

Deterministic and Random Signals

Deterministic signals are those signals whose values are completely specified for any given time. Thus a deterministic signal can be modelled by a known function of time t.

For example consider $x(t) = 5\sin(10t + \pi/4)$

```
t = linspace(0,2*pi*20,100);
xt = 5*sin(10*t + pi/4);
plot(t,xt),grid,xlabel('t'),ylabel('x(t)')
```




Random signals

Random signals are those signals that take random values at any given time and must be characterised statistically.

Random signals are often used to simulate noise on a signal.

```
% Plot a Random Signal
plot(0.5 + 0.25 * rand(100,1)),ylim([0,1]),grid,title('Random Signal'),...
xlabel('Time t (s)'),ylabel('Amplitude')
```



We will not discuss random signals in this module or the next, but if you are interested, they are covered in detail in Chapters 8 and 9 of [Hsu, 2020].

Even and Odd Signals

An even signal

A signal x(t) is referred to as an even signal if

$$x(t) = x(-t)$$

Skip to main content

See Fig. 13 for an example of an even signal.




Fig. 13 An example of an even signal

An odd signal

A signal x(t) is referred to as an odd signal if

$$x(-t) = -x(t)$$

See Fig. 14 for an example of an odd signal.




Fig. 14 An example of an even signal

$$x(t) = x(-t)$$

Decomposing signals into even and odd parts

Any signal x(t) can be expressed as the sum of two signals, one of which is even and one of which is odd. That is:

$$x(t) = x_e(t) + x_o(t)$$

Where

$$x_e(t) = rac{1}{2}\{x(t) + x(-t)\}$$

$$x_o(t) = rac{1}{2} \{x(t) - x(-t)\}$$

Note the product of two even signals or two odd signals is an even signal and that the product of an even signal and an odd signal is an odd signal.

Examples 1

Example 1.1: Signals



MATLAB Example

We will solve these examples by hand and then give the solution in the MATLAB lab.

A continuous-time signal x(t) is shown in Fig. 15.




Fig. 15 The signal for Example 1.1

Sketch and label each of the following signals.

- a). x(t-2);
- b). x(2t);
- c). x(t/2);
- d). x(-t).

For the answer, refer to the lecture recording or see solved problem 1.1 in [Hsu, 2020]

Example 1.2: Uniform sampling

MATLAB Example

We will solve these examples by hand and then give the solution in the MATLAB lab.

1.2). Given the continuous-time signal specified by

$$x\left(t\right) = egin{cases} 1 - |t| & -1 \leq t \leq 1 \\ 0 & \text{otherwise} \end{cases}$$

determine the discrete-time sequence obtained by uniform sampling of x(t) with a ${\it Skip \ to \ main \ content}$

- a). 0.25 s
- b). 0.5 s, and
- c). 1 s.

For the answer, refer to the lecture recording or see solved problem 1.3 in [Hsu, 2020].

Example 1.3: Odd and even signals



MATLAB Example

We will solve these examples by hand and then give the solution in the MATLAB lab.

Sketch and label the even and odd components of the signals shown in Fig. 16.




Fig. 16 Signals for Example 1.3.

For the answer, refer to the lecture recording or see solved problem 1.5 in [Hsu, 2020].

Example 1.4

Find the odd and even components of $x(t) = e^{jt}$.

For the answer, refer to the lecture recording or see solved problem 1.6 in [Hsu, 2020].

Example 1.5

Show that the product of two even signals or of two odd signals is an even signal and that <u>Skip to main content</u> For the answer, refer to the lecture recording or see solved problem 1.7 in [Hsu, 2020].

Example 1.6

Show that

a). If x(t) is even

$$\int_{-a}^a x(t) dt = 2 \int_0^a x(t) dt.$$

b). If x(t) is odd

$$x(0) = 0$$

$$\int_{-a}^{a} x(t) \, dt = 0.$$

For the answer, refer to the lecture recording or see solved problem 1.8 in [Hsu, 2020].

Summary

In this lecture we have started our look at signals and the classification of signals.

In particular we have looked at

- Continuous-Time Signals x(t)
- Discrete-Time Signals x[n]
- More on discrete-time signals
- Analogue and Digital Signals
- Real and Complex Signals
- Deterministic and Random Signals
- Even and Odd Signals

Unit 2.1: Take aways

* *Continuous time signal m(+)

- *Discrete-time dignal: x[n]
- Sampled data: $x_n = x[n] = x(t_n)$
- ullet Uniform sampling: $x_n=x[n]=x(nT_s)$ where T_s is the sampling period.
- Even signal: x(t) = x(-t)
- Odd signal: x(-t) = -x(t)
- ullet Decomposing signals into even and odd parts: $x(t)=x_e(t)+x_o(t)$ where

$$x_e(t) = \frac{1}{2} \{x(t) + x(-t)\}$$
 and

$$x_o(t) = \frac{1}{2} \{x(t) - x(-t)\}.$$

Next Time

- Periodic and Nonperiodic Signals
- Energy and Power Signals

References

[Hsu20](1,2,3,4,5,6,7,8,9) Hwei P. Hsu. Schaums outlines signals and systems. McGraw-Hill, New York, NY, 2020. ISBN 9780071634724. Available as an eBook. URL: https://www.accessengineeringlibrary.com/content/book/9781260454246.

Various
Unit 2: Signals and Systems

Next
<u>Unit 2.2: Periodic, Energy and</u> >
Power Signals