```
of the OneNote Class Notebook so that you can add your own notes using OneNote.
          You are expected to have at least watched the video presentation of Chapter 6.4 of the notes before coming to class. If you
           haven't watch it afterwards!
          After class, the lecture recording and the annotated version of the worksheets will be made available through Canvas.
          Agenda
            • Discrete Time Systems (Notes)
            • Transfer Functions in the Z-Domain (Notes)

    Modelling digital systems in MATLAB/Simulink

            • Continuous System Equivalents
            • In-class demonstration: Digital Butterworth Filter
          Discrete Time Systems
           In the lecture that introduced the z-transform we talked about the representation of a discrete-time (DT) system by the model
           shown below:
                                             x_d[n] = x(nT_s) y_d[n] = y(nT_s)
                                                                  Discrete Time
                                                                                                                           \rightarrow y(t)
            x(t)
                                                                                                     DT/CT
                                     CT/DT
                                                                     System
                              ADC
                                                                                                             DAC
                                                                       T_s
          In this session, we want to explore the contents of the central block.
          Example 5
          Karris Example 9.10:
          The difference equation describing the input-output relationship of a DT system with zero initial conditions, is:
                                           y[n] - 0.5y[n-1] + 0.125y[n-2] = x[n] + x[n-1]
          Compute:
            1. The transfer function H(z)
            2. The DT impulse response h[n]
            3. The response y[n] when the input x[n] is the DT unit step u_0[n]
          5.1. The transfer function
                                                             H(z) = \frac{Y(z)}{U(z)} = \dots?
          5.2. The DT impulse response
           Start with:
                                                         \frac{H(z)}{z} = \frac{z - 1}{z^2 + 0.5z + 0.125}
          MATLAB Solution
In [ ]: clear all
           imatlab_export_fig('print-svg') % Static svg figures.
           cd matlab
           pwd
           format compact
          See dtm_ex1_2.mlx. (Also available as dtm_ex1_2.m.)
           The difference equation describing the input-output relationship of the DT system with zero initial conditions, is:
                                           y[n] - 0.5y[n-1] + 0.125y[n-2] = x[n] + x[n-1]
           Transfer function
           Numerator z + 1
In [ ]: Nz = [0 1 1];
          Denominator z^2 - 0.5z + 0.125
In []: Dz = [1 -0.5 \ 0.125];
           Poles and residues
In []: [r,p,k] = residue(Nz,Dz)
           Impulse Response
In [ ]: Hz = tf(Nz,Dz,1)
           hn = impulse(Hz, 15);
           Plot the response
In [ ]: stem([0:15], hn)
           grid
           title('Example 5 - Part 2')
           xlabel('n')
           ylabel('Impulse response h[n]')
          Response as stepwise continuous y(t)
In [ ]: impulse(Hz, 15)
           title('Example 5 - Part 2 - As Analogue Signal')
           xlabel('nTs [s]')
           ylabel('Impulse response h(t)')
          5.3. The DT step response
                                                              Y(z) = H(z)X(z)
                                                                u_0[n] \Leftrightarrow \frac{z}{z-1}
                                                 Y(z) = H(z)U_0(z) = \frac{z^2+z}{z^2+0.5z+0.125} \cdot \frac{z}{z-1}
                                                     \frac{Y(z)}{z} = \frac{z^2 + z}{(z^2 + 0.5z + 0.125)(z - 1)}
          Solved by inverse Z-transform.
          MATLAB Solution
           See dtm ex1 3.mlx. (Also available as dtm ex1 3.m.)
In [ ]: open dtm_ex1_3
          Results
                                                                   Example 1 - Part 3
                                     2.5
                                   Stepresponse y[n]
                                     0.5
          Modelling DT systems in MATLAB and Simulink
          We will consider some examples in class
          MATLAB
           Code extracted from <a href="https://doi.org/dtm.ex1_3.m">dtm_ex1_3.m</a>:
In [ ]: Ts = 1;
           z = tf('z', Ts);
In []: Hz = (z^2 + z)/(z^2 - 0.5 * z + 0.125)
In [ ]: step(Hz)
           title('Example 1 - Part 3 - As Analogue Signal')
           xlabel('nTs [s]')
           ylabel('Step response y(t)')
           axis([0,15,0,3.5])
          Simulink Model
           See dtm.slx:
                                                                 z^2+z
                                                             z2-0.5z+0.125
                                                           Discrete Time System
In [ ]:
           dtm
           Results
                                                                      Scope
                            Time offset: 0
          Converting Continuous Time Systems to Discrete Time Systems
          Continuous System Equivalents
            • There is no digital system that uniquely represents a continuous system
            • This is because as we are sampling, we only have knowledge of signals being processed at the sampling instants, and
               need to reconstruct the inter-sample behaviour.
            • In practice, only a small number of transformations are used.
            • The derivation of these is beyond the scope of this module, but here we'll demonstrate the ones that MATLAB provides in a
               function called c2d
          MATLAB c2d function
          Let's see what the help function says:
In [ ]: help c2d
In [ ]: doc c2d
          Example 6
            • Design a 2nd-order butterworth low-pass anti-aliasing filter with transfer function H(s) for use in sampling music.
            • The cut-off frequency \omega_c=20 kHz and the filter should have an attenuation of at least -80 dB in the stop band.
            ullet Choose a suitable sampling frequency for the audio signal and give the transfer function H(z) and an algorithm to
               implement h[n]
          Solution
          See <u>digi_butter.mlx</u>.
          First determine the cut-off frequency \omega_c
                                                     \omega_c = 2\pi f_c = 2 \times \pi \times 20 \times 10^3 \text{ rad/s}
In [ ]: wc = 2*pi*20e3
                                                           \omega_c = 125.66 \times 10^3 \text{ rad/s}
          From the lecture on filters, we know the 2nd-order butterworth filter has transfer function:
                                                    H(s) = \frac{Y(s)}{U(s)} = \frac{\omega_c^2}{s^2 + \omega_c \sqrt{2} s + \omega_c^2}
          Substituting for \omega_c = 125.6637 \times 10^3 this is ...?
In [ ]: Hs = tf(wc^2,[1 wc*sqrt(2), wc^2])
                                                  H(s) = \frac{15.79 \times 10^9}{s^2 + 177.7 \times 10^3 s + 15.79 \times 10^9}
          Bode plot
           MATLAB:
In [ ]: bode(Hs, {1e4,1e8})
           grid
          Sampling Frequency
          From the bode diagram, the frequency at which |H(j\omega)| is -80 dB is approx 12.6\times10^6 rad/s.
          To avoid aliasing, we should choose a sampling frequency twice this = ?
          \omega_s = 2 \times 12.6 \times 10^6 rad/s.
In [ ]: ws = 2* 12.6e6
          So
          \omega_s = 25.2 \times 10^6 \text{ rad/s}.
          Sampling frequency (f_s) in Hz = ?
                                                              f_s = \omega_s/(2\pi) \text{ Mhz}
In [ ]: fs = ws/(2*pi)
                                                               f_s = 40.11 \text{ Mhz}
          Sampling time T_s = ?
          T_s = 1/fs s
In [ ]: Ts = 1/fs
                                                             T_s = 1/f_s \approx 0.25 \ \mu s
          Digital Butterworth
          zero-order-hold equivalent
In []: Hz = c2d(Hs, Ts)
          Step response
In [ ]: step(Hz)
          Algorithm
           From previous result:
                                              H(z) = \frac{Y(z)}{U(z)} = \frac{486.6 \times 10^{-6} z + 476.5 \times 10^{-6}}{z^2 - 1.956z + 0.9567}
          Dividing top and bottom by z^2 ...
                                           H(z) = \frac{Y(z)}{U(z)} = \frac{486.6 \times 10^{-6} z^{-1} + 476.5 \times 10^{-6} z^{-2}}{1 - 1.956 z^{-1} + 0.9567 z^{-2}}
          expanding out ...
                                              Y(z) - 1.956z^{-1}Y(z) + 0.9567z^{-2}Y(z) =
                                                 486.6 \times 10^{-6} z^{-1} U(z) + 476.5 \times 10^{-6} z^{-2} U(z)
           Inverse z-transform gives ...
                                               y[n] - 1.956y[n-1] + 0.9567y[n-2] =
                                                 486.6 \times 10^{-6}u[n-1] + 476.5 \times 10^{-6}u[n-2]
          in algorithmic form (compute y[n] from past values of u and y) ...
                                    y[n] = 1.956y[n-1] - 0.9567y[n-2] + 486.6 \times 10^{-6}u[n-1] + \dots
                                       476.5 \times 10^{-6} u[n-2]
           Block Diagram of the digital BW filter
                                                                                              y[n]
                                     u[n]
                                                                                            y[n-1]
                            u[n-1]
                                                                              1.956
                                            486.6e-6
                                                                                           y[n-2]
                            u[n-2]
                                                                            0.9567
          As Simulink Model
           digifilter.slx
In [ ]: open digifilter
          Convert to code
          To implement:
                          y[n] = 1.956y[n-1] - 0.9567y[n-2] + 486.6 \times 10^{-6}u[n-1] + 476.5 \times 10^{-6}u[n-2]
               /* Initialize */
               Ts = 2.4933e-07; /* more probably some fraction of clock speed */
               ynm1 = 0; ynm2 = 0; unm1 = 0; unm2 = 0;
               while (true) {
                    un = read_adc;
```

yn = 1.956*ynm1 - 0.9567*ynm2 + 486.6e-6*unm1 + 476.5e-6*unm2;

PC soundcards can sample audio at 44.1 kHz so this implies that the anti-aliasing filter is much sharper than this one as

You might wish to find out what order butterworth filter would be needed to have $f_c=20\,\mathrm{kHz}$ and f_stop of 22.05 kHz.

write_dac(yn);

wait(Ts);

}

Comments

 $f_s/2 = 22.05$ kHz.

/* store past values */
ynm2 = ynm1; ynm1 = yn;
unm2 = unm1; unm1 = un;

Worksheet 17

Colophon

To accompany Chapter 6.4 Models of Discrete-Time Systems

An annotatable copy of the notes for this presentation will be distributed before the second class meeting as **Worksheet 17** in the **Week 9: Classroom Activities** section of the Canvas site. I will also distribute a copy to your personal **Worksheets** section

This worksheet can be downloaded as a PDF file. We will step through this worksheet in class.