

## Models of Discrete-Time Systems

## Colophon

An annotatable worksheet for this presentation is available as **Worksheet 17**.

- The Jupytext source code for this page is dt\_systems/4/dt\_models.md.
- You can view the notes for this presentation as a webpage (HTML).
- This page is downloadable as a PDF file.

## Scope and Background Reading

In this section we will explore digital systems and learn more about the z-transfer function model.


The material in this presentation and notes is based on Chapter 9 (Starting at <u>Section 9.7</u>) of [<u>Kar12</u>]. I have skipped the section on digital state-space models.

## Agenda

- Discrete Time Systems
- Transfer Functions in the Z-Domain
- Modelling digital systems in Matlab/Simulink
- Converting Continuous Time Systems to Discrete Time Systems
- Example: Digital Butterworth Filter

## Discrete Time Systems

In the lecture that introduced the z-transform we talked about the representation of a discrete-time (DT) system by the model shown below:



In this session, we want to explore the contents of the central block.

## DT System as a Sequence Processor

- As noted in the previous slide, the discrete time system (DTS) 'takes as an input the sequence  $x_d[n]^{\gamma}$  which in a physical signal would be obtained by sampling the continuous time signal x(t) using an analogue to digital converter (ADC).
- It produces another sequence  $y_d[n]$  by processing the input sequence in some way.
- The output sequence is converted into an analogue signal y(t) by a digital to analogue converter (DAC).

#### Colophon

Scope and Background Reprint to PD

<u>Agenda</u>

**Discrete Time Systems** 

DT System as a Sequence Processor

What is the nature of the DTS?

<u>Transfer Functions in the Z-Domain</u>
<u>Take Z-Transform of both sides</u>

Gather terms

Define transfer function

DT impulse response

Example 5

Modelling DT systems in MATLAB and Simulink

MATLAB

Simulink Model

Converting Continuous Time Systems

to Discrete Time Systems

Continuous System Equivalents

MATLAB c2d function

**Example: Digital Butterworth Filter** 

**Solution** 

Summary

Reference

Solutions to Example 5

Solution to 5.1.

Solution to 5.2.

Solution to 5.3.

# • F

#### What is the nature of the DTS?

- The discrete time system (DTS) is a block that converts a sequence  $x_d[n]$  into another sequence  $y_d[n]$
- The transformation will be a difference equation h[n]
- By analogy with CT systems, h[n] is the impulse response of the DTS, and y[n] can be obtained by convolving h[n] with  $x_d[n]$  so:

$$y_d[n] = h[n] * x_d[n]$$

• Taking the z-transform of h[n] we get H(z), and from the transform properties, convolution of the signal  $x_d[n]$  by system h[n] will be *multiplication* of the z-transforms:

$$Y_d(z) = H(z)X_d(z)$$

• So, what does h[n] and therefore H(z) look like?

## Transfer Functions in the Z-Domain

Let us assume that the sequence transformation is a *difference equation* of the form<sup>2</sup>:

$$y[n] + a_1 y[n-1] + a_2 y[n-2] + \dots + a_k y[n-k]$$
  
=  $b_0 x[n] + b_1 u[n-1] + b_2 u[n-2] + \dots + b_k u[n-k]$ 

#### Take Z-Transform of both sides

From the z-transform properties

$$f[n-m] \Leftrightarrow z^{-m}F(z)$$

so....

$$Y(z) + a_1 z^{-1} Y(z) + a_2 z^{-2} Y(z) + \dots + a_k z^{-k} Y(z) = \dots$$
$$b_0 U(z) + b_1 z^{-1} U(z) + b_2 z^{-2} U(z) + \dots + b_k z^{-k} U(z)$$

#### Gather terms

$$(1 + a_1 z^{-1} + a_2 z^{-2} + \cdots + a_k z^{-k}) Y(z) =$$

$$(b_0 + b_1 z^{-1} + b_2 z^{-2} + \cdots + b_k z^{-k}) U(z)$$

from which ...

$$Y(z) = \left(\frac{b_0 + b_1 z^{-1} + b_2 z^{-2} + \dots b_k z^{-k}}{1 + a_1 z^{-1} + a_2 z^{-2} + \dots a_k z^{-k}}\right) U(z)$$

#### Define transfer function

We define the discrete time transfer function H(z) := Y(z)/U(z) so...

$$H(z) = \frac{Y(z)}{U(z)} = \frac{b_0 + b_1 z^{-1} + b_2 z^{-2} + \dots b_k z^{-k}}{1 + a_1 z^{-1} + a_2 z^{-2} + \dots a_k z^{-k}}$$

$$H(z) = \frac{b_0 z^k + b_1 z^{k-1} + b_2 z^{k-2} + \dots + b_{k-1} z + b_k}{z^k + a_1 z^{k-1} + a_2 z^{k-2} + \dots + a_{k-1} z + a_k}$$



## DT impulse response

The discrete-time impulse reponse h[n] is the response of the DT system to the input  $x[n] = \delta[n]$ 

Last week we showed that  $\mathcal{Z}\{\delta[n]\}$  was defined by the transform pair

$$\delta[n] \Leftrightarrow 1$$

so

$$h[n] = \mathcal{Z}^{-1} \{ H(z).1 \} = \mathcal{Z}^{-1} \{ H(z) \}$$

We will work through an example in class.

[Skip next slide in Pre-Lecture]

## Example 5

Karris Example 9.10:

The difference equation describing the input-output relationship of a DT system with zero initial conditions, is:

$$y[n] - 0.5y[n-1] + 0.125y[n-2] = x[n] + x[n-1]$$

Compute:

- 1. The transfer function H(z)
- 2. The DT impulse response h[n]
- 3. The response y[n] when the input x[n] is the DT unit step  $u_0[n]$

#### 5.1. The transfer function

$$H(z) = \frac{Y(z)}{U(z)} = \dots?$$

## 5.2. The DT impulse response

Start with:

$$\frac{H(z)}{z} = \frac{z - 1}{z^2 + 0.5z + 0.125}$$





#### Matlab Solution

```
clear all
imatlab_export_fig('print-svg') % Static svg figures.
cd matlab
pwd
format compact
```

See dtm\_ex1\_2.mlx. (Also available as dtm\_ex1\_2.m.)

The difference equation describing the input-output relationship of the DT system with zero initial conditions, is:

$$y[n] - 0.5y[n-1] + 0.125y[n-2] = x[n] + x[n-1]$$

Transfer function

Numerator  $z^2 + z$ 

```
Nz = [1 1 0];
```

Denominator  $z^2 - 0.5z + 0.125$ 

```
Dz = [1 -0.5 0.125];
```

Poles and residues

```
[r,p,k] = residue(Nz,Dz)
```

Impulse Response

```
Hz = tf(Nz,Dz,1)
hn = impulse(Hz, 15);
```

Plot the response

```
stem([0:15], hn)
grid
title('Example 5 - Part 2')
xlabel('n')
ylabel('Impulse response h[n]')
```

Response as stepwise continuous y(t)





#### 5.3. The DT step response

$$Y(z) = H(z)X(z)$$

$$u_0[n] \Leftrightarrow \frac{z}{z-1}$$

We will work through this example in class.

[Skip next slide in Pre-Lecture]

$$Y(z) = H(z)U_0(z) = \frac{z^2 + z}{z^2 + 0.5z + 0.125} \cdot \frac{z}{z-1}$$

$$= \frac{z(z^2 + z)}{(z^2 + 0.5z + 0.125)(z-1)}$$

$$\frac{Y(z)}{z} = \frac{z^2 + z}{(z^2 + 0.5z + 0.125)(z-1)}$$

Solved by inverse Z-transform.

#### Matlab Solution


See dtm ex1 3.mlx. (Also available as dtm ex1 3.m.)

open dtm\_ex1\_3

Results







## Modelling DT systems in MATLAB and Simulink

We will consider some examples in class

## **MATLAB**

Code extracted from <a href="https://dtm.ex1\_3.m">dtm\_ex1\_3.m</a>:


```
Ts = 1;
z = tf('z', Ts);

Hz = (z^2 + z)/(z^2 - 0.5 * z + 0.125)


step(Hz)
grid
title('Example 1 - Part 3 - As Analogue Signal')
xlabel('nTs [s]')
ylabel('Step response y(t)')
axis([0,15,0,3.5])
```

## Simulink Model

See dtm.slx:



### Results



# Converting Continuous Time Systems to Discrete Time Systems

In analogue electronics, to implement a filter we would need to resort to op-amp circuits with resistors, capacitors and inductors acting as energy dissipation, storage and release devices.

- In modern digital electronics, it is often more convenient to take the original transfer function H(s) and produce an equivalent H(z).
- We can then determine a difference equation that will respresent h[n] and implement this as computer algorithm.
- Simple storage of past values in memory becomes the repository of past state rather than the integrators and derivative circuits that are needed in the analogue world.

To achieve this, all we need is to be able to do is to sample and process the signals quickly enough to avoid violating Nyquist-Shannon's sampling theorem.

## Continuous System Equivalents

- There is no digital system that uniquely represents a continuous system
- This is because as we are sampling, we only have knowledge of signals being processed at the sampling instants, and need to *reconstruct* the inter-sample behaviour.
- In practice, only a small number of transformations are used.
- The derivation of these is beyond the scope of this module, but in class we'll demonstrate the ones that MATLAB provides in a function called c2d

#### MATLAB c2d function

Let's see what the help function says:

| he <sup>-</sup> | Lp c2d |
|-----------------|--------|
|                 |        |
| do              | c c2d  |

## **Example: Digital Butterworth Filter**

- Design a 2nd-order butterworth low-pass anti-aliasing filter with transfer function H(s) for use in sampling music.
- The cut-off frequency  $\omega_c=20$  kHz and the filter should have an attenuation of at least -80 dB in the stop band.
- Choose a suitable sampling frequency for the audio signal and give the transfer function H(z) and an algorithm to implement h[n]

#### Solution

See digi butter.mlx.

First determine the cut-off frequency  $\omega_c$ 

$$\omega_c = 2\pi f_c = 2 \times \pi \times 20 \times 10^3 \text{ rad/s}$$

$$wc = 2*pi*20e3$$

$$\omega_c = 125.66 \times 10^3 \text{ rad/s}$$

From the lecture on filters, we know the 2nd-order butterworth filter has transfer function:

$$H(s) = \frac{Y(s)}{U(s)} = \frac{\omega_c^2}{s^2 + \omega_c \sqrt{2} s + \omega_c^2}$$

Substituting for  $\omega_c = 125.6637 \times 10^3$  this is ...?

$$Hs = tf(wc^2,[1 wc*sqrt(2), wc^2])$$

$$H(s) = \frac{15.79 \times 10^9}{s^2 + 177.7 \times 10^3 s + 15.79 \times 10^9}$$

#### Bode plot

MATLAB:

bode(Hs,{1e4,1e8})
grid

#### Sampling Frequency

From the bode diagram, the frequency at which  $|H(j\omega)|$  is -80 dB is approx  $12.6 \times 10^6$  rad/s.

To avoid aliasing, we should choose a sampling frequency twice this =?

$$\omega_s = 2 \times 12.6 \times 10^6$$
 rad/s.

So

$$\omega_s = 25.2 \times 10^6$$
 rad/s.

Sampling frequency  $(f_s)$  in Hz = ?

$$f_s = \omega_s/(2\pi) \text{ Mhz}$$

$$fs = ws/(2*pi)$$

$$f_s = 40.11 \text{ Mhz}$$

Sampling time  $T_s = ?$ 



$$Ts = 1/fs$$

$$T_s = 1/f_s \approx 0.25 \ \mu s$$

#### Digital Butterworth

zero-order-hold equivalent

$$Hz = c2d(Hs, Ts)$$

#### Step response

step(Hz)

#### Algorithm

From previous result:

$$H(z) = \frac{Y(z)}{U(z)} = \frac{486.6 \times 10^{-6} z + 476.5 \times 10^{-6}}{z^2 - 1.956z + 0.9567}$$

Dividing top and bottom by  $z^2 \dots$ 

$$H(z) = \frac{Y(z)}{U(z)} = \frac{486.6 \times 10^{-6} z^{-1} + 476.5 \times 10^{-6} z^{-2}}{1 - 1.956 z^{-1} + 0.9567 z^{-2}}$$

expanding out ...

$$Y(z) - 1.956z^{-1}Y(z) + 0.9567z^{-2}Y(z) =$$

$$486.6 \times 10^{-6}z^{-1}U(z) + 476.5 \times 10^{-6}z^{-2}U(z)$$

Inverse z-transform gives ...


$$y[n] - 1.956y[n - 1] + 0.9567y[n - 2] =$$

$$486.6 \times 10^{-6}u[n - 1] + 476.5 \times 10^{-6}u[n - 2]$$

in algorithmic form (compute y[n] from past values of u and y) ...

$$y[n] = 1.956y[n-1] - 0.9567y[n-2] + 486.6 \times 10^{-6}u[n-1] + \dots$$
  
 $476.5 \times 10^{-6}u[n-2]$ 

#### Block Diagram of the digital BW filter



open digifilter



#### Convert to code

To implement:

$$y[n] = 1.956y[n-1] - 0.9567y[n-2] + 486.6 \times 10^{-6}u[n-1] + 476.5 \times 10^{-6}u[n-2]$$

```
/* Initialize */
Ts = 2.4933e-07; /* more probably some fraction of clock speed */
ynm1 = 0; ynm2 = 0; unm1 = 0; unm2 = 0;
while (true) {
    un = read_adc;
    yn = 1.956*ynm1 - 0.9567*ynm2 + 486.6e-6*unm1 + 476.5e-6*unm2;
    write_dac(yn);
    /* store past values */
    ynm2 = ynm1; ynm1 = yn;
    unm2 = unm1; unm1 = un;
    wait(Ts);
}
```

#### Comments

PC soundcards can sample audio at 44.1 kHz so this implies that the anti-aliasing filter is much sharper than this one as  $f_s/2 = 22.05$  kHz.

You might wish to find out what order butterworth filter would be needed to have  $f_c=20$  kHz and  $f_{\rm stop}$  of 22.05 kHz.

## Summary

- Discrete Time Systems
- Transfer Functions in the Z-Domain
- Modelling digital systems in MATLAB/Simulink
- Continuous System Equivalents
- In-class demonstration: Digital Butterworth Filter

## Reference

#### [<u>Kar12</u>]

Steven T. Karris. *Signals and systems with MATLAB computing and Simulink modeling*. Orchard Publishing, Fremont, CA., 2012. ISBN 9781934404232. Library call number: TK5102.9 K37 2012 LOCATE. URL: <a href="https://ebookcentral.proquest.com/lib/swansea-ebooks/reader.action?docID=3384197">https://ebookcentral.proquest.com/lib/swansea-ebooks/reader.action?docID=3384197</a>.

## Solutions to Example 5

#### Solution to 5.1.

The transfer function is

$$H(z) = \frac{Y(z)}{X(z)} = \frac{z^2 + z}{z^2 - 0.5z + 0.125}$$

## Solution to 5.2.

The DT impulse response:

## $h[n] = \left(\frac{\sqrt{2}}{4}\right)^n \left(\cos\left(\frac{n\pi}{4}\right) + 5\sin\left(\frac{n\pi}{4}\right)\right)$

## 0



## Solution to 5.3.

Step response:

$$y[n] = \left(3.2 - \left(\frac{\sqrt{2}}{4}\right)^n \left(2.2\cos\left(\frac{n\pi}{4}\right) + 0.6\sin\left(\frac{n\pi}{4}\right)\right)\right) u_0[n]$$

By Dr Chris P. Jobling

© Copyright Swansea University (2019-2022).

This page was created by <u>Dr Chris P. Jobling for Swansea University</u>.