## iemisc: Construction Measurement Examples

## Irucka Embry, E.I.T. ( $EcoC^2S$ )

## 2023-09-24

## Contents

Replicate the R code	2
Fraction (or Mixed number) to a Decimal (Numeric Vector)  Example 1	<b>2</b> 2
Construction Decimal (Measurement in feet inch fraction returned as a decimal value)  Example 1 (Convert a feet inch fraction measurement to its decimal equivalent)  a) Multiply t1 by t2 and return the answer in acres  b) Square t1 and return the answer in acres  c) Both a) and b) can be expressed using the following as well  d) Return the sum of t1 - t5  e) Return the traditional vector result for t1 - t16  f) Return the librecad vector result result for t1 - t16  Example 2 [Verify the sum]  Example 3 [Perimeter sum]  Example 4 [Total surface area & volume for riprap]  Example 5 [Examples from the Spike reference]  a) Matching the decimal value for 3 3/8 inches  Example 6 [Print a table with equivalent length measurements]	3 3 3 3 3 4 4 4 5 6 6 7 7 9 10 10
Construction Fraction         Example 1          Example 2          Example 3          a) Multiplication          b) Division          c) Addition          d) Subtraction (Negative result)          d) Subtraction (Positive result)          Example 4	13 13 14 14 15 15 16 16
Construction Decimal Engineering (LibreCAD Style)  Examples	1 <b>7</b> 17
R Help for iemisc Functions	18
Works Cited	27
EcoC2S Links	27

## Replicate the R code

Note: If you wish to replicate the R code below, then you will need to copy and paste the following commands in R first (to make sure you have all the packages and their dependencies):

```
install.packages(c("install.load", "iemisc", "units", "knitr"))
# install the packages and their dependencies

# load the required packages
install.load::load_package("iemisc", "units")
# load needed packages using the load_package function from the install.load
# package (it is assumed that you have already installed these packages)
import::from(fpCompare, "%==%")
```

## Fraction (or Mixed number) to a Decimal (Numeric Vector)

#### Example 1

Convert the following mixed number values to a decimal number. The non-numeric (character) values are ignored with the frac to numeric function.

```
trxt <- "1 1/3"
frac_to_numeric(trxt)
## [1] 1.333333
tlrxy <- "4 1/8 inches"
frac_to_numeric(tlrxy)
## [1] 4.125
tmrxy <- "12 13/16 inches"
frac_to_numeric(tmrxy)
## [1] 12.8125
hjtevo <- "28/3 inches"
frac_to_numeric(hjtevo)
## [1] 9.333333</pre>
```

# Construction Decimal (Measurement in feet inch fraction returned as a decimal value)

#### Example 1 (Convert a feet inch fraction measurement to its decimal equivalent)

In the following example, the expressed values are the same in t1 through t16 (34 feet 3 1/2 inches); however, the only difference exists in the character strings. The point here is to show that the character values do not really matter because it is the numeric values that actually determine the decimal equivalent. The decimal equivalent will be expressed in decimal feet when the result is traditional and it will be expressed in decimal inches when the result is librecad.

```
t1 <- "34'-3 1/2\""
t2 <- "34-3 1/2\""
t3 <- "34' 3 1/2\""
t4 <- "34'-3 1/2"
t5 <- "34-3 1/2"
t6 <- "34 3 1/2"
t7 <- "34 ft 3 1/2 in"
t8 <- "34 3 1/2"
t9 <- "34 fts 3 1/2 in"
t10 <- "34 foot 3 1/2 in"
t11 <- "34 foot 3 1/2 inch"
t12 <- "34 foot 3 1/2 in"
t13 <- "34 feet 3 1/2 in"
t14 <- "34 feet 3 1/2 inch"
t15 <- "34 feet 3 1/2 in"
t16 <- "34 FEEt 3 1/2 IN"
```

a) Multiply t1 by t2 and return the answer in acres

```
(construction_decimal(t1, result = "traditional", output = "vector") * construction_decimal(t2,
    result = "traditional", output = "vector") * 4)/43560

## [1] 0.1079815
# acres
```

b) Square t1 and return the answer in acres

```
(construction_decimal(t1, result = "traditional", output = "vector")^2 * 4)/43560
## [1] 0.1079815
# acres
```

c) Both a) and b) can be expressed using the following as well

```
t1_ft2 <- set_units((construction_decimal(t1, result = "traditional", output = "vector") *
        construction_decimal(t2, result = "traditional", output = "vector") * 4), US_survey_foot^2)

t1_acres <- t1_ft2

units(t1_acres) <- make_units(acre)
t1_acres

## 0.1079815 [acre]

t1_ft2s <- set_units((construction_decimal(t1, result = "traditional", output = "vector")^2 *
        4), US_survey_foot^2)

t1_acress <- t1_ft2s

units(t1_acress) <- make_units(acre)
t1_acress
## 0.1079815 [acre]</pre>
```

#### d) Return the sum of t1 - t5

```
sum(construction_decimal(t1, result = "traditional", output = "vector"), construction_decimal(t2,
    result = "traditional", output = "vector"), construction_decimal(t3, result = "traditional",
    output = "vector"), construction_decimal(t4, result = "traditional", output = "vector"),
    construction_decimal(t5, result = "traditional", output = "vector"))
## [1] 171.4583
```

#### e) Return the traditional vector result for t1 - t16

```
construction_decimal(t1, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t2, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t3, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t4, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t5, result = "traditional", output = "vector")
## [1] 34.29167
```

```
construction_decimal(t6, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t7, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t8, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t9, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t10, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t11, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t12, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t13, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t14, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t15, result = "traditional", output = "vector")
## [1] 34.29167
construction_decimal(t16, result = "traditional", output = "vector")
## [1] 34.29167
```

#### f) Return the librecad vector result result for t1 - t16

```
construction_decimal(t1, result = "librecad", output = "vector")

## [1] 411.5

construction_decimal(t2, result = "librecad", output = "vector")

## [1] 411.5

construction_decimal(t3, result = "librecad", output = "vector")

## [1] 411.5

construction_decimal(t4, result = "librecad", output = "vector")

## [1] 411.5
```

```
construction_decimal(t5, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t6, result = "librecad", output = "vector")
construction_decimal(t7, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t8, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t9, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t10, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t11, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t12, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t13, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t14, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t15, result = "librecad", output = "vector")
## [1] 411.5
construction_decimal(t16, result = "librecad", output = "vector")
## [1] 411.5
```

#### Example 2 [Verify the sum]

In the following example, verify that the sum of m1 through m6 [33 feet 3 1/2 inches, 32 feet 1 inch, 32 feet 1 inches. As long as the last value is TRUE, then the verification is complete.

```
m1 <- "33'-3 1/2\""
m2 <- "32'-1"
m3 <- "32'-1"
m4 <- "32'-1"
m5 <- "32'-1"
```

#### Example 3 [Perimeter sum]

Calculate the sum of an object with the following perimeter measurements [3 inches, 8 inches, 6 inches, 2 5/8 inches, 2 feet 6 3/4 i

```
sum(construction_decimal("0 3", result = "traditional", output = "vector"), construction_decimal("0 8",
    result = "traditional", output = "vector"), construction_decimal("0 6", result = "traditional",
    output = "vector")) * sum(construction_decimal("0 2 5/8", result = "traditional",
    output = "vector"), 3 * construction_decimal("2 6 3/4", result = "traditional",
    output = "vector"), construction_decimal("0 2 5/8", result = "traditional", output = "vector"))
## [1] 11.51042
```

#### Example 4 [Total surface area & volume for riprap]

Calculate the amount of surface area fill, in acres, for riprap placement and the volume of fill in yards<sup>3</sup> along a streambank.

```
riprap <- set_units(construction_decimal("0 15.0", result = "traditional", output = "vector"),</pre>
    US_survey_foot)
riprap
## 1.25 [US_survey_foot]
riprap_yd <- riprap
units(riprap_yd) <- make_units(yd)</pre>
riprap_yd
## 0.4166675 [yd]
OHWM_width <- set_units(25, US_survey_foot)</pre>
OHWM_width
## 25 [US_survey_foot]
width <- set_units(47, US_survey_foot)</pre>
width
## 47 [US_survey_foot]
bank_area1 <- width * bank
bank_area1
## 3397.056 [US_survey_foot^2]
bank_area2 <- bank_area1
units(bank_area2) <- make_units(yd^2)</pre>
bank_area2
## 377.4521 [yd<sup>2</sup>]
bank_area3 <- bank_area1
units(bank_area3) <- make_units(acres)</pre>
bank_area3
## 0.07798566 [acres]
vol_bank <- riprap_yd * bank_area2</pre>
vol_bank
## 157.272 [yd<sup>3</sup>]
bank_area_OHWM1 <- OHWM_width * bank</pre>
bank_area_OHWM1
## 1806.944 [US_survey_foot^2]
```

```
bank_area_OHWM2 <- bank_area1</pre>
units(bank_area_OHWM2) <- make_units(yd^2)</pre>
bank_area_OHWM2
## 377.4521 [yd<sup>2</sup>]
bank_area_OHWM3 <- bank_area1</pre>
units(bank_area_OHWM3) <- make_units(acres)</pre>
bank_area_OHWM3
## 0.07798566 [acres]
vol_bank_OHWM <- riprap_yd * bank_area_OHWM2</pre>
vol_bank_OHWM
## 157.272 [yd<sup>3</sup>]
fill_ft2 <- bank_area_OHWM1</pre>
fill_ft2
## 1806.944 [US_survey_foot^2]
fill_acres <- bank_area_OHWM3</pre>
fill_acres
## 0.07798566 [acres]
fill_yd2 <- bank_area_OHWM2</pre>
fill_yd2
## 377.4521 [yd<sup>2</sup>]
fill_yd3 <- vol_bank_OHWM</pre>
fill_yd3
## 157.272 [yd<sup>3</sup>]
```

### Example 5 [Examples from the Spike reference]

```
psst <- "7' 4 5/16\""
pssts <- "0 3 3/8\""
wall1 <- "12' 7\""
wall2 <- "40' 9\""</pre>
```

```
construction_decimal(psst, result = "traditional", output = "vector")
## [1] 7.359375
construction_decimal(pssts, result = "traditional", output = "vector")
## [1] 0.28125
construction_decimal(wall1, result = "traditional", output = "vector")
## [1] 12.58333
construction_decimal(wall2, result = "traditional", output = "vector")
## [1] 40.75
```

#### a) Matching the decimal value for 3 3/8 inches

Since pssts is a fraction representing 3 3/8 inches, it is better to use the frac\_to\_numeric function or the construction\_decimal function with the librecad result instead of using the construction\_decimal function with the traditional result to match the decimal value from the Spike reference.

```
pssts1 <- "3 3/8\""
frac_to_numeric(pssts1)
## [1] 3.375
# or more simply
pssts1b <- "3 3/8 in"
# checks
frac_to_numeric(pssts1b)
## [1] 3.375
frac_to_numeric(pssts1) %==% frac_to_numeric(pssts1b)
## [1] TRUE
frac_to_numeric(pssts1) %==% construction_decimal(pssts, result = "librecad", output = "vector")
## [1] TRUE
frac_to_numeric(pssts1b) %==% construction_decimal(pssts, result = "librecad", output = "vector")
## [1] TRUE</pre>
```

#### Example 6 [Print a table with equivalent length measurements]

In a tabular format, show the equivalents to 1 feet 2 7/16 inches, 6 feet 8 3/4 inches, 6 feet 5 3/256 inches in decimal inches, decimal feet, decimal yards, decimal millimeters, decimal centimeters, and decimal meters.

```
librecad1 <- "1 2 7/16\""
construction_decimal(librecad1, result = "traditional", output = "vector")
## [1] 1.203125
knitr::kable(format(construction_decimal(librecad1, result = "traditional", output = "table"),
    digits = 6, nsmall = 0))
                                      Measurement
                                                    Units
                                      14.437500
                                                    in
                                      1.203125
                                                    ft
                                      0.401042
                                                    yd
                                      366.712500
                                                    \mathrm{mm}
                                      36.671250
                                                    cm
                                      0.366712
                                                    \mathbf{m}
construction_decimal(librecad1, result = "librecad", output = "vector")
## [1] 14.4375
knitr::kable(format(construction_decimal(librecad1, result = "librecad", output = "table"),
    digits = 4, nsmall = 0))
                                      Measurement
                                                    Units
                                      14.4375
                                                    in
                                      1.2031
                                                    ft
                                      0.4010
                                                    yd
                                      366.7125
                                                    mm
                                      36.6713
                                                    cm
                                      0.3667
                                                    \mathbf{m}
librecad2 <- "6' 8 3/4 in"
construction_decimal(librecad2, result = "traditional", output = "vector")
## [1] 6.729167
knitr::kable(format(construction_decimal(librecad2, result = "traditional", output = "table"),
    digits = 6, nsmall = 6))
                                      Measurement
                                                    Units
                                      80.750000
                                                    in
                                      6.729167
                                                    ft
                                      2.243056
                                                    yd
                                      2051.050000
                                                    mm
                                      205.105000
                                                    cm
                                      2.051050
                                                    m
```

```
construction_decimal(librecad2, result = "librecad", output = "vector")
## [1] 80.75
knitr::kable(format(construction_decimal(librecad2, result = "librecad", output = "table"),
    digits = 2, nsmall = 2))
                                      Measurement
                                                    Units
                                      80.75
                                                    in
                                      6.73
                                                    ft
                                      2.24
                                                    yd
                                      2051.05
                                                    mm
                                      205.10
                                                    cm
                                      2.05
                                                    _{\mathrm{m}}
librecad3 <- "6'-5 3/256\""
construction_decimal(librecad3, result = "traditional", output = "vector")
## [1] 6.417643
knitr::kable(format(construction_decimal(librecad3, result = "traditional", output = "table"),
    digits = 6, nsmall = 6))
                                      Measurement
                                                    Units
                                      77.011719
                                                    in
                                      6.417643
                                                    ft
                                      2.139214
                                                    yd
                                      1956.097656
                                                    mm
                                      195.609766
                                                    cm
                                      1.956098
                                                    \mathbf{m}
construction_decimal(librecad3, result = "librecad", output = "vector")
## [1] 77.01172
knitr::kable(format(construction_decimal(librecad3, result = "librecad", output = "table"),
    digits = 5, nsmall = 5))
                                                        \mathbf{s}
```

Measurement	Unit
77.01172	in
6.41764	ft
2.13921	yd
1956.09766	mm
195.60977	$\mathrm{cm}$
1.95610	$\mathbf{m}$

#### **Construction Fraction**

#### Example 1

Return the fractional equivalents for the decimal value of 6 feet 5 3/256 inches.

```
checker <- "6'-5 3/256 in"
checkers <- construction_decimal(checker, result = "traditional", output = "vector")</pre>
checkers
## [1] 6.417643
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 0)
## [1] "6 ft 5 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 2)
## [1] "6 ft 5 0/2 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 4)
## [1] "6 ft 5 0/4 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 8)
## [1] "6 ft 5 0/8 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 16)
## [1] "6 ft 5 0/16 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 32)
## [1] "6 ft 5 0/32 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 64)
## [1] "6 ft 5 1/64 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 100)
## [1] "6 ft 5 1/100 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 128)
## [1] "6 ft 5 2/128 in"
construction_fraction(checkers, type = "traditional", result = "traditional", fraction = 256)
## [1] "6 ft 5 3/256 in"
```

#### Example 2

Return the fractional equivalents for the decimal value of 77.6875 inches.

```
checkin <- 77.6875
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 0)
## [1] "6 ft 5 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 2)
## [1] "6 ft 5 1/2 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 4)
## [1] "6 ft 5 3/4 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 8)
## [1] "6 ft 5 5/8 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 16)
## [1] "6 ft 5 11/16 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 32)
## [1] "6 ft 5 22/32 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 64)
## [1] "6 ft 5 44/64 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 100)
## [1] "6 ft 5 69/100 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 128)
## [1] "6 ft 5 88/128 in"
construction_fraction(checkin, type = "librecad", result = "traditional", fraction = 256)
## [1] "6 ft 5 176/256 in"
```

#### Example 3

Given the lengths of 5 feet 1 3/4 inches and 21 feet 7 3/8. Multiply, divide, add, and subtract the value to compare the results to the CalculatorSoup.com reference.

#### a) Multiplication

```
The answer is "111.225 ft² (16016.4063 in²)".

length1 <- "5 feet 1 3/4 inches"

length2 <- "21 feet 7 3/8"

length_product_in <- construction_decimal(length1, result = "librecad", output = "vector") *

construction_decimal(length2, result = "librecad", output = "vector")
```

```
## [1] 16016.41
length_product_ft <- construction_decimal(length1, result = "traditional", output = "vector") *</pre>
    construction_decimal(length2, result = "traditional", output = "vector")
length_product_ft
## [1] 111.225
construction_fraction(length_product_ft, type = "traditional", result = "traditional",
    fraction = 8)
## [1] "111 ft 2 6/8 in"
# Alternatively, this could all be done in a single step as well:
construction_fraction((construction_decimal(length1, result = "traditional", output = "vector") *
    construction_decimal(length2, result = "traditional", output = "vector")), type = "traditional",
    result = "traditional", fraction = 8)
## [1] "111 ft 2 6/8 in"
b) Division
The answer is "0.2381".
length1 <- "5 feet 1 3/4 inches"</pre>
length2 <- "21 feet 7 3/8"</pre>
length_quotient <- construction_decimal(length1, result = "librecad", output = "vector")/construction_d</pre>
    result = "librecad", output = "vector")
length_quotient
## [1] 0.2380723
construction_fraction(length_quotient, type = "traditional", result = "traditional",
    fraction = 8)
## [1] "0 ft 2 7/8 in"
# Alternatively, this could all be done in a single step as well:
construction_fraction((construction_decimal(length1, result = "traditional", output = "vector")/constru
    result = "traditional", output = "vector")), type = "traditional", result = "traditional",
    fraction = 8)
## [1] "0 ft 2 7/8 in"
```

## The answer is "26 ft 9 1/8 in".

c) Addition

length\_product\_in

```
length_sum <- sum(construction_decimal(length1, result = "traditional", output = "vector"),</pre>
    construction_decimal(length2, result = "traditional", output = "vector"))
construction_fraction(length_sum, type = "traditional", result = "traditional", fraction = 8)
## [1] "26 ft 9 1/8 in"
# Alternatively, this could all be done in a single step as well:
construction_fraction(sum(construction_decimal(length1, result = "traditional", output = "vector"),
    construction_decimal(length2, result = "traditional", output = "vector")), type = "traditional",
   result = "traditional", fraction = 8)
## [1] "26 ft 9 1/8 in"
d) Subtraction (Negative result)
The answer is "-16 ft 5 5/8 in".
length_difference1 <- construction_decimal(length1, result = "traditional", output = "vector") -</pre>
    construction_decimal(length2, result = "traditional", output = "vector")
construction fraction(length difference1, type = "traditional", result = "traditional",
   fraction = 8)
## [1] "-16 ft -5 -5/8 in"
# Alternatively, this could all be done in a single step as well:
construction_fraction((construction_decimal(length1, result = "traditional", output = "vector") -
    construction_decimal(length2, result = "traditional", output = "vector")), type = "traditional",
   result = "traditional", fraction = 8)
## [1] "-16 ft -5 -5/8 in"
d) Subtraction (Positive result)
length_difference2 <- construction_decimal(length2, result = "traditional", output = "vector") -</pre>
    construction_decimal(length1, result = "traditional", output = "vector")
construction_fraction(length_difference2, type = "traditional", result = "traditional",
   fraction = 8)
## [1] "16 ft 5 5/8 in"
# Alternatively, this could all be done in a single step as well:
construction_fraction((construction_decimal(length2, result = "traditional", output = "vector") -
    construction_decimal(length1, result = "traditional", output = "vector")), type = "traditional",
   result = "traditional", fraction = 8)
## [1] "16 ft 5 5/8 in"
```

#### Example 4

"Imagine you've bought a wooden panel, 5 meters long. You plan to cut it into six equal parts, but you have only a tape measure with the fractional inches scale. We can measure the length with precision down to 1/32"." From the Omni Calculator: Inches to Fraction Calculator reference.

```
What is the length for each of the 6 boards cut?
```

```
panel <- set_units(5, "m")</pre>
panel
## 5 [m]
panel ft <- panel
units(panel_ft) <- make_units(ft)</pre>
panel_ft
## 16.4042 [ft]
panel_6 <- panel_ft/6
panel_6
## 2.734033 [ft]
construction_fraction(drop_units(panel_6), type = "traditional", result = "traditional",
    fraction = 16)
## [1] "2 ft 8 13/16 in"
construction_fraction(drop_units(panel_6), type = "traditional", result = "traditional",
    fraction = 32)
## [1] "2 ft 8 26/32 in"
```

## Construction Decimal Engineering (LibreCAD Style)

#### Examples

```
librecad1a <- "6' 8 3/4 in"

construction_decimal_eng(librecad1a)

## [1] "6'-8.75\""

librecad2a <- "6'-5 3/256\""

construction_decimal_eng(librecad2a)

## [1] "6'-5.01171875\""</pre>
```

#### R Help for iemisc Functions

Please refer to the iemisc [https://CRAN.R-project.org/package=iemisc] help definitions for the frac\_to\_numeric, construction\_decimal, and construction\_fraction functions below:

```
## Registered S3 method overwritten by 'printr':
##
    method
                           from
    knit print.data.frame rmarkdown
## <environment: namespace:printr>
help(frac_to_numeric, package = "iemisc")
Fraction (or Mixed number) to a Decimal (Numeric Vector)
Description:
Converts a fraction or a mixed number to a decimal
Usage:
frac_to_numeric(n)
Arguments:
  n: character vector that contains the fraction or mixed number
      (can also include text, ex. inch, inches, etc. that will be
      removed from the vector)
Value:
the numeric 'vector' as a decimal
If you have a measurement in feet + inches, then use
 'construction_fraction' instead.
Author(s):
Irucka Embry
Source:
removing all non-numeric characters from a string, but not "." - R
help on nabble.com answered by David Winsemius on Jul 26, 2016.
 <https://web.archive.org/web/20190730141421/http://r.789695.n4.nabble.com/removing-all-non-numeric-cha</pre>
Retrieved thanks to the Internet Archive: Wayback Machine.
References:
   1. Bill Venables, 2016-02-10, "Vulgar Fractions in R",
      fractional vignette,
      <https://CRAN.R-project.org/package=fractional/vignettes/Vulgar_Fractions_in_R.html>.
```

2. The Home Depot, 9 December 2022, "How to Read a Tape Measure", <a href="https://archive.vn/fhBmg">https://archive.vn/fhBmg</a>>. Provided the

acceptance into CRAN.

archive.today webpage capture for The Home Depot URL for

<https://en.wikipedia.org/wiki/Pi>. Examples: # Please refer to the iemisc: Construction Measurement Examples vignette for # additional examples # Example 1 -- Reference 1 library(iemisc) xx <- as.character(fractional::fractional(1:9 / 12))</pre> try(frac\_to\_numeric(xx)) # Please note that there will be an error because this function is designed to # only process one fraction at a time. lapply(xx, frac\_to\_numeric) # Please note that this is the correct way to work with several fractions at once. # Example 2 library(iemisc) xi <- fracture::fracture((50:65) / 12)</pre> try(frac\_to\_numeric(xi)) # Please note that there will be an error because this function is designed to # only process one fraction at a time. lapply(xi, frac\_to\_numeric) # Please note that this is the correct way to work with several fractions at once. # Example 3 library(iemisc) xyy <- fracture::fracture((1:11) / 12)</pre> try(frac\_to\_numeric(xyy)) # Please note that there will be an error because this function is designed to # only process one fraction at a time. lapply(xyy, frac\_to\_numeric) # Please note that this is the correct way to work with several fractions at once.

3. Wikimedia Foundation, Inc. Wikipedia, 29 December 2021, "Pi",

```
# Example 4
library(iemisc)
xft <- as.character(MASS::fractions((1:70) / 12))</pre>
try(frac_to_numeric(xft))
# Please note that there will be an error because this function is designed to
# only process one fraction at a time.
lapply(xft, frac_to_numeric)
# Please note that this is the correct way to work with several fractions at once.
# Example 5
library(iemisc)
pix <- "270/11"
pi1 <- "22/7" # Reference 3
pi2 <- "355/113" # Reference 3
frac_to_numeric(pix)
frac_to_numeric(pi1)
frac_to_numeric(pi2)
# Example 6
# If you have a construction measurement that includes a dimension in feet,
# such as 49 ft 7 5/8 in, don't use the frac_to_numeric function, instead
# use the construction_fraction function.
library(iemisc)
xxift <- "49 ft 7 5/8 in"
construction_decimal(xxift, result = "traditional", output = "vector")
# Example 7 -- Reference 2
```

```
truss_marks <- "19 3/16 inches"
frac to numeric(truss marks)
help(construction_decimal, package = "iemisc")
Construction Decimal
Description:
Convert a construction measurement in US Customary Units (foot +
 inch) with or without a fraction into its equivalent as a decimal
Usage:
 construction_decimal(
   measurement,
   result = c("traditional", "librecad"),
   output = c("vector", "table")
)
Arguments:
measurement: character vector that contains the construction measurement (foot + inch)
result: character vector that contains the decimal type options are traditional (ex. 1.203125 = 1'-2 7/16''
where the whole number is the value in ft and the decimal is the value in inches & librecad (ex. 14.43112 =
1'-2 7/16"), whereby LibreCAD defines its decimal unit as "integer part separated from the fractional part
of a number by a decimal". Thus, both the whole number and the decimal is the value in inches.
output: character vector that contains the type of output. The options are vector (just the single value as
a decimal) and table the decimal value in inch (in), feet (ft), yard (yd), millimeters (mm), centimeters (cm),
and meters (m).
Value:
the construction measurement value as a numeric 'vector' as a
decimal or as a table (depends on the output parameters)
Note:
 If you only have a measurement in inches, then use
 'frac_to_numeric' instead.
Author(s):
 Irucka Embry
Source:
   1. removing all non-numeric characters from a string, but not
      "." - R help on nabble.com answered by David Winsemius on Jul
      26, 2016. See
      <https://web.archive.org/web/20190730141421/http://r.789695.n4.nabble.com/removing-all-non-numeri</pre>
      Retrieved thanks to the Internet Archive: Wayback Machine
   2. r - How to not run an example using roxygen2? - Stack
      Overflow answered and edited by samkart on Jul 9 2017. (Also
      see the additional comments in response to the answer.) See
      <https://stackoverflow.com/questions/12038160/how-to-not-run-an-example-using-roxygen2>.
```

3. devtools - Issues in R package after CRAN asked to replace

```
dontrun by donttest - Stack Overflow answered by Hong Ooi on
      Sep 1 2020. (Also see the additional comments in response to
      the answer.) See
      <https://stackoverflow.com/questions/63693563/issues-in-r-package-after-cran-asked-to-replace-don</pre>
  4. regex - Replace single backslash in R - Stack Overflow
      answered and edited by Hong Ooi on Aug 21, 2014. (Also see
      the additional comments in response to the answer.) See
      <https://stackoverflow.com/questions/25424382/replace-single-backslash-in-r>.
References:
   1. LibreCAD v2.2.0 - User Manual - Fundamentals: Units, 7 May
      <https://librecad-docs-dev.readthedocs.io/en/latest/ref/fundamentals.html#units>.
   2. Spike, 1 January 2022, "Foot and Inch to Decimal Format
     Conversion",
      <https://www.spikevm.com/calculators/fraction-decimal-calculators.php>.
Examples:
 # Please refer to the iemisc: Construction Measurement Examples vignette for
# additional examples
# Example 1
library(iemisc)
 construction_decimal("2'-0\"", result = "traditional", output = "vector")
 construction_decimal("1'-2 7/16\"", result = "librecad", output = "vector")
 # Example 2
library(iemisc)
 construction_decimal("0 6", result = "traditional", output = "vector")
 construction_decimal("0 6", result = "librecad", output = "vector")
 # Example 3
 library(iemisc)
tss1 <- "48'-0 1/2\""
 tss2 <- "56-9 1/2\""
 sum(construction_decimal(tss1, result = "traditional", output = "vector"),
 construction_decimal(tss2, result = "traditional", output = "vector"))
```

```
# See Source 2 and Source 3
# Example 4
library(iemisc)
 try(construction_decimal(5, result = "traditional", output =
 "vector")) # please see the error message
 ex_error <- character(0)</pre>
 try(construction_decimal(ex_error, result = "traditional",
 output = "vector")) # please see the error message
 try(construction_decimal(NA, result = "traditional", output =
 "vector")) # please see the error message
 try(construction_decimal("feet", result = "traditional", output =
 "vector")) # please see the error message
# Example 5
library(iemisc)
 app1 <- "5' 2\""
 app2 <- "6' 3\""
 app3 <- construction_decimal(app1, result = "traditional", output = "vector") *
 construction_decimal(app2, result = "traditional", output = "vector")
 app3
# If you want to have the fractional value using 16ths, do the following:
 construction_fraction(app3, type = "traditional", result = "traditional",
fraction = 16)
help(construction_fraction, package = "iemisc")
Construction Fraction
Description:
Convert a construction measurement in US Customary Units as a
decimal into its nearest equivalent as foot + inch with or without
a fraction
Usage:
 construction_fraction(
  measurement,
   type = c("traditional", "librecad"),
   result = c("traditional", "inch"),
  fraction = c(0, 2, 4, 8, 16, 32, 64, 100, 128, 256)
```

)

#### Arguments:

measurement: numeric vector that contains the construction measurement as a decimal

type: character vector that contains the decimal type options are traditional (ex. 1.203125 = 1'-2 7/16\" where the whole number is the value in ft and the decimal is the value in inches & librecad (ex. 14.4375 = 1'-2 7/16\"), whereby LibreCAD defines its decimal unit as "integer part separated from the fractional part of a number by a decimal". Thus, both the whole number and the decimal is the value in inches.

result: character vector that contains the resulting fraction type (options are traditional (ex. 1.203125 = 1 ft 2.7/16 in) & inch (ex. 14.4375 = 14.7/16 in)). This is the same as fractional (fractional inch) in LibreCAD.

fraction: numeric vector that contains the fractional part to return. The options are 0, 2, 4, 8, 16, 32, 64, 100, 128, or 256.

#### Value:

the construction measurement value as a character 'vector' as foot + fraction of an inch or as inch + fraction of an inch (depends on the parameters)

#### Author(s):

Irucka Embry

#### References:

- Spike, 7 May 2022, "How to Convert Feet in Decimal Format to Foot, Inch and Fraction Values", <a href="https://www.spikevm.com/construction-math/convert-decimal-fraction.php">https://www.spikevm.com/construction-math/convert-decimal-fraction.php</a>.
- 3. LibreCAD, User Manual Fundamentals: Units: Architectural and Decimal, 7 May 2022, <a href="https://librecad-docs-dev.readthedocs.io/en/latest/ref/fundamentals.html#units">https://librecad-docs-dev.readthedocs.io/en/latest/ref/fundamentals.html#units</a>.
- 4. Inch Calculator. Inch Fraction Calculator Convert Decimal to Inches, 9 May 2022, <a href="https://www.inchcalculator.com/inch-fraction-calculator/">https://www.inchcalculator.com/inch-fraction-calculator/</a>.

#### Examples:

 $\mbox{\tt\#}$  Please refer to the iemisc: Construction Measurement Examples vignette for  $\mbox{\tt\#}$  additional examples

#### library(iemisc)

# Example 1 from the Spike Reference

check1 <- 18.649 # decimal feet

construction\_fraction(check1, type = "traditional", result =

```
"traditional", fraction = 16)
# Reverse the calculation to check out the absolute error
check2 <- construction_decimal(construction_fraction(check1,</pre>
type = "traditional", result = "traditional", fraction = 16),
result = "traditional", output = "vector")
fracture::fracture(check2 - check1) # difference in inches
# by approximate error
approxerror(check2, check1) # answer as a percent (\%)
# check all other fraction levels
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 0)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 2)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 4)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 8)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 32)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 64)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 100)
construction_fraction(check1, type = "traditional", result =
"traditional", fraction = 128)
# Example 2
library(iemisc)
import::from(fpCompare, "%==%")
x1 <- construction_fraction(1.203125, type = "traditional", result =
"traditional", fraction = 16)
```

```
x2 <- construction_fraction(14.4375, type = "librecad", result =</pre>
"inch", fraction = 16)
x3 <- construction_fraction(14.4375, type = "librecad", result =</pre>
"traditional", fraction = 16)
x4 <- construction_fraction(14.43112, type = "librecad", result =
"traditional", fraction = 16)
x5 <- construction_fraction(14.43112, type = "librecad", result =
"inch", fraction = 16)
ex1 <- frac_to_numeric(x2)</pre>
ex2 <- construction_decimal(x1, result = "librecad", output = "vector")</pre>
ex3 <- construction_decimal(x3, result = "librecad", output = "vector")</pre>
ex4 <- construction_decimal(x4, result = "librecad", output = "vector")</pre>
ex5 <- frac_to_numeric(x5)</pre>
# check if ex1, ex2, ex3, ex4, and ex5 are equivalent
ex1 %==% ex2
ex1 %==% ex3
ex1 %==% ex4
ex1 %==% ex5
ex2 %==% ex3
ex2 %==% ex4
ex2 %==% ex5
ex3 %==% ex4
ex3 %==% ex5
ex4 %==% ex5
# Example 3 (from the Inch Calculator Reference)
library(iemisc)
construction_fraction(2.695, type = "librecad", result = "traditional",
fraction = 16)
```

```
construction_fraction(2.695, type = "librecad", result = "inch",
fraction = 16)

# Example 4

library(iemisc)

construction_fraction(17.71354, type = "traditional", result = "traditional",
fraction = 16)

construction_fraction(17.71354, type = "traditional", result = "inch",
fraction = 16)
```

#### Works Cited

Furey, Edward "Feet and Inches Calculator" at https://www.calculatorsoup.com/calculators/construction/feetandinches.php from CalculatorSoup, https://www.calculatorsoup.com - Online Calculators, Last updated: November 12, 2018

Omni Calculator, "Inches to Fraction Calculator", Created by Wojciech Sas, PhD, Last updated: Jun 05, 2023, https://www.omnicalculator.com/conversion/inches-to-fraction.

Spike, 1 January 2022, "Foot and Inch to Decimal Format Conversion", https://www.spikevm.com/calculators/fraction-decimal-calculators.php.

#### EcoC<sup>2</sup>S Links

```
EcoC<sup>2</sup>S Home - https://www.ecoccs.com/
About EcoC<sup>2</sup>S - https://www.ecoccs.com/about_ecoc<sup>2</sup>s.html
Services - https://www.ecoccs.com/services.html
1 Stop Shop - https://www.ecoccs.com/other_biz.html
Products - https://www.questionuniverse.com/products.html
Media - https://www.ecoccs.com/media.html
Resources - https://www.ecoccs.com/resources.html
R Trainings and Resources provided by EcoC<sup>2</sup>S (Irucka Embry, E.I.T.) - https://www.ecoccs.com/rtraining.html
```

## Copyright and License

All R code written by Irucka Embry is distributed under the GPL-3 (or later) license, see the GNU General Public License {GPL} page.

All written content originally created by Irucka Embry is copyrighted under the Creative Commons Attribution-ShareAlike 4.0 International License. All other written content retains the copyright of the original author(s).

This work is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License.