

## 90° 3:1 Gearbox Assembly Instructions




## **Parts**






## **Assembly**


Step 1: Slide the pinion gear into position.



Step 2: Position the bevel gear and slide the output shaft through the gear and frame.



Step 3: Slide the bushing onto the output shaft so it sits in the frame.



<u>Step 4:</u>
Use a cotter pin to secure the output shaft.

