# Smart cards attacks and protections

Louis Goubin Université de Versailles-St-Quentin-en-Yvelines

Université Paris-Saclay
M1 informatique – Site de Versailles
UE « Calcul Sécurisé »

1ère partie







# La sécurité logique est une abstraction

# OL'attaquant échange des messages avec le système :

- Messages connus: adversaire passif (écoute)
- Messages choisis (de façon adaptative) : adversaire actif

# OPuis utilise ces messages pour mettre en défaut des objectifs de sécurité :

- Confidentialité : e-mails, numéros de cartes, voix, ...
- Integrité: téléchargement de logiciels, ...
- Authenticité : contrôle d'accès, signature électronique, ...
- Anonymat: paiement anonyme, vote électronique, ...

**—** ...







# Sécurité au niveau cryptographique

# OAlgorithmes cryptographiques = composants de base de la sécurité

- Chiffrement, signature, authentification, ...
- S'appuient fortement sur les mathématiques : probabilités, combinatoire, théorie des codes, théorie de nombres, réseaux euclidiens, corps finis, courbes (hyper)elliptisues, géométrie algébrique, graphes, ...
- Secret = Clé (principe de Kerckhoff, 1883)



- Les attaques utilisent des techniques de cryptanalyse
- Preuves of securité (partielles), sous l'hypothèse de la difficulté d'un certain problème mathématique (théorie de la complexité)







# Securité au niveau des protocoles

# OProcotoles = Sur un réseau, supposé hostile

- Des intrus peuvent lire, modifier et effacer le trafic, peuvent prendre le contrôle d'un ou plusieurs éléments du réseau.
- Des attacks souvent non-intuitives ::
  - Attaques de base : utilisent les fonctionnalités de base, dans un ordre arbitraire.
  - Attaques plus complexes : utilisent également des proprités subtiles des algorithmes cryptographiques, ou l'analyse statistique du trafic...
- Preuves de sécurité pour les protocoles :
  - Modèle mathématique/logique du système & des objectifs de sécurité
  - Procédure effective pour vérifier la preuve (méthodes formelles).







# Sécurité physique

- OModèle de sécurité plus général : utilise les aspects physiques du calcul.
- OMenace potentielle pour tout dispositif portable/embarqué (spécialement les cartes à puce)
- Attaques invasives vs non invasives
  - Attaques invasives 
     \* « dépackager » le circuit pour avoir un accès direct à ses composents (e.g. connecter un fil sur un bus de données pour écouter les données transférées)
  - Attaques non-invasives → utilisent uniquement les informations disponibles de façon externe (temps de calcul, consommation de courant, ...)









# The RSA Algorithm







# RSA Cryptosystem (1977)

# de facto standard of public-key cryptosystems

```
p, q: primes, n = pq, ed = 1 \mod (p-1)(q-1),
```

e, n: public key, d: secret key, (factoring, n: 1024 bits)

M: message,  $M \in \{0,1,2,...,n-1\}$ .

Encryption:  $C = M^e \mod n$ 

e: small  $(2^{16}+1)$ 

Decryption:  $M = C^d \mod n$ 

**d**: large (d>n<sup>1/2</sup>)







# **Fast Exponentiation**

The binary representation of  $d = d[k-1]2^{k-1} + d[k-2]2^{k-2} + ... + d[1]2^1 + d[0]2^0$ , where d[k-1]=1.

# Left-to-right binary method

```
Input C, n, d
```

Output Cd mod n

$$X=C;$$

For i=k-2 to 0

 $X = X^2 \mod n$ ;

if d[i]=1, then  $X=X*C \mod n$ ;

Return X

cubic complexity  $O((\log n)^3)$ .

- we need about 1500 modular multiplications for 1024-bit n,d on average.


d = 179769313486231590772930519078902473361797697894230657273430081157732639445209167262771634937140456477800995856 4863673560357494227785840418926558467439899258695049140360821770965996851973903412635215659390188627764072341203 1668285970266526289737711820513944871376325649575655785893257302729658745304709432808







# RSA Decryption using Chinese Remainder Theorem



RSA decryption using the CRT can be computed about 4 times faster than the original decryption.







# **RSA** with CRT

```
Algorithm RSA_Decryption_CRT (n=pq)
Input C, n, p, q, dp, dq, p_inv_q
Output M
```

Pre-computation avoiding inversion

```
1: Mp = C^{dp} \mod p;
```

2:  $Mq = C^{dq} \mod q$ ;

3:  $v = (Mq - Mp) p_i nv_q \mod q$ ;

4: M = Mp + pv;

5: Return M

PKCS #1, http://www.rsasecurity.com/rsalabs/pkcs/









Contact | Members Login | E-mail This Page | Site Map | Content Library | Search

Company Solutions Products Services Partners Worldwide Training Support

RSA Security Home > RSA Laboratories > PKCS > PKCS #1

### PKCS #1 - RSA Cryptography Standard

This document provides recommendations for the implementation of public-key cryptography based on the RSA algorithm, covering the following aspects: cryptographic primitives; encryption schemes; signature schemes with appendix; ASN.1 syntax for representing keys and for identifying the schemes.

### Version 2.1

- PKCS #1: RSA Cryptography Standard: MS-Word, Acrobat PDF.
- ASN Module for PKCS #1 v2.1
- Errata for PKCS #1 v2.1 (txt)
- NOTE: A new OID has been defined for the combination of the v1.5 signature scheme and the SHA-224 hash function:

sha224WithRSAEncryption OBJECT IDENTIFIER ::= { pkcs-1 14 }

Like the other sha\*WithRSAEncryption OIDs in PKCS #1 v2.1, this OID has NULL parameters. The DigestInfo encoding for SHA-224 (see Section 9.2, Note 1) is:

(0x)30 2d 30 0d 06 09 60 86 48 01 65 03 04 02 04 05 00 04 1c || H

### Version 2.0

- PKCS #1 RSA Cryptography Standard: MS-Word, ASCII. View changes to previous draft.
- PKCS #1 Amd. 1: Multi-Prime RSA: MS-Word, Adobe Acrobat, PostScript.

### Version 1.5

RSA Encryption Standard: ASCII, MS-Word, PostScript and Gzip PostScript

### **Related Documents**

- Corrected: ASN.1 module for PKCS #1 v2.0
- . Presentation of v 2.0 (PowerPoint) from the '98 Workshop
- PKCS #1 Informational RFC (3447): ASCII

### **Test Vectors**

RSA-OAEP and RSA-PSS test vectors (.zip file)


PKCS Home | PKCS Mailing Lists #1 | #3 | #5 | #6 | #7 | #8 | #9 | #10 | #11 | #12 | #13 | #15

Questions and comments can be submitted via our contact form.





# **Security Analysis of RSA Cryptosystem**









# Timing Attacks







# What are Timing Attacks?

- OThe term "Timing Attack" was first introduced at CRYPTO'96 in Paul Kocher's paper
- OFew other theoretical approaches without practical experiments up to the end of 97'
- Theory was put into practice in early 98'
- OTiming attacks belong to the large family of "side channel" attacks







# What are Timing Attacks?

### **OPrinciple of Timing Attacks:**

- Secret data are processed in the card
- Processing time
  - depends on the value of the secret data
  - leaks information about the secret data
  - can be measured (or at least their differences)

### OPractical attack conditions


- Possibility to monitor the processing of the secret data
- Have a way to record processing times
- Have basic computational & statistical tools
- Have some knowledge of the implementation







# What are Timing Attacks?









# Timing attack on RSA

- Timing Attacks: by precisely measuring the time it takes the smartcard to perform an decryption, Marvin can discover *d*.
- "repeated squaring algorithm", compute  $C=M^d \mod N$ .  $d=d_nd_{n-1}...d_0$ 
  - Set z equals to M and C=1. For i=0,...n do:
  - if  $d_i=1$  set  $C=C^*z \mod N$
  - set z equal to  $z^2 \mod N$

At the end, C has the value  $M^d$  mod N

○ To mount attack, Marvin asks the smartcard to generate signatures on a large number of random messages  $M_1, M_2, ...M_k \in \mathbb{Z}_N^*$  and measure the time  $T_i$  it takes to generate each signature.







# Timing attack on RSA

# O Timing Attack

- O If  $d_1=1$ , smartcard computes  $Cz=MM^2 \mod N$  and, Otherwise it does not. Let  $t_i$  be the time it takes the smart card to compute  $M_iM_i^2 \mod N$ . The  $t_i$ 's differ from each other and depends on  $M_i$ . Marvin measures them offline.
- When  $d_1=1$ , the two ensembles  $\{t_i\}$  and  $\{T_i\}$  are correlated. when  $d_1=0$ , they behave as independent random variables. By measuring the correlation, Marvin can determine  $d_1=1$  or 0.
- O Continuing in this way, he can discover  $d_2, d_3...$  and so on.
- O Solutions: 1) add appropriate delay s.t. modular exponentiation always takes a fixed amount of time. 2) Rivest's blinding trick.
- O Kocher's Power cryptanalysis?







# Power Analysis Attacks







# **Power Analysis: Basic Principles**

### OICC's Power Consumption leaks information about data processing

Power Consumption = f(processing, data)

### ODeduce information about secret data and processing

- empirical methods
- statistical treatment

### OExample: reverse engineering of an algorithm

- The algorithm structure
- Electrical signatures

### OSingle Power Analysis (SPA)


- Attack against the DES key schedule
- Attack against RSA







# **Power Analysis Tools**










# **Experimental equipment**









# Information leakage

# The power consumption of a chip depends on

- the manipulated data
- the executed instruction

# OLeakage models

- Hamming Weight of the data, address, code Op
  - HW(0) = 0
  - $HW(1) = HW(2) = HW(4) = HW(2^n) = 1$
  - HW(3) = HW(5) = HW(6) = HW(9) = 2
  - •
  - HW(255) = HW(0xFF) = 8
- Transitions weight (flipping bits on a bus state) :
  - HW (state<sub>i</sub> ⊕ state<sub>i-1</sub>)
- Other models, chips & technologies ...








# Information leakage











# Information leakage








# **Power Consumption of RSA-CRT**





Cited from the paper: R.Novak, ``SPA-Based Adaptive Chosen Ciphertext Attack on RSA Implementation," PKC 2002, LNCS 2274, pp.252-262, 2002.







# **Side Channel Attacks**

# **Left-to-right binary method**

Input M, n, d

Output M<sup>d</sup> mod n

X=M;


For i=k-2 to 0

 $X = X*X \mod n$ ;

if d[i]=1, then  $X=X*M \mod n$ ;

Return X

The time or the power to execute Squaring and Multiplication are different (side/channel information).







Cited from Clavier et. al, Universal exponentiation algorithm: A first step towards provable SPA-resistance CHES 2001, LNCS 2162, pp. 300 108 2001

# Simple Power Analysis

# OSimple (Single) Power Analysis context

- Find out a secret or private key
- Known algorithm
- Unknown implementation (background culture recommended)

### **O**Conditions

- 1 card available
- Learning phase required (signature location)
- Key inference on a single curve (with relevant height of view)
- Possibly known plain or ciphertext







**OSPA** against RSA private exponentiation

$$s = m^d \mod n$$

- n large modulus, say 1024 bits (n = p \* q, with p & q large primes)
- m message : slightly smaller than n (say 1023 bits)
- s signature
- d private exponent such that :  $e * d = 1 \mod (p-1)(q-1)$ , with e public exponent

The attacker aims at retrieving d







- Obasic "square and multiply" algorithm
- Oexponent bits scanned from MSB to LSB (left to right)

Let k = bitsize of d (say 1024)

Let s = m

For i = k-2 down to 0

Let  $s = s*s \mod n (SQUARE)$ 

If (bit i of d) is 1 then

Let s = s\*m mod n (MULTIPLY)

End if

**Example:**  $s = m^9 = m^{1001b}$ 

init (MSB 1) s = m

round 2 (bit 0)  $s = m^2$ 

round 1 (bit 0)  $s = (m^2)^2 = m^4$ 


round 0 (bit 1)  $s = (m^4)^2 * m = m^9$ 

End for
























# What you can do with SPA

# **OSPA** uses implementation related patterns

# **OSPA** strategy

- algorithm knowledge
- reverse engineering phase (signature location)
- representation tuning (height of view, zoom, visualisation)
- then play with implementation assumptions...

# OSPA is always specific due to

- the algorithm implementation
- the applicative constraints
- the chip's technology (electrical properties)
- possible counter-measures...







## Counter-measures


- OCounter-measure: anything that foils the attack!
- **OTrivial** counter-measure
  - prohibit code branches conditioned by the secret bits
- Advanced counter-measures
  - algorithm specification refinement
    - code structure
    - · data whitening
  - implementation design based on the chip's resources
    - play with instructions set
    - hardware electrical behaviour (current scrambler, desynchronisation, cryptoprocessor...)







# **Effects of Counter-measures**





# **Differential Power Analysis**

- Orequired number of acquisitions: 500 to 10,000
- **Oprerequisite** 
  - physical access to the card under attack
  - access to either plaintext M or ciphertext C
  - varying plaintext and constant key
  - algorithm specifications (MANDATORY)

### Ocost

- A few dollars (to a few thousands)
- A few days training
- Average good level of expertise
- Chip and implementation independent








#### Odescription:

choose a subset (subK<sub>i</sub>) of n bits of K<sub>1</sub>
 K

subK<sub>i</sub>

- perform a statistical test for each possible value of a subKi








#### **ODPA** statistical test:

a batch of data acquisitions for various messages M<sub>k</sub>



• the corresponding plaintext M<sub>k</sub> or the cipherktext C<sub>k</sub>

dfdsffb fdgcxv lkkjlsdq
the yalues of the subK<sub>i</sub> lklkjlsdq










#### **ODPA** statistical test:


- selection function D :
  - sort curves according to M<sub>k</sub> or C<sub>k</sub> for each value of a subK<sub>i</sub>
  - output = image of a target bit of the algorithm



























### Oiterate on all possible sub-keys:




Ofind the remaining bits through exhaustive search


























### Counter-measures

- **O**Add noise
- OScramble power consumption or stabilize it
- ORandomize all sensitive data variables with a fresh mask for every execution of an algorithm
- ORandomize, randomize, randomize ...
  - Secret keys
  - Messages
  - Private exponents
  - Bases
  - Moduli







# Example: DPA on RSA (1)

- ODPA attacks on Modular exponentiation techniques [CHES'99 MDS]
- ODPA monobit exponentiation (« Square and Multiply » exponentiation algorithm 2):
- OA(0) = 1
- Ofor i = 0 to m-1
  - $A(0) = A(0)^2 \mod N$
  - $A(1) = A(0)*X \mod N$
  - $A(0) = A(d_i)$
- **Onext**
- Oreturn A(0)







# Example: DPA on RSA (2)

#### OHypotheses:

- attacker has control of inputs to target device.
- attacker has some knowledge of the implementation hence can compute intermediate results using an offline simulation
- OSecret exponent extracted bit by bit
- Of or i = 0 to m
- set d' =  $d_0...d_{i-1}||1$  and d' =  $d_0...d_{i-1}||0$
- accept d' which produces best correlation/match with the offline calculation.







# **Conclusion on Power Analysis Attacks**

- ONaïve smartcard implementations of cryptosystems can leak secret data.
- **OPower Analysis Attacks** 
  - target symmetric and asymmetric cryptosystems
  - -- practical, 'fast' and cheap
  - difficult to circumvent
  - countermeasures may impact efficiency.







### First DPA Countermeasures

- ORemove data dependent processing.
- OIntroduce 'noise' to reduce signal to noise ratio.
- Vertical noise in the CPU processing
- Horizontal noise insertion of dummy cycles or instructions in the CPU processing may make synchronisation difficult.
- Concurrent processing.
- Hamming weight balancing.
- OAll of these can be circumvented given enough processing examples.







### **DPA Countermeasures for RSA**

- Algebraic approaches (power consumption is not directly correlated with sensitive data).
  - Exponent Blinding
    - 'add' a random number, r, to the exponent.
       d → d + r \* phi(N)
  - Exponent splitting
    - E.g. represent  $d = d_1 + d_2$  where  $d_1 = r$ ,  $d_2 = d$ -r and r is random.
  - Message Blinding
    - $M \rightarrow r_1^* M \mod N \ (r_1 \text{ random}).$
  - Modulus Blinding
    - $N \rightarrow r_2^* N$  ( $r_2$  random).
  - Randomised exponentiation
    - numerous approaches.







# (Differential) Fault Attacks







### Introduction

- OFault Attacks where first published as a way of jeopardising computations of cryptographic algorithms (RSA, DSA, DES).
- OHowever, you can imagine to implement fault attacks on other processes inside a microprocessor.
- OFault attacks are real industrial security concern:
  - To pass some certification, like FIPS140-1 level 3 (US government security certification), you should prove that your system resists to fault attacks.







# Different types of faults

#### **OTransients Faults.**

Appear randomly in a system, have various unpredictable causes.

#### **OLatent or Internal Faults.**

- Are the result of hardware or low level software default (floating point unit on Pentium chips,...).
- Rarely controllable

#### Induced Faults.

- Appear after intentional stress (E²) or hardware "mutilation", can be transient or permanent.
- Sometimes controllable with knowledge of the physical/chemical/electrical behaviour of the chip.







### The DFA crisis: 1996

### OSeptember 96

- Attack on RSA CRT by Bellcore (EuroCrypt'97)
- Attack improvements by Lenstra

#### October 96

- 18: DFA on DES by Biham et Shamir
- 29: Attack on RSA and ElGamal
- 30: DFA on unknown cryptosystems by Biham & Shamir.
   «Differential Fault Analysis of Secret Key Cryptosystems» (Crypto'97)

#### ONovember 96

 Attack of CRT on LUC and Demytko by Marc Joye and JJ Quisquater







# Attack on standard signature

### **O**Hypothesis:

- the message m and its signature  $s = m^d$  are known
- a fault is injected on one bit i of d
- this results in a wrong signature s'=m<sup>d'</sup>
- O Then:
- $S'/S = m^{d'-d} = m^{2'} \quad \text{mod n if bit } i \text{ was } 0$
- O or
- $s'/s = m^{d'-d} = m^{-2'} \mod n \text{ if bit } i \text{ was } 1$

One bit in random position of the secret exponent is discovered every round.







# Attack on standard signature

- OFaults can be induced on more than one bit, making analysis slightly more difficult.
- OThis attack is compatible with transient or permanent faults.







### **Recall on CRT**

OThe Chinese Remainder Theorem is used in RSA in order to speed up exponentiation by a factor of 4.

### OExponentiation is performed in three steps

- $s_p = m^d \mod p$  is computed (in fact,  $d_p$  is used)
- $s_q = m^d \mod q$  is computed (in fact,  $d_q$  is used)
- the signature is recombined with CRT as

$$s = a.s_p + b.s_q \mod n$$
,

The constants a and b are precomputed such that

$$a = 1 \mod p$$
,  $b = 0 \mod p$ ,

$$a = 0 \mod q$$
,  $b = 1 \mod q$ .





# Attack on CRT exponentiation

OThis attack was first published by Lenstra.

#### OHypothesis:

- − s, signature of a message *m* is known.
- a fault is injected in the exponentiation mod p.
- ODue to error injection,  $s_p$  becomes  $s_p$ '

$$s' = a.s_p' + b.s_q \mod n,$$
  
 $s'-s = (a.s_p' + b.s_q) - (a.s_p + b.s_q) \mod n$ 

$$S'-s=a.(s_p'-s_p) \bmod n$$

O the prime q divides a and can be retrieved by Gcd.








# **Summary of the Differential Fault Attack**(DFA)

An attacker obtains a decryption which is computed in a wrong way.



In the RSA using the CRT, if an attacker can cause a fault for the computation of Mq, then n can be factored by gcd(M-M',n)=p.







### Counter-measures on RSA

### • Applicative counter-measures

- Use a random padding with sufficient variability
- Compute the result twice and compare
- Verify that  $s^e = m \mod n$  when e is known
  - e is usually a small number, verification is very fast

### Algorithmic counter-measures

- One possible counter-measure on RSA-CRT intends to protect both half-exponentiations by:
  - choosing a small random number r
  - computing  $s_{pr} = m^d \mod pr$  et  $s_r = m^d \mod r$
  - checking whether  $s_{pr} \mod r = s_r$







# Hardware aspects of fault attacks

OFlaw injection in this case is a hardly controllable and reproducible process.

### OImplementation is not that easy:

- Stress on memories, during read/writing/retention
  - By means of variations on power supply, frequency
  - Through various types of radiation
- Modifications on hardware mechanism
  - Using probing or FIB
    - Buses
    - Random generators
    - Crypto-coprocessors
    - Hardware DES







### Fault attacks and smart cards

- ONeed expertise in measurements and hardware to implement efficient fault attacks.
- OSmart cards give many tools to defeat fault attacks:
  - Tamper-evidence
    - Security sensors, security mechanisms
  - Software counter-measures
    - On algorithms, on secret storage





