

Contoso Electronics

Equipment Reference & Maintenance Guide

Bench Digital Multimeter

Contoso PrecisionMeter DM-6500

Asset Identification

Field	Detail
Asset ID	CE-DMM-1100
Category	Test & Measurement
Manufacturer	Contoso Instruments Division
Location	Electrical Test Lab - Bench 1
Installation Date	2023-02-01
Warranty Expiry	2027-02-01
Support Contact	test.equipment.support@contoso.com ext. 4210

Overview

The Contoso PrecisionMeter DM-6500 is a 6½-digit bench digital multimeter used for precise measurement of voltage, current, resistance, frequency, and temperature during calibration, verification, and quality testing.

Technical Specifications

Parameter	Value
Display Digits	6½ (1,200,000 counts)
DCV Accuracy	0.0035% of reading
Max Voltage	1000 V DC / 750 V AC
Max Current	10 A
Functions	V, I, Ω, freq, cap, temp, continuity
Interface	USB, LAN, GPIB
Power	100-240 VAC, 50/60 Hz

Preventive Maintenance Schedule

Interval	Task
Monthly	Verify against a known reference standard.
Quarterly	Inspect test leads and fuses; clean terminals.
Annual	Full traceable calibration.
As needed	Replace current-input fuse after overload.

Safety Guidelines

- Never exceed input voltage/current ratings for the selected function.
- Use CAT-rated leads appropriate for the measurement.
- Disconnect before switching between current and voltage inputs.
- Replace fuses only with the specified type and rating.

Common Issues & Troubleshooting

Symptom	Recommended Action
No current reading	Check current-input fuse; verify lead in correct jack.
Unstable readings	Check lead connections; enable appropriate filtering/NPLC.
Reading offset	Perform zero/null; recalibrate if out of tolerance.
OL displayed	Range/limit exceeded - select correct function and range.

Contoso Electronics internal maintenance documentation. For service requests, contact test.equipment.support@contoso.com | ext. 4210 or submit a work order through the maintenance portal.