

Document Title	Specification of RESTful communication
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	876

Document Status	Final
Part of AUTOSAR Standard	Adaptive Platform
Part of Standard Release	18-10

	Document Change History			
Date	Release	Changed by	Description	
2018-10-31	18-10	AUTOSAR Release Management	Updated APIs to use ara::core typesMinor editorial fixes	
2018-03-29	18-03	AUTOSAR Release Management	 Added HTTP/JSON network binding Added support for payload compression Adapted Event API Added support for binary data Minor extensions on API (e.g. helper functions) 	
2017-10-27	17-10	AUTOSAR Release Management	Initial release	



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Table of Contents

1	Introduction and functional overview				
2	Acronyms and Abbreviations				
3	Related documentation				
	3.1Input documents3.2Related standards and norms3.3Related specification	16 16 16			
4	Constraints and assumptions	17			
	4.1 Limitations	17 17			
5	Dependencies to other functional clusters	18			
6	Requirements Tracing	19			
7	Functional specification	35			
	7.1 General description	35 35 37 37 38			
	7.2 Support Functionality	39 41 42 42			
	7.6 Client	45 47 51 51 52 52			
	7.8.4 Route	52 53 54 56 56 60			
8	API specification	62			
	8.1 ara::rest::Allocator	62 62 62 63			



	8.1.4	deallocate	3
	8.1.5	is_equal	3
8.2	ara::rest:	::Client	4
	8.2.1	NotificationHandlerType 6	4
	8.2.2	SubscriptionStateHandlerType 6	4
	8.2.3	Client	5
	8.2.4	Client	5
	8.2.5	operator=	6
	8.2.6	Stop	6
	8.2.7	Send	6
	8.2.8	Subscribe	7
	8.2.9	GetError	7
	8.2.10	ObserveError	8
8.3	ara::rest:	::Event	8
	8.3.1	Event	8
	8.3.2	operator=	9
	8.3.3	Unsubscribe	9
	8.3.4	Resubscribe	
	8.3.5	GetUri	0
	8.3.6	GetSubscriptionState	_
	8.3.7	operator==	_
	8.3.8	operator!=	1
	8.3.9	operator<	2
8.4		::IteratorRange	_
	8.4.1	Iterator	
	8.4.2	IteratorRange	
	8.4.3	begin	
	8.4.4	end	
	8.4.5	begin	_
	8.4.6	end	-
8.5		::MovelteratorRange	-
0.0	8.5.1	Movelterator	
	8.5.2	MovelteratorRange	_
	8.5.3	begin	_
	8.5.4	end	_
	8.5.5	begin	_
	8.5.6	end	_
8.6		::Matches	_
0.0	8.6.1	MatchRange	
	8.6.2	Count	
	8.6.3	Get	-
	8.6.4	Get	_
8.7		::Match	_
0.7	8.7.1	Get	_
	8.7.2	GetAs	
8.8		cogm::Array	_
0.0	arat5l.		U



	8.8.1	Self type
	8.8.2	ParentType
	8.8.3	Iterator
	8.8.4	Constituerator
	8.8.5	ValueRange
	8.8.6	ConstValueRange
	8.8.7	MoveRange
	8.8.8	GetParent
	8.8.9	GetParent
	8.8.10	HasParent
	8.8.11	GetSize
	8.8.12	IsEmpty
	8.8.13	GetValue
	8.8.14	GetValue
	8.8.15	GetValues
	8.8.16	GetValues
	8.8.17	Append
	8.8.18	Insert
	8.8.19	Remove
	8.8.20	Release
	8.8.21	Replace
	8.8.22	Clear
	8.8.23	Make
	8.8.24	Make
	8.8.25	Array
	8.8.26	Array
8.9		cogm::Field
	8.9.1	SelfType
	8.9.2	ParentType
	8.9.3	GetParent
	8.9.4	GetParent
	8.9.5	HasParent
	8.9.6	GetName
	8.9.7	GetValue
	8.9.8	GetValue
	8.9.9	SetValue
	8.9.10	Replace Value
	8.9.11	Make
	8.9.12	Make
	8.9.13	Field
	8.9.14	Field
8.10		:ogm::Int
	8.10.1	SelfType 96
	8.10.2	ParentType
	8.10.3	ValueType 97
	8.10.4	GetParent



	8.10.5	GetParent	98
	8.10.6	HasParent	98
	8.10.7	GetValue	99
	8.10.8	SetValue	99
	8.10.9	Make	99
	8.10.10	Make	00
	8.10.11	Int	00
8.11	ara::rest::	:ogm::Node)1
	8.11.1	SelfType	21
	8.11.2	ParentType)1
	8.11.3	GetParent)2
	8.11.4	GetParent)2
	8.11.5	HasParent)2
	8.11.6	~Node)3
	8.11.7	Node)3
	8.11.8	operator=)4
	8.11.9	GetAllocator)4
	8.11.10	GetAllocator)4
	8.11.11	Node)5
8.12	ara::rest::	ogm::Object)5
	8.12.1	SelfType)5
	8.12.2	ParentType	ე6
	8.12.3	Iterator	ე6
	8.12.4	Constiterator	ე6
	8.12.5	FieldRange)7
	8.12.6	ConstFieldRange)7
	8.12.7	MoveFieldRange	38
	8.12.8	GetParent	38
	8.12.9	GetParent	ე8
	8.12.10	HasParent	ე9
	8.12.11	GetSize	ე9
	8.12.12	IsEmpty	ე9
	8.12.13	GetFields	10
	8.12.14	GetFields	10
	8.12.15	HasField	11
	8.12.16	Find	11
	8.12.17	Find	11
	8.12.18	Insert	12
	8.12.19	Remove	12
	8.12.20	Release	13
	8.12.21	Replace	13
	8.12.22	Clear	14
	8.12.23	Make	14
	8.12.24	Make	
	8.12.25	Object	
	8.12.26	Object	_



8.13	ara::rest:	::ogm::Real	116
	8.13.1	SelfType	116
	8.13.2	ParentType	117
	8.13.3	ValueType	117
	8.13.4	GetParent	117
	8.13.5	GetParent	118
	8.13.6	HasParent	118
	8.13.7	GetValue	118
	8.13.8	SetValue	119
	8.13.9	Make	119
	8.13.10	Make	120
	8.13.11	Real	120
8.14	ara::rest:	::ogm::String	120
	8.14.1	SelfType	121
	8.14.2	ParentType	121
	8.14.3	ValueType	121
	8.14.4	GetParent	122
	8.14.5	GetParent	122
	8.14.6	HasParent	122
	8.14.7	GetValue	123
	8.14.8	SetValue	123
	8.14.9	Make	124
	8.14.10	Make	124
	8.14.11	String	125
	8.14.12	String	125
8.15	ara::rest:	::ogm::Value	125
	8.15.1	SelfType	126
	8.15.2	ParentType	126
	8.15.3	GetParent	126
	8.15.4	GetParent	127
	8.15.5	HasParent	127
	8.15.6	Value	127
8.16	ara::rest:	::Pattern	128
	8.16.1	Pattern	128
	8.16.2	operator==	128
	8.16.3	operator!=	129
	8.16.4	operator<	129
8.17	ara::rest:	::ReplyHeader	130
	8.17.1	GetStatus	130
	8.17.2	SetStatus	130
	8.17.3	GetUri	130
	8.17.4	SetUri	131
	8.17.5	HasField	131
	8.17.6	InsertField	132
	8.17.7	EraseField	132
	8.17.8	GetField	132



	8.17.9		33
	8.17.10	NumFields	33
	8.17.11	ClearFields	34
	8.17.12	FieldIteratorRange	34
	8.17.13	ConstFieldIteratorRange	34
	8.17.14		35
	8.17.15	GetFields	36
8.18	ara::rest:		36
	8.18.1	Reply	36
	8.18.2		37
	8.18.3	GetHeader	37
	8.18.4	GetObject	38
	8.18.5		38
	8.18.6	ReleaseBinary	38
8.19	ara::rest:		39
	8.19.1		39
	8.19.2	SetMethod	39
	8.19.3		40
	8.19.4		40
	8.19.5		40
	8.19.6		41
	8.19.7		41
	8.19.8		42
	8.19.9		42
	8.19.10		43
	8.19.11		43
	8.19.12		43
	8.19.13		44
	8.19.14		44
	8.19.15		45
	8.19.16		45
	8.19.17		46
8.20			46
00	8.20.1		46
	8.20.2		47
	8.20.3	- F	47
	8.20.4		 48
	8.20.5		.0 48
	8.20.6	· ·	0 48
	8.20.7	- 4	-0 49
	8.20.8		49
	8.20.9	- 4	4 9
8.21		· ·	50 50
0.21	8.21.1		50 50
	8.21.2	21	50 51
	8.21.3	0	วา 51
	0.41.0	ConstRouteRange	JI



	8.21.4	Router	
	8.21.5	Router	52
	8.21.6	operator()	52
	8.21.7	InsertRoute	53
	8.21.8	EmplaceRoute	53
	8.21.9	SetDefaultHandler	54
	8.21.10	RouteCount	54
	8.21.11	Routes	54
	8.21.12	Routes	55
	8.21.13	RemoveRoute	55
	8.21.14	FindRoute	55
	8.21.15	Clear	6
8.22	ara::rest:	:Route	6
	8.22.1	Upshot	6
	8.22.2	RouteHandlerType	57
	8.22.3	Route	57
	8.22.4	operator()	58
	8.22.5	GetRequestMethod	58
	8.22.6	GetPattern	59
	8.22.7	operator==	59
	8.22.8	operator!=	59
	8.22.9	operator<	60
8.23	ara::rest:	:ServerEvent	60
	8.23.1	ServerEvent	60
	8.23.2	operator=	
	8.23.3	Notify	31
	8.23.4	Notify	32
	8.23.5	SetSubscriptionState	32
	8.23.6	GetSubscriptionState	32
	8.23.7	GetUri	
	8.23.8	SendError	3
	8.23.9	operator==	34
	8.23.10	operator!=	34
	8.23.11	operator<	35
8.24	ara::rest:	:ServerReply	35
	8.24.1	ServerReply	35
	8.24.2	operator=	
	8.24.3	GetHeader	6
	8.24.4	Send 16	6
	8.24.5	Send	
	8.24.6	Send 16	
	8.24.7	Redirect	
8.25		:ServerRequest	
	8.25.1	ServerRequest	
	8.25.2	operator=	
	8.25.3	GetHeader	39



	8.25.4	GetObject	39
	8.25.5	ReleaseObject	70
	8.25.6	ReleaseBinary	7 0
8.26	ara::rest::	Server	⁷ 1
	8.26.1	RequestHandlerType	⁷ 1
	8.26.2	SubscriptionHandlerType	⁷ 1
	8.26.3	SubscriptionStateHandlerType	⁷ 1
	8.26.4	Server	⁷ 2
	8.26.5	operator=	⁷ 2
	8.26.6	Server	⁷ 2
	8.26.7	Start	73
	8.26.8	Stop	73
	8.26.9	ObserveSubscriptions	7 4
	8.26.10	GetError	7 4
	8.26.11	ObserveError	7 5
8.27	ara::rest::	StdAllocator	7 5
	8.27.1	value_type	7 5
	8.27.2	StdAllocator	7 6
	8.27.3	StdAllocator	7 6
	8.27.4	StdAllocator	7
	8.27.5	allocate	7
	8.27.6	deallocate	7
	8.27.7	select_on_container_copy_construction	78
	8.27.8	resource	78
8.28	ara::rest::	:Uri::Builder	79
	8.28.1	Builder	79
	8.28.2	Builder	79
	8.28.3	Builder	30
	8.28.4	Builder	30
	8.28.5	Scheme	31
	8.28.6	UserInfo	
	8.28.7	Host	31
	8.28.8	Port	
	8.28.9	Path	
	8.28.10	Path	33
	8.28.11	PathSegment	33
	8.28.12	PathSegments	
	8.28.13	PathSegmentsFrom	
	8.28.14	PathSegmentAt 18	
	8.28.15	PathSegmentAt	
	8.28.16	Query	
	8.28.17	QueryParameter	
	8.28.18	QueryParameter	
	8.28.19	QueryParameterAt	
	8.28.20	QueryParameterAt	
	8.28.21	QueryParameterAt	38



	8.28.22	Fragment	188
	8.28.23	Fragment	188
	8.28.24	ToUri	189
	8.28.25	ToPath	189
	8.28.26	ToQuery	190
8.29	ara::rest:	:Uri::Path::Segment	190
	8.29.1	Get	190
	8.29.2	GetAs	191
	8.29.3	operator==	191
	8.29.4	operator!=	191
	8.29.5	operator<	192
8.30		:Uri::Path	192
	8.30.1	IteratorRange	193
	8.30.2	NumSegments	193
	8.30.3	GetSegments	193
	8.30.4	operator==	194
	8.30.5	operator!=	194
	8.30.6	operator<	194
8.31		:Uri::Query::Parameter	195
	8.31.1	GetKey	195
	8.31.2	GetKeyAs	196
	8.31.3	HasValue	196
	8.31.4	GetValue	196
	8.31.5	GetValueAs	197
8.32		:Uri::Query	197
0.0_	8.32.1	IteratorRange	198
	8.32.2	NumParameters	198
	8.32.3	GetParameters	198
	8.32.4	GetParameter	199
	8.32.5	Find	199
	8.32.6	HasKey	200
8.33			200
0.00	8.33.1	Part	200
	8.33.2	LENGTH MAX	201
	8.33.3	operator	201
	8.33.4	Uri	202
	8.33.5	HasScheme	202
	8.33.6	GetScheme	203
	8.33.7	HasUserInfo	203
	8.33.8	GetUserinfo	203
	8.33.9	HasHost	204
	8.33.10	GetHost	204
	8.33.11	HasPort	204
	8.33.12	GetPort	205
	8.33.13	HasPath	205
	8.33.14	GetPath	



	8.33.15	HasQuery	206
	8.33.16	GetQuery	206
	8.33.17	HasFragment	207
	8.33.18	GetFragment	207
	8.33.19	GetFragmentAs	207
	8.33.20	IsEmpty	208
	8.33.21	IsRelative	208
	8.33.22	IsOpaque	209
	8.33.23	IsHierarchical	209
8.34		:Uuid	209
	8.34.1	MakeV1	210
	8.34.2	MakeV3	210
	8.34.3	MakeV4	210
	8.34.4	MakeV5	211
	8.34.5	Uuid	211
	8.34.6	Uuid	212
	8.34.7	Uuid	212
	8.34.8	GetTimeLow	212
	8.34.9	GetTimeMid	213
	8.34.10	GetTimeHighAndVersion	213
	8.34.11	GetClockSeq	214
	8.34.12	GetNode	214
	8.34.13	operator==	214
	8.34.14	operator!=	215
	8.34.15	operator<	215
8.35		:ogm	215
0.00	8.35.1	Copy	215
	8.35.2	Copy	216
	8.35.3	Visit	216
	8.35.4	Visit	217
	8.35.5	Visit	217
	8.35.6	Visit	218
	8.35.7	VisitAll	218
	8.35.8	VisitAll	219
	8.35.9		219
	8.35.10	VisitAll	219
	8.35.11	Get	220
	8.35.12		220
			221
	8.35.13	GetValue	
	8.35.14	GetValue	221
	8.35.15	Set	222
	8.35.16	Set	222
	8.35.17	Set	222
	8.35.18	SetValue	223
	8.35.19	SetValue	223
	8.35.20	Cast	224





	8.36 ara::rest		224
	8.36.1	RequestMethod	224
	8.36.2	SubscriptionState	225
	8.36.3	EventPolicy	225
	8.36.4	ShutdownPolicy	
	8.36.5	StartupPolicy	226
	8.36.6	Function	227
	8.36.7	Pointer	227
	8.36.8	Task	227
	8.36.9	duration t	228
	8.36.10	operator==	228
	8.36.11	operator!=	229
	8.36.12	NewDeleteAllocator	229
	8.36.13	GetDefaultAllocator	229
	8.36.14	SetDefaultAllocator	230
	8.36.15	operator==	230
	8.36.16	operator!=	230
	8.36.17	operator	231
	8.36.18	operator	231
	8.36.19	MakeIteratorRange	232
	8.36.20	MakeMoveIteratorRange	232
	8.36.21	Resolve	233
	8.36.22	Normalize	233
	8.36.23	Relativize	233
	8.36.24	ToString	234
	8.36.25	ToString	234
	8.36.26	ToString	235
	8.36.27	ToString	235
	8.36.28	ToString	236
	8.36.29	ToString	236
	8.36.30	ToString	237
	8.36.31	InstanceIdentifier	237
Α	Mentioned Clas	s Tables	238



1 Introduction and functional overview

This document contains the requirements on the functionality, API and the configuration of the AUTOSAR Adaptive RESTful Communication as part of the Adaptive AUTOSAR platform foundation.

The Communication Management in general realizes functionality to establish communication paths between Adaptive AUTOSAR Applications. This document describes the RESTful Communication part (ara::rest API) whereas [1] covers Service Oriented Communication (ara::com API).

The API design of ara::rest is based on the REST paradigm introduced by [2]. The API is geared towards low and predictable resource usage which is often important in the automotive domain. This specification is focused on the low-level components to provide all features required to design RESTful APIs and deploy services on top.



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the Communication Management that are not included in the AUTOSAR glossary [3].

Abbreviation / Acronym:	Description:
REST	Representational State Transfer
HTTP	Hypertext Transfer Protocol
TLS	Transport Layer Security
MIME	Multipurpose Internet Mail Extensions



3 Related documentation

3.1 Input documents

- [1] Specification of Communication Management AUTOSAR SWS CommunicationManagement
- [2] REST: Architectural Styles and the Design of Network-based Software Architectures
- [3] Glossary
 AUTOSAR_TR_Glossary
- [4] Requirements on Communication Management AUTOSAR_RS_CommunicationManagement
- [5] RFC 3986, Uniform Resource Identifier (URI): Generic Syntax
- [6] SOME/IP Protocol Specification AUTOSAR_PRS_SOMEIPProtocol
- [7] RFC 4122, A Universally Unique IDentifier (UUID) URN Namespace
- [8] RFC 2616, Hypertext Transfer Protocol HTTP/1.1
- [9] RFC 7159, The JavaScript Object Notation (JSON) Data Interchange Format
- [10] RFC 1951, DEFLATE Compressed Data Format Specification version 1.3
- [11] RFC 1952, GZIP file format specification version 4.3

3.2 Related standards and norms

See chapter 3.1.

3.3 Related specification

See chapter 3.1.



4 Constraints and assumptions

4.1 Limitations

The interfaces are only specified to the point to make semantics clear. To be precise this document does not yet fully specify the qualification C++ functions noexcept, overloading of functions to provide move semantics for optimization purposes nor does it claim to be const-correct. Move semantics in particular are specified where required for semantic correctness only. Also only HTTP network binding aspects of the AUTOSAR meta model are currently supported by the SWS_REST. No modeling of the Rest-ServiceInterface internal structure is possible with the current SWS_REST. The error handling for RESTful communication is currently limited due to the fact that errors are not reported in the context of a request transmission.

4.2 Applicability to car domains

No restrictions to applicability.



5 Dependencies to other functional clusters

There are currently no dependencies to other functional clusters.



6 Requirements Tracing

The following tables reference the requirements specified in the Requirements on Communication Management document [4] and links to the fulfillment of these.

Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[RS_CM_00300]	The Communication	[SWS_REST_01101] [SWS_REST_01102]
	Management shall provide a	[SWS_REST_01103] [SWS_REST_01104]
	framework to support the	[SWS_REST_01105] [SWS_REST_01106]
	RESTful communication	[SWS_REST_01107] [SWS_REST_01108]
	paradigm introduced by [2].	[SWS_REST_01109] [SWS_REST_01110]
		[SWS_REST_01111] [SWS_REST_01201]
		[SWS_REST_01203] [SWS_REST_01301]
		[SWS_REST_01302] [SWS_REST_01304]
		[SWS_REST_01305] [SWS_REST_01306]
		[SWS_REST_01307] [SWS_REST_01308]
		[SWS_REST_01312] [SWS_REST_01313]
		[SWS_REST_01314] [SWS_REST_01315]
		[SWS_REST_01316] [SWS_REST_01317]
		[SWS_REST_01318] [SWS_REST_01401]
		[SWS_REST_01402] [SWS_REST_01403]
		[SWS_REST_01404] [SWS_REST_01405]
		[SWS_REST_01406] [SWS_REST_01407]
		[SWS_REST_01408] [SWS_REST_01409]
		[SWS_REST_01410] [SWS_REST_01411]
		[SWS_REST_01412] [SWS_REST_01413] [SWS_REST_01414] [SWS_REST_01415]
		[SWS_REST_01414] [SWS_REST_01417]
		[SWS_REST_01418] [SWS_REST_01419]
		[SWS_REST_01420] [SWS_REST_01421]
		[SWS REST 01422] [SWS REST 01501]
		[SWS REST 01502] [SWS REST 01503]
		[SWS REST 01504] [SWS REST 01505]
		SWS REST 01506 SWS REST 01507
		[SWS_REST_01508] [SWS_REST_01509]
		[SWS_REST_01510] [SWS_REST_01511]
		[SWS_REST_01512] [SWS_REST_01513]
		[SWS_REST_01514] [SWS_REST_01515]
		[SWS_REST_01516] [SWS_REST_01517]
		[SWS_REST_01518] [SWS_REST_01519]
		[SWS_REST_01522] [SWS_REST_01523]
		SWS_REST_01524] [SWS_REST_01525]



Requirement	Description	Satisfied by
	-	[SWS_REST_01526] [SWS_REST_01527]
		[SWS_REST_01528] [SWS_REST_01529]
		[SWS_REST_01530] [SWS_REST_01531]
		[SWS_REST_01532] [SWS_REST_01533]
		[SWS_REST_01534] [SWS_REST_01535]
		[SWS_REST_01536] [SWS_REST_01537]
		[SWS_REST_01538] [SWS_REST_01601]
		[SWS_REST_01602] [SWS_REST_01603]
		[SWS REST 01604] [SWS REST 01605]
		[SWS_REST_01606] [SWS_REST_01607]
		[SWS_REST_01608] [SWS_REST_01609]
		[SWS_REST_01610] [SWS_REST_01611]
		[SWS_REST_01612] [SWS_REST_01613]
		[SWS_REST_01614] [SWS_REST_01615]
		[SWS_REST_01616] [SWS_REST_01617]
		[SWS_REST_01618] [SWS_REST_01619]
		[SWS_REST_01620] [SWS_REST_01621]
		[SWS_REST_01622] [SWS_REST_01623]
		[SWS_REST_01624] [SWS_REST_01625]
		[SWS_REST_01626] [SWS_REST_01627]
		[SWS REST 01628] [SWS REST 01629]
		[SWS_REST_01701] [SWS_REST_01702]
		[SWS_REST_01703] [SWS_REST_01704]
		[SWS_REST_01705] [SWS_REST_01706]
		[SWS_REST_01707] [SWS_REST_01708]
		[SWS_REST_01709] [SWS_REST_01710]
		[SWS_REST_01711] [SWS_REST_01712]
		[SWS_REST_01713] [SWS_REST_01714]
		[SWS_REST_01715] [SWS_REST_02000]
		[SWS_REST_02001] [SWS_REST_02002]
		[SWS_REST_02003] [SWS_REST_02004]
		[SWS_REST_02005] [SWS_REST_02006]
		[SWS_REST_02007] [SWS_REST_02008]
		[SWS_REST_02009] [SWS_REST_02010]
		[SWS_REST_02011] [SWS_REST_02012]
		[SWS_REST_02013] [SWS_REST_02014]
		[SWS_REST_02015] [SWS_REST_02016]
		[SWS_REST_02017] [SWS_REST_02018]
		[SWS_REST_02019] [SWS_REST_02020]
		[SWS_REST_02021] [SWS_REST_02022]
		[SWS_REST_02023] [SWS_REST_02024]
		[SWS_REST_02025] [SWS_REST_02026]
		[SWS_REST_02027] [SWS_REST_02028] [SWS_REST_02029] [SWS_REST_02030]
		[SWS_REST_02027] [SWS_REST_02028]
		[SWS_REST_02027] [SWS_REST_02028] [SWS_REST_02029] [SWS_REST_02030]
		[SWS_REST_02027] [SWS_REST_02028] [SWS_REST_02029] [SWS_REST_02030] [SWS_REST_02031] [SWS_REST_02033]



Requirement	Description	Satisfied by
-	-	[SWS_REST_02040] [SWS_REST_02041]
		[SWS_REST_02042] [SWS_REST_02043]
		[SWS_REST_02044] [SWS_REST_02045]
		[SWS_REST_02046] [SWS_REST_02047]
		[SWS_REST_02048] [SWS_REST_02049]
		[SWS_REST_02050] [SWS_REST_02051]
		[SWS_REST_02052] [SWS_REST_02053]
		[SWS_REST_02054] [SWS_REST_02055]
		[SWS_REST_02056] [SWS_REST_02057]
		[SWS_REST_02058] [SWS_REST_02059]
		[SWS_REST_02060] [SWS_REST_02061]
		[SWS_REST_02062] [SWS_REST_02063]
		[SWS_REST_02064] [SWS_REST_02065]
		[SWS_REST_02066] [SWS_REST_02067]
		[SWS_REST_02068] [SWS_REST_02069]
		[SWS_REST_02070] [SWS_REST_02071]
		[SWS_REST_02072] [SWS_REST_02073]
		[SWS_REST_02074] [SWS_REST_02075]
		[SWS_REST_02076] [SWS_REST_02077]
		[SWS_REST_02078] [SWS_REST_02079]
		[SWS_REST_02080] [SWS_REST_02081]
		[SWS_REST_02082] [SWS_REST_02083]
		[SWS_REST_02084] [SWS_REST_02085]
		[SWS_REST_02086] [SWS_REST_02087]
		[SWS_REST_02088] [SWS_REST_02089]
		[SWS_REST_02090] [SWS_REST_02091]
		[SWS_REST_02092] [SWS_REST_02093]
		[SWS_REST_02094] [SWS_REST_02095]
		[SWS_REST_02096] [SWS_REST_02097]
		[SWS_REST_02098] [SWS_REST_02099]
		[SWS_REST_02100] [SWS_REST_02101]
		SWS_REST_02102] [SWS_REST_02103]
		[SWS_REST_02104] [SWS_REST_02105]
		[SWS_REST_02106] [SWS_REST_02107]
		[SWS_REST_02108] [SWS_REST_02109]
		[SWS_REST_02110] [SWS_REST_02111]
		[SWS_REST_02112] [SWS_REST_02113]
		[SWS_REST_02114] [SWS_REST_02115]
		[SWS_REST_02116] [SWS_REST_02117]
		[SWS_REST_02118] [SWS_REST_02119]
		[SWS_REST_02120] [SWS_REST_02121]
		[SWS_REST_02122] [SWS_REST_02123]
		[SWS_REST_02124] [SWS_REST_02125]
		[SWS_REST_02126] [SWS_REST_02127]
		[SWS_REST_02128] [SWS_REST_02129]
		[SWS_REST_02130] [SWS_REST_02131]
		[SWS_REST_02132] [SWS_REST_02133]
		[SWS_REST_02134] [SWS_REST_02135]



Requirement	Description	Satisfied by
-		[SWS REST 02136] [SWS REST 02137]
		[SWS_REST_02138] [SWS_REST_02139]
		[SWS_REST_02140] [SWS_REST_02141]
		[SWS_REST_02142] [SWS_REST_02143]
		SWS REST 02144] SWS REST 02145]
		[SWS_REST_02146] [SWS_REST_02147]
		[SWS_REST_02148] [SWS_REST_02149]
		[SWS_REST_02150] [SWS_REST_02151]
		[SWS REST 02152] [SWS REST 02153]
		[SWS_REST_02154] [SWS_REST_02155]
		[SWS_REST_02156] [SWS_REST_02157]
		[SWS_REST_02158] [SWS_REST_02159]
		[SWS_REST_02160] [SWS_REST_02161]
		[SWS_REST_02162] [SWS_REST_02163]
		[SWS_REST_02164] [SWS_REST_02165]
		[SWS_REST_02166] [SWS_REST_02167]
		[SWS_REST_02168] [SWS_REST_02169]
		[SWS_REST_02170] [SWS_REST_02171]
		[SWS_REST_02172] [SWS_REST_02173]
		[SWS_REST_02174] [SWS_REST_02175]
		[SWS_REST_02176] [SWS_REST_02177]
		[SWS_REST_02178] [SWS_REST_02179]
		[SWS_REST_02180] [SWS_REST_02181]
		[SWS_REST_02182] [SWS_REST_02183]
		[SWS_REST_02184] [SWS_REST_02185]
		[SWS_REST_02186] [SWS_REST_02187]
		[SWS_REST_02188] [SWS_REST_02189]
		[SWS_REST_02190] [SWS_REST_02191]
		[SWS_REST_02192] [SWS_REST_02193]
		[SWS_REST_02194] [SWS_REST_02195]
		[SWS_REST_02196] [SWS_REST_02197]
		[SWS_REST_02198] [SWS_REST_02199]
		[SWS_REST_02200] [SWS_REST_02201]
		[SWS_REST_02202] [SWS_REST_02203]
		[SWS_REST_02204] [SWS_REST_02205]
		[SWS_REST_02206] [SWS_REST_02207]
		[SWS_REST_02208] [SWS_REST_02209]
		[SWS_REST_02210] [SWS_REST_02211]
		[SWS_REST_02212] [SWS_REST_02213]
		[SWS_REST_02214] [SWS_REST_02215]
		[SWS_REST_02216] [SWS_REST_02217]
		[SWS_REST_02218] [SWS_REST_02219]
		[SWS_REST_02220] [SWS_REST_02221]
		[SWS_REST_02222] [SWS_REST_02223]
		[SWS_REST_02224] [SWS_REST_02225]
		[SWS_REST_02226] [SWS_REST_02227]
		[SWS_REST_02228] [SWS_REST_02229]
		[SWS_REST_02230] [SWS_REST_02231]



Requirement	Description	Satisfied by
<u>.</u>		[SWS_REST_02232] [SWS_REST_02233]
		[SWS_REST_02234] [SWS_REST_02235]
		[SWS_REST_02236] [SWS_REST_02237]
		[SWS REST 02238] [SWS REST 02239]
		SWS REST 02240 SWS REST 02241
		SWS REST 02242 SWS REST 02243
		[SWS_REST_02244] [SWS_REST_02245]
		SWS REST 02246 SWS REST 02247
		SWS REST 02248 SWS REST 02249
		[SWS_REST_02250] [SWS_REST_02251]
		[SWS_REST_02252] [SWS_REST_02253]
		[SWS_REST_02254] [SWS_REST_02255]
		[SWS_REST_02256] [SWS_REST_02257]
		[SWS_REST_02258] [SWS_REST_02259]
		[SWS_REST_02260] [SWS_REST_02261]
		[SWS_REST_02262] [SWS_REST_02263]
		[SWS_REST_02264] [SWS_REST_02265]
		SWS REST 02266 SWS REST 02267
		[SWS_REST_02268] [SWS_REST_02269]
		[SWS_REST_02270] [SWS_REST_02271]
		[SWS_REST_02272] [SWS_REST_02273]
		[SWS_REST_02274] [SWS_REST_02275]
		SWS REST 02276 SWS REST 02277
		[SWS_REST_02278] [SWS_REST_02279]
		[SWS_REST_02280] [SWS_REST_02281]
		[SWS_REST_02282] [SWS_REST_02283]
		[SWS_REST_02284] [SWS_REST_02285]
		[SWS_REST_02286] [SWS_REST_02287]
		[SWS_REST_02288] [SWS_REST_02289]
		[SWS_REST_02290] [SWS_REST_02291]
		[SWS REST 02292] [SWS REST 02293]
		[SWS_REST_02294] [SWS_REST_02295]
		[SWS_REST_02296] [SWS_REST_02297]
		[SWS_REST_02298] [SWS_REST_02299]
		[SWS_REST_02300] [SWS_REST_02301]
		[SWS_REST_02302] [SWS_REST_02303]
		[SWS_REST_02304] [SWS_REST_02305]
		[SWS_REST_02306] [SWS_REST_02307]
		[SWS_REST_02308] [SWS_REST_02309]
		[SWS_REST_02310] [SWS_REST_02311]
		[SWS_REST_02312] [SWS_REST_02313]
		[SWS_REST_02314] [SWS_REST_02315]
		[SWS_REST_02316] [SWS_REST_02317]
		[SWS_REST_02318] [SWS_REST_02319]
		[SWS_REST_02320] [SWS_REST_02321]
		[SWS_REST_02322] [SWS_REST_02323]
		[SWS_REST_02324] [SWS_REST_02325]
		[SWS_REST_02326] [SWS_REST_02327]



Requirement	Description	Satisfied by
		[SWS REST 02328] [SWS REST 02329]
		[SWS REST 02330] [SWS REST 02331]
		[SWS_REST_02332] [SWS_REST_02333]
		[SWS REST 02334] [SWS REST 02335]
		[SWS_REST_02336] [SWS_REST_02337]
		[SWS_REST_02338] [SWS_REST_02339]
		[SWS REST 02340] [SWS REST 02341]
		[SWS_REST_02342] [SWS_REST_02343]
		[SWS REST 02344] [SWS REST 02345]
		[SWS_REST_02346] [SWS_REST_02347]
		[SWS_REST_02348] [SWS_REST_02349]
		[SWS_REST_02350] [SWS_REST_02351]
		[SWS_REST_02353] [SWS_REST_02353]
		[SWS_REST_02354] [SWS_REST_02355]
		[SWS_REST_02360] [SWS_REST_02361]
		[SWS_REST_02363] [SWS_REST_02363]
		[SWS_REST_02364] [SWS_REST_02365]
		[SWS_REST_02366] [SWS_REST_02367]
		[SWS_REST_02366] [SWS_REST_02367]
		[SWS_REST_02370] [SWS_REST_02371]
		[SWS_REST_02370] [SWS_REST_02371]
		[SWS_REST_02374] [SWS_REST_02375]
		[SWS_REST_02374] [SWS_REST_02375]
		[SWS_REST_02376] [SWS_REST_02377]
		[SWS_REST_02380] [SWS_REST_02381]
		[SWS_REST_02382] [SWS_REST_02383] [SWS_REST_02384] [SWS_REST_02385]
		[SWS_REST_02386] [SWS_REST_02387] [SWS_REST_02388] [SWS_REST_02389]
		[SWS_REST_02390] [SWS_REST_02391] [SWS_REST_02392] [SWS_REST_02393]
		[SWS_REST_02392] [SWS_REST_02393]
		[SWS_REST_02395] [SWS_REST_02396] [SWS_REST_02397] [SWS_REST_02398]
		[SWS_REST_02397] [SWS_REST_02396] [SWS_REST_02400]
		[SWS_REST_02401] [SWS_REST_02400]
		[SWS_REST_02401][SWS_REST_02402]
		[SWS_REST_02405] [SWS_REST_02406] [SWS_REST_02407] [SWS_REST_02409]
		[SWS_REST_02410] [SWS_REST_02411]
		[SWS_REST_02412] [SWS_REST_02413]
		[SWS_REST_02414] [SWS_REST_02415]
		[SWS_REST_02416] [SWS_REST_02417]
		[SWS_REST_02418] [SWS_REST_02419]
		[SWS_REST_02420] [SWS_REST_02421]
		[SWS_REST_02422] [SWS_REST_02423]
		[SWS_REST_02424] [SWS_REST_02425]
		[SWS_REST_02426] [SWS_REST_02427]
		SWS_REST_02428] [SWS_REST_02489]



Requirement	Description	Satisfied by
ricquirement	Description	[SWS_REST_02490] [SWS_REST_02492]
		[SWS_REST_02493] [SWS_REST_02494]
		[SWS REST 02496] [SWS REST 02497]
		[SWS REST 02498] [SWS REST 02499]
		[SWS_REST_02501] [SWS_REST_02502]
		[SWS_REST_02503] [SWS_REST_02505]
		[SWS_REST_02506] [SWS_REST_02507]
		[SWS_REST_02508] [SWS_REST_02511]
		[SWS_REST_02512] [SWS_REST_02513] [SWS_REST_02514] [SWS_REST_02515]
		[SWS_REST_02516] [SWS_REST_02517]
		[SWS_REST_02518] [SWS_REST_02519]
		[SWS_REST_02520] [SWS_REST_02528]
		[SWS_REST_02529] [SWS_REST_02805]
		[SWS_REST_02889] [SWS_REST_02932]
		[SWS_REST_02973] [SWS_REST_02989]
IDC CM 000047	The Communication	[SWS_REST_02991] [SWS_REST_10902]
[RS_CM_00301]	The Communication	[SWS_REST_01301] [SWS_REST_01302]
	Management shall provide an	[SWS_REST_01304] [SWS_REST_01305]
	abstraction of network protocols for RESTful services.	[SWS_REST_01306] [SWS_REST_01307]
	for RESTrui services.	[SWS_REST_01308] [SWS_REST_01312]
		[SWS_REST_01313] [SWS_REST_01314]
		[SWS_REST_01315] [SWS_REST_01316]
		[SWS_REST_01317] [SWS_REST_01318]
		[SWS_REST_01401] [SWS_REST_01402]
		[SWS_REST_01403] [SWS_REST_01404]
		[SWS_REST_01405] [SWS_REST_01406]
		[SWS_REST_01407] [SWS_REST_01408]
		[SWS_REST_01409] [SWS_REST_01410]
		[SWS_REST_01411] [SWS_REST_01412] [SWS_REST_01413] [SWS_REST_01414]
		[SWS_REST_01415] [SWS_REST_01416]
		[SWS_REST_01416] [SWS_REST_01416]
		[SWS_REST_01417] [SWS_REST_01410]
		[SWS_REST_01421] [SWS_REST_01422]
		[SWS_REST_01501] [SWS_REST_01502]
		[SWS_REST_01504] [SWS_REST_01504]
		[SWS_REST_01505] [SWS_REST_01506]
		[SWS REST 01507] [SWS REST 01508]
		[SWS_REST_01509] [SWS_REST_01510]
		[SWS_REST_01511] [SWS_REST_01512]
		[SWS_REST_01513] [SWS_REST_01514]
		[SWS_REST_01515] [SWS_REST_01516]
		[SWS_REST_01517] [SWS_REST_01518]
		[SWS_REST_01519] [SWS_REST_01522]
		[SWS_REST_01523] [SWS_REST_01524]
		[SWS REST 01525] [SWS REST 01526]
		[SWS_REST_01527] [SWS_REST_01528]
		[SWS_REST_01529] [SWS_REST_01530]
		[SWS_REST_01531] [SWS_REST_01532]
		[SWS_REST_01533] [SWS_REST_01534]
		[SWS_REST_01535] [SWS_REST_01536]
		[SWS_REST_01537] [SWS_REST_01538]
		[[0440_11E01_01007] [0440_11E01_01000]



Requirement	Description	Satisfied by
		[SWS_REST_02006] [SWS_REST_02007]
		[SWS_REST_02008] [SWS_REST_02009]
		[SWS_REST_02010] [SWS_REST_02011]
		[SWS_REST_02012] [SWS_REST_02013]
		[SWS_REST_02014] [SWS_REST_02015]
		[SWS_REST_02016] [SWS_REST_02238]
		[SWS_REST_02239] [SWS_REST_02240]
		[SWS_REST_02241] [SWS_REST_02242]
		[SWS_REST_02243] [SWS_REST_02244]
		[SWS_REST_02245] [SWS_REST_02246]
		[SWS_REST_02247] [SWS_REST_02248]
		[SWS_REST_02249]
[RS_CM_00304]	The Communication	[SWS_REST_01101] [SWS_REST_01102]
	Management shall support URIs	[SWS_REST_02022] [SWS_REST_02167]
	according to RFC3986 [5] to	[SWS_REST_02168] [SWS_REST_02178]
	identify data.	[SWS_REST_02179] [SWS_REST_02259]
		[SWS_REST_02260] [SWS_REST_02261]
		[SWS_REST_02262] [SWS_REST_02263]
		[SWS_REST_02264] [SWS_REST_02265]
		[SWS_REST_02266] [SWS_REST_02267]
		[SWS_REST_02268] [SWS_REST_02269]
		[SWS_REST_02270] [SWS_REST_02271]
		[SWS_REST_02272] [SWS_REST_02273]
		[SWS_REST_02274] [SWS_REST_02275]
		[SWS_REST_02276] [SWS_REST_02277]
		[SWS_REST_02278] [SWS_REST_02279]
		[SWS_REST_02280] [SWS_REST_02281] [SWS_REST_02282] [SWS_REST_02283]
		[SWS_REST_02284] [SWS_REST_02285]
		[SWS_REST_02286] [SWS_REST_02287]
		[SWS_REST_02288] [SWS_REST_02289]
		[SWS REST 02290] [SWS REST 02291]
		[SWS REST 02292] [SWS REST 02293]
		[SWS REST 02294] [SWS REST 02295]
		[SWS_REST_02296] [SWS_REST_02297]
		[SWS REST 02298] [SWS REST 02299]
		[SWS_REST_02300] [SWS_REST_02301]
		[SWS_REST_02302] [SWS_REST_02303]
		[SWS_REST_02304] [SWS_REST_02305]
		[SWS_REST_02306] [SWS_REST_02307]
		[SWS_REST_02308] [SWS_REST_02309]
		[SWS_REST_02310] [SWS_REST_02311]
		[SWS_REST_02312] [SWS_REST_02313]
		[SWS_REST_02314] [SWS_REST_02315]
		[SWS_REST_02316] [SWS_REST_02317]
		[SWS_REST_02318] [SWS_REST_02319]
		[SWS_REST_02320] [SWS_REST_02321]
		[SWS_REST_02322] [SWS_REST_02323]



Requirement	Description	Satisfied by
-	-	[SWS_REST_02324] [SWS_REST_02325]
		[SWS_REST_02326] [SWS_REST_02327]
		[SWS_REST_02328] [SWS_REST_02329]
		[SWS_REST_02330] [SWS_REST_02372]
		[SWS REST 02373] [SWS REST 02374]
		[SWS_REST_02375] [SWS_REST_02376]
		[SWS_REST_02377] [SWS_REST_02378]
		[SWS_REST_02379] [SWS_REST_02380]
		- - - - -
		[SWS_REST_02381] [SWS_REST_02422]
		[SWS_REST_02424] [SWS_REST_02425]
		[SWS_REST_02426] [SWS_REST_02427]
		[SWS_REST_02489] [SWS_REST_02490]
		[SWS_REST_02492] [SWS_REST_02493]
		[SWS_REST_02494] [SWS_REST_02496]
		[SWS_REST_02497] [SWS_REST_02498]
		[SWS_REST_02499] [SWS_REST_02501]
		[SWS_REST_02502] [SWS_REST_02503]
		[SWS_REST_02505] [SWS_REST_02506]
		[SWS_REST_02507] [SWS_REST_02511]
		[SWS_REST_02512] [SWS_REST_02513]
		[SWS_REST_02514] [SWS_REST_02517]
		[SWS_REST_02518] [SWS_REST_02519]
		[SWS_REST_02520] [SWS_REST_10902]
[RS_CM_00305]	The Communication	[SWS_REST_01304] [SWS_REST_01702]
	Management shall represent	[SWS_REST_01703] [SWS_REST_01704]
	data as an tree of objects.	[SWS_REST_01705] [SWS_REST_01706]
	•	[SWS_REST_01707] [SWS_REST_01708]
		[SWS_REST_01709] [SWS_REST_01710]
		[SWS_REST_01711] [SWS_REST_01712]
		[SWS_REST_01713] [SWS_REST_01714]
		[SWS_REST_01715] [SWS_REST_02036]
		[SWS_REST_02037] [SWS_REST_02038]
		[SWS_REST_02039] [SWS_REST_02040]
		[SWS_REST_02041] [SWS_REST_02042]
		[SWS_REST_02043] [SWS_REST_02044]
		[SWS REST 02045] [SWS REST 02046]
		[SWS_REST_02047] [SWS_REST_02048]
		[SWS_REST_02049] [SWS_REST_02050]
		[SWS_REST_02051] [SWS_REST_02052]
		[SWS REST 02053] [SWS REST 02054]
		[SWS_REST_02055] [SWS_REST_02056]
		[SWS_REST_02057] [SWS_REST_02058]
		[SWS REST 02059] [SWS REST 02060]
		[SWS REST 02061] [SWS REST 02062]
		[SWS REST 02063] [SWS REST 02064]
		[SWS REST 02065] [SWS REST 02066]
		[SWS_REST_02067] [SWS_REST_02068]
		[0**0_11L01_02007][0**0_11L01_02000]



Requirement	Description	Satisfied by
-		[SWS_REST_02069] [SWS_REST_02070]
		[SWS_REST_02071] [SWS_REST_02072]
		[SWS_REST_02073] [SWS_REST_02074]
		[SWS_REST_02075] [SWS_REST_02076]
		[SWS REST 02077] [SWS REST 02078]
		[SWS_REST_02079] [SWS_REST_02080]
		[SWS_REST_02081] [SWS_REST_02082]
		[SWS_REST_02083] [SWS_REST_02084]
		[SWS_REST_02085] [SWS_REST_02086]
		[SWS_REST_02087] [SWS_REST_02088]
		[SWS_REST_02089] [SWS_REST_02090]
		[SWS_REST_02091] [SWS_REST_02092]
		[SWS_REST_02093] [SWS_REST_02094]
		[SWS_REST_02095] [SWS_REST_02096]
		[SWS_REST_02097] [SWS_REST_02098]
		[SWS_REST_02099] [SWS_REST_02100]
		[SWS_REST_02101] [SWS_REST_02102]
		[SWS_REST_02103] [SWS_REST_02104]
		[SWS_REST_02105] [SWS_REST_02106]
		[SWS_REST_02103] [SWS_REST_02108]
		[SWS_REST_02107] [SWS_REST_02110]
		[SWS_REST_02109][SWS_REST_02110]
		[SWS_REST_02113] [SWS_REST_02114]
		[SWS_REST_02115] [SWS_REST_02116]
		[SWS_REST_02117] [SWS_REST_02118]
		[SWS_REST_02119] [SWS_REST_02120] [SWS_REST_02121] [SWS_REST_02122]
		- - - - -
		[SWS_REST_02123] [SWS_REST_02124] [SWS_REST_02125] [SWS_REST_02126]
		[SWS_REST_02127] [SWS_REST_02128]
		[SWS_REST_02129] [SWS_REST_02130]
		[SWS_REST_02131] [SWS_REST_02130]
		[SWS_REST_02133] [SWS_REST_02134]
		[SWS_REST_02135] [SWS_REST_02134]
		[SWS_REST_02133] [SWS_REST_02138]
		[SWS_REST_02137][SWS_REST_02136] [SWS_REST_02139][SWS_REST_02140]
		[SWS_REST_02141] [SWS_REST_02142]
		[SWS_REST_02143] [SWS_REST_02144] [SWS_REST_02145] [SWS_REST_02146]
		. - - .
		[SWS_REST_02147] [SWS_REST_02148]
		[SWS_REST_02149] [SWS_REST_02150] [SWS_REST_02151] [SWS_REST_02152]
		. - - .
		[SWS_REST_02153] [SWS_REST_02154]
		[SWS_REST_02155] [SWS_REST_02156]
		[SWS_REST_02157] [SWS_REST_02158]
		[SWS_REST_02343] [SWS_REST_02344]
		[SWS_REST_02345] [SWS_REST_02346]
		SWS_REST_02347] [SWS_REST_02348]



Requirement	Description	Satisfied by
-	-	[SWS_REST_02389] [SWS_REST_02390]
		[SWS_REST_02391] [SWS_REST_02392]
		[SWS_REST_02393] [SWS_REST_02403]
		[SWS_REST_02404] [SWS_REST_02405]
		[SWS_REST_02406] [SWS_REST_02407]
		[SWS_REST_02409] [SWS_REST_02410]
		[SWS_REST_02411] [SWS_REST_02412]
		[SWS_REST_02413] [SWS_REST_02414]
		[SWS_REST_02415] [SWS_REST_02416]
		[SWS_REST_02417] [SWS_REST_02418]
		[SWS_REST_02419] [SWS_REST_02420]
		[SWS_REST_02421] [SWS_REST_02423]
[RS_CM_00306]	The Communication	[SWS_REST_02036] [SWS_REST_02037]
	Management shall provide an	[SWS_REST_02038] [SWS_REST_02039]
	Object Graph which is	[SWS_REST_02040] [SWS_REST_02041]
	independent of the used	[SWS_REST_02042] [SWS_REST_02043]
	serialization format.	[SWS_REST_02044] [SWS_REST_02045]
		[SWS_REST_02046] [SWS_REST_02047]
		[SWS_REST_02048] [SWS_REST_02049]
		[SWS_REST_02050] [SWS_REST_02051]
		[SWS_REST_02052] [SWS_REST_02053]
		[SWS_REST_02054] [SWS_REST_02055]
		[SWS_REST_02056] [SWS_REST_02057]
		[SWS_REST_02058] [SWS_REST_02059]
		[SWS_REST_02060] [SWS_REST_02061]
		[SWS_REST_02062] [SWS_REST_02063] [SWS_REST_02064] [SWS_REST_02065]
		[SWS_REST_02066] [SWS_REST_02067]
		[SWS_REST_02068] [SWS_REST_02069]
		[SWS_REST_02070] [SWS_REST_02071]
		[SWS_REST_02072] [SWS_REST_02073]
		[SWS_REST_02074] [SWS_REST_02075]
		[SWS REST 02076] [SWS REST 02077]
		[SWS_REST_02078] [SWS_REST_02079]
		[SWS_REST_02080] [SWS_REST_02081]
		[SWS_REST_02082] [SWS_REST_02083]
		[SWS_REST_02084] [SWS_REST_02085]
		[SWS_REST_02086] [SWS_REST_02087]
		[SWS_REST_02088] [SWS_REST_02089]
		[SWS_REST_02090] [SWS_REST_02091]
		[SWS_REST_02092] [SWS_REST_02093]
		[SWS_REST_02094] [SWS_REST_02095]
		[SWS_REST_02096] [SWS_REST_02097]
		[SWS_REST_02098] [SWS_REST_02099]
		[SWS_REST_02100] [SWS_REST_02101]
		[SWS_REST_02102] [SWS_REST_02103]
		[SWS_REST_02104] [SWS_REST_02105]
		[SWS_REST_02106] [SWS_REST_02107]



Requirement	Description	Satisfied by
- 4-		[SWS REST 02108] [SWS REST 02109]
		SWS REST 02110 SWS REST 02111
		[SWS_REST_02112] [SWS_REST_02113]
		[SWS_REST_02114] [SWS_REST_02115]
		[SWS_REST_02116] [SWS_REST_02117]
		[SWS_REST_02118] [SWS_REST_02119]
		[SWS_REST_02120] [SWS_REST_02121]
		[SWS_REST_02122] [SWS_REST_02123]
		[SWS_REST_02124] [SWS_REST_02125]
		[SWS_REST_02126] [SWS_REST_02127]
		[SWS_REST_02128] [SWS_REST_02129]
		[SWS_REST_02130] [SWS_REST_02131]
		[SWS_REST_02132] [SWS_REST_02133]
		[SWS_REST_02134] [SWS_REST_02135]
		[SWS_REST_02136] [SWS_REST_02137]
		[SWS_REST_02138] [SWS_REST_02139]
		[SWS_REST_02140] [SWS_REST_02141] [SWS_REST_02142] [SWS_REST_02143]
		[SWS_REST_02142] [SWS_REST_02145]
		[SWS REST 02146] [SWS REST 02147]
		[SWS_REST_02148] [SWS_REST_02149]
		[SWS_REST_02150] [SWS_REST_02151]
		[SWS REST 02152] [SWS REST 02153]
		[SWS_REST_02154] [SWS_REST_02155]
		[SWS_REST_02156] [SWS_REST_02157]
		[SWS_REST_02158] [SWS_REST_02343]
		[SWS_REST_02344] [SWS_REST_02345]
		[SWS_REST_02346] [SWS_REST_02347]
		[SWS_REST_02348] [SWS_REST_02389]
		[SWS_REST_02390] [SWS_REST_02391]
		[SWS_REST_02392] [SWS_REST_02393]
		[SWS_REST_02403] [SWS_REST_02404]
		[SWS_REST_02405] [SWS_REST_02406]
		[SWS_REST_02407] [SWS_REST_02409]
		[SWS_REST_02410] [SWS_REST_02411]
		[SWS_REST_02412] [SWS_REST_02413] [SWS_REST_02414] [SWS_REST_02418]
		[SWS_REST_02414] [SWS_REST_02416] [SWS_REST_02419]
		[SWS_REST_02421]
[RS CM 00307]	The Communication	[SWS_REST_02036] [SWS_REST_02037]
[Management shall provide an	[SWS_REST_02038] [SWS_REST_02039]
	Object Graph where each Object	[SWS_REST_02040] [SWS_REST_02041]
	is strongly typed.	[SWS_REST_02042] [SWS_REST_02043]
		[SWS_REST_02044] [SWS_REST_02045]
		[SWS_REST_02046] [SWS_REST_02047]
		[SWS_REST_02048] [SWS_REST_02049]
		[SWS_REST_02050] [SWS_REST_02051]
		[SWS_REST_02052] [SWS_REST_02053]
		[SWS_REST_02054] [SWS_REST_02055]
		[SWS_REST_02056] [SWS_REST_02057]
		[SWS_REST_02058] [SWS_REST_02059]



Requirement	Description	Satisfied by
	_	[SWS_REST_02060] [SWS_REST_02061]
		[SWS_REST_02062] [SWS_REST_02063]
		[SWS_REST_02064] [SWS_REST_02065]
		[SWS REST 02066] [SWS REST 02067]
		[SWS_REST_02068] [SWS_REST_02069]
		[SWS_REST_02070] [SWS_REST_02071]
		[SWS_REST_02072] [SWS_REST_02073]
		[SWS REST 02074] [SWS REST 02075]
		[SWS_REST_02076] [SWS_REST_02077]
		[SWS REST 02078] [SWS REST 02079]
		[SWS_REST_02080] [SWS_REST_02081]
		[SWS_REST_02080] [SWS_REST_02083]
		[SWS_REST_02084] [SWS_REST_02085]
		[SWS_REST_02086] [SWS_REST_02087]
		[SWS_REST_02088] [SWS_REST_02089]
		[SWS_REST_02090] [SWS_REST_02091]
		[SWS_REST_02092] [SWS_REST_02093]
		[SWS_REST_02094] [SWS_REST_02095]
		[SWS_REST_02096] [SWS_REST_02097]
		[SWS_REST_02098] [SWS_REST_02099]
		[SWS_REST_02100] [SWS_REST_02101]
		[SWS_REST_02102] [SWS_REST_02103]
		[SWS_REST_02104] [SWS_REST_02105]
		[SWS_REST_02106] [SWS_REST_02107]
		[SWS_REST_02108] [SWS_REST_02109]
		[SWS_REST_02110] [SWS_REST_02111]
		[SWS_REST_02112] [SWS_REST_02113]
		[SWS_REST_02114] [SWS_REST_02115]
		[SWS_REST_02116] [SWS_REST_02117]
		[SWS_REST_02118] [SWS_REST_02119]
		[SWS_REST_02120] [SWS_REST_02121]
		[SWS_REST_02122] [SWS_REST_02123]
		[SWS_REST_02124] [SWS_REST_02125]
		[SWS_REST_02126] [SWS_REST_02127]
		[SWS_REST_02128] [SWS_REST_02129]
		[SWS_REST_02130] [SWS_REST_02131]
		[SWS_REST_02132] [SWS_REST_02133]
		[SWS_REST_02134] [SWS_REST_02135]
		[SWS_REST_02136] [SWS_REST_02137]
		[SWS_REST_02138] [SWS_REST_02139]
		[SWS_REST_02140] [SWS_REST_02141]
		[SWS_REST_02142] [SWS_REST_02143]
		[SWS_REST_02144] [SWS_REST_02145]
		[SWS_REST_02146] [SWS_REST_02147]
		[SWS_REST_02148] [SWS_REST_02149]
		[SWS_REST_02150] [SWS_REST_02151]
		[SWS_REST_02152] [SWS_REST_02153]
		[SWS_REST_02154] [SWS_REST_02155]

— AUTOSAR CONFIDENTIAL —



Requirement	Description	Satisfied by
	•	[SWS_REST_02156] [SWS_REST_02157]
		[SWS_REST_02158] [SWS_REST_02343]
		[SWS_REST_02344] [SWS_REST_02345]
		[SWS_REST_02346] [SWS_REST_02347]
		[SWS_REST_02348] [SWS_REST_02389]
		[SWS_REST_02390] [SWS_REST_02391]
		[SWS_REST_02392] [SWS_REST_02393]
		SWS REST 02403 SWS REST 02404
		SWS REST 02405 SWS REST 02406
		[SWS_REST_02407] [SWS_REST_02409]
		[SWS_REST_02410] [SWS_REST_02411]
		[SWS_REST_02412] [SWS_REST_02413]
		[SWS_REST_02414] [SWS_REST_02418]
		[SWS_REST_02419] [SWS_REST_02420]
		[SWS_REST_02421]
[RS_CM_00308]	The Communication	[SWS REST 02039] [SWS REST 02040]
[110_000000]	Management shall provide	[SWS REST 02041] [SWS REST 02042]
	methods to read and manipulate	[SWS_REST_02043] [SWS_REST_02044]
	the Object Graph	[SWS REST 02045] [SWS REST 02046]
		[SWS REST 02047] [SWS REST 02048]
		[SWS_REST_02049] [SWS_REST_02050]
		[SWS REST 02051] [SWS REST 02052]
		[SWS_REST_02053] [SWS_REST_02054]
		[SWS_REST_02055] [SWS_REST_02056]
		[SWS_REST_02057] [SWS_REST_02058]
		[SWS_REST_02059] [SWS_REST_02060]
		[SWS_REST_02061] [SWS_REST_02065]
		[SWS_REST_02066] [SWS_REST_02067]
		[SWS_REST_02068] [SWS_REST_02069]
		[SWS_REST_02070] [SWS_REST_02071]
		[SWS_REST_02072] [SWS_REST_02073]
		[SWS_REST_02074] [SWS_REST_02075]
		[SWS_REST_02076] [SWS_REST_02081]
		[SWS_REST_02082] [SWS_REST_02083]
		[SWS_REST_02084] [SWS_REST_02085]
		[SWS REST 02086] [SWS REST 02087]
		[SWS_REST_02088] [SWS_REST_02092]
		[SWS REST 02093] [SWS REST 02094]
		[SWS_REST_02095] [SWS_REST_02096]
		[SWS_REST_02097] [SWS_REST_02098]
		[SWS_REST_02099] [SWS_REST_02100]
		[SWS_REST_02104] [SWS_REST_02105]
		[SWS_REST_02106] [SWS_REST_02107]
		[SWS_REST_02108] [SWS_REST_02109]
		[SWS_REST_02110] [SWS_REST_02111]
		[SWS_REST_02112] [SWS_REST_02113]
		[SWS_REST_02114] [SWS_REST_02115]
		[SWS_REST_02116] [SWS_REST_02117]
		[SWS_REST_02118] [SWS_REST_02119]
		[SWS_REST_02120] [SWS_REST_02121]
		[SWS_REST_02122] [SWS_REST_02123]



Requirement	Description	Satisfied by
-	-	[SWS_REST_02124] [SWS_REST_02125]
		[SWS_REST_02126] [SWS_REST_02131]
		[SWS_REST_02132] [SWS_REST_02133]
		[SWS_REST_02134] [SWS_REST_02135]
		[SWS_REST_02136] [SWS_REST_02137]
		[SWS_REST_02138] [SWS_REST_02143]
		[SWS_REST_02144] [SWS_REST_02145]
		[SWS_REST_02146] [SWS_REST_02147]
		[SWS_REST_02148] [SWS_REST_02149]
		[SWS_REST_02150] [SWS_REST_02151]
		[SWS_REST_02155] [SWS_REST_02156]
		[SWS_REST_02157] [SWS_REST_02158]
		[SWS_REST_02343] [SWS_REST_02344]
		[SWS_REST_02345] [SWS_REST_02346]
		[SWS_REST_02347] [SWS_REST_02348]
		[SWS_REST_02389] [SWS_REST_02390]
		[SWS_REST_02391] [SWS_REST_02392]
		[SWS_REST_02393] [SWS_REST_02403] [SWS_REST_02404] [SWS_REST_02405]
		[SWS_REST_02404] [SWS_REST_02405] [SWS_REST_02406]
		[SWS_REST_02400] [SWS_REST_02407]
		[SWS_REST_02410] [SWS_REST_02412]
		[SWS_REST_02413] [SWS_REST_02414]
		[SWS_REST_02418] [SWS_REST_02419]
		[SWS_REST_02420] [SWS_REST_02421]
[RS CM 00309]	The Communication	[SWS_REST_02027] [SWS_REST_02028]
[Management shall provide a	[SWS_REST_02029] [SWS_REST_02030]
	way to match requests to	[SWS_REST_02031] [SWS_REST_02033]
	corresponding server handlers	[SWS_REST_02034] [SWS_REST_02035]
	and vice versa.	[SWS_REST_02159] [SWS_REST_02160]
		[SWS_REST_02161] [SWS_REST_02162]
		[SWS_REST_02163]
[RS_CM_00310]	The Communication	[SWS_REST_01616] [SWS_REST_01617]
	Management shall provide an	[SWS_REST_01618] [SWS_REST_01624]
	interface to install request	[SWS_REST_02244]
	handlers.	
[RS_CM_00311]	The Communication	[SWS_REST_01001] [SWS_REST_01002]
	Management shall provide type	[SWS_REST_01003] [SWS_REST_01004]
	aliases for abstraction of	[SWS_REST_01005] [SWS_REST_01007]
	standard C++ components.	[SWS_REST_01011] [SWS_REST_01013]
		[SWS_REST_01014] [SWS_REST_01015]
		[SWS_REST_01016] [SWS_REST_01017]
		[SWS_REST_01018] [SWS_REST_01019]
		[SWS_REST_01020] [SWS_REST_02354]
		[SWS_REST_02355] [SWS_REST_02360]



Requirement	Description	Satisfied by
[RS CM 00312]	The Communication	[SWS REST 01801] [SWS REST 01802]
[o_oj	Management shall provide	[SWS_REST_01803] [SWS_REST_01804]
	HTTP/1.1 to transport RESTful	[SWS REST 01805] [SWS REST 01806]
	requests and responses.	[SWS REST 01807] [SWS REST 01808]
	requests and responses.	[SWS REST 01816] [SWS REST 01817]
		[SWS_REST_01818] [SWS_REST_01819]
		[SWS_REST_01820] [SWS_REST_01821]
		[SWS_REST_01822] [SWS_REST_01823]
		[SWS_REST_01824] [SWS_REST_01825]
		[SWS_REST_01826] [SWS_REST_01827]
		[SWS_REST_01828] [SWS_REST_01829]
		[SWS_REST_01830] [SWS_REST_01831]
		[SWS_REST_01830][SWS_REST_01833]
		[SWS_REST_01834] [SWS_REST_01852]
[DC_CM_00040]	The Communication	[SWS_REST_01859]
[RS_CM_00313]	The Communication	[SWS_REST_01851] [SWS_REST_01852]
	Management shall provide a	[SWS_REST_01854]
	JSON-based serialization for the	[SWS_REST_01855] [SWS_REST_01856]
	payload of RESTful requests	[SWS_REST_01857] [SWS_REST_01858]
	and responses.	[SWS_REST_01859] [SWS_REST_01899]
[RS_CM_00314]	The Communication	[SWS_REST_01810] [SWS_REST_01811]
	Management shall provide	[SWS_REST_01812] [SWS_REST_01813]
	Websockets to establish event	[SWS_REST_01814] [SWS_REST_01815]
	communication.	



7 Functional specification

7.1 General description

This chapter and chapter 8 specify an API design for a RESTful application framework for Adaptive AUTOSAR. Traditionally RESTful services are applications of the mobile world where resource constraints are not as severe as in the automotive domain. Neither clients, servers, transport protocols, formats and last but not least RESTful applications on top of all this are usually particularly geared towards low and predictable resource usage. Providing RESTful services in an environment with strict quality requirements such as low and deterministic memory and processing time is therefore particularly challenging. ara::rest is specifically designed for this use-case.




Figure 7.1: Typical RESTful service stack

A typical RESTful API stack is depicted in figure 7.1. In this, ara::rest provides the lower to stack elements and a generic data representation from which elements like a domain-specific API and a domain-specific data model can be constructed.

7.1.1 Architectural concepts

35 of 241

The ara::rest framework is modular in that it enables developers to access different layers involved in RESTful message transactions directly. This is in contrast to ara::com whose focus is to provide to the developer a traditional function call interface and to hide all details of the transactions beyond this point. This shifts some technical effort but also a lot of control away from the developer into a monolithic black box. This is a feasible design choice since there is a clear and very simple notion of what such an API constitutes: C-style functions.



As opposed to this RESTful APIs are an entirely unclear design target. Specific designs range from entirely data driven access up to simulation of RPC interfaces. In ara::com interfaces are precisely defined and message payloads are known to the byte. In RESTful APIs in general this is not necessarily the case. Control of a service is exercised entirely by means of (often dynamic) data. Specific functionality of a service is triggered by any combination of URI and data payload in the messages themselves and it is up to the service to interpret this data and turn this back into actual side-effects. To make the contrast clear, in ara::com a "meta contract" of the API exists which allows a high degree of optimization since the form of interaction is "function calls with mostly static data".

For RESTful APIs such a basic concept does not exist. Therefore RESTful API design is a two-step process of first designing a specific instance of an API which defines a class of services that agree on the general rules of interaction and second defining specific services by using the tools enabled by those rules. To make this more hands-on, there might exists a vendor-specific implementation of ara::rest, there might exist a OEM-specific RESTful API on top of this and there might exists a domain-specific service built by means of this RESTful API. ara::rest specifically addresses these requirements by incorporating a modular design which supports developers at the level of API as well as service design. The following diagram illustrates its general design. It depicts how a service application is composed in ara::rest:




Figure 7.2: ara::rest component stack

All ara::rest communication is performed through protocol-specific bindings. By default ara::rest abstracts from these protocol details. The generic REST layer of ara::rest only provides three fundamental abstractions: a tree-structured message payload (Object Graph), a URI and a request method (like GET or POST known from HTTP). From these basic primitives domain-specific RESTful APIs can be composed (such as W3C ViWi) which defines a concrete high-level protocol for interaction via object graphs, URIs and methods. Its purpose is to define the rules for access into a domain-specific data model and to provide an abstract (C++) API to an application.



The unified data representation, called Object Graph Model (OGM) comprises of a very limited set of data primitives which reflects the simplicity of usual RESTful communication artifacts (such as JSON message payloads).




Figure 7.3: Class diagram of the Object Graph Model

7.1.2 Design Scope

This specification covers the topics support-library, client/server endpoints and object graph data structure in detail. It does not yet cover topics related to mapping the AUTOSAR meta model onto ara::rest. Security features like a built-in support for authentication are not conclusively decided upon.

7.1.3 Design objectives

ara::rest has been carefully designed to enable implementations with deterministic timing, low resource footprint and low latency while being simple enough to reason about aspects of software safety. This sets it apart from existing C++ RESTful service frameworks. In the following a brief overview of its key design objectives are provided.

- Component-based: ara::rest is a construction kit to build RESTful APIs. It does
 not directly define a specific API upon which services can be realized. Instead
 it supports its construction by providing basic components that enable efficient
 implementations with a high degree of resource control to meet software safety
 requirements.
- Standard compatibility: ara::rest abstracts from standard C++ for some key components. On the one hand some critical features are not yet sufficiently mature, are not yet part of the standard or are incomplete. On the other hand some standard components inhibit safe and efficient implementations when it comes to resource control and asynchronous programming. Therefore ara::rest defines a small set of type aliases which allow for an implementation to provide custom components if the platform does not support them yet, or for enhanced safety and efficiency. ara::rest is carefully designed to enable the use of standard C++ com-



ponents for quick deployment (abstraction then boils down to simple type aliases) but also enables an implementation to replace all of them by custom components. It is not a wrapper.

- Asynchronous programming model: ara:rest is designed for asynchronous I/O
 as its default programming model. Consequently implementations can be highly
 responsive without the need for multi-threading. ara::rest does not enforce a
 single-thread execution model though. It is up to a concrete implementation how
 computing resources are being exploited.
- Task-based execution model: ara::rest is designed for low latency and low resource usage by defining a task-based execution model which complements the asynchronous programming model. ara::rest tasks abstract from traditional threading as they leave unspecified whether a task corresponds to a POSIX thread one-to-one, or whether it corresponds to a lightweight user-level thread abstraction or none of the above.
- User-defined memory management: To complement the stack-based resource model, all dynamic data structures of ara::rest support a custom allocator model to support safety and efficiency at all levels. (Allocators are compatible with C++17 PMR.) They complement the abstraction of certain critical standard C++ components.
- Unified data abstraction: The framework provides a unified API to handle message payloads and optionally the underlying data model of services. ara::rest communicates via tree-structured data called object graphs. It provides all necessary abstractions to build, traverse and dissect object graphs at C++ level. It reflects the capabilities of JSON to some extent for easy serialization. However it is designed with two additional objectives in mind. First, object graphs are designed for ara::rest specifically. Although they can be used independently of other ara::rest components, they fit into the general resource model. Second, object graphs can be specialized such that abstract objects can be derived from the AUTOSAR meta model. This lifts the handling of message payloads from the handling of primitives data types such as int, strings or "records" to the level of handling Doors, Windows and Batteries, for example. Nevertheless, a domain-specific ara::rest server that replies with a "Battery" object in its payload can communicate with a client which has no such notion and vice versa. This is key to enable communication with non-AUTOSAR RESTful clients and services. In addition this abstraction simplifies the mapping into Classic AUTOSAR since abstract object graphs precisely map to static struct representations required by SOME/IP [6].

7.1.4 Basic Components

ara::rest can roughly be subdivided into functional blocks as depicted in figure 7.4.






Figure 7.4: Basic components comprising ara::rest

The Object Graph is a protocol-independent tree-like data structure which is the cornerstone of all ara::rest communication. Its purpose is to map to a protocol format such as JSON as well as to C structs. This maximizes compatibility with non-ARA communication peers and Classic AUTOSAR. Object graphs are transmitted in messages which abstract completely from a concrete underlying protocol binding.

Messages encapsulate the entire context of a request/reply communication cycle in the asynchronous programming model of ara::rest.

The routing concept provides a means to map requests (including request method and URI) onto user-defined handler functions. Routing is the cornerstone to lift abstraction from generic REST into a specific kind of RESTful API.

Uri is a generic RFC-compliant, memory-efficient and exception-safe URI representation. ara::rest provides so-called (network) endpoints for server and client communication which both provide a comparable degree of resource control.

The entire framework design is strictly geared towards maximal resource control. All computations and allocations can be strictly controlled and customized to the precise needs of an application (deployment).

7.2 Support Functionality

The ara::rest framework requires abstractions from some standard C++ components that are particularly critical in terms of resource control and safety. This provides much greater control of resources such as allocation of memory and computing time and allows to fix many of the existing problems with standard C++ components. However all of these abstractions indeed have an existing counterpart defined in the C++ standard (C++11 or C++17). In AUTOSAR some of these C++ components already has an abstraction in the Adaptive Core Types, [?,]. In these cases the ara::core types shall be used.

[SWS_REST_01001] Use of support type aliases [The support type aliases specified in this section may either alias standard C++ library types as available, or alias custom but API-compliant implementations, such as ara::core::types. | (RS CM 00311)

[SWS_REST_01002] Duration type [A type alias ara::rest::duration_t shall exist to express time spans of precision of at least microseconds. |(RS_CM_00311)



[SWS_REST_01003] Pointer type [A type ara::rest::Pointer shall exist that models the precise semantics of std::unique_ptr.](RS_CM_00311)

[SWS_REST_01004] Basic string type [ara::core::String shall be used for std::basic_string semantics. | (RS CM 00311)

[SWS_REST_01005] String type [ara::core::String shall be used for std::string semantics. | (RS_CM_00311)

[SWS_REST_01007] Basic String View [ara::core::StringView shall be used for std::basic_string_view semantics. | (RS CM 00311)

[SWS_REST_01011] String View type [ara::core::StringView shall be used for std::string_view semantics. | (RS_CM_00311)

[SWS_REST_01013] Function type [A type alias template shall exist that models the precise semantics of std::function. The following type alias template may be used:

```
1 template<typename T>
2 using Function = std::function<T>;
```

```
(RS CM 00311)
```

[SWS_REST_01014] Task type [A type alias template shall exist that models the precise semantics of C++14 std::future. ara::core::Future shall be used. The following type alias template may be used:

```
1 template<typename T>
2 using Task = ara::core::Future<T>;
```

```
(RS_CM_00311)
```

[SWS_REST_01016] Iterator ranges [A type IteratorRange shall be defined as a thin wrapper around a pair of iterators according to API ara::rest::IteratorRange. | (RS CM 00311)

[SWS_REST_01017] Allocator [A type ara::rest::Allocator shall exist that models the precise semantics of C++17 std::pmr::memory_resource. The following type alias may be used, if available:

```
using Allocator = std::experimental::pmr::memory_resource;
```

```
(RS_CM_00311)
```

[SWS_REST_01018] Allocator Adapter [For compatibility, a standard allocator adapter type shall be provided that models the precise semantics of C++17 std::pmr::polymorphic_allocator. The following type alias template may be used, if available:

```
1 template<typename T>
```



```
2 using StdAllocator = std::experimental::pmr::polymorphic_allocator<T>;
```

```
(RS CM 00311)
```

[SWS_REST_01019] NewDelete Allocator | For compatibility, a default allocator type shall be provided that models the precise semantics of C++17 std::pmr::new_delete_resource. This type shall allocate and free memory via default new and delete operators internally. The following type alias template may be used, if available:

```
template<typename T>
using NewDeleteAllocator = std::experimental::pmr::new_delete_resource;
|(RS CM 00311)
```

[SWS_REST_01020] Get and Set Default Allocator There shall exist two functions to request () and reset () a global default allocator instance. The following type alias template may be used, if available:

```
1 Allocator* GetDefaultAllocator() noexcept;
2 Allocator* SetDefaultAllocator(Allocator*) noexcept;
|(RS CM 00311)
```

7.3 URI

ara::rest::Uri is a universal container for RFC 3986 [5] compliant identifiers and is specifically designed with resource control in mind. ara::rest messaging is essentially based on two kinds of payloads: object graph and URI. In simple transactions, URIs potentially yield larger memory footprints than the message payloads themselves. An efficient URI type is therefore required.

[SWS_REST_01101] URI API [This type shall at least provide the interface along with its functional description as specified in ara::rest::Uri.](RS_CM_00300, RS_CM_00304)

[SWS_REST_01102] URI UTF-8 [ara::rest::Uri shall support UTF-8 in percent-encoded form (see RFC 3986 [5]). Otherwise no awareness of a particular character encoding is required.] (RS_CM_00300 , RS_CM_00304)

[SWS_REST_01103] URI String conversion [All ara::rest::Uri member functions that return string objects shall return a textual representation in non-percent-encoded form. All forms of ara::rest::ToString shall return a percent or non-percent encoded form, depending the flag specified as its function argument.] (RS CM 00300)

[SWS_REST_01104] URI Mutability $[ara::rest::Uri shall be immutable. New versions of URI objects can only by created via ara::rest::Uri::Builder.] (RS_CM_00300)$



[SWS_REST_01105] URI Exceptions [ara::rest::Uri shall not throw. (RS_CM_00300)

[SWS_REST_01106] URI Maximal Length [ara::rest::Uri shall keep a constant length limit of 2048 bytes including potential string terminators and shall be provided via ara::rest::Uri::LENGTH_MAX. | (RS CM 00300)

[SWS_REST_01107] Builder API [ara::rest::Uri::Builder shall at least provide the API defined in its API specification. | (RS CM 00300)

[SWS_REST_01108] Builder Exceptions [ara::rest::Uri::Builder may throw. | (RS CM 00300)

[SWS_REST_01109] URI Normalization [ara::rest::Normalize shall normalize ara::rest::Uris according to RFC 3986 [5]. | (RS CM 00300)

[SWS_REST_01110] URI Resolve [ara::rest::Resolve shall resolve ara::rest::Uris according to RFC 3986 [5]. | (RS CM 00300)

[SWS_REST_01111] URI Relativize | ara::rest::Relativize shall relativize ara::rest::Uris according to RFC 3986 [5]. | (RS_CM_00300)

7.4 UUID

[SWS_REST_01201] UUID type [To represent UUIDs according to RFC 4122 [7], ara::rest::Uuid shall be defined according to its API specification.] (RS CM 00300)

[SWS_REST_01203] UUID exceptions [ara::rest::Uuid shall not throw exceptions during construction. $|(RS_CM_00300)|$

[SWS_REST_02428] UUID Construction Semantics [UUID constructor shall construct an UUID with zero values. UUID generation is provided by static helper functions ara::rest::Uuid::MakeV1, ara::rest::Uuid::MakeV3, ara::rest::Uuid::MakeV4, ara::rest::Uuid::MakeV5.](RS_CM_00300)

7.5 Endpoints

ara::rest provides two (network) endpoints - ara::rest::Client and ara::rest::Server - that manage I/O and resources of RESTful communication. This section specifies the common requirements for both client and server. Specific requirements for the ara::rest::Client and the ara::rest::Server can be found in Chapter 7.6 and 7.7.

[SWS_REST_01301] Endpoints [ara::rest endpoints shall have no notion of the underlying communication protocol. | (RS CM 00300, RS CM 00301)



[SWS_REST_01302] Endpoint RESTful communication paradigm ☐ ara::rest endpoints may violate the REST-principle by maintaining state about their respective peers internally, depending on the requirements of the underlying transport protocol used in peer communication. ☐ (RS CM 00300, RS CM 00301)

[SWS_REST_01304] Endpoint I/O abstraction [All communication of an application with a remote peer shall be performed via ara::rest::RequestMethod, ara::rest::Uri and the Object Graph Model.](RS_CM_00300, RS_CM_00301, RS_CM_00305)

[SWS_REST_01305] Request Methods [All accesses into an application data model shall be performed with a small, predefined set of request methods that denote whether an access shall be reading (GET), creating (POST), creating or changing (PUT), deleting (DELETE) or introspection (OPTIONS). Their precise semantics is application-defined. An enumeration ara::rest::RequestMethod shall exist which represents these respective access methods as well as ara::rest::operator| for recombination. [RS CM 00300, RS CM 00301)

[SWS_REST_01306] SubscriptionState [To facilitate events, an implementation shall provide an enumeration <code>ara::rest::SubscriptionState</code> whose elements shall have the following semantics: An event subscription "subscribed" if client and server successfully performed a subscription handshake. It is "canceled" if both peers agreed to cancel the subscription. If the state is neither "subscribed" nor "canceled" it shall be "invalid". | (RS CM 00300, RS CM 00301)

[SWS_REST_01307] EventPolicy [Events in ara::rest can be subscribed to in different modes. An implementation shall provide an enumeration ara::rest::EventPolicy that shall provide the following semantics for event subscriptions:

- ara::rest::EventPolicy::kTriggered: An event is only triggered upon explicit request through ara::rest::ServerEvent::Notify. The given time bound limits the number of requests per time frame to at most once.
- ara::rest::EventPolicy::kPeriodic: An event is triggered in constant time frames. Explicit triggers of events have not effect.
- EventPolicy::kTriggered|EventPolicy::kPeriodic: An event is triggered the end of each given time frame, if and only if a trigger has been issued within this frame at least once. Additional triggers shall have no effect.

(RS CM 00300, RS CM 00301)

[SWS_REST_01308] ShutdownPolicy [To facilitate a well-defined shutdown of an endpoint, an implementation shall provide an enumeration ara::rest::ShutdownPolicy which shall provide the general semantics as described subsequently. Specific semantic differences between client and server are specified below.

• ara::rest::ShutdownPolicy::kForced: A forced shutdown shall cancel (terminate) all transactions as fast as possible and does not block the caller for



"unreasonably" (implementation-defined) long period of time. During a forced shutdown, further network I/O is not allowed. A forced shutdown shall not allocate new memory resources. Apart from this semantics of these policies are implementation defined.

• ara::rest::ShutdownPolicy::kGraceful: Endpoints may shut down "gracefully", which shall allow all ongoing transactions to finish while blocking the caller. Precise semantics of these policies are implementation defined.

(RS CM 00300, RS CM 00301)

[SWS_REST_01312] Reply Header [A ara::rest::ReplyHeader shall exist which shall provide mutable access to ara::rest::RequestMethod and ara::rest::Uri of a ara::rest::Reply or ara::rest::ServerReply. The precise semantics of ara::rest::ReplyHeader::GetStatus and ara::rest::ReplyHeader::SetStatus as well as ara::rest::ReplyHeader::GetUri and ara::rest::ReplyHeader::SetUri is protocol-dependent. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01313] Request Header [A ara::rest::RequestHeader shall exist which shall provide mutable access to ara::rest::RequestMethod and ara::rest::Uri of a ara::rest::Request or ara::rest::ServerRequest. | (RS CM 00300, RS CM 00301)

[SWS_REST_01314] Instance identifier [A ara::rest::InstanceIdentifier shall relate to the corresponding port in the meta model of the SoftwareComponent—Type over the InstanceRef. Note that the port name of the meta model alone is not sufficient to clearly identify it in its final instantiation, where the same component implementation might be instantiated multiple times in the code and then eventually started multiple times in different processes. This is a generic problem which also exists on ara::com. | (RS CM 00300, RS CM 00301)

[SWS_REST_01315] RestServiceInterface [The RestServiceInterface shall contain the model of a specific RESTful service. Note that further modeling of how such a service looks like is already present in TPS_Manifest but it is currently not applied in this SWS document. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01316] Network binding [RestServiceInterface implemented by ara::rest::Client and ara::rest::Server shall be bound to a specific network binding.] $(RS_CM_00300, RS_CM_00301)$

[SWS_REST_01317] TLS secure channel for RESTful communication $[A TLS secure channel shall be used for RESTful communication if a TlsSecureComProps instance is referenced by RestHttpPortPrototypeMapping. <math>](RS_CM_00300, RS_CM_00301)$

[SWS_REST_01318] TLS secure channel for event communication \lceil A TLS secure channel shall be used for event-based communication if a TlsSecureComProps instance is referenced by RestHttpPortPrototypeMapping. \rfloor (RS_CM_00300, RS_CM_00301)



7.6 Client

ara::rest requires the existence of a type ara::rest::Client which represents the client network endpoint for RESTful communication. A client is not bound to a particular remote endpoint.

[SWS_REST_01401] Client Resources [ara::rest::Client maintains all resources related to communication with a peer. Upon destruction, all such resources shall be released. |(RS CM 00300, RS CM 00301)

[SWS_REST_01402] Client Interface \[An ara::rest::Client \] shall at least provide the interface as specified in its API specification and according to the detailed semantics specified there. \[(RS_CM_00300, RS_CM_00301) \]

[SWS_REST_01403] Client Instances [ara::rest::Client shall not be copyable. It shall be movable. | (RS CM 00300, RS CM 00301)

[SWS_REST_01404] Client Multiplicity [ara::rest::Client shall not be bound to one particular peer. As such, a client is not bound to a particular server instance.] (RS_CM_00300, RS_CM_00301)

[SWS_REST_01405] Client Asynchronicity $\lceil ara::rest::Client$ shall be able to operate according to its semantic requirements without employing multi-threading. Consequently, a user shall be aware of the fact that invoking blocking functions such as ara::rest::Task<T>::wait() may degrade service quality. \rfloor (RS_CM_00300, RS_CM_00301)

[SWS_REST_01406] Client Concurrency [It is implementation-defined whether ara::rest::Client is operating concurrently. Consequently, a user shall be aware of the fact that invoking blocking functions may degrade service quality.] (RS_CM_00300, RS_CM_00301)

[SWS_REST_01407] Client Construction [ara::rest::Client] shall be provided with a unique identifier that selects an implementation-defined configuration record. $[RS_CM_00300, RS_CM_00301]$

[SWS_REST_01408] Client Startup [ara::rest::Client] shall be ready for transmission to remote hosts if construction succeeded. In particular, a client may throw if construction fails. Otherwise, an error shall be indicated via ara::rest::Client::GetError. $](RS_CM_00300, RS_CM_00301)$

[SWS_REST_01409] Client Shutdown [ara::rest::Client shall be stopped via ara::rest::Client::Stop according to the semantics specified in its API specification and SWS REST 01308. | (RS CM 00300, RS CM 00301)

[SWS_REST_01410] Client Stop [ara::rest::Client::Stop shall be thread-safe. After it has been invoked, calling ara::rest::Client::Send, ara::rest::Client::Subscribe Or ara::rest::Client::Stop shall have no effect. | (RS_CM_00300, RS_CM_00301)



[SWS_REST_01411] Client Stop Task [ara::rest::Client::Stop returns a Task which shall only complete once shutdown succeeded. It may throw otherwise.] (RS CM 00300, RS CM 00301)

[SWS_REST_01412] Client Sending $\lceil ara::rest::Client::Send$ shall transmit an ara::rest::Request to a peer specified via the given request URI. The call shall never block even for multiple requests to the same peer. $\rfloor (RS_CM_00300, RS_CM_00301)$

[SWS_REST_01413] Client Peer Addressing \[ara::rest::Client::Send shall transmit a request to the peer specified by the uri authority part via \[ara::rest::Uri::GetHost and ara::rest::Uri::GetPort. If not such information is available a client shall fall back to the host address and port given by the network binding configuration. \[(RS_CM_00300, RS_CM_00301) \]

[SWS_REST_01414] Client Events [An implementation shall provide ara::rest::Client::Subscribe to create ara::rest::Event instances which represent a single event subscription. ara::rest::Client::Subscribe shall never block. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01415] Client Event Uri [The URI passed to ara::rest::Client::Subscribe denotes an entity to subscribe to. URI query parameters shall be taken into account.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01416] Client Event Policy \[An implementation shall honor the event policy passed to according to [SWS_REST_01307] along with the time bound specified. \[(RS \ CM \ 00300, RS \ CM \ 00301) \]

[SWS_REST_01417] Client Event Notification \lceil An instance of ara::rest::Client::NotificationHandlerType shall be passed to ara::rest::Client::Subscribe for the asynchronous reception of event notification. $|(RS_CM_00300, RS_CM_00301)|$

[SWS_REST_01418] Client Event Status [An instance of ara::rest::Client::SubscriptionStateHandlerType may be passed to ara::rest::Client::Subscribe for the asynchronous changes to the event status. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01419] Client Exception $\lceil ara::rest::Client$ itself may throw during construction and during regular operation only for errors that leave the client in an undefined state. $|(RS_CM_00300, RS_CM_00301)|$

[SWS_REST_01420] Client Error [All errors not leaving a client in an undefined state shall be indicated via ara::rest::Client::GetError and ara::rest::Client::ObserveError. In particular this concerns all I/O related errors. The type ara::core::ErrorCode shall be used for error codes.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01421] Client Request [ara::rest::Request shall be non-copyable and shall maintain all resources related to issue a data request to a peer. In particular, the lifetime of a request object and the lifetime of the objects passed to it for



transmission shall be independent. This implies copying or moving. $\[\] (RS_CM_00300, RS_CM_00301) \]$

[SWS_REST_01422] Client Reply [ara::rest::Reply shall be non-copyable and shall maintain all resources related to reception of data from a peer. The lifetime of all resources referenced by a reply object is bound to the lifetime of the reply itself. This implies copying or moving. |(RS_CM_00300, RS_CM_00301)

7.7 Server

ara::rest requires the existence of a type ara::rest::Server which represents the server network endpoint for RESTful communication along with its components.

[SWS_REST_01501] Server Resources [ara::rest::Server maintains all resources related to communication with a peer. Upon destruction, all such resources shall be released. |(RS CM 00300, RS CM 00301)

[SWS_REST_01502] Server Interface [An ara::rest::Server shall at least provide the interface as specified in the API specification and according to the detailed semantics specified there. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01503] Server Instances [ara::rest::Server shall not be copyable. It shall be movable. | (RS CM 00300, RS CM 00301)

[SWS_REST_01504] Server Multibinding [ara::rest::Server] shall be able to handle multiple transport protocol bindings concurrently. $](RS_CM_00300, RS_CM_00301)$

[SWS_REST_01505] Server Multiplicity [ara::rest::Server shall be able to handle multiple peers concurrently over potentially multiple transport protocols.] (RS CM 00300, RS CM 00301)

[SWS_REST_01506] Server Asynchronicity $\lceil ara::rest::Server$ shall be able to operate according to its semantic requirements without employing multi-threading. Consequently, a user shall be aware of the fact that invoking blocking functions such as ara::rest::Task<T>::wait() may degrade service quality. \rfloor (RS_CM_00300, RS_CM_00301)

[SWS_REST_01507] Server Concurrency [It is implementation-defined whether ara::rest::Server is operating concurrently. Consequently, an application developer shall be aware of the fact that invoking blocking functions may degrade service quality. | (RS CM 00300, RS CM 00301)

[SWS_REST_01508] Server Construction [ara::rest::Server shall be provided with a unique identifier that selects an implementation-defined configuration record. | (RS CM 00300, RS CM 00301)



[SWS_REST_01509] Server Startup [ara::rest::Server shall not be operational until ara::rest::Server::Start is invoked explicitly.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01510] Server Startup Policies \[\text{To facilitate a well-defined startup of a server endpoint, an implementation shall provide an enumeration \[\ara::rest::StartupPolicy \] which shall provide the following general semantics:

- StartupPolicy::kDetached: the server endpoint shall not block its calling context during startup and regular operation.
- StartupPolicy::kAttached: the server endpoint shall block its calling context during startup and regular operation as long as it is explicitly shut down.

(RS CM 00300, RS CM 00301)

[SWS_REST_01511] Server Startup Task [ara::rest::Server::Start returns a Task which shall only complete once startup succeeded. It may throw otherwise.] (RS_CM_00300, RS_CM_00301)

[SWS_REST_01512] Server Shutdown \[ara::rest::Server shall be stopped via ara::rest::Server::Stop according to the semantics specified in its API specification and [SWS_REST_01308]. \[(RS_CM_00300, RS_CM_00301) \]

[SWS_REST_01513] Server Restart [ara::rest::Server shall leave its instances in a well-defined state after shutdown such that a subsequent startup remains feasible. | (RS CM 00300, RS CM 00301)

[SWS_REST_01514] Server Stop \lceil ara::rest::Server::Stop shall be thread-safe. After it has been invoked, no new requests shall be accepted. \rfloor (RS_CM_00300, RS_CM_00301)

[SWS_REST_01515] Server Stop Task [ara::rest::Server::Stop returns a Task which shall only complete once shutdown succeeded. It may throw otherwise.] (RS CM 00300, RS CM 00301)

[SWS_REST_01516] Server User Message Notification \lceil ara::rest::Server shall invoke the user-defined handler function specified in its destructor at least as early as a valid message header has been received. It is implementation-defined whether the handler is activated only when the entire message has been received. $\rfloor (RS_CM_00300, RS_CM_00301)$

[SWS_REST_01517] Server Event Subscriptions [ara::rest::Server shall accept event subscriptions without user-intervention. It shall inform the application of new subscriptions or subscription state changes via ara::rest::Server::ObserveSubscriptions.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01518] Server Event Data Request [Depending on the subscription parameters, event notifications shall be issued at certain points in time. ara::rest::Server shall issue a regular GET request to the application for the URI and the respective query parameters as supplied by the subscriber. To the application



such a request shall be indistinguishhable from regular requests. $\[\] (RS_CM_00300, RS_CM_00301) \]$

[SWS_REST_01519] Server Event Object [Each subscription shall be represented by a unique ara::rest::ServerEvent object which shall maintain all resources related to this subscription. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01522] Server Event Object Destruction [Upon destruction of a ara::rest::ServerEvent object the corresponding event subscription shall be terminated instantly, unilaterally and all managed server-side resources shall be released. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01523] Server Event Object Subscription Cancellation [ara::rest::ServerEvent::SetSubscriptionState called with parameter ara::rest::SubscriptionState::kCanceled shall cancel the subscription in accordance to the rules of the underlying protocols implementing the event mechanism. |(RS_CM_00300, RS_CM_00301)

[SWS_REST_01525] Server Event Object Notify | ara::rest::ServerEvent::Notify shall notify its corresponding ara::rest::Server instance of potential updates. The notifications are only triggered for URIs with an active subscription. \(\) (RS_CM_00300, RS_CM_00301)

[SWS_REST_01526] Server Event Object Notify Semantics [Following a call to ara::rest::ServerEvent::Notify, it is the responsibility of ara::rest::Server to decide whether an actual event notification message shall be transmitted to the subscriber. The actual data that should be transmitted can either be received in the ara::rest::ServerEvent::Notify call, or obtained from the related URI. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01527] Server Event Observation [ara::rest::Server::ObserveSubscriptions shall be used by an application to register user-defined handler functions to be called on new subscriptions and state changed to existing subscriptions.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01528] Server **Event** Creation An instance of ara::rest::Server::SubscriptionHandlerType that is registered via ara::rest::Server::ObserveSubscriptions called is ara::rest::Server for each newly accepted subscription. It is the responsibility of the server object to create an instance of ara::rest::ServerEvent and pass it to the user via the handler function. | (RS CM 00300, RS CM 00301)

[SWS_REST_01529] Server Event Status Changes [An instance of ara::rest::Server::SubscriptionStateHandlerType that is regis-



tered via ara::rest::Server::ObserveSubscriptions is called by ara::rest::Server for each detected state change of a subscription according to ara::rest::SubscriptionState. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01530] Server Exception [ara::rest::Server itself may throw during construction and during regular operation only for errors that leave the server in an undefined state.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01531] Server Error [All errors not leaving a server in an undefined state shall be indicated via ara::rest::Server::GetError and ara::rest::Server::ObserveError. In particular this concerns all I/O related errors. The type ara::core::ErrorCode shall be used for error codes.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01532] Server Requests and Responses | ara::rest::ServerRequest and ara::rest::ServerReply shall be instantiated by ara::rest::Server for each received request message. Both objects shall manage all resource related to the current transaction. An application shall neither construct or destroy these objects. | (RS_CM_00300, RS_CM_00301)

[SWS_REST_01533] Server Request Semantics A reference of ara::rest::ServerRequest shall be passed to the user-defined handler function as soon as a valid message header has been accepted. Access to message payloads shall be asynchronous via ara::rest::ServerRequest::GetObject or ara::rest::ServerRequest::ReleaseObject respectively.](RS_CM_00300, RS_CM_00301)

[SWS_REST_01534] Server Reply Semantics [A reference of ara::rest::ServerReply may be passed to the user-defined handler function along with a reference to its corresponding ara::rest::ServerRequest. The instance shall be initialized such that it represents an empty reply message.] (RS_CM_00300, RS_CM_00301)

[SWS_REST_01535] Server Reply Send Semantics [ara::rest::ServerReply::Send shall trigger the transmission of a message to sender of the respective request. Upon destruction a ara::rest::ServerReply shall call Send implicitly. | (RS CM 00300, RS CM 00301)

[SWS_REST_01536] Server Reply Multiple Send Semantics ara::rest::ServerReply::Send shall not be called multiple times.

(RS_CM_00300, RS_CM_00301)

[SWS_REST_01537] Server Reply Redirect Semantics | ara::rest::ServerReply::Redirect shall issue a protocol-dependent client redirection which shall cause a client to repeat the request to the endpoint indicated via ara::rest::ReplyHeader::SetUri. | (RS CM 00300, RS CM 00301)

[SWS_REST_01538] Server Reply Send/Redirect Interaction

[ara::rest::ServerReply::Send shall not be called after



ara::rest::ServerReply::Redirect, and vice versa.](RS_CM_00300, RS_CM_00301)

7.8 Routing

Routing is multiplexing of server requests depending on the valuation of ara::rest::RequestMethod and ara::rest::Uri. It connects RESTful API accesses with an underlying execution or data model. In the following the components for routing are specified bottom-up.

7.8.1 Patterns

[SWS_REST_01601] Pattern API \[\] An implementation shall provide a type \[\ara::rest::Pattern \] that satisfies at least the interface and basic semantics as defined in the API specification below. \[\left(RS_CM_00300) \]

[SWS_REST_01602] Pattern Syntax [ara::rest::Pattern represents a pattern string to match against ara::rest::Uri::Path instances. A pattern string may be composed of all valid URI path characters as well as characters "*" and "**" (wildcards). | (RS CM 00300)

[SWS_REST_01603] Pattern General Wildcard semantics [Wildcards shall match URI path segments, not general string characters in an URI. In other words, URI path segment delimiters "/" restrict matching. | (RS CM 00300)

Example: Pattern /foo/*/bar shall match URI path /foo/baz/bar. It shall not match URI path /foo/baz/bab/baz nor /foo/bar. | (RS CM 00300)

[SWS_REST_01605] Pattern Double Wildcard semantics [Wildcard characters "**" shall match any number of path segments (including none).

Example: Pattern /foo/** shall match URI path /foo, /foo/baz and /foo/baz/bar. It shall not match URI paths that do not begin with /foo. $|RS_CM_00300|$

[SWS_REST_01606] Pattern Comparability [ara::rest::Pattern shall be equal-to, unequal-to and less-than comparable. | (RS CM 00300)

[SWS_REST_01607] Pattern Order Criterion [ara::rest::Pattern shall be less-than comparable and form a lexicographic order is which URI path segments are considered "characters" in left-to-right order.

Example: It holds that "car" < "car/window" which means "car" before "/car/window". For wildcards the order "**" < "*" < "anything else" holds. |(RS CM 00300)



7.8.2 Match

[SWS_REST_01608] Match API Γ An implementation shall provide a type ara::rest::Match that satisfies at least the interface and basic semantics as defined in the API specification below. Γ

[SWS_REST_01609] Match Creation [When matching URIs against patterns, then for every path segment matched against either single wildcard "*" or double wildcard "**" an instance of ara::rest::Match shall be created. | (RS CM 00300)

[SWS_REST_01610] Match Access As String [ara::rest::Match::Get shall return a view of the matched URI segment. | (RS_CM_00300)

[SWS_REST_01611] Match Access As Type [ara::rest::Match::GetAs shall convert the match into type T specified by the template parameter. Type T shall be InputStreamable: there shall exist a global function std::istream& operator»(std::istream&, const T&) that performs lexical conversion. If conversion fails, GetAs() shall throw std::invalid_argument. Function overload GetAs(T&&) shall perform the same conversion but instead of throwing it returns the function argument if conversion fails. |(RS CM 00300)

7.8.3 Matches

[SWS_REST_01612] Matches API An implementation shall provide a type ara::rest::Matches that satisfies at least the interface and basic semantics as defined in the API specification below. | (RS_CM_00300)

[SWS_REST_01613] Matches Creation \[\] When matching URIs against patterns, then a ara::rest::Matches instance shall be created that shall contain all ara::rest::Match objects created. Matches shall own the Match instances and release them upon destruction. \[\] (RS_CM_00300)

[SWS_REST_01614] Matches of General Path Segments [Matches shall not represent non-wildcard path segments. | (RS_CM_00300)

7.8.4 Route

[SWS_REST_01615] Route API $\[\]$ An implementation shall provide a type ara::rest::Route that satisfies at least the interface and basic semantics as defined in the API specification below. $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$ $\[\]$

[SWS_REST_01616] Route Semantics [ara::rest::Route shall call the user-defined function of type ara::rest::Route::RouteHandlerType provided as a constructor argument if ara::rest::RequestMethod and ara::rest::Pattern provided as constructor arguments match the request method and URI of the ara::rest::ServerRequest passed to ara::rest::Route::operator().] (RS_CM_00300, RS_CM_00310)



[SWS_REST_01617] Route Match [If a route matches, the ara::rest::Route::RouteHandlerType specified via its constructor shall be called along with the respective request and reply objects, and a set of ara::rest::Matches that represent wildcard matches of the request URI.] (RS_CM_00300, RS_CM_00310)

[SWS_REST_01618] Route Return Values [ara::rest::Route::operator() returns values of type ara::rest::Route::Upshot. The respective return values shall have the following effect on the routing described later:

- ara::rest::Route::Upshot::kAccept: ara::rest::Router shall not search for further matches.
- ara::rest::Route::Upshot::kYield: ara::rest::Router shall select the next matching route (multiple routes may match) or the default handler function in case of no next matching route.
- ara::rest::Route::Upshot::kDefault: ara::rest::Router shall execute its default handler function (specified below).

(RS_CM_00300, RS_CM_00310)

[SWS_REST_01619] Route Comparability [ara::rest::Route shall be equal-to, unequal-to and less-than comparable. | (RS CM 00300)

[SWS_REST_01620] Route Order Criterion [Routes shall compare less-than in lexicographic order such that the given ara::rest::Uri::Path compare first, the given ara::rest::RequestMethod compare last. | (RS_CM_00300)

[SWS_REST_01621] Route Order Criterion for RequestMethod \lceil While ara::rest::Uri is ordered lexicographically, ara::rest::RequestMethod shall be less-than comparable for route matching according to the following rule: The order of request methods is lexicographic with each enumerator representing a character of a string concatenated by operator \mid . Therefore, for single "digits" it holds that $kGET < kPOST < \ldots$ etc according to their underlying numeric values. For multiple "digits" it holds that - for example - $kGET < kGET \mid kPOST < kGET \mid kPUT < \ldots < kAny$. But note that $kGET \mid kPUT == kPUT \mid kGET$. In words, the most precise specifiers (singleton request methods) have precedence over the less precise specificiation of sets of enumerators. This is not the same as simply taking the underlying numeric value of the OR-combined enumerators. \mid (RS_CM_00300)

7.8.5 Router

[SWS_REST_01622] Router API \[\] An implementation shall provide a type ara::rest::Router that satisfies at least the interface and basic semantics as defined in the API specification below. \[\((RS \) CM \) 00300 \((RS \) CM \]

[SWS_REST_01623] Router Semantics [ara::rest::Router shall maintain an ordered set of routes and it shall find a matching route by comparing the request



method and URI components of a given ara::rest::ServerRequest against each given ara::rest::Route in the set. | (RS_CM_00300)

[SWS_REST_01624] Router Usage [A router is a pre-defined request handler type which may be passed to the constructor of ara::rest::Server in order to demultiplex messaging. | (RS_CM_00300, RS_CM_00310)

[SWS_REST_01625] Router Route Order \lceil Routes shall be matched according to their order criterion as defined above from "smallest" to "greatest". Incomparable routes shall be matched in the order of insertion into a router. $\rfloor (RS_CM_00300)$

[SWS_REST_01626] Router Route Match [If a route matches, its ara::rest::Route::operator() shall be called.] (RS_CM_00300)

[SWS_REST_01628] Router Default Route [If no route matches, the request handler function specified via ara::rest::Router::SetDefaultHandler shall be called, if it has been set. If no such handler is set, the router shall silently ignore the request currently under inspection. $|(RS_CM_00300)|$

7.9 Object Graph Model

ara::rest message payloads are always represented as object graph data-structures (object graph models; OGM). OGM serve as a universal exchange format.

[SWS_REST_01701] OGM Representation [All transport-specific message payloads shall be converted to and from OGM for communication and interaction with a service application. | (RS_CM_00300)

[SWS_REST_01702] OGM **Syntax** An implementation shall provide a basic set of data types whose interfaces shall at least satisfy interfaces and basic functionalities according to their API specificaara::rest::ogm::Node, tions provided ara::rest::oqm::Field, by ara::rest::oqm::Value, ara::rest::ogm::String, ara::rest::ogm::Int, ara::rest::ogm::Real, ara::rest::ogm::Array and ara::rest::ogm::Object. | (RS CM 00300, RS CM 00305)



[SWS_REST_01703] OGM Semantics: Internal Ownership [OGM instances are always trees. Each parent node shall uniquely own its children.](RS_CM_00300, RS_CM_00305)

[SWS_REST_01704] OGM Semantics: External Ownership [Ownership of an OGM shall never be shared within an application. The lifetime of an OGM shall strictly be bound to the lifetime of the Pointer instance owning an OGM after construction.] (RS_CM_00300, RS_CM_00305)

[SWS_REST_01705] OGM Construction Semantics \lceil OGM node constructors are non-public. To construct OGM nodes their respective static Make() member functions shall be used which return a Pointer instance that own the OGM just created. Only leaf-types in the type hierarchy may be instantiated. |(RS CM 00300, RS CM 00305)|

[SWS_REST_01706] OGM Destruction Semantics [If an owner (a parent node or a Pointer holding a reference to an OGM) is destroyed, all owned objects shall be destroyed too. | (RS CM 00300, RS CM 00305)

[SWS_REST_01707] OGM Copy Semantics [An OGM cannot be copied directly or implicitly. To copy an OGM ara::rest::ogm::Copy shall be used.] (RS CM 00300, RS CM 00305)

[SWS_REST_01708] OGM Move Semantics For Owners [To move an OGM, its owning Pointer instance shall be moved. | (RS_CM_00300, RS_CM_00305)

[SWS_REST_01709] OGM Move Semantics For Non-owners: Release [To obtain ownership of subtrees, member functions with prefix "Release" shall be called on the owning OGM node. Only node types that represent sets (ara::rest::ogm::Array and ara::rest::ogm::Object) may be empty and therefore have a "Release" functionality. | (RS CM 00300, RS CM 00305)

[SWS_REST_01710] OGM Move Semantics For Non-owners: Replace \lceil For consistency, some node types have "Replace" functions instead of "Release". To take on ownership of a sub-tree, it shall be replaced by a suitable replacement object. $\lceil RS_CM_00300, RS_CM_00305 \rceil$

[SWS_REST_01711] OGM Iterator Semantics \[Some OGM node types are iterable. Iterators shall not expose any internal data management. The respective iterator types shall provide C++ references directly to the referenced set elements \((RS_CM_00300, RS_CM_00305) \)

[SWS_REST_01712] OGM String encoding [ara::rest::ogm::String shall support UTF-8. | (RS CM 00300, RS CM 00305)

[SWS_REST_01713] OGM Int precision [ara::rest::ogm::Int is signed and shall be at least as precise as a C++ std::int64_t integer type.](RS_CM_00300, RS_CM_00305)

[SWS_REST_01714] OGM Real precision \lceil ara::rest::ogm::Real shall be at least as precise as a C++ double floating point type. \rfloor (RS_CM_00300, RS_CM_00305)



[SWS_REST_02423] OGM Thread safety [Setting and getting values of OGM nodes shall be thread safe. | (RS CM 00300, RS CM 00305)

[SWS_REST_01715] OGM Visit [ara::rest::ogm::Visit implements the visit pattern and shall expose the actual type of an OGM node from a reference to any of its parents in the OGM node type hierarchy. | (RS_CM_00300, RS_CM_00305)

[SWS_REST_02415] OGM VisitAll | ara::rest::ogm::VisitAll implements the recursive visit pattern and shall expose the actual types of OGM nodes from a reference traversing all values of the given node. | (RS_CM_00300, RS_CM_00305)

[SWS_REST_02417] OGM Cast $[ara::rest::ogm::Cast implements functionality for casting ara::rest::ogm::Node objects to concrete OGM node types.] (RS_CM_00300, RS_CM_00305)$

7.10 Network binding

The following chapters describe the requirements according to specific bus protocol bindings and the serialization. In the current version, only HTTP/1.1 [8] with JSON [9] payload is supported.

7.10.1 Transport protocol

[SWS_REST_01801] Transport protocol [An implementation shall implement HTTP/1.1 [8] to transport the payload over the network. | (RS CM 00312)

[SWS_REST_01802] Mapping of ara::rest::RequestMethod kGet \lceil ara::rest::RequestS with the ara::rest::RequestMethod kGet shall be transported over the HTTP/1.1 GET method. $\lceil (RS_CM_00312) \rceil$

[SWS_REST_01803] Mapping of ara::rest::RequestMethod kPost | ara::rest::RequestS with the ara::rest::RequestMethod kPost shall be transported over the HTTP/1.1 POST method. | (RS CM 00312)

[SWS_REST_01804] Mapping of ara::rest::RequestMethod kPut | ara::rest::RequestS with the ara::rest::RequestMethod kPut shall be transported over the HTTP/1.1 PUT method. | (RS_CM_00312)

[SWS_REST_01805] Mapping of ara::rest::RequestMethod kHead \lceil ara::rest::RequestS with the ara::rest::RequestMethod kHead shall be transported over the HTTP/1.1 HEAD method. $|(RS_CM_00312)|$



[SWS_REST_01806] Mapping of ara::rest::RequestMethod kDelete [ara::rest::Requests with the ara::rest::RequestMethod kDelete shall be transported over the HTTP/1.1 DELETE method. | (RS CM 00312)

[SWS_REST_01807] Mapping of ara::rest::RequestMethod kOptions [ara::rest::RequestS with the ara::rest::RequestMethod kOptions shall be transported over the HTTP/1.1 OPTIONS method.] (RS_CM_00312)

[SWS_REST_01810] Websocket handling \[\text{Websocket} \text{ channel shall be opened during the first } \ara::rest::Event \text{ subscription.} \] Websocket \text{ channel shall be kept open until all } \ara::rest::Events \text{ and } \ara::rest::ServerEvents \text{ on the channel have been canceled or invalidated.} \] There \text{ shall be one Websocket channel between } \ara::rest::Client \text{ and } \ara::rest::Server \text{ for all events.} \] In \text{ case the channel is closed without canceling all the events they shall be immediately invalidated by changing the event subscription states to \ara::rest::SubscriptionState::kInvalid.} \[\((RS_CM_00314) \) \]

[SWS_REST_01811] Event subscription message | ara::rest::Event subscription message shall be sent as JSON over Websocket channel. Subscription message shall always be sent by the ara::rest::Client::Subscribe API call. After successful response to the subscription message on the Client side, the event subscription state shall be changed to ara::rest::SubscriptionState::kSubscribed. Subscription message shall be in the following format:

(RS_CM_00314)

[SWS REST 01812] Event cancellation message Event can-JSON cellation message shall Websocket be sent as over channel when either ara::rest::Event::Unsubscribe ara::rest::ServerEvent::SetSubscriptionState ara::rest::SubscriptionState::kCanceled is called. No other payload is allowed on the channel before or after the response to the cancellation message. After successful response to the cancellation message on the Client side, the event subscription state shall be changed to ara::rest::SubscriptionState::kCanceled. Cancellation message shall be in the following format:

```
1 {
2    "type": "unsubscribe", // Message type as string
3    "event": <entity_uri> // Entity_URI to subscribe as string
```



```
4 }
5
```

(RS CM 00314)

[SWS_REST_01813] Event state responses [Subscription and cancellation messages shall be responded as JSON over the Websocket channel. The type field shall be either "subscribe", "unsubscribe" or "resubscribe" depending on the responded ara::rest::ServerEvent::SetSubscriptionState. message set with The shall be sent immediately after call response ara::rest::ServerEvent::SetSubscriptionState. The response shall be in the following format:

(RS CM 00314)

[SWS_REST_01814] Event error message [Event error messages shall be transmitted as JSON over the Websocket channel. Errors shall lead to immediate invalidation of the ara::rest::Event and corresponding ara::rest::ServerEvent. Therefore the ara::rest::Server application shall call ara::rest::ServerEvent::SetSubscriptionState with parameter ara::rest::SubscriptionState::kInvalid. The event error message is issued by ara::rest::ServerEvent::SendError where the parameter error—Code matches to the JSON key "code" and errorMessage to "data". The error shall be sent immediately after call to the ara::rest::ServerEvent::SendError. The message shall be in the following format:

(RS_CM_00314)

[SWS REST 01815] Event data response Event notifications shall **JSON** by ara::rest::Server be transported as over the Websocket channel. Event notifications shall only sent if the subscription of the ara::rest::ServerEvent state is ara::rest::SubscriptionState::kSubscribed. The response shall be in the following format:



(RS CM 00314)

[SWS_REST_01816] Compression support [An implementation shall provide data compression support to improve transfer speed and network bandwidth utilization.] (RS CM 00312)

[SWS_REST_01817] Compression support DEFLATE \lceil An implementation shall provide data compression support with the DEFLATE algorithm according to [10] and as listed in HttpAcceptEncodingEnum. $|(RS_CM_00312)|$

[SWS_REST_01818] Compression support GZIP \lceil An implementation shall provide data compression support with the GZIP algorithm according to [11] and as listed in HttpAcceptEncodingEnum. \rceil (RS_CM_00312)

[SWS_REST_01819] Compression support \lceil Data compression shall be hidden from the application context. $|(RS_CM_00312)|$

[SWS_REST_01820] Compression support [The accepted data compression of a ara::rest::Client shall be as configured in acceptsEncoding of the RestHttpPortPrototypeMapping. | (RS CM 00312)

[SWS_REST_01833] Compression of small payloads [An implementation may skip compression of payloads which is smaller than 1400 bytes to optimize CPU usage.] (RS_CM_00312)

[SWS_REST_01834] Compression of small payloads [If there is a multi selection of HttpAcceptEncodingEnum, the GZIP algorithm shall be prefered from DEFLATE by the ara::rest::Server when responding to requests. | (RS CM 00312)

[SWS_REST_01821] Default host for ara::rest::Client [Host address given by host shall be used if no information is given by ara::rest::Uri::GetHost for a ara::rest::Request. | (RS_CM_00312)

[SWS_REST_01822] Default TCP port for ara::rest::Client | TCP port given by tcpPort shall be used if no information is given by ara::rest::Uri::GetPort for a ara::rest::Request. | (RS_CM_00312)

[SWS_REST_01823] IP address configuration for ara::rest::Server | ara::rest::Server | shall | bind | to | the | IP | address | given | by | the | Ipv4Configuration/Ipv6Configuration | attribute | of | the | NetworkEndpoint | that | is referenced | the | referenced | in role | networkEndpointAddress | by | host. | (RS_CM_00312)

[SWS_REST_01824] TCP port configuration for ara::rest::Server [The ara::rest::Server shall bind to the tcpPort of the RestHttpPortPrototypeMapping. | (RS_CM_00312)



[SWS_REST_01825] Accept content type HTTP field for binary data requests [ara::rest::Client and ara::rest::Server applications shall provide the requested MIME-Type in the HTTP accept header for binary data. | (RS_CM_00312)

[SWS_REST_01826] ara::rest::Client set accept content type of HTTP/1.1 GET requests for binary data [HTTP accept header shall be set with the function ara::rest::RequestHeader::SetField before sending the HTTP/1.1 GET request.](RS_CM_00312)

[SWS_REST_01827] ara::rest::Client get binary HTTP response data [The function ara::rest::Reply::ReleaseBinary shall be used to get the binary data of a ara::rest::Reply transmitted with HTTP. |(RS_CM_00312)

[SWS_REST_01828] ara::rest::Server set binary HTTP/1.1 GET response
payload [The function ara::rest::ServerReply::Send2 shall be used to provide the binary data content of the HTTP response. | (RS_CM_00312)

[SWS_REST_01829] ara::rest::Server set HTTP content type of response containing binary data [HTTP content type of the response shall be set with the function ara::rest::ReplyHeader::SetField before sending the response.] (RS_CM_00312)

[SWS_REST_01830] ara::rest::Client set content type type of HTTP/1.1 PUT and POST requests for sending binary data [HTTP content type header shall be set with the function ara::rest::RequestHeader::SetField before sending the HTTP/1.1 PUT or POST request.](RS_CM_00312)

[SWS_REST_01832] ara::rest::Server get binary payload for HTTP/1.1 PUT and POST requests [The function ara::rest::ServerRequest::ReleaseBinary shall be used to get the binary data content of the HTTP/1.1 PUT or POST request. | (RS_CM_00312)

7.10.2 Serialization of payload

On application level the ara::rest message payload is (with the exception of binary data) represented as object graph data-structures. This data representation needs to be serialized first before it can be transmitted. The necessary mapping of the object graph data-structures to the ara::rest message payload is specified in this chapter.

[SWS_REST_01851] Serialization format [An implementation shall serialize the ara::rest message payload with JSON [9]. | (RS CM 00313)

[SWS_REST_01852] Default HTTP content type \[An implementation shall set the HTTP content type header field to the MIME "application/json" as default for



ara::rest::RequestMethod kPost and kPut requests. Note that the application can still override the content type with ara::rest::ReplyHeader::SetField. | (RS_CM_00313, RS_CM_00312)

[SWS_REST_01859] Default HTTP accept type [An implementation shall set the HTTP accept header field to the MIME "application/json" as default for ara::rest::RequestMethod kGet request. Note that the application can still override the accept header field with ara::rest::RequestHeader::SetField. | (RS CM 00313, RS_CM_00312)

[SWS_REST_01856] Serialization of ara::rest::ogm::Int [The ara::rest::ogm::Int shall be serialized as a JSON integer value. (RS_CM_00313)

[SWS_REST_01858] Serialization of ara::rest::ogm::String [The ara::rest::ogm::String shall be serialized as a JSON string. | (RS CM 00313)

[SWS_REST_01899] Serialization of other MIME-types [Serialization of other MIME-types then "application/json" (e.g. binary data) is implementation-defined.] (RS CM 00313)



8 API specification

This chapter contains the formal API documentation of ara::rest.

8.1 ara::rest::Allocator

[SWS_REST_02000] [ara::rest::Allocator class shall be declared in the ara/rest/allocator.h header file:

class ara::rest::Allocator;

(RS CM 00300)

8.1.1 Allocator

Service name:	ara::rest::Allocator::Allocator	
Type:	Member function	
Syntax:	ara::rest::Allocator::Allocator()=default	
Function param:	None	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/allocator.h	
Class:	ara::rest::Allocator	
Description:	Constructs this object.	

Table 8.1: ara::rest::Allocator::Allocator

[SWS_REST_02001] ara::rest::Allocator::Allocator | Table 8.1 describes the interface ara::rest::Allocator::Allocator.|(RS_CM_00300)

8.1.2 ~Allocator

Service name:	ara::rest::Allocator::~Allocator	
Type:	Member function	
Syntax:	<pre>virtual ara::rest::Allocator::~Allocator()</pre>	
Function param:	None	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/allocator.h	
Class:	ara::rest::Allocator	
Description:	Destroys this object.	

Table 8.2: ara::rest::Allocator::~Allocator

- AUTOSAR CONFIDENTIAL -



[SWS_REST_02002] ara::rest::Allocator::~Allocator [Table 8.2 describes the interface ara::rest::Allocator::~Allocator.] (RS_CM_00300)

8.1.3 allocate

Service name:	ara::rest::Allocator::allocate		
Type:	Member function		
Syntax:	<pre>void* ara::rest::Allocator::allocate(std::size_t</pre>		
	bytes, std::size_t		
	alignment=alignof(std::max_align_t))		
Function param:	bytes	desired size of the memory area to be allocated	
Function param:	alignment	alignment of the memory area	
Return value:	a pointer to the allocated memory area		
Exceptions:	Implementation-defined		
Header file:	ara/rest/allocator.h		
Class:	ara::rest::Allocator		
Description:	Allocates a memory a	Allocates a memory area.	

Table 8.3: ara::rest::Allocator::allocate

[SWS_REST_02003] ara::rest::Allocator::allocate [Table 8.3 describes the interface ara::rest::Allocator::allocate.|(RS_CM_00300)

8.1.4 deallocate

Service name:	ara::rest::Allocator::deallocate		
Type:	Member function	Member function	
Syntax:	void ara::rest::	Allocator::deallocate(void *p,	
	std::size_t byte	s, std::size_t	
	alignment=alignof(std::max_align_t))		
Function param:	р	pointer to the allocated memory area	
Function param:	bytes	size of the allocated memory area	
Function param:	alignment	alignment of allocated memory area	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/allocator.h		
Class:	ara::rest::Allocator		
Description:	Releases a memory area.		

Table 8.4: ara::rest::Allocator::deallocate

[SWS_REST_02004] ara::rest::Allocator::deallocate [Table 8.4 describes the interface ara::rest::Allocator::deallocate.] (RS_CM_00300)

8.1.5 is equal



Service name:	ara::rest::Allocator::is_equal			
Type:	Member function	Member function		
Syntax:	bool ara::rest::	bool ara::rest::Allocator::is_equal(const Allocator		
	&alloc) const			
Function param:	alloc	an allocator to compare against		
Return value:	true if the two allocators compare equal			
Exceptions:	noexcept			
Header file:	ara/rest/allocator.h			
Class:	ara::rest::Allocator			
Description:	Tests whether two allo	Tests whether two allocators are equal. Allocators are equal if memory		
	allocated by one can be deallocated by the other.			

Table 8.5: ara::rest::Allocator::is_equal

[SWS_REST_02005] ara::rest::Allocator::is_equal [Table 8.5 describes the interface ara::rest::Allocator::is_equal.|(RS_CM_00300)

8.2 ara::rest::Client

[SWS_REST_02006] [ara::rest::Client class shall be declared in the ara/rest/client.h header file:

class ara::rest::Client;

(RS CM 00300, RS CM 00301)

8.2.1 NotificationHandlerType

Name:	NotificationHandlerType	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::Client::NotificationHandlerType =</pre>	
	<pre>void(const ogm::Object&)</pre>	
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	Denotes a callback function for notifications.	

Table 8.6: ara::rest::Client::NotificationHandlerType

[SWS_REST_02007] NotificationHandlerType [Table 8.6 describes the type alias ara::rest::Client::NotificationHandlerType.](RS_CM_00300, RS_CM_00301)

8.2.2 SubscriptionStateHandlerType

Name:	SubscriptionStateHandlerType



Туре:	Member type alias	
Syntax:	<pre>using ara::rest::Client::SubscriptionStateHandlerType =</pre>	
	void(const Event&, SubscriptionState)	
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	Denotes a callback to call if subscription status changes.	

Table 8.7: ara::rest::Client::SubscriptionStateHandlerType

[SWS_REST_02008] SubscriptionStateHandlerType | Table 8.7 describes the type alias ara::rest::Client::SubscriptionStateHandlerType.] (RS_CM_00300, RS_CM_00301)

8.2.3 **Client**

Service name:	ara::rest::Client::Client	
Type:	Member function	
Syntax:	ara::rest::Clien	t::Client(const
	ara::rest::Insta	nceIdentifier &inst_id, Allocator
	*alloc=GetDefaultAllocator())	
Function param:	inst_id	ara::rest::InstanceIdentifier identifies
		concrete service instace
Function param:	alloc	allocator for dynamic memory
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	Constructs a client.	

Table 8.8: ara::rest::Client::Client

[SWS_REST_02009] ara::rest::Client::Client [Table 8.8 describes the interface ara::rest::Client::Client.|(RS_CM_00300, RS_CM_00301)

8.2.4 Client

Service name:	ara::rest::Client::Client
Type:	Member function
Syntax:	ara::rest::Client::Client(const Client &) = delete
Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/client.h
Class:	ara::rest::Client
Description:	non-copy-constructible

Table 8.9: ara::rest::Client::Client



[SWS_REST_02010] ara::rest::Client::Client | Table 8.9 describes the interface ara::rest::Client::Client.] (RS_CM_00300, RS_CM_00301)

8.2.5 operator=

Service name:	ara::rest::Client::operator=	
Type:	Member function	
Syntax:	Client& ara::rest::Client::operator=(const Client	
	&)=delete	
Return value:	a value of type Client &	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	non-copy-assignable	

Table 8.10: ara::rest::Client::operator=

[SWS_REST_02011] ara::rest::Client::operator= [Table 8.10 describes the interface ara::rest::Client::operator=.|(RS_CM_00300, RS_CM_00301)

8.2.6 Stop

Service name:	ara::rest::Client::Stop	
Type:	Member function	
Syntax:	Task <void> ara::rest::Client::Stop(ShutdownPolicy</void>	
	policy=ShutdownP	olicy::kGraceful)
Function param:	policy	shutdown policy
Return value:	a task waiting for shutdown to complete	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	Requests a client shutdown. If shutting down gracefully, the client waits	
	for all transactions to finish. If not, then all connections must be termi-	
	nated instantly.	

Table 8.11: ara::rest::Client::Stop

[SWS_REST_02012] ara::rest::Client::Stop [Table 8.11 describes the interface ara::rest::Client::Stop.|(RS_CM_00300, RS_CM_00301)

8.2.7 Send

Service name:	ara::rest::Client::Send
Type:	Member function
Syntax:	Task <pointer<reply> > ara::rest::Client::Send(const</pointer<reply>
	Request &req)



Function param:	req	a request message
Return value:	a task waiting for the	corresponding reply
Exceptions:	Implementation-define	ed
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	in the client configurate ration record is identif	peer. Issues a request to the peer either specified tion record or the URI of the request. The configuive by the id specified in the Client constructor. If overwrites the configuration record.

Table 8.12: ara::rest::Client::Send

[SWS_REST_02013] ara::rest::Client::Send [Table 8.12 describes the interface ara::rest::Client::Send.|(RS_CM_00300, RS_CM_00301)

8.2.8 Subscribe

Service name:	ara::rest::Client::Subse	cribe	
Type:	Member function		
Syntax:	Task <event> ara:</event>	Task <event> ara::rest::Client::Subscribe(const Uri</event>	
	&uri, EventPolic	y policy, duration_t time, const	
	Function< Notific	cationHandlerType > ¬ify, const	
	Function< Subscr	iptionStateHandlerType > &state={})	
Function param:	uri	the event to subscribe to	
Function param:	policy	the notification policy	
Function param:	time	time bound as a parameter of the notification policy	
Function param:	notify	user-defined event notification handler function	
Function param:	state	user-define subscription state observer function	
Return value:	a task waiting for the E	Event construction and subscription Reply.	
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/client.h		
Class:	ara::rest::Client		
Description:	Performs an event su	Performs an event subscription. An event is uniquely identified by its	
	Uri. A subscription to an event means that if preconditions are met a		
	notification is issued whose message payload is identical to the result		
	set obtained by issuing	g a GET request on the Uri.	

Table 8.13: ara::rest::Client::Subscribe

[SWS_REST_02014] ara::rest::Client::Subscribe [Table 8.13 describes the interface ara::rest::Client::Subscribe.|(RS_CM_00300, RS_CM_00301)

8.2.9 GetError

Service name:	ara::rest::Client::GetError
Type:	Member function
Syntax:	ara::core::ErrorCode ara::rest::Client::GetError()
	const



Function param:	None
Return value:	status of the client
Exceptions:	noexcept
Header file:	ara/rest/client.h
Class:	ara::rest::Client
Description:	Obtain client status.

Table 8.14: ara::rest::Client::GetError

[SWS_REST_02015] ara::rest::Client::GetError [Table 8.14 describes the interface ara::rest::Client::GetError.|(RS CM 00300, RS CM 00301)

8.2.10 ObserveError

Service name:	ara::rest::Client::Obse	rveError
Type:	Member function	
Syntax:	<pre>void ara::rest::Client::ObserveError(const Function</pre>	
	<pre>void(ara::core::ErrorCode) > &hnd)</pre>	
Function param:	hnd	user-defined handler function to called on status
		changes
Return value:	None	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/client.h	
Class:	ara::rest::Client	
Description:	Observe status chang	es.

Table 8.15: ara::rest::Client::ObserveError

[SWS_REST_02016] ara::rest::Client::ObserveError [Table 8.15 describes the interface ara::rest::Client::ObserveError.|(RS_CM_00300, RS_CM_00301)

8.3 ara::rest::Event

[SWS_REST_02017] [ara::rest::Event class shall be declared in the ara/rest/client.h header file:

class ara::rest::Event;

(RS_CM_00300)

8.3.1 **Event**

Service name:	ara::rest::Event::Event
Type:	Member function
Syntax:	ara::rest::Event::Event(const Event &)=delete



Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/client.h
Class:	ara::rest::Event
Description:	Non-copyable.

Table 8.16: ara::rest::Event::Event

[SWS_REST_02018] ara::rest::Event::Event [Table 8.16 describes the interface ara::rest::Event::Event.](RS_CM_00300)

8.3.2 operator=

Service name:	ara::rest::Event::operator=
Type:	Member function
Syntax:	Event& ara::rest::Event::operator=(const Event
	&)=delete
Return value:	a value of type Event &
Exceptions:	Implementation-defined
Header file:	ara/rest/client.h
Class:	ara::rest::Event
Description:	Non-copy-assignable.

Table 8.17: ara::rest::Event::operator=

[SWS_REST_02019] ara::rest::Event::operator= [Table 8.17 describes the interface ara::rest::Event::operator=.|(RS_CM_00300)

8.3.3 Unsubscribe

Service name:	ara::rest::Event::Unsubscribe
Type:	Member function
Syntax:	Task <bool> ara::rest::Event::Unsubscribe()</bool>
Function param:	None
Return value:	a task waiting for cancellation which returns true on success.
Exceptions:	Implementation-defined
Header file:	ara/rest/client.h
Class:	ara::rest::Event
Description:	Cancels an event subscription by issuing a cancelation request. A subscription can also be terminated (but not canceled) by destroying the correspond Event object.

Table 8.18: ara::rest::Event::Unsubscribe

[SWS_REST_02020] ara::rest::Event::Unsubscribe | Table 8.18 describes the interface ara::rest::Event::Unsubscribe.|(RS_CM_00300)



8.3.4 Resubscribe

Service name:	ara::rest::Event::Resubscribe
Type:	Member function
Syntax:	Task <bool> ara::rest::Event::Resubscribe()</bool>
Function param:	None
Return value:	a task waiting for re-subscription to be finished which returns true on
	success
Exceptions:	Implementation-defined
Header file:	ara/rest/client.h
Class:	ara::rest::Event
Description:	Re-subscribes to an event. Resubscription to an already subscribed
	event is valid but has not user-visible effect.

Table 8.19: ara::rest::Event::Resubscribe

[SWS_REST_02021] ara::rest::Event::Resubscribe [Table 8.19 describes the interface ara::rest::Event::Resubscribe.|(RS_CM_00300)

8.3.5 GetUri

Service name:	ara::rest::Event::GetUri
Type:	Member function
Syntax:	const Uri& ara::rest::Event::GetUri() const
Function param:	None
Return value:	the Uri corresponding to this event subscription
Exceptions:	noexcept
Header file:	ara/rest/client.h
Class:	ara::rest::Event
Description:	Returns the event Uri.

Table 8.20: ara::rest::Event::GetUri

[SWS_REST_02022] ara::rest::Event::GetUri [Table 8.20 describes the interface ara::rest::Event::GetUri.|(RS_CM_00300, RS_CM_00304)

8.3.6 GetSubscriptionState

Service name:	ara::rest::Event::GetSubscriptionState	
Type:	Member function	
Syntax:	SubscriptionState	
	ara::rest::Event::GetSubscriptionState() const	
Function param:	None	
Return value:	the current subscription state as perceived by the client	
Exceptions:	noexcept	
Header file:	ara/rest/client.h	
Class:	ara::rest::Event	
Description:	Returns the current subscription state.	



Table 8.21: ara::rest::Event::GetSubscriptionState

[SWS_REST_02023] ara::rest::Event::GetSubscriptionState [Table 8.21 describes the interface ara::rest::Event::GetSubscriptionState.|(RS_CM_00300)

8.3.7 operator==

Service name:	ara::rest::Event::opera	tor==
Type:	Non-member function	
Syntax:	friend bool operator==(const Event &a, const Event	
	(d&	
Function param:	а	an event
Function param:	b	an event
Return value:	true if a and b are equ	al
Exceptions:	noexcept	
Header file:	ara/rest/client.h	
Namespace:	ara::rest::Event	
Description:	Tests events for equal	ity.

Table 8.22: ara::rest::Event::operator==

[SWS_REST_02024] ara::rest::Event::operator== [Table 8.22 describes the interface ara::rest::Event::operator==.|(RS_CM_00300)

8.3.8 operator!=

Service name:	ara::rest::Event::operator!=	
Type:	Non-member function	
Syntax:	friend bool operator!=(const Event &a, const Event	
	(d&	
Function param:	а	an event
Function param:	b	an event
Return value:	true if a and b are une	qual
Exceptions:	noexcept	
Header file:	ara/rest/client.h	
Namespace:	ara::rest::Event	
Description:	Tests events for inequ	ality.

Table 8.23: ara::rest::Event::operator!=

[SWS_REST_02025] ara::rest::Event::operator!= [Table 8.23 describes the interface ara::rest::Event::operator!=.](RS_CM_00300)



8.3.9 operator<

Service name:	ara::rest::Event::opera	itor<
Type:	Non-member function	
Syntax:	friend bool operator<(const Event &a, const Event &b)	
Function param:	а	an event
Function param:	b	an event
Return value:	true if a less-than b	
Exceptions:	noexcept	
Header file:	ara/rest/client.h	
Namespace:	ara::rest::Event	
Description:	Tests events for their partial order Order criterion is implementation-	
	defined.	

Table 8.24: ara::rest::Event::operator<

[SWS_REST_02026] ara::rest::Event::operator< [Table 8.24 describes the interface ara::rest::Event::operator<.|(RS_CM_00300)

8.4 ara::rest::IteratorRange

[SWS_REST_02382] [ara::rest::IteratorRange class shall be declared in the ara/rest/iterator.h header file:

```
template <typename IterT >
class ara::rest::IteratorRange;

(RS_CM_00300)
```

8.4.1 Iterator

Name:	Iterator
Type:	Member type alias
Syntax:	using ara::rest::IteratorRange< IterT >::Iterator = IterT
Header file:	ara/rest/iterator.h
Class:	ara::rest::IteratorRange
Description:	Type of the underlying pair of iterators.

Table 8.25: ara::rest::lteratorRange::lterator

[SWS_REST_02383] Iterator [Table 8.25 describes the type alias ara::rest::IteratorRange::Iterator.|(RS CM 00300)

8.4.2 IteratorRange

Service name:	ara::rest::IteratorRange::IteratorRange
---------------	---



Type:	Member function	
Syntax:	ara::rest::Itera	torRange< IterT
	>::IteratorRange	(Iterator first, Iterator last)
Function param:	first	an iterator denoting the start of the sequence
Function param:	last	an iterator denoting the end of the sequence
Return value:	None	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/iterator.h	
Class:	ara::rest::IteratorRang	
Description:	Constructs an Iterator struction, see Makelte	Range from a pair of iterators. For convenient conratorRange().

Table 8.26: ara::rest::IteratorRange::IteratorRange

[SWS_REST_02384] ara::rest::IteratorRange::IteratorRange [Table 8.26 describes the interface ara::rest::IteratorRange::IteratorRange.] (RS_CM_00300)

8.4.3 begin

Service name:	ara::rest::IteratorRange::begin
Type:	Member function
Syntax:	<pre>Iterator ara::rest::IteratorRange< IterT >::begin()</pre>
	const
Function param:	None
Return value:	an iterator
Exceptions:	Implementation-defined
Header file:	ara/rest/iterator.h
Class:	ara::rest::IteratorRange
Description:	Returns the start of the sequence.

Table 8.27: ara::rest::lteratorRange::begin

[SWS_REST_02385] ara::rest::IteratorRange::begin [Table 8.27 describes the interface ara::rest::IteratorRange::begin.|(RS CM 00300)

8.4.4 end

Service name:	ara::rest::IteratorRange::end
Type:	Member function
Syntax:	<pre>Iterator ara::rest::IteratorRange< IterT >::end()</pre>
	const
Function param:	None
Return value:	an iterator
Exceptions:	Implementation-defined
Header file:	ara/rest/iterator.h
Class:	ara::rest::IteratorRange
Description:	Returns the end of the sequence.

Table 8.28: ara::rest::lteratorRange::end



[SWS_REST_02386] ara::rest::IteratorRange::end [Table 8.28 describes the interface ara::rest::IteratorRange::end.] (RS_CM_00300)

8.4.5 begin

Service name:	ara::rest::IteratorRang	e::begin
Type:	Non-member funct	ion
Syntax:	friend Iterator	begin(const IteratorRange &r)
Function param:	r	an InteratorRange
Return value:	the start of the sequer	nce
Exceptions:	Implementation-define	ed
Header file:	ara/rest/iterator.h	
Namespace:	ara::rest::IteratorRang	е
Description:	Non-member equivale	ent of IteratorRange::begin()

Table 8.29: ara::rest::lteratorRange::begin

[SWS_REST_02387] ara::rest::IteratorRange::begin [Table 8.29 describes the interface ara::rest::IteratorRange::begin.] (RS_CM_00300)

8.4.6 end

Service name:	ara::rest::IteratorRang	e::end	
Type:	Non-member funct	ion	
Syntax:	friend Iterator	friend Iterator end(const IteratorRange &r)	
Function param:	r	an InteratorRange	
Return value:	the end of the sequen	ce	
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/iterator.h		
Namespace:	ara::rest::IteratorRang	е	
Description:	Non-member equivale	ent of IteratorRange::end()	

Table 8.30: ara::rest::lteratorRange::end

[SWS_REST_02388] ara::rest::IteratorRange::end [Table 8.30 describes the interface ara::rest::IteratorRange::end.] (RS_CM_00300)

8.5 ara::rest::MoveIteratorRange

[SWS_REST_02395] [ara::rest::MoveIteratorRange class shall be declared in the ara/rest/iterator.h header file:

```
template <typename IterT >
class ara::rest::MoveIteratorRange;
```

(RS CM 00300)



8.5.1 Movelterator

Name:	MoveIterator
Type:	Member type alias
Syntax:	<pre>using ara::rest::MoveIteratorRange< IterT >::MoveIterator =</pre>
	IterT
Header file:	ara/rest/iterator.h
Class:	ara::rest::MoveIteratorRange
Description:	Type of the underlying pair of movable iterators.

Table 8.31: ara::rest::MovelteratorRange::Movelterator

[SWS_REST_02397] Iterator [Table 8.31 describes the type alias ara::rest::MoveIteratorRange::MoveIterator.|(RS_CM_00300)

8.5.2 MovelteratorRange

Service name:	ara::rest::MoveIterator	Range::MoveIteratorRange
Type:	Member function	
Syntax:	ara::rest::MoveI	teratorRange< IterT
	>::MoveIteratorR	ange(MoveIterator first, MoveIterator
	last)	
Function param:	first	an iterator denoting the start of the sequence
Function param:	last	an iterator denoting the end of the sequence
Return value:	None	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/iterator.h	
Class:	ara::rest::MoveIterator	Range
Description:		eratorRange from a pair of movable iterators. For on, see MakeMoveIteratorRange().

Table 8.32: ara::rest::MovelteratorRange::MovelteratorRange

[SWS_REST_02398] ara::rest::MoveIteratorRange::IteratorRange [Table 8.32 describes the interface ara::rest::MoveIteratorRange::MoveIteratorRange.] (RS_CM_00300)

8.5.3 begin

Service name:	ara::rest::MoveIteratorRange::begin
Type:	Member function
Syntax:	MoveIterator ara::rest::MoveIteratorRange< IterT
	>::begin() const
Function param:	None
Return value:	a movable iterator
Exceptions:	Implementation-defined
Header file:	ara/rest/iterator.h
Class:	ara::rest::MoveIteratorRange



Description:	Returns the start of the sequence.
--------------	------------------------------------

Table 8.33: ara::rest::MovelteratorRange::begin

[SWS_REST_02399] ara::rest::MoveIteratorRange::begin [Table 8.33 describes the interface ara::rest::MoveIteratorRange::begin.|(RS_CM_00300)

8.5.4 end

Service name:	ara::rest::MoveIteratorRange::end
Type:	Member function
Syntax:	MoveIterator ara::rest::MoveIteratorRange< IterT
	>::end() const
Function param:	None
Return value:	a movable iterator
Exceptions:	Implementation-defined
Header file:	ara/rest/iterator.h
Class:	ara::rest::MoveIteratorRange
Description:	Returns the end of the sequence.

Table 8.34: ara::rest::MovelteratorRange::end

[SWS_REST_02400] ara::rest::MoveIteratorRange::end [Table 8.34 describes the interface ara::rest::MoveIteratorRange::end.](RS_CM_00300)

8.5.5 begin

Service name:	ara::rest::MoveIterator	'Range::begin
Type:	Non-member funct	ion
Syntax:	friend MoveItera	tor begin(const MoveIteratorRange &r)
Function param:	r	a MovelteratorRange
Return value:	the start of the sequer	nce
Exceptions:	Implementation-define	ed
Header file:	ara/rest/iterator.h	
Namespace:	ara::rest::MoveIterator	Range
Description:	Non-member equivale	ent of MoveIteratorRange::begin()

Table 8.35: ara::rest::MovelteratorRange::begin

[SWS_REST_02401] ara::rest::MoveIteratorRange::begin | Table 8.35 describes the interface ara::rest::MoveIteratorRange::begin.|(RS CM 00300)

8.5.6 end

Service name: ara::rest::MovelteratorRange::end



Type:	Non-member funct	ion
Syntax:	friend MoveItera	tor end(const MoveIteratorRange &r)
Function param:	r	a MoveInteratorRange
Return value:	the end of the sequen	ce
Exceptions:	Implementation-define	ed
Header file:	ara/rest/iterator.h	
Namespace:	ara::rest::MoveIterator	Range
Description:	Non-member equivale	ent of MoveIteratorRange::end()

Table 8.36: ara::rest::MoveIteratorRange::end

[SWS_REST_02402] ara::rest::MoveIteratorRange::end | Table 8.36 describes the interface ara::rest::MoveIteratorRange::end.|(RS CM 00300)

8.6 ara::rest::Matches

[SWS_REST_02027] [ara::rest::Matches class shall be declared in the ara/rest/routing.h header file:

class ara::rest::Matches;

(RS CM 00300, RS CM 00309)

8.6.1 MatchRange

Name:	MatchRange
Type:	Member type alias
Syntax:	using ara::rest::Matches::MatchRange =
	<pre>IteratorRange<unspecified_iterator_type></unspecified_iterator_type></pre>
Header file:	ara/rest/routing.h
Class:	ara::rest::Matches
Description:	An IteratorRange of all pattern matches for this Route.

Table 8.37: ara::rest::Matches::MatchRange

[SWS_REST_02028] MatchRange [Table 8.37 describes the type alias ara::rest::Matches::MatchRange.|(RS CM 00300, RS CM 00309)

8.6.2 Count

Service name:	ara::rest::Matches::Count
Type:	Member function
Syntax:	std::size_t ara::rest::Matches::Count() const
Function param:	None
Return value:	the number of URI matches



Exceptions:	noexcept
Header file:	ara/rest/routing.h
Class:	ara::rest::Matches
Description:	Provides the number of URI wildcard matches after applying a pattern to
	a route.

Table 8.38: ara::rest::Matches::Count

[SWS_REST_02029] ara::rest::Matches::Count [Table 8.38 describes the interface ara::rest::Matches::Count.|(RS_CM_00300, RS_CM_00309)

8.6.3 Get

Service name:	ara::rest::Matches::Ge	et
Type:	Member function	
Syntax:	const Match& ara	::rest::Matches::Get(std::size_t i)
	const	
Function param:	i	index to the i'th URI wildcard match
Return value:	return type	
Exceptions:	noexcept	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Matches	
Description:	Provides access to a	specific URI match.

Table 8.39: ara::rest::Matches::Get

[SWS_REST_02030] ara::rest::Matches::Get \lceil Table 8.39 describes the interface ara::rest::Matches::Get. \rceil (RS_CM_00300, RS_CM_00309)

8.6.4 Get

Service name:	ara::rest::Matches::Get
Type:	Member function
Syntax:	MatchRange ara::rest::Matches::Get() const
Function param:	None
Return value:	a range of URI matches
Exceptions:	noexcept
Header file:	ara/rest/routing.h
Class:	ara::rest::Matches
Description:	Provides access to the sequence of URI (wildcard) matches. After
	this route has been matched against a given request, all wildcard URI matches are accessible with this range.
	materies are accession with the range.

Table 8.40: ara::rest::Matches::Get

[SWS_REST_02031] ara::rest::Matches::Get [Table 8.40 describes the interface ara::rest::Matches::Get.](RS_CM_00300, RS_CM_00309)



8.7 ara::rest::Match

[SWS_REST_02033] [ara::rest::Match class shall be declared in the ara/rest/routing.h header file:

class ara::rest::Match;

(RS_CM_00300, RS_CM_00309)

8.7.1 Get

Service name:	ara::rest::Match::Get
Type:	Member function
Syntax:	StringView ara::rest::Match::Get() const
Function param:	None
Return value:	a string of the matches path segment
Exceptions:	noexcept(std::is_nothrow_constructible< StringView
	>::value)
Header file:	ara/rest/routing.h
Class:	ara::rest::Match
Description:	Returns a path segment as a string.

Table 8.41: ara::rest::Match::Get

[SWS_REST_02034] ara::rest::Match::Get [Table 8.41 describes the interface ara::rest::Match::Get.] (RS CM 00300, RS CM 00309)

8.7.2 GetAs

Service name:	ara::rest::Match::GetAs
Type:	Member function template
Syntax:	template <typename t=""></typename>
	T ara::rest::Match::GetAs(T &&def={})
Function param:	def if conversion fails,
Return value:	The converted value of conversion succeeded, otherwise it returns the
	function argument.
Exceptions:	Implementation-defined
Header file:	ara/rest/routing.h
Class:	ara::rest::Match
Description:	Returns a type-converted path segment. Applies a type conversion on the matched path segment. The conversion result is assigned to the function argument which is subsequently returned. If conversion fails the function argument is returned unchanged. So either form is valid: GetAs <string>(), GetAs(string{my_allocator}), GetAs<string>("conversion failed")</string></string>

Table 8.42: ara::rest::Match::GetAs



[SWS_REST_02035] ara::rest::Match::GetAs [Table 8.42 describes the interface ara::rest::Match::GetAs.|(RS_CM_00300, RS_CM_00309)

8.8 ara::rest::ogm::Array

[SWS_REST_02036] [ara::rest::ogm::Array class shall be declared in the ara/rest/ogm/array.h header file:

class ara::rest::ogm::Array : public ara::rest::ogm::Value;

(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307)

8.8.1 SelfType

Name:	SelfType
Type:	Member type alias
Syntax:	using ara::rest::ogm::Array::SelfType = Array
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Its own type.

Table 8.43: ara::rest::ogm::Array::SelfType

[SWS_REST_02037] SelfType | Table 8.43 describes the type alias ara::rest::ogm::Array::SelfType.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.8.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Array::ParentType = Value</pre>
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Type of its parent in the OGM type hierarchy.

Table 8.44: ara::rest::ogm::Array::ParentType

[SWS_REST_02038] ParentType [Table 8.44 describes the type alias ara::rest::ogm::Array::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.8.3 Iterator



Name:	Iterator
Type:	Member type alias
Syntax:	using ara::rest::ogm::Array::Iterator =
	unspecified_iterator_type
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	A forward iterator of the represented set values.

Table 8.45: ara::rest::ogm::Array::lterator

[SWS_REST_02039] Iterator [Table 8.45 describes the type alias ara::rest::ogm::Array::Iterator.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.4 Constiterator

Name:	ConstIterator
Туре:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Array::ConstIterator =</pre>
	unspecified_iterator_type
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Value iterator.

Table 8.46: ara::rest::ogm::Array::Constiterator

[SWS_REST_02040] Constiterator [Table 8.46 describes the type alias ara::rest::ogm::Array::ConstIterator.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.5 ValueRange

Name:	ValueRange
Type:	Member type alias
Syntax:	using ara::rest::ogm::Array::ValueRange =
	<pre>IteratorRange<iterator></iterator></pre>
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Iterator range.

Table 8.47: ara::rest::ogm::Array::ValueRange

[SWS_REST_02041] ValueRange [Table 8.47 describes the type alias ara::rest::ogm::Array::ValueRange.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.8.6 ConstValueRange

Name:	ConstValueRange	
Туре:	Member type alias	
Syntax:	<pre>using ara::rest::ogm::Array::ConstValueRange =</pre>	
	<pre>IteratorRange<constiterator></constiterator></pre>	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Iterator range.	

Table 8.48: ara::rest::ogm::Array::ConstValueRange

[SWS_REST_02042] ConstValueRange Table 8.48 describes the type ara::rest::ogm::Array::ConstValueRange.](RS_CM_00300, alias RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.8.7 MoveRange

Name:	MoveRange
Туре:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Array::MoveRange =</pre>
	<pre>IteratorRange<moveiterator></moveiterator></pre>
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Movelterator range.

Table 8.49: ara::rest::ogm::Array::MoveRange

[SWS REST 02403] MoveRange [Table 8.49 describes the type alias ara::rest::ogm::Array::MoveRange.|(RS_CM_00300, RS CM 00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.8 GetParent

Service name:	ara::rest::ogm::Array::GetParent	
Type:	Member function	
Syntax:	Node* ara::rest::ogm::Array::GetParent()	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.50: ara::rest::ogm::Array::GetParent



[SWS_REST_02043] ara::rest::ogm::Array::GetParent | Table | 8.50 | describes the interface | ara::rest::ogm::Array::GetParent.](RS_CM_00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.8.9 GetParent

Service name:	ara::rest::ogm::Array::GetParent
Type:	Member function
Syntax:	const Node* ara::rest::ogm::Array::GetParent() const
Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.51: ara::rest::ogm::Array::GetParent

[SWS_REST_02044] ara::rest::ogm::Array::GetParent [Table 8.51 describes the interface ara::rest::ogm::Array::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.10 HasParent

Service name:	ara::rest::ogm::Array::HasParent
Type:	Member function
Syntax:	bool ara::rest::ogm::Array::HasParent() const
Function param:	None
Return value:	true if this node has a structural parent
Exceptions:	noexcept
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Denotes whether this node has a structural parent.

Table 8.52: ara::rest::ogm::Array::HasParent

[SWS_REST_02045] ara::rest::ogm::Array::HasParent | Table | 8.52 | describes the | interface | ara::rest::ogm::Array::HasParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.11 **GetSize**

Service name:	ara::rest::ogm::Array::GetSize
Type:	Member function
Syntax:	std::size_t ara::rest::ogm::Array::GetSize() const



Function param:	None
Return value:	the number of array elements
Exceptions:	noexcept
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Returns the number of elements.

Table 8.53: ara::rest::ogm::Array::GetSize

[SWS_REST_02046] ara::rest::ogm::Array::GetSize [Table 8.53 describes the interface ara::rest::ogm::Array::GetSize.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.12 **IsEmpty**

Service name:	ara::rest::ogm::Array::lsEmpty
Type:	Member function
Syntax:	bool ara::rest::ogm::Array::IsEmpty() const
Function param:	None
Return value:	true if the array holds no elements
Exceptions:	noexcept
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Returns whether the array holds no elements.

Table 8.54: ara::rest::ogm::Array::lsEmpty

[SWS_REST_02047] ara::rest::ogm::Array::IsEmpty [Table 8.54 describes the interface ara::rest::ogm::Array::IsEmpty.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.13 GetValue

Service name:	ara::rest::ogm::Array::GetValue		
Type:	Member function		
Syntax:	Value& ara::rest	Value& ara::rest::ogm::Array::GetValue(std::size_t	
	index)		
Function param:	index	an integral index into the array	
Return value:	a reference to a Value	a reference to a Value	
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/array.h		
Class:	ara::rest::ogm::Array		
Description:	Returns a Value at a specific index. If the index is out-of-bounds, the result in undefined.		

Table 8.55: ara::rest::ogm::Array::GetValue



[SWS_REST_02048] ara::rest::ogm::Array::GetValue | Table 8.55 describes the interface ara::rest::ogm::Array::GetValue.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.14 GetValue

Service name:	ara::rest::ogm::Array::GetValue		
Type:	Member function	Member function	
Syntax:	const Value&		
	ara::rest::ogm::/	Array::GetValue(std::size_t index)	
	const		
Function param:	index	an integral index into the array	
Return value:	a reference to a Value		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/array.h		
Class:	ara::rest::ogm::Array		
Description:		specific index. If the index is out-of-bounds, the	
	result in undefined.		

Table 8.56: ara::rest::ogm::Array::GetValue

[SWS_REST_02049] ara::rest::ogm::Array::GetValue [Table 8.56 describes the interface ara::rest::ogm::Array::GetValue.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.15 GetValues

Service name:	ara::rest::ogm::Array::GetValues
Type:	Member function
Syntax:	<pre>ValueRange ara::rest::ogm::Array::GetValues()</pre>
Function param:	None
Return value:	an iterator range of values
Exceptions:	noexcept
Header file:	ara/rest/ogm/array.h
Class:	ara::rest::ogm::Array
Description:	Returns a range of values.

Table 8.57: ara::rest::ogm::Array::GetValues

[SWS_REST_02050] ara::rest::ogm::Array::GetValues [Table 8.57 describes the interface ara::rest::ogm::Array::GetValues.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.16 GetValues



Service name:	ara::rest::ogm::Array::GetValues	
Type:	Member function	
Syntax:	<pre>ConstValueRange ara::rest::ogm::Array::GetValues()</pre>	
	const	
Function param:	None	
Return value:	an iterator range of values	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Returns a range of values.	

Table 8.58: ara::rest::ogm::Array::GetValues

[SWS_REST_02051] ara::rest::ogm::Array::GetValues [Table 8.58 describes the interface ara::rest::ogm::Array::GetValues.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.17 Append

Service name:	ara::rest::ogm::Array::Append		
Type:	Member function		
Syntax:	<pre>void ara::rest::ogm::Array::Append(Pointer< Value ></pre>		
	&&v)		
Function param:	v a Pointer to a value		
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/array.h		
Class:	ara::rest::ogm::Array		
Description:	Appends a Value obje	Appends a Value object to the array.	

Table 8.59: ara::rest::ogm::Array::Append

[SWS_REST_02052] ara::rest::ogm::Array::Append [Table 8.59 describes the interface ara::rest::ogm::Array::Append.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.18 Insert

Service name:	ara::rest::ogm::Array::Insert	
Type:	Member function	
Syntax:	void ara::rest::	ogm::Array::Insert(Iterator iter,
	Pointer< Value > &&v)	
Function param:	iter	an Array iterator
Function param:	v a value to insert.	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	



Class:	ara::rest::ogm::Array
Description:	Inserts a Value at a specific position into the Array. Inserts a value before the element pointed to by the iterator argument. To insert a Value ownership has to be passeed to the Array

Table 8.60: ara::rest::ogm::Array::Insert

8.8.19 Remove

Service name:	ara::rest::ogm::Array::Remove	
Type:	Member function	
Syntax:	Iterator ara::re	st::ogm::Array::Remove(Iterator iter)
Function param:	iter an iterator pointing to an array element	
Return value:	an iterator pointing to the element following the one just removed.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Removes an element from the array. Removes the element pointed to be	
	the iterator argument	

Table 8.61: ara::rest::ogm::Array::Remove

[SWS_REST_02054] ara::rest::ogm::Array::Remove | Table 8.61 describes the interface ara::rest::ogm::Array::Remove.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.20 Release

87 of 241

Service name:	ara::rest::ogm::Array::Release	
Type:	Member function	
Syntax:	std::pair <iterat< th=""><th>or, Pointer<value> ></value></th></iterat<>	or, Pointer <value> ></value>
	ara::rest::ogm::	Array::Release(Iterator iter)
Function param:	iter an iterator pointing to the element to be removed	
Return value:	a pair of the iterator pointing to the element following the one just deleted	
	and a pointer to the element	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Similar to Remove but does not destroy the removed element. Instead of	
	destroying the removed element, ownership is passed back to the user	

Table 8.62: ara::rest::ogm::Array::Release



[SWS_REST_02055] ara::rest::ogm::Array::Release [Table 8.62 describes the interface ara::rest::ogm::Array::Release.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.21 Replace

Service name:	ara::rest::ogm::Array::Replace	
Type:	Member function	
Syntax:	Pointer <value></value>	
	ara::rest::ogm:::	Array::Replace(Iterator iter,
	Pointer< Value >	&&v)
Function param:	iter	an iterator pointing to the element to be removed
Function param:	V	a pointer to the value to replace the one pointed to
		by iter
Return value:	a pointer to the old array element	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Replaces an element by a new one without the destroying the old one.	
	Replaces an array element without destroying it. Instead the replaced	
	element is returned. E	ffectively, ownership is passed back to the user.

Table 8.63: ara::rest::ogm::Array::Replace

[SWS_REST_02056] ara::rest::ogm::Array::Replace [Table 8.63 describes the interface ara::rest::ogm::Array::Replace.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.22 Clear

Service name:	ara::rest::ogm::Array::Clear	
Type:	Member function	
Syntax:	<pre>void ara::rest::ogm::Array::Clear()</pre>	
Function param:	None	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Removes and destroys all elements of the array.	

Table 8.64: ara::rest::ogm::Array::Clear



8.8.23 Make

Service name:	ara::rest::ogm::Array::Make	
Type:	Member function	
Syntax:	template <typena< th=""><th>me Ts></th></typena<>	me Ts>
	static Pointer <s< th=""><th>elfType></th></s<>	elfType>
	ara::rest::ogm::Array::Make(Ts &&ts)	
Function param:	ts	constructor arguments forwarded to the constructor
	of this type	
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Creates a node of type	e SelfType.

Table 8.65: ara::rest::ogm::Array::Make

8.8.24 Make

Service name:	ara::rest::ogm::Array::Make	
Type:	Member function	
Syntax:	template <typena< th=""><th>me Ts></th></typena<>	me Ts>
	static Pointer <se< th=""><th>elfType></th></se<>	elfType>
	ara::rest::ogm::/	Array::Make(Allocator *alloc, Ts
	&&ts)	
Function param:	alloc an allocator to use to construct this node	
Function param:	ts	constructor arguments forwarded to the constructor
	of this type	
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Creates a node of type	e SelfType.

Table 8.66: ara::rest::ogm::Array::Make

[SWS_REST_02059] ara::rest::ogm::Array::Make | Table 8.66 describes the interface ara::rest::ogm::Array::Make.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.8.25 Array

Service name:	ara::rest::ogm::Array::Array	
Type:	Member function	



Syntax:	template <typename ts=""></typename>	
	ara::rest::ogm::	Array::Array(Pointer< Ts > &&ts)
Function param:	ts OGM objects to insert into the array	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/array.h	
Class:	ara::rest::ogm::Array	
Description:	Constructs an Array.	

Table 8.67: ara::rest::ogm::Array::Array

8.8.26 Array

Service name:	ara::rest::ogm::Array::Array		
Type:	Member function	Member function	
Syntax:	template <typename ts=""></typename>		
	ara::rest::ogm::Array::Array(Allocator *alloc,		
	Pointer< Ts > &&ts)		
Function param:	alloc	an allocator	
Function param:	ts	OGM objects to insert into the array	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/array.h		
Class:	ara::rest::ogm::Array		
Description:	Constructs an Array.		

Table 8.68: ara::rest::ogm::Array::Array

8.9 ara::rest::ogm::Field

[SWS_REST_02062] [ara::rest::ogm::Field class shall be declared in the ara/rest/ogm/field.h header file:

```
class ara::rest::ogm::Field : public ara::rest::ogm::Node;
```

(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307)



8.9.1 SelfType

Name:	SelfType
Type:	Member type alias
Syntax:	using ara::rest::ogm::Field::SelfType = Field
Header file:	ara/rest/ogm/field.h
Class:	ara::rest::ogm::Field
Description:	Its own type.

Table 8.69: ara::rest::ogm::Field::SelfType

[SWS_REST_02063] SelfType | Table 8.69 describes the type alias ara::rest::ogm::Field::SelfType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.9.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Field::ParentType = Node</pre>
Header file:	ara/rest/ogm/field.h
Class:	ara::rest::ogm::Field
Description:	Type of its parent in the OGM type hierarchy.

Table 8.70: ara::rest::ogm::Field::ParentType

[SWS_REST_02064] ParentType [Table 8.70 describes the type alias ara::rest::ogm::Field::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.9.3 GetParent

Service name:	ara::rest::ogm::Field::GetParent	
Type:	Member function	
Syntax:	Node* ara::rest::ogm::Field::GetParent()	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.71: ara::rest::ogm::Field::GetParent

[SWS_REST_02065] ara::rest::ogm::Field::GetParent | Table | 8.71 | describes the | interface | ara::rest::ogm::Field::GetParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.9.4 GetParent

Service name:	ara::rest::ogm::Field::GetParent	
Type:	Member function	
Syntax:	const Node* ara::rest::ogm::Field::GetParent() const	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.72: ara::rest::ogm::Field::GetParent

[SWS_REST_02066] ara::rest::ogm::Field::GetParent [Table 8.72 describes the interface ara::rest::ogm::Field::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.5 HasParent

Service name:	ara::rest::ogm::Field::HasParent	
Type:	Member function	
Syntax:	bool ara::rest::ogm::Field::HasParent() const	
Function param:	None	
Return value:	true if this node has a structural parent	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Denotes whether this node has a structural parent.	

Table 8.73: ara::rest::ogm::Field::HasParent

[SWS_REST_02067] ara::rest::ogm::Field::HasParent [Table 8.73 describes the interface ara::rest::ogm::Field::HasParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.6 GetName

Service name:	ara::rest::ogm::Field::GetName	
Type:	Member function	
Syntax:	<pre>const StringView& ara::rest::ogm::Field::GetName()</pre>	
	const	
Function param:	None	
Return value:	a name	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	



Description:	Return the name of a Field. Fields names are immutable. To set a differ-		
	ent name a new Field must be inserted.		

Table 8.74: ara::rest::ogm::Field::GetName

[SWS_REST_02068] ara::rest::ogm::Field::GetName | Table 8.74 describes the interface ara::rest::ogm::Field::GetName.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.7 GetValue

Service name:	ara::rest::ogm::Field::GetValue	
Type:	Member function	
Syntax:	<pre>const Value& ara::rest::ogm::Field::GetValue() const</pre>	
Function param:	None	
Return value:	a reference to the current field value	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Returns the value represented by a Field.	

Table 8.75: ara::rest::ogm::Field::GetValue

[SWS_REST_02069] ara::rest::ogm::Field::GetValue [Table 8.75 describes the interface ara::rest::ogm::Field::GetValue.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.8 GetValue

Service name:	ara::rest::ogm::Field::GetValue	
Type:	Member function	
Syntax:	<pre>Value& ara::rest::ogm::Field::GetValue()</pre>	
Function param:	None	
Return value:	a reference to the current field value	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Returns the value represented by a Field.	

Table 8.76: ara::rest::ogm::Field::GetValue

[SWS_REST_02070] ara::rest::ogm::Field::GetValue [Table 8.76 describes the interface ara::rest::ogm::Field::GetValue.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.9.9 SetValue

Service name:	ara::rest::ogm::Field::SetValue	
Type:	Member function	
Syntax:	<pre>void ara::rest::ogm::Field::SetValue(Pointer< Value ></pre>	
	(V&&)	
Function param:	V	a new Value
Return value:	None	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Sets a new value. The previous value is destroyed	

Table 8.77: ara::rest::ogm::Field::SetValue

[SWS_REST_02071] ara::rest::ogm::Field::SetValue [Table 8.77 describes the interface ara::rest::ogm::Field::SetValue.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.10 ReplaceValue

Service name:	ara::rest::ogm::Field::ReplaceValue		
Type:	Member function	Member function	
Syntax:	Pointer <value></value>		
	ara::rest::ogm::Field::ReplaceValue(Pointer< Value >		
	&&v)		
Function param:	V	a new Value	
Return value:	the old value		
Exceptions:	noexcept		
Header file:	ara/rest/ogm/field.h		
Class:	ara::rest::ogm::Field		
Description:	Sets a new value and returns the old one.		

Table 8.78: ara::rest::ogm::Field::ReplaceValue

[SWS_REST_02072] ara::rest::ogm::Field::ReplaceValue [Table 8.78 describes the interface ara::rest::ogm::Field::ReplaceValue.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.11 Make

Service name:	ara::rest::ogm::Field::Make	
Type:	Member function	
Syntax:	template <typename ts=""></typename>	
	static Pointer <selftype></selftype>	
	ara::rest::ogm::Field::Make(Ts &&ts)	
Function param:	ts	constructor arguments forwarded to the constructor
		of this type



Return value:	a pointer to a node of type SelfType
Exceptions:	Implementation-defined
Header file:	ara/rest/ogm/field.h
Class:	ara::rest::ogm::Field
Description:	Creates a node of type SelfType.

Table 8.79: ara::rest::ogm::Field::Make

[SWS_REST_02073] ara::rest::ogm::Field::Make | Table 8.79 describes the interface ara::rest::ogm::Field::Make.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.12 Make

Service name:	ara::rest::ogm::Field::N	Make	
Type:	Member function	Member function	
Syntax:	<pre>template <typename ts=""> static Pointer<selftype></selftype></typename></pre>		
	ara::rest::ogm::Field::Make(Allocator *alloc, Ts &&ts)		
Function param:	alloc	an allocator to use to construct this node	
Function param:	ts	constructor arguments forwarded to the constructor of this type	
Return value:	a pointer to a node of type SelfType		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/field.h		
Class:	ara::rest::ogm::Field		
Description:	Creates a node of type	Creates a node of type SelfType.	

Table 8.80: ara::rest::ogm::Field::Make

[SWS_REST_02074] ara::rest::ogm::Field::Make | Table 8.80 describes the interface ara::rest::ogm::Field::Make.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.13 Field

Service name:	ara::rest::ogm::Field::F	ield
Type:	Member function	
Syntax:	ara::rest::ogm::Field::Field(const String &name,	
	Pointer< Value > &&value)	
Function param:	name	name of this Field
Function param:	value	value object attached to this Field
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	



Description:	Constructs a Field.	
--------------	---------------------	--

Table 8.81: ara::rest::ogm::Field::Field

[SWS_REST_02075] ara::rest::ogm::Field::Field [Table 8.81 describes the interface ara::rest::ogm::Field::Field.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.9.14 Field

Service name:	ara::rest::ogm::Field::F	Field
Type:	Member function	
Syntax:	ara::rest::ogm::1	Field::Field(Allocator *alloc, const
	String &key, Poin	nter< Value > &&val)
Function param:	alloc	an allocator
Function param:	key	a field name
Function param:	val	a field value
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/field.h	
Class:	ara::rest::ogm::Field	
Description:	Constructs field, providing an allocator. The allocator argument may be	
	used for internal allocation purposes.	

Table 8.82: ara::rest::ogm::Field::Field

[SWS_REST_02076] ara::rest::ogm::Field::Field [Table 8.82 describes the interface ara::rest::ogm::Field::Field.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.10 ara::rest::ogm::Int

[SWS_REST_02077] [ara::rest::ogm::Int class shall be declared in the ara/rest/ogm/int.h header file:

```
class ara::rest::ogm::Int : public ara::rest::ogm::Value;
```

](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.10.1 SelfType

Name:	SelfType
Туре:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Int::SelfType = Int</pre>
Header file:	ara/rest/ogm/int.h



Class:	ara::rest::ogm::Int
Description:	Its own type.

Table 8.83: ara::rest::ogm::Int::SelfType

[SWS_REST_02078] SelfType [Table 8.83 describes the type alias ara::rest::ogm::Int::SelfType.](RS_CM_00300 , RS_CM_00305 , RS_CM_00306 , RS_CM_00307)

8.10.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Int::ParentType = Value</pre>
Header file:	ara/rest/ogm/int.h
Class:	ara::rest::ogm::Int
Description:	Type of its parent in the OGM type hierarchy.

Table 8.84: ara::rest::ogm::Int::ParentType

[SWS_REST_02079] ParentType [Table 8.84 describes the type alias ara::rest::ogm::Int::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.10.3 ValueType

Name:	ValueType
Type:	Member type alias
Syntax:	using ara::rest::ogm::Int::ValueType = std::int64_t
Header file:	ara/rest/ogm/int.h
Class:	ara::rest::ogm::Int
Description:	Type of its corresponding C++ data type.

Table 8.85: ara::rest::ogm::Int::ValueType

[SWS_REST_02080] ValueType [Table 8.85 describes the type alias ara::rest::ogm::Int::ValueType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.10.4 GetParent

Service name:	ara::rest::ogm::Int::GetParent	
Type:	Member function	
Syntax:	<pre>Node* ara::rest::ogm::Int::GetParent()</pre>	



Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/int.h
Class:	ara::rest::ogm::Int
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.86: ara::rest::ogm::Int::GetParent

[SWS_REST_02081] ara::rest::ogm::Int::GetParent [Table 8.86 describes the interface ara::rest::ogm::Int::GetParent.|(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.10.5 GetParent

Service name:	ara::rest::ogm::Int::GetParent	
Type:	Member function	
Syntax:	<pre>const Node* ara::rest::ogm::Int::GetParent() const</pre>	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/int.h	
Class:	ara::rest::ogm::Int	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.87: ara::rest::ogm::Int::GetParent

[SWS_REST_02082] ara::rest::ogm::Int::GetParent [Table 8.87 describes the interface ara::rest::ogm::Int::GetParent.|(RS_CM_00300, RS_CM_00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.10.6 HasParent

Service name:	ara::rest::ogm::Int::HasParent	
Type:	Member function	
Syntax:	bool ara::rest::ogm::Int::HasParent() const	
Function param:	None	
Return value:	true if this node has a structural parent	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/int.h	
Class:	ara::rest::ogm::Int	
Description:	Denotes whether this node has a structural parent.	

Table 8.88: ara::rest::ogm::Int::HasParent



[SWS_REST_02083] ara::rest::ogm::Int::HasParent | Table 8.88 describes the interface ara::rest::ogm::Int::HasParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.10.7 GetValue

Service name:	ara::rest::ogm::Int::GetValue
Type:	Member function
Syntax:	ValueType ara::rest::ogm::Int::GetValue() const
Function param:	None
Return value:	a value of type ValueType
Exceptions:	noexcept
Header file:	ara/rest/ogm/int.h
Class:	ara::rest::ogm::Int
Description:	Returns its value as a C++ data type.

Table 8.89: ara::rest::ogm::Int::GetValue

[SWS_REST_02084] ara::rest::ogm::Int::GetValue [Table 8.89 describes the interface ara::rest::ogm::Int::GetValue.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.10.8 SetValue

Service name:	ara::rest::ogm::Int::SetValue		
Type:	Member function	Member function	
Syntax:	<pre>void ara::rest::ogm::Int::SetValue(ValueType v)</pre>		
Function param:	V	a value	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/ogm/int.h		
Class:	ara::rest::ogm::Int		
Description:	Sets the current value from a C++ data type.		

Table 8.90: ara::rest::ogm::Int::SetValue

8.10.9 Make

Service name:	ara::rest::ogm::Int::Make
Type:	Member function



Syntax:	<pre>template <typename ts=""> static Pointer<selftype> ara::rest::ogm::Int::Make(Ts &&ts)</selftype></typename></pre>	
Function param:	ts	constructor arguments forwarded to the constructor of this type
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/int.h	
Class:	ara::rest::ogm::Int	
Description:	Creates a node of type SelfType.	

Table 8.91: ara::rest::ogm::Int::Make

[SWS_REST_02086] ara::rest::ogm::Int::Make | Table 8.91 describes the interface ara::rest::ogm::Int::Make.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.10.10 Make

Service name:	ara::rest::ogm::Int::Make		
Type:	Member function	Member function	
Syntax:	<pre>template <typename ts=""> static Pointer<selftype></selftype></typename></pre>		
	ara::rest::ogm::	Int::Make(Allocator *alloc, Ts	
	&&ts)		
Function param:	alloc	an allocator to use to construct this node	
Function param:	ts	constructor arguments forwarded to the constructor of this type	
Return value:	a pointer to a node of type SelfType		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/int.h		
Class:	ara::rest::ogm::Int		
Description:	Creates a node of type SelfType.		

Table 8.92: ara::rest::ogm::Int::Make

[SWS_REST_02087] ara::rest::ogm::Int::Make | Table 8.92 describes the interface ara::rest::ogm::Int::Make.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.10.11 Int

Service name:	ara::rest::ogm::Int::Int	
Type:	Member function	
Syntax:	<pre>ara::rest::ogm::Int::Int(ValueType value=ValueType{})</pre>	
Function param:	value	an intial value
Return value:	None	



Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/int.h	
Class:	ara::rest::ogm::Int	
Description:	Connstructs an Int.	

Table 8.93: ara::rest::ogm::Int::Int

[SWS_REST_02088] ara::rest::ogm::Int::Int | Table 8.93 describes the interface ara::rest::ogm::Int::Int.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11 ara::rest::ogm::Node

[SWS_REST_02089] [ara::rest::ogm::Node class shall be declared in the ara/rest/ogm/node.h header file:

class ara::rest::ogm::Node;

(RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.11.1 SelfType

Name:	SelfType
Type:	Member type alias
Syntax:	using ara::rest::ogm::Node::SelfType = Node
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Type of this OGM node.

Table 8.94: ara::rest::ogm::Node::SelfType

[SWS_REST_02090] SelfType [Table 8.94 describes the type alias ara::rest::ogm::Node::SelfType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.11.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Node::ParentType = void</pre>
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Type of its parent in the OGM type hierarchy.

Table 8.95: ara::rest::ogm::Node::ParentType



[SWS_REST_02091] ParentType [Table 8.95 describes the type alias ara::rest::ogm::Node::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.11.3 GetParent

Service name:	ara::rest::ogm::Node::GetParent	
Type:	Member function	
Syntax:	ParentType* ara::rest::ogm::Node::GetParent()	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/node.h	
Class:	ara::rest::ogm::Node	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.96: ara::rest::ogm::Node::GetParent

[SWS_REST_02092] ara::rest::ogm::Node::GetParent [Table 8.96 describes the interface ara::rest::ogm::Node::GetParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11.4 GetParent

Service name:	ara::rest::ogm::Node::GetParent
Type:	Member function
Syntax:	<pre>const ParentType* ara::rest::ogm::Node::GetParent()</pre>
	const
Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.97: ara::rest::ogm::Node::GetParent

[SWS_REST_02093] ara::rest::ogm::Node::GetParent [Table 8.97 describes the interface ara::rest::ogm::Node::GetParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11.5 HasParent

Service name:	ara::rest::ogm::Node::HasParent
Type:	Member function



Syntax:	bool ara::rest::ogm::Node::HasParent() const
Function param:	None
Return value:	true of this node has a parent
Exceptions:	noexcept
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Denotes whether this node has a structural parent.

Table 8.98: ara::rest::ogm::Node::HasParent

[SWS_REST_02094] ara::rest::ogm::Node::HasParent [Table 8.98 describes the interface ara::rest::ogm::Node::HasParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11.6 ~Node

Service name:	ara::rest::ogm::Node::~Node
Type:	Member function
Syntax:	<pre>virtual ara::rest::ogm::Node::~Node()</pre>
Function param:	None
Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Destructor.

Table 8.99: ara::rest::ogm::Node::~Node

8.11.7 Node

Service name:	ara::rest::ogm::Node::Node
Type:	Member function
Syntax:	ara::rest::ogm::Node::Node(const Node &)=delete
Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Non-copyable; copy with ogm::Copy()

Table 8.100: ara::rest::ogm::Node::Node



8.11.8 operator=

Service name:	ara::rest::ogm::Node::operator=
Type:	Member function
Syntax:	Node& ara::rest::ogm::Node::operator=(const Node
	&)=delete
Return value:	a value of type Node &
Exceptions:	Implementation-defined
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Non-copy-assignable; copy with ogm::Copy()

Table 8.101: ara::rest::ogm::Node::operator=

[SWS_REST_02097] ara::rest::ogm::Node::operator= [Table 8.101 describes the interface ara::rest::ogm::Node::operator=.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11.9 GetAllocator

Service name:	ara::rest::ogm::Node::GetAllocator
Type:	Member function
Syntax:	Allocator* ara::rest::ogm::Node::GetAllocator()
Function param:	None
Return value:	a pointer to an allocator
Exceptions:	noexcept
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Returns a pointer to the allocator that manages this subtree.

Table 8.102: ara::rest::ogm::Node::GetAllocator

[SWS_REST_02098] ara::rest::ogm::Node::GetAllocator [Table 8.102 describes the interface ara::rest::ogm::Node::GetAllocator.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11.10 GetAllocator

Service name:	ara::rest::ogm::Node::GetAllocator
Type:	Member function



Syntax:	<pre>const Allocator* ara::rest::ogm::Node::GetAllocator()</pre>
	const
Function param:	None
Return value:	a pointer to an allocator
Exceptions:	noexcept
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Returns a pointer to the allocator that manages this subtree.

Table 8.103: ara::rest::ogm::Node::GetAllocator

[SWS_REST_02099] ara::rest::ogm::Node::GetAllocator | Table 8.103 describes the interface ara::rest::ogm::Node::GetAllocator.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.11.11 Node

Service name:	ara::rest::ogm::Node::Node
Type:	Member function
Syntax:	ara::rest::ogm::Node::Node()
Function param:	None
Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/ogm/node.h
Class:	ara::rest::ogm::Node
Description:	Constructs a node. Inaccessible to the user

Table 8.104: ara::rest::ogm::Node::Node

8.12 ara::rest::ogm::Object

[SWS_REST_02101] [ara::rest::ogm::Object class shall be declared in the ara/rest/ogm/object.h header file:

```
class ara::rest::ogm::Object : public ara::rest::ogm::Value;
```

(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307)

8.12.1 SelfType

Name:	SelfType



Туре:	Member type alias
Syntax:	using ara::rest::ogm::Object::SelfType = Object
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Its own type.

Table 8.105: ara::rest::ogm::Object::SelfType

[SWS_REST_02102] SelfType [Table 8.105 describes the type alias ara::rest::ogm::Object::SelfType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.12.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Object::ParentType = Value</pre>
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Type of its parent in the OGM type hierarchy.

Table 8.106: ara::rest::ogm::Object::ParentType

[SWS_REST_02103] ParentType [Table 8.106 describes the type alias ara::rest::ogm::Object::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.12.3 Iterator

Name:	Iterator
Туре:	Member type alias
Syntax:	using ara::rest::ogm::Object::Iterator =
	unspecified_iterator_type
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Value iterator.

Table 8.107: ara::rest::ogm::Object::Iterator

[SWS_REST_02104] Iterator [Table 8.107 describes the type alias ara::rest::ogm::Object::Iterator.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.4 Constiterator



Name:	ConstIterator
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Object::ConstIterator =</pre>
	unspecified_iterator_type
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Value iterator.

Table 8.108: ara::rest::ogm::Object::Constlterator

[SWS_REST_02105] Constiterator [Table 8.108 describes the type alias ara::rest::ogm::Object::ConstIterator.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.5 FieldRange

Name:	FieldRange
Type:	Member type alias
Syntax:	using ara::rest::ogm::Object::FieldRange =
	<pre>IteratorRange<iterator></iterator></pre>
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Iterator range.

Table 8.109: ara::rest::ogm::Object::FieldRange

[SWS_REST_02106] FieldRange [Table 8.109 describes the type alias ara::rest::ogm::Object::FieldRange.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.6 ConstFieldRange

Name:	ConstFieldRange
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Object::ConstFieldRange =</pre>
	<pre>IteratorRange<constiterator></constiterator></pre>
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Iterator range.

Table 8.110: ara::rest::ogm::Object::ConstFieldRange

[SWS_REST_02107] ConstFieldRange [Table 8.110 describes the type alias ara::rest::ogm::Object::ConstFieldRange.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.12.7 MoveFieldRange

Name:	MoveFieldRange
Туре:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Object::MoveFieldRange =</pre>
	<pre>IteratorRange<moveiterator></moveiterator></pre>
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Movelterator range.

Table 8.111: ara::rest::ogm::Object::MoveFieldRange

[SWS_REST_02404] MoveFieldRange [Table 8.111 describes the type alias ara::rest::ogm::Object::MoveFieldRange.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.8 GetParent

Service name:	ara::rest::ogm::Object::GetParent
Type:	Member function
Syntax:	Node* ara::rest::ogm::Object::GetParent()
Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.112: ara::rest::ogm::Object::GetParent

[SWS_REST_02108] ara::rest::ogm::Object::GetParent [Table 8.112 describes the interface ara::rest::ogm::Object::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.9 GetParent

Service name:	ara::rest::ogm::Object::GetParent
Type:	Member function
Syntax:	<pre>const Node* ara::rest::ogm::Object::GetParent() const</pre>
Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.113: ara::rest::ogm::Object::GetParent



[SWS_REST_02109] ara::rest::ogm::Object::GetParent | Table | 8.113 | describes the | interface | ara::rest::ogm::Object::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.10 HasParent

Service name:	ara::rest::ogm::Object::HasParent
Type:	Member function
Syntax:	bool ara::rest::ogm::Object::HasParent() const
Function param:	None
Return value:	true if this node has a structural parent
Exceptions:	noexcept
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Denotes whether this node has a structural parent.

Table 8.114: ara::rest::ogm::Object::HasParent

[SWS_REST_02110] ara::rest::ogm::Object::HasParent [Table 8.114 describes the interface ara::rest::ogm::Object::HasParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.11 GetSize

Service name:	ara::rest::ogm::Object::GetSize
Type:	Member function
Syntax:	std::size_t ara::rest::ogm::Object::GetSize() const
Function param:	None
Return value:	the number of array elements
Exceptions:	noexcept
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Returns the number of elements.

Table 8.115: ara::rest::ogm::Object::GetSize

[SWS_REST_02111] ara::rest::ogm::Object::GetSize [Table 8.115 describes the interface ara::rest::ogm::Object::GetSize.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.12 IsEmpty

Service name:	ara::rest::ogm::Object::IsEmpty		
Type:	Member function		
Syntax:	bool ara::rest::ogm::Object::IsEmpty() const		



Function param:	None
Return value:	true if the array holds no elements
Exceptions:	noexcept
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Returns whether the object holds no elements.

Table 8.116: ara::rest::ogm::Object::IsEmpty

8.12.13 GetFields

Service name:	ara::rest::ogm::Object::GetFields
Type:	Member function
Syntax:	FieldRange ara::rest::ogm::Object::GetFields()
Function param:	None
Return value:	an iterator range of fields
Exceptions:	noexcept
Header file:	ara/rest/ogm/object.h
Class:	ara::rest::ogm::Object
Description:	Returns a range of fields.

Table 8.117: ara::rest::ogm::Object::GetFields

[SWS_REST_02113] ara::rest::ogm::Object::GetFields [Table 8.117 describes the interface ara::rest::ogm::Object::GetFields.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.14 GetFields

Service name:	ara::rest::ogm::Object::GetFields	
Type:	Member function	
Syntax:	ConstFieldRange ara::rest::ogm::Object::GetFields()	
	const	
Function param:	None	
Return value:	an iterator range of fields	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object	
Description:	Returns a range of fields.	

Table 8.118: ara::rest::ogm::Object::GetFields



[SWS_REST_02114] ara::rest::ogm::Object::GetFields [Table 8.118 describes the interface ara::rest::ogm::Object::GetFields.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.15 HasField

Service name:	ara::rest::ogm::Object::HasField		
Type:	Member function	Member function	
Syntax:	bool ara::rest::ogm::Object::HasField(StringView		
	name) const		
Function param:	name	of the field to search for	
Return value:	true if a field of the given name exists		
Exceptions:	noexcept		
Header file:	ara/rest/ogm/object.h		
Class:	ara::rest::ogm::Object		
Description:	Checks whether a field of a given name exists.		

Table 8.119: ara::rest::ogm::Object::HasField

[SWS_REST_02115] ara::rest::ogm::Object::HasField [Table 8.119 describes the interface ara::rest::ogm::Object::HasField.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.16 Find

Service name:	ara::rest::ogm::Object::Find		
Type:	Member function	Member function	
Syntax:	Iterator ara::re	<pre>Iterator ara::rest::ogm::Object::Find(StringView</pre>	
	name)	name)	
Function param:	name	field name to look up	
Return value:	an iterator pointing to	an iterator pointing to the position of the element.	
Exceptions:	noexcept	noexcept	
Header file:	ara/rest/ogm/object.h	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object		
Description:	Searches for a field of	Searches for a field of the given name. If the given field name is not	
	found, the return value will be equal to GetFields().end().		

Table 8.120: ara::rest::ogm::Object::Find

[SWS_REST_02116] ara::rest::ogm::Object::Find [Table 8.120 describes the interface ara::rest::ogm::Object::Find.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.17 Find



Service name:	ara::rest::ogm::Object::Find		
Type:	Member function	Member function	
Syntax:	ConstIterator ar	ConstIterator ara::rest::ogm::Object::Find(StringView	
	name) const	name) const	
Function param:	name	field name to look up	
Return value:	an iterator pointing to the position of the element.		
Exceptions:	noexcept	noexcept	
Header file:	ara/rest/ogm/object.h		
Class:	ara::rest::ogm::Object		
Description:	Searches for a field of	Searches for a field of the given name. If the given field name is not	
	found, the return value	found, the return value will be equal to GetFields().end().	

Table 8.121: ara::rest::ogm::Object::Find

[SWS_REST_02117] ara::rest::ogm::Object::Find [Table 8.121 describes the interface ara::rest::ogm::Object::Find.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.18 Insert

Service name:	ara::rest::ogm::Object::Insert		
Type:	Member function	Member function	
Syntax:	bool ara::rest::c	<pre>bool ara::rest::ogm::Object::Insert(Pointer< Field ></pre>	
	&&f)	&&f)	
Function param:	f	field to insert	
Return value:	true if insertion was performed.		
Exceptions:	Implementation-define	Implementation-defined	
Header file:	ara/rest/ogm/object.h	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object		
Description:	Inserts a field into the object. If a field of the same name already exists, no insertion is performed. In this case the passed pointer to Field is not invalidated.		

Table 8.122: ara::rest::ogm::Object::Insert

8.12.19 Remove

Service name:	ara::rest::ogm::Object::Remove	
Type:	Member function	
Syntax:	Iterator ara::rest::ogm::Object::Remove(Iterator	
	iter)	
Function param:	iter	an iterator pointing to an element.
Return value:	an iterator pointing to the element following the one just removed.	



Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object	
Description:	Removes value from the set. Removes an element from the set. Removal	
	invalidates all iterators referencing the respectice element.	

Table 8.123: ara::rest::ogm::Object::Remove

[SWS_REST_02119] ara::rest::ogm::Object::Remove | Table 8.123 describes the interface ara::rest::ogm::Object::Remove.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.20 Release

Service name:	ara::rest::ogm::Object::Release		
Type:	Member function	Member function	
Syntax:	std::pair <iterat< th=""><th>or, Pointer<field> ></field></th></iterat<>	or, Pointer <field> ></field>	
	ara::rest::ogm::	Object::Release(Iterator iter)	
Function param:	iter	an iterator pointing to the element to be removed	
Return value:	a pair of the iterator pointing to the element following the one just deleted		
	and a pointer to the element		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/object.h		
Class:	ara::rest::ogm::Object		
Description:	Similar to Remove but does not destroy the removed element. Instead of		
	destroying the remove	ed element, ownership is passed back to the user	

Table 8.124: ara::rest::ogm::Object::Release

[SWS_REST_02120] ara::rest::ogm::Object::Release [Table 8.124 describes the interface ara::rest::ogm::Object::Release.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.21 Replace

Service name:	ara::rest::ogm::Object::Replace		
Type:	Member function		
Syntax:	Pointer <field></field>		
	ara::rest::ogm::Object::Replace(Iterator iter,		
	Pointer< Field > &&field)		
Function param:	iter an iterator pointing to the element to be replaced		
Function param:	field	field Field to replace the current value	
Return value:	a Pointer to the old element		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/object.h		
Class:	ara::rest::ogm::Object		



Description:	Replaces an element by a new one without the destroying the old one.
	Replaces a field without destroying it. Instead the replaced element is
	returned. Effectively, ownership of the old element is passed back to the
	user.

Table 8.125: ara::rest::ogm::Object::Replace

[SWS_REST_02121] ara::rest::ogm::Object::Replace [Table 8.125 describes the interface ara::rest::ogm::Object::Replace.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.22 Clear

Service name:	ara::rest::ogm::Object::Clear	
Type:	Member function	
Syntax:	<pre>void ara::rest::ogm::Object::Clear()</pre>	
Function param:	None	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object	
Description:	Removes all elements.	

Table 8.126: ara::rest::ogm::Object::Clear

[SWS_REST_02122] ara::rest::ogm::Object::Clear | Table 8.126 describes the interface ara::rest::ogm::Object::Clear.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.23 Make

Service name:	ara::rest::ogm::Object::Make	
Type:	Member function	
Syntax:	template <typename ts=""></typename>	
	static Pointer <se< th=""><th>elfType></th></se<>	elfType>
	ara::rest::ogm::Object::Make(Ts &&ts)	
Function param:	ts	constructor arguments forwarded to the constructor
		of this type
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object	
Description:	Creates a node of type	e SelfType.

Table 8.127: ara::rest::ogm::Object::Make



[SWS_REST_02123] ara::rest::ogm::Object::Make [Table 8.127 describes the interface ara::rest::ogm::Object::Make.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.24 Make

Service name:	ara::rest::ogm::Object::Make	
Type:	Member function	
Syntax:	template <typena< th=""><th>me Ts></th></typena<>	me Ts>
	static Pointer <s< th=""><th>elfType></th></s<>	elfType>
	ara::rest::ogm::	Object::Make(Allocator *alloc, Ts
	&&ts)	
Function param:	alloc an allocator to use to construct this node	
Function param:	ts	constructor arguments forwarded to the constructor
		of this type
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/object.h	
Class:	ara::rest::ogm::Object	
Description:	Creates a node of type	e SelfType.

Table 8.128: ara::rest::ogm::Object::Make

[SWS_REST_02124] ara::rest::ogm::Object::Make | Table 8.128 describes the interface ara::rest::ogm::Object::Make.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.12.25 Object

Service name:	ara::rest::ogm::Object::Object		
Type:	Member function		
Syntax:	template <typename ts=""></typename>		
	ara::rest::ogm::	ara::rest::ogm::Object::Object(Pointer< Ts >	
	&&fields)		
Function param:	fields Fields to be attached to this object		
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/object.h		
Class:	ara::rest::ogm::Object		
Description:	Constructs an Object.		

Table 8.129: ara::rest::ogm::Object::Object

[SWS_REST_02125] ara::rest::ogm::Object::Object [Table 8.129 describes the interface ara::rest::ogm::Object::Object.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.12.26 Object

Service name:	ara::rest::ogm::Object::Object		
Type:	Member function	Member function	
Syntax:	template <typename ts=""></typename>		
	ara::rest::ogm::	Object::Object(Allocator *alloc,	
	Pointer< Ts > &&fields)		
Function param:	alloc	an allocator	
Function param:	fields	fields Fields to be attached to this object	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/object.h		
Class:	ara::rest::ogm::Object		
Description:	Constructs an Object.		

Table 8.130: ara::rest::ogm::Object::Object

[SWS_REST_02126] ara::rest::ogm::Object::Object [Table 8.130 describes the interface ara::rest::ogm::Object::Object.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.13 ara::rest::ogm::Real

[SWS_REST_02127] [ara::rest::ogm::Real class shall be declared in the ara/rest/ogm/real.h header file:

```
class ara::rest::ogm::Real : public ara::rest::ogm::Value;
```

(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307)

8.13.1 SelfType

Name:	SelfType
Туре:	Member type alias
Syntax:	using ara::rest::ogm::Real::SelfType = Real
Header file:	ara/rest/ogm/real.h
Class:	ara::rest::ogm::Real
Description:	Its own type.

Table 8.131: ara::rest::ogm::Real::SelfType

[SWS_REST_02128] SelfType [Table 8.131 describes the type alias ara::rest::ogm::Real::SelfType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)



8.13.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Real::ParentType = Value</pre>
Header file:	ara/rest/ogm/real.h
Class:	ara::rest::ogm::Real
Description:	Type of its parent in the OGM type hierarchy.

Table 8.132: ara::rest::ogm::Real::ParentType

[SWS_REST_02129] ParentType [Table 8.132 describes the type alias ara::rest::ogm::Real::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.13.3 ValueType

Name:	ValueType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Real::ValueType = long double</pre>
Header file:	ara/rest/ogm/real.h
Class:	ara::rest::ogm::Real
Description:	Type of its corresponding C++ data type.

Table 8.133: ara::rest::ogm::Real::ValueType

[SWS_REST_02130] ValueType [Table 8.133 describes the type alias ara::rest::ogm::Real::ValueType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.13.4 GetParent

Service name:	ara::rest::ogm::Real::GetParent	
Type:	Member function	
Syntax:	Node* ara::rest::ogm::Real::GetParent()	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/real.h	
Class:	ara::rest::ogm::Real	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.134: ara::rest::ogm::Real::GetParent

[SWS_REST_02131] ara::rest::ogm::Real::GetParent [Table 8.134 describes the interface ara::rest::ogm::Real::GetParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.13.5 GetParent

Service name:	ara::rest::ogm::Real::GetParent
Type:	Member function
Syntax:	const Node* ara::rest::ogm::Real::GetParent() const
Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/real.h
Class:	ara::rest::ogm::Real
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.135: ara::rest::ogm::Real::GetParent

[SWS_REST_02132] ara::rest::ogm::Real::GetParent [Table 8.135 describes the interface ara::rest::ogm::Real::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.13.6 HasParent

Service name:	ara::rest::ogm::Real::HasParent
Type:	Member function
Syntax:	bool ara::rest::ogm::Real::HasParent() const
Function param:	None
Return value:	true if this node has a structural parent
Exceptions:	noexcept
Header file:	ara/rest/ogm/real.h
Class:	ara::rest::ogm::Real
Description:	Denotes whether this node has a structural parent.

Table 8.136: ara::rest::ogm::Real::HasParent

[SWS_REST_02133] ara::rest::ogm::Real::HasParent [Table 8.136 describes the interface ara::rest::ogm::Real::HasParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.13.7 GetValue

Service name:	ara::rest::ogm::Real::GetValue	
Type:	Member function	
Syntax:	<pre>ValueType ara::rest::ogm::Real::GetValue() const</pre>	
Function param:	None	
Return value:	a value of type ValueType	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/real.h	
Class:	ara::rest::ogm::Real	
Description:	Returns its value as a C++ data type.	



Table 8.137: ara::rest::ogm::Real::GetValue

8.13.8 SetValue

Service name:	ara::rest::ogm::Real::SetValue		
Type:	Member function	Member function	
Syntax:	<pre>void ara::rest::ogm::Real::SetValue(ValueType v)</pre>		
Function param:	V	a value	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/ogm/real.h		
Class:	ara::rest::ogm::Real		
Description:	Sets the current value from a C++ data type.		

Table 8.138: ara::rest::ogm::Real::SetValue

[SWS_REST_02135] ara::rest::ogm::Real::SetValue | Table 8.138 describes the interface ara::rest::ogm::Real::SetValue.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.13.9 Make

Service name:	ara::rest::ogm::Real::Make	
Type:	Member function	
Syntax:	template <typename ts=""></typename>	
	static Pointer <se< th=""><th>elfType></th></se<>	elfType>
	ara::rest::ogm::Real::Make(Ts &&ts)	
Function param:	ts	constructor arguments forwarded to the constructor
		of this type
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/real.h	
Class:	ara::rest::ogm::Real	
Description:	Creates a node of type	e SelfType.

Table 8.139: ara::rest::ogm::Real::Make

[SWS_REST_02136] ara::rest::ogm::Real::Make [Table 8.139 describes the interface ara::rest::ogm::Real::Make.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.13.10 Make

Service name:	ara::rest::ogm::Real::N	ara::rest::ogm::Real::Make	
Type:	Member function	Member function	
Syntax:	template <typena< th=""><th>me Ts></th></typena<>	me Ts>	
	static Pointer <s< th=""><th>elfType></th></s<>	elfType>	
	ara::rest::ogm:::	Real::Make(Allocator *alloc, Ts	
	&&ts)		
Function param:	alloc	an allocator to use to construct this node	
Function param:	ts	constructor arguments forwarded to the constructor	
		of this type	
Return value:	a pointer to a node of type SelfType		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/real.h		
Class:	ara::rest::ogm::Real		
Description:	Creates a node of type SelfType.		

Table 8.140: ara::rest::ogm::Real::Make

[SWS_REST_02137] ara::rest::ogm::Real::Make | Table 8.140 describes the interface ara::rest::ogm::Real::Make.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.13.11 Real

Service name:	ara::rest::ogm::Real::Real		
Type:	Member function		
Syntax:	ara::rest::ogm::1	ara::rest::ogm::Real::Real(ValueType	
	<pre>value=ValueType{})</pre>		
Function param:	value	an intial value	
Return value:	None		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/ogm/real.h		
Class:	ara::rest::ogm::Real		
Description:	Connstructs an Real.		

Table 8.141: ara::rest::ogm::Real::Real

8.14 ara::rest::ogm::String

[SWS_REST_02139] [ara::rest::ogm::String class shall be declared in the ara/rest/ogm/string.h header file:

class ara::rest::ogm::String : public ara::rest::ogm::Value;



(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307)

8.14.1 SelfType

Name:	SelfType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::String::SelfType = String</pre>
Header file:	ara/rest/ogm/string.h
Class:	ara::rest::ogm::String
Description:	Its own type.

Table 8.142: ara::rest::ogm::String::SelfType

[SWS_REST_02140] SelfType [Table 8.142 describes the type alias ara::rest::ogm::String::SelfType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.14.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::String::ParentType = Value</pre>
Header file:	ara/rest/ogm/string.h
Class:	ara::rest::ogm::String
Description:	Type of its parent in the OGM type hierarchy.

Table 8.143: ara::rest::ogm::String::ParentType

[SWS_REST_02141] ParentType | Table 8.143 describes the type alias ara::rest::ogm::String::ParentType.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.14.3 ValueType

Name:	ValueType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::String::ValueType =</pre>
	ara::core::StringView
Header file:	ara/rest/ogm/string.h
Class:	ara::rest::ogm::String
Description:	Type of its corresponding C++ data type.

Table 8.144: ara::rest::ogm::String::ValueType



[SWS_REST_02142] ValueType [Table 8.144 describes the type alias ara::rest::ogm::String::ValueType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.14.4 GetParent

Service name:	ara::rest::ogm::String::GetParent	
Type:	Member function	
Syntax:	Node* ara::rest::ogm::String::GetParent()	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/string.h	
Class:	ara::rest::ogm::String	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.145: ara::rest::ogm::String::GetParent

[SWS_REST_02143] ara::rest::ogm::String::GetParent | Table | 8.145 | describes the | interface | ara::rest::ogm::String::GetParent.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.14.5 GetParent

Service name:	ara::rest::ogm::String::GetParent	
Type:	Member function	
Syntax:	<pre>const Node* ara::rest::ogm::String::GetParent() const</pre>	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/string.h	
Class:	ara::rest::ogm::String	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.146: ara::rest::ogm::String::GetParent

[SWS_REST_02144] ara::rest::ogm::String::GetParent [Table 8.146 describes the interface ara::rest::ogm::String::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.14.6 HasParent

Service name:	ara::rest::ogm::String::HasParent	
Type:	Member function	
Syntax:	bool ara::rest::ogm::String::HasParent() const	



Function param:	None
Return value:	true if this node has a structural parent
Exceptions:	noexcept
Header file:	ara/rest/ogm/string.h
Class:	ara::rest::ogm::String
Description:	Denotes whether this node has a structural parent.

Table 8.147: ara::rest::ogm::String::HasParent

[SWS_REST_02145] ara::rest::ogm::String::HasParent [Table 8.147 describes the interface ara::rest::ogm::String::HasParent.](RS_CM_00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.14.7 GetValue

Service name:	ara::rest::ogm::String::GetValue
Type:	Member function
Syntax:	ValueType ara::rest::ogm::String::GetValue() const
Function param:	None
Return value:	a value of type ValueType
Exceptions:	Implementation-defined
Header file:	ara/rest/ogm/string.h
Class:	ara::rest::ogm::String
Description:	Returns its value as a C++ data type.

Table 8.148: ara::rest::ogm::String::GetValue

8.14.8 SetValue

Service name:	ara::rest::ogm::String::SetValue		
Type:	Member function	Member function	
Syntax:	<pre>void ara::rest::ogm::String::SetValue(const ValueType</pre>		
	&v)		
Function param:	V	a value	
Return value:	None		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/ogm/string.h		
Class:	ara::rest::ogm::String		
Description:	Sets the current value	Sets the current value from a C++ data type.	

Table 8.149: ara::rest::ogm::String::SetValue



8.14.9 Make

Service name:	ara::rest::ogm::String::Make	
Type:	Member function	
Syntax:	template <typena< th=""><th>me Ts></th></typena<>	me Ts>
	static Pointer <s< th=""><th>elfType></th></s<>	elfType>
	ara::rest::ogm::String::Make(Ts &&ts)	
Function param:	ts	constructor arguments forwarded to the constructor
		of this type
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/string.h	
Class:	ara::rest::ogm::String	
Description:	Creates a node of type SelfType.	

Table 8.150: ara::rest::ogm::String::Make

[SWS_REST_02148] ara::rest::ogm::String::Make [Table 8.150 describes the interface ara::rest::ogm::String::Make.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.14.10 Make

Service name:	ara::rest::ogm::String::Make	
Type:	Member function	
Syntax:	template <typename ts=""></typename>	
	static Pointer <se< th=""><th>elfType></th></se<>	elfType>
	ara::rest::ogm::String::Make(Allocator *alloc, Ts	
	&&ts)	
Function param:	alloc	an allocator to use to construct this node
Function param:	ts	constructor arguments forwarded to the constructor
		of this type
Return value:	a pointer to a node of type SelfType	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/string.h	
Class:	ara::rest::ogm::String	
Description:	Creates a node of type SelfType.	

Table 8.151: ara::rest::ogm::String::Make

[SWS_REST_02149] ara::rest::ogm::String::Make [Table 8.151 describes the interface ara::rest::ogm::String::Make.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.14.11 String

Service name:	ara::rest::ogm::String::String	
Type:	Member function	
Syntax:	ara::rest::ogm::String::String(ValueType	
	<pre>value=ValueType{})</pre>	
Function param:	value	an intial value
Return value:	None	
Exceptions:	Implementation-define	d
Header file:	ara/rest/ogm/string.h	
Class:	ara::rest::ogm::String	
Description:	Connstructs an String.	

Table 8.152: ara::rest::ogm::String::String

8.14.12 String

Service name:	ara::rest::ogm::String::String	
Type:	Member function	
Syntax:	ara::rest::ogm:::	String::String(Allocator *alloc,
	<pre>ValueType value=ValueType{})</pre>	
Function param:	alloc	an allocator
Function param:	value	an intial value
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/string.h	
Class:	ara::rest::ogm::String	
Description:	Connstructs an String.	

Table 8.153: ara::rest::ogm::String::String

8.15 ara::rest::ogm::Value

[SWS_REST_02152] [ara::rest::ogm::Value class shall be declared in the ara/rest/ogm/value.h header file:

class ara::rest::ogm::Value : public ara::rest::ogm::Node;

(RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307)



8.15.1 SelfType

Name:	SelfType
Type:	Member type alias
Syntax:	using ara::rest::ogm::Value::SelfType = Value
Header file:	ara/rest/ogm/value.h
Class:	ara::rest::ogm::Value
Description:	Its own type.

Table 8.154: ara::rest::ogm::Value::SelfType

[SWS_REST_02153] SelfType [Table 8.154 describes the type alias ara::rest::ogm::Value::SelfType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.15.2 ParentType

Name:	ParentType
Type:	Member type alias
Syntax:	<pre>using ara::rest::ogm::Value::ParentType = Node</pre>
Header file:	ara/rest/ogm/value.h
Class:	ara::rest::ogm::Value
Description:	Type of its parent in the OGM type hierarchy.

Table 8.155: ara::rest::ogm::Value::ParentType

[SWS_REST_02154] ParentType [Table 8.155 describes the type alias ara::rest::ogm::Value::ParentType.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307)

8.15.3 GetParent

Service name:	ara::rest::ogm::Value::GetParent	
Type:	Member function	
Syntax:	Node* ara::rest::ogm::Value::GetParent()	
Function param:	None	
Return value:	a pointer to its parent node	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/value.h	
Class:	ara::rest::ogm::Value	
Description:	Returns a (strongly-typed) pointer to its parent node.	

Table 8.156: ara::rest::ogm::Value::GetParent

[SWS_REST_02155] ara::rest::ogm::Value::GetParent [Table 8.156 describes the interface ara::rest::ogm::Value::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)



8.15.4 GetParent

Service name:	ara::rest::ogm::Value::GetParent
Type:	Member function
Syntax:	const Node* ara::rest::ogm::Value::GetParent() const
Function param:	None
Return value:	a pointer to its parent node
Exceptions:	noexcept
Header file:	ara/rest/ogm/value.h
Class:	ara::rest::ogm::Value
Description:	Returns a (strongly-typed) pointer to its parent node.

Table 8.157: ara::rest::ogm::Value::GetParent

[SWS_REST_02156] ara::rest::ogm::Value::GetParent [Table 8.157 describes the interface ara::rest::ogm::Value::GetParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.15.5 HasParent

Service name:	ara::rest::ogm::Value::HasParent	
Type:	Member function	
Syntax:	bool ara::rest::ogm::Value::HasParent() const	
Function param:	None	
Return value:	true if this node has a structural parent	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/value.h	
Class:	ara::rest::ogm::Value	
Description:	Denotes whether this node has a structural parent.	

Table 8.158: ara::rest::ogm::Value::HasParent

[SWS_REST_02157] ara::rest::ogm::Value::HasParent [Table 8.158 describes the interface ara::rest::ogm::Value::HasParent.](RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.15.6 Value

Service name:	ara::rest::ogm::Value::Value	
Type:	Member function	
Syntax:	ara::rest::ogm::Value::Value()	
Function param:	None	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/value.h	
Class:	ara::rest::ogm::Value	
Description:	Constructs a node. Inaccessible to the user	



Table 8.159: ara::rest::ogm::Value::Value

8.16 ara::rest::Pattern

[SWS_REST_02159] [ara::rest::Pattern class shall be declared in the ara/rest/routing.h header file:

class ara::rest::Pattern;

(RS CM 00300, RS CM 00309)

8.16.1 Pattern

Service name:	ara::rest::Pattern::Pattern		
Type:	Member function	Member function	
Syntax:	ara::rest::Pattern::Pattern(StringView pat)		
Function param:	pat	a pattern string	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/routing.h		
Class:	ara::rest::Pattern		
Description:	Constructs a Pattern.		

Table 8.160: ara::rest::Pattern::Pattern

[SWS_REST_02160] ara::rest::Pattern::Pattern [Table 8.160 describes the interface ara::rest::Pattern:|(RS_CM_00300, RS_CM_00309)

8.16.2 operator==

Service name:	ara::rest::Pattern::operator==		
Type:	Non-member funct:	Non-member function	
Syntax:	friend bool operator == (const Pattern &a, const		
	Pattern &b)		
Function param:	a	a Pattern	
Function param:	b	b a Patern	
Return value:	true if arguments compare equal		
Exceptions:	noexcept		
Header file:	ara/rest/routing.h		
Namespace:	ara::rest::Pattern		



Description:	Compares patterns for equality.
--------------	---------------------------------

Table 8.161: ara::rest::Pattern::operator==

[SWS_REST_02161] ara::rest::Pattern::operator== [Table 8.161 describes the interface ara::rest::Pattern::operator==.|(RS_CM_00300, RS_CM_00309)|

8.16.3 operator!=

Service name:	ara::rest::Pattern::operator!=		
Type:	Non-member funct	Non-member function	
Syntax:	friend bool oper	friend bool operator!=(const Pattern &a, const	
	Pattern &b)		
Function param:	а	a Pattern	
Function param:	b	a Patern	
Return value:	true if arguments compare inequal		
Exceptions:	noexcept		
Header file:	ara/rest/routing.h		
Namespace:	ara::rest::Pattern		
Description:	Compares patterns for inequality.		

Table 8.162: ara::rest::Pattern::operator!=

[SWS_REST_02162] ara::rest::Pattern::operator!= [Table 8.162 describes the interface ara::rest::Pattern::operator!=.|(RS CM 00300, RS CM 00309)

8.16.4 operator<

Service name:	ara::rest::Pattern::operator<			
Type:	Non-member funct	Non-member function		
Syntax:	friend bool oper	ator<(const Pattern &a, const Pattern		
	&b)			
Function param:	а	a Pattern		
Function param:	b a Patern			
Return value:	true if 'a' is less-than 'b' accoring to Pattern order critera.			
Exceptions:	noexcept			
Header file:	ara/rest/routing.h			
Namespace:	ara::rest::Pattern			
Description:	Compares patterns for order.			

Table 8.163: ara::rest::Pattern::operator<

[SWS_REST_02163] ara::rest::Pattern::operator< [Table 8.163 describes the interface ara::rest::Pattern::operator<.|(RS_CM_00300, RS_CM_00309)



8.17 ara::rest::ReplyHeader

[SWS_REST_02164] [ara::rest::ReplyHeader class shall be declared in the ara/rest/header.h header file:

class ara::rest::ReplyHeader;

(RS_CM_00300)

8.17.1 GetStatus

Service name:	ara::rest::ReplyHeader::GetStatus	
Type:	Member function	
Syntax:	<pre>int ara::rest::ReplyHeader::GetStatus() const</pre>	
Function param:	None	
Return value:	a status code	
Exceptions:	noexcept	
Header file:	ara/rest/header.h	
Class:	ara::rest::ReplyHeader	
Description:	Returns the current message status code. Status codes are binding- specific	

Table 8.164: ara::rest::ReplyHeader::GetStatus

[SWS_REST_02165] ara::rest::ReplyHeader::GetStatus [Table 8.164 describes the interface ara::rest::ReplyHeader::GetStatus.] (RS CM 00300)

8.17.2 SetStatus

Service name:	ara::rest::ReplyHeader::SetStatus		
Type:	Member function		
Syntax:	<pre>void ara::rest::ReplyHeader::SetStatus(int code)</pre>		
	const		
Function param:	code an integral status code		
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Sets a message status	Sets a message status code. Status codes are binding-specific	

Table 8.165: ara::rest::ReplyHeader::SetStatus

[SWS_REST_02166] ara::rest::ReplyHeader::SetStatus [Table 8.165 describes the interface ara::rest::ReplyHeader::SetStatus.|(RS_CM_00300)

8.17.3 GetUri



Service name:	ara::rest::ReplyHeader::GetUri		
Type:	Member function		
Syntax:	const Uri& ara::rest::ReplyHeader::GetUri() const		
Function param:	None		
Return value:	a Uri		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Returns a Uri. It is binding-specific how Uri map to the transport protocol		
	format.		

Table 8.166: ara::rest::ReplyHeader::GetUri

[SWS_REST_02167] ara::rest::ReplyHeader::GetUri [Table 8.166 describes the interface ara::rest::ReplyHeader::GetUri.] (RS_CM_00300, RS_CM_00304)

8.17.4 SetUri

Service name:	ara::rest::ReplyHeader::SetUri		
Type:	Member function		
Syntax:	void ara::rest::	<pre>void ara::rest::ReplyHeader::SetUri(const Uri &uri)</pre>	
Function param:	uri	a Uri	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Allows to set a Uri. It is binding-specific how Uri map to the transport protocol format.		

Table 8.167: ara::rest::ReplyHeader::SetUri

[SWS_REST_02168] ara::rest::ReplyHeader::SetUri [Table 8.167 describes the interface ara::rest::ReplyHeader::SetUri.](RS_CM_00300, RS_CM_00304)

8.17.5 HasField

Service name:	ara::rest::ReplyHeader::HasField		
Type:	Member function		
Syntax:	bool ara::rest::1	ReplyHeader::HasField(const	
	StringView &key) const		
Function param:	key	key of the field.	
Return value:	true if the field exists		
Exceptions:	Implementation-defined		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Denotes whether a fie	Denotes whether a field exists	

Table 8.168: ara::rest::ReplyHeader::HasField



[SWS_REST_02489] ara::rest::ReplyHeader::HasField [Table 8.168 describes the interface ara::rest::ReplyHeader::HasField.](RS_CM_00300, RS CM 00304)

8.17.6 InsertField

Service name:	ara::rest::ReplyHeader::InsertField	
Type:	Member function	
Syntax:	bool ara::rest::	ReplyHeader::InsertField(const
	StringView &key, const StringView &value)	
Function param:	key key of the field.	
Function param:	value value of the field.	
Return value:	true if a new field has been inserted	
Exceptions:	Implementation-defined	
Header file:	ara/rest/header.h	
Class:	ara::rest::ReplyHeader	
Description:	Inserts a field if it does	s not exist

Table 8.169: ara::rest::ReplyHeader::InsertField

[SWS_REST_02490] ara::rest::ReplyHeader::InsertField [Table 8.169 describes the interface ara::rest::ReplyHeader::InsertField.](RS_CM_00300, RS_CM_00304)

8.17.7 EraseField

Service name:	ara::rest::ReplyHeader::EraseField		
Type:	Member function		
Syntax:	bool ara::rest::	bool ara::rest::ReplyHeader::EraseField(const	
	StringView &key) noexept		
Function param:	key key of the field to be erased.		
Return value:	true if field has been erased otherwise false		
Exceptions:	noexept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Erases a field from the	e header	

Table 8.170: ara::rest::ReplyHeader::EraseField

[SWS_REST_02492] ara::rest::ReplyHeader::EraseField [Table 8.170 describes the interface ara::rest::ReplyHeader::EraseField.](RS_CM_00300, RS_CM_00304)

8.17.8 GetField



Service name:	ara::rest::ReplyHeader::GetField		
Type:	Member function	Member function	
Syntax:	StringView ara::rest::ReplyHeader::GetField(const		
	StringView &key)		
Function param:	key key of the field to be accessed.		
Return value:	StringView to the value of the field		
Exceptions:	std::invalid_argument if key does not exist		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Accesses a field value)	

Table 8.171: ara::rest::ReplyHeader::GetField

[SWS_REST_02493] ara::rest::ReplyHeader::GetField [Table 8.171 describes the interface ara::rest::ReplyHeader::GetField.](RS_CM_00300, RS CM 00304)

8.17.9 SetField

Service name:	ara::rest::ReplyHeader::SetField		
Type:	Member function	Member function	
Syntax:	void ara::rest::	ReplyHeader::SetField(const	
	StringView &key,	StringView &key, const StringView &value) noexcept	
Function param:	key key of the field to be set.		
Function param:	value value of the field to be set.		
Return value:	void		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Sets a fields value. If t	Sets a fields value. If field does not exist, it is inserted.	

Table 8.172: ara::rest::ReplyHeader::SetField

[SWS_REST_02494] ara::rest::ReplyHeader::SetField [Table 8.172 describes the interface ara::rest::ReplyHeader::SetField.](RS_CM_00300, RS_CM_00304)

8.17.10 NumFields

Service name:	ara::rest::ReplyHeader::NumFields		
Type:	Member function		
Syntax:	<pre>std::size_t ara::rest::ReplyHeader::NumFields() const</pre>		
	noexcept		
Return value:	the number of fields.		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		



Description:	Returns the number of fields in this header.
--------------	--

Table 8.173: ara::rest::ReplyHeader::NumFields

[SWS_REST_02496] ara::rest::ReplyHeader::NumFields [Table 8.173 describes the interface ara::rest::ReplyHeader::NumFields.](RS_CM_00300, RS_CM_00304)

8.17.11 ClearFields

Service name:	ara::rest::ReplyHeader::ClearFields		
Type:	Member function		
Syntax:	<pre>void ara::rest::ReplyHeader::ClearFields() noexcept</pre>		
Return value:	void		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Erases all fields in this header.		

Table 8.174: ara::rest::ReplyHeader::ClearFields

[SWS_REST_02497] ara::rest::ReplyHeader::ClearFields [Table 8.174 describes the interface ara::rest::ReplyHeader::ClearFields.](RS_CM_00300, RS_CM_00304)

8.17.12 FieldIteratorRange

Name:	FieldIteratorRange	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::ReplyHeader::FieldIteratorRange =</pre>	
	ara::rest::IteratorRange <unspecified_iterator_type></unspecified_iterator_type>	
Header file:	ara/rest/header.h	
Class:	ara::rest::ReplyHeader	
Description:	! Iterator range of header fields	

Table 8.175: ara::rest::ReplyHeader::FieldIteratorRange

[SWS_REST_02515] FieldIteratorRange [Table 8.175 describes the type alias ara::rest::ReplyHeader::FieldIteratorRange.](RS_CM_00300)

8.17.13 ConstFieldIteratorRange

Name:	ConstFieldIteratorRange	
Type:	Member type alias	



Syntax:	<pre>using ara::rest::ReplyHeader::ConstFieldIteratorRange =</pre>		
	ara::rest::IteratorRange <unspecified_iterator_type></unspecified_iterator_type>		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	! Const iterator range of header fields		

Table 8.176: ara::rest::ReplyHeader::ConstFieldIteratorRange

[SWS_REST_02516] ConstFieldIteratorRange [Table 8.176 describes the type alias ara::rest::ReplyHeader::ConstFieldIteratorRange.|(RS_CM_00300)

8.17.14 FindField

Service name:	ara::rest::ReplyHeader::FindField		
Type:	Member function		
Syntax:	FieldIteratorRange::Iterator		
	ara::rest::Reply	ara::rest::ReplyHeader::FindField(StringView key)	
	noexcept		
Function param:	key key of the field to be found.		
Return value:	an iterator to field		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Returns an iterator to	a field.	

Table 8.177: ara::rest::ReplyHeader::FindField

[SWS_REST_02517] ara::rest::ReplyHeader::FindField [Table 8.177 describes the interface ara::rest::ReplyHeader::FindField.](RS_CM_00300, RS_CM_00304)

Service name:	ara::rest::ReplyHeader::FindField		
Type:	Member function	Member function	
Syntax:	ConstFieldIterat	ConstFieldIteratorRange::Iterator	
	ara::rest::Reply	ara::rest::ReplyHeader::FindField(StringView key)	
	const noexcept		
Function param:	key key of the field to be found.		
Return value:	an iterator to field		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::ReplyHeader		
Description:	Returns an iterator to	a field.	

Table 8.178: ara::rest::ReplyHeader::FindField const

[SWS_REST_02518] ara::rest::ReplyHeader::FindField [Table 8.178 describes the interface ara::rest::ReplyHeader::FindField.](RS_CM_00300, RS_CM_00304)



8.17.15 GetFields

Service name:	ara::rest::ReplyHeader::GetFields	
Type:	Member function	
Syntax:	FieldIteratorRange::Iterator	
	ara::rest::ReplyHeader::GetFields() noexcept	
Return value:	an IteratorRange of header fields	
Exceptions:	noexcept	
Header file:	ara/rest/header.h	
Class:	ara::rest::ReplyHeader	
Description:	Returns a range of header fields.	

Table 8.179: ara::rest::ReplyHeader::GetFields

[SWS_REST_02519] ara::rest::ReplyHeader::GetFields [Table 8.179 describes the interface ara::rest::ReplyHeader::GetFields.](RS_CM_00300, RS_CM_00304)

Service name:	ara::rest::ReplyHeader::GetFields	
Type:	Member function	
Syntax:	ConstFieldIteratorRange::Iterator	
	ara::rest::ReplyHeader::GetFields() const noexcept	
Return value:	an IteratorRange of header fields	
Exceptions:	noexcept	
Header file:	ara/rest/header.h	
Class:	ara::rest::ReplyHeader	
Description:	Returns a range of header fields.	

Table 8.180: ara::rest::ReplyHeader::GetFields const

[SWS_REST_02520] ara::rest::ReplyHeader::GetFields [Table 8.180 describes the interface ara::rest::ReplyHeader::GetFields.](RS_CM_00300, RS_CM_00304)

8.18 ara::rest::Reply

[SWS_REST_02169] [ara::rest::Reply class shall be declared in the ara/rest/client.h header file:

```
class ara::rest::Reply;
```

(RS_CM_00300)

8.18.1 Reply

Service name:	ara::rest::Reply::Reply	
Type:	Member function	



Syntax:	ara::rest::Reply::Reply(const Reply &)=delete	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Reply	
Description:	Non-copyable.	

Table 8.181: ara::rest::Reply::Reply

[SWS_REST_02170] ara::rest::Reply::Reply [Table 8.181 describes the interface ara::rest::Reply::Reply.|(RS_CM_00300)

8.18.2 operator=

Service name:	ara::rest::Reply::operator=	
Type:	Member function	
Syntax:	Reply& ara::rest::Reply::operator=(const Reply	
	&)=delete	
Return value:	a value of type Reply &	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Reply	
Description:	Non-copy-assignable.	

Table 8.182: ara::rest::Reply::operator=

[SWS_REST_02171] ara::rest::Reply::operator= [Table 8.182 describes the interface ara::rest::Reply::operator=.|(RS_CM_00300)

8.18.3 GetHeader

Service name:	ara::rest::Reply::GetHeader	
Type:	Member function	
Syntax:	ReplyHeader const& ara::rest::Reply::GetHeader()	
	const	
Function param:	None	
Return value:	a reference to a ReplyHeader	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Reply	
Description:	Obtains the message header. Requests the message header from the	
	endpoint. Accessing the message header is always synchronous.	

Table 8.183: ara::rest::Reply::GetHeader

[SWS_REST_02172] ara::rest::Reply::GetHeader [Table 8.183 describes the interface ara::rest::Reply::GetHeader.](RS_CM_00300)



8.18.4 GetObject

Service name:	ara::rest::Reply::GetObject	
Type:	Member function	
Syntax:	Task <ogm::object const&=""></ogm::object>	
	ara::rest::Reply::GetObject() const	
Function param:	None	
Return value:	returns a task waiting for the message payload to be received.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Reply	
Description:	Obtains the reply message payload.	

Table 8.184: ara::rest::Reply::GetObject

[SWS_REST_02173] ara::rest::Reply::GetObject [Table 8.184 describes the interface ara::rest::Reply::GetObject.](RS_CM_00300)

8.18.5 ReleaseObject

Service name:	ara::rest::Reply::ReleaseObject	
Type:	Member function	
Syntax:	Task <pointer<ogm::object> ></pointer<ogm::object>	
	ara::rest::Reply::ReleaseObject()	
Function param:	None	
Return value:	returns a task waiting for the message payload to be received.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Reply	
Description:	Obtains the reply message payload.	

Table 8.185: ara::rest::Reply::ReleaseObject

[SWS_REST_02174] ara::rest::Reply::ReleaseObject [Table 8.185 describes the interface ara::rest::Reply::ReleaseObject.](RS_CM_00300)

8.18.6 ReleaseBinary

Service name:	ara::rest::Reply::ReleaseBinary	
Type:	Member function	
Syntax:	Task <pointer<ara::core::string></pointer<ara::core::string>	
	ara::rest::Reply::ReleaseBinary()	
Function param:	None	
Return value:	returns a task waiting for the binary message payload to be received.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Reply	
Description:	Obtains the reply binary payload.	



Table 8.186: ara::rest::Reply::ReleaseBinary

[SWS_REST_02973] ara::rest::Reply::ReleaseBinary [Table 8.186 describes the interface ara::rest::Reply::ReleaseBinary.|(RS_CM_00300)

8.19 ara::rest::RequestHeader

[SWS_REST_02175] [ara::rest::RequestHeader class shall be declared in the ara/rest/header.h header file:

class ara::rest::RequestHeader;

(RS_CM_00300)

8.19.1 GetMethod

Service name:	ara::rest::RequestHeader::GetMethod	
Type:	Member function	
Syntax:	RequestMethod ara::rest::RequestHeader::GetMethod()	
	const	
Function param:	None	
Return value:	a request method	
Exceptions:	noexcept	
Header file:	ara/rest/header.h	
Class:	ara::rest::RequestHeader	
Description:	Returns the request method.	

Table 8.187: ara::rest::RequestHeader::GetMethod

[SWS_REST_02176] ara::rest::RequestHeader::GetMethod [Table 8.187 describes the interface ara::rest::RequestHeader::GetMethod.|(RS_CM_00300)

8.19.2 SetMethod

Service name:	ara::rest::RequestHeader::SetMethod	
Type:	Member function	
Syntax:	void	
	ara::rest::RequestHeader::SetMethod(RequestMethod	
	met)	
Function param:	met	a RequestMethod
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/header.h	
Class:	ara::rest::RequestHeader	



Description:	Allows to set the request method.
--------------	-----------------------------------

Table 8.188: ara::rest::RequestHeader::SetMethod

[SWS_REST_02177] ara::rest::RequestHeader::SetMethod [Table 8.188 describes the interface ara::rest::RequestHeader::SetMethod.|(RS CM 00300)

8.19.3 GetUri

Service name:	ara::rest::RequestHeader::GetUri
Type:	Member function
Syntax:	const Uri& ara::rest::RequestHeader::GetUri() const
Function param:	None
Return value:	a Uri
Exceptions:	noexcept
Header file:	ara/rest/header.h
Class:	ara::rest::RequestHeader
Description:	Returns a Uri.

Table 8.189: ara::rest::RequestHeader::GetUri

[SWS_REST_02178] ara::rest::RequestHeader::GetUri [Table 8.189 describes the interface ara::rest::RequestHeader::GetUri.](RS_CM_00300, RS_CM_00304)

8.19.4 **SetUri**

Service name:	ara::rest::RequestHeader::SetUri			
Type:	Member function	Member function		
Syntax:	<pre>void ara::rest::RequestHeader::SetUri(const Uri &uri)</pre>			
Function param:	uri a Uri			
Return value:	None			
Exceptions:	Implementation-defined			
Header file:	ara/rest/header.h			
Class:	ara::rest::RequestHeader			
Description:	Allows to set a Uri.			

Table 8.190: ara::rest::RequestHeader::SetUri

[SWS_REST_02179] ara::rest::RequestHeader::SetUri [Table 8.190 describes the interface ara::rest::RequestHeader::SetUri.](RS_CM_00300, RS_CM_00304)

8.19.5 HasField



Service name:	ara::rest::RequestHea	der::HasField	
Type:	Member function		
Syntax:	bool ara::rest::	bool ara::rest::RequestHeader::HasField(const	
	StringView &key) const		
Function param:	key	key of the field.	
Return value:	true if the field exists		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Denotes whether a fie	ld exists	

Table 8.191: ara::rest::RequestHeader::HasField

[SWS_REST_02498] ara::rest::RequestHeader::HasField [Table 8.191 describes the interface ara::rest::RequestHeader::HasField.](RS_CM_00300, RS_CM_00304)

8.19.6 InsertField

Service name:	ara::rest::RequestHeader::InsertField		
Type:	Member function	Member function	
Syntax:	bool ara::rest::	RequestHeader::InsertField(const	
	StringView &key,	StringView &key, const Stringview &value)	
Function param:	key key of the field.		
Function param:	value value of the field.		
Return value:	true if a new field has been inserted		
Exceptions:	Implementation-defined		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Inserts a field if it does not exist		

Table 8.192: ara::rest::RequestHeader::InsertField

[SWS_REST_02499] ara::rest::RequestHeader::InsertField [Table 8.192 describes the interface ara::rest::RequestHeader::InsertField.](RS_CM_00300, RS_CM_00304)

8.19.7 EraseField

Service name:	ara::rest::RequestHeader::EraseField	
Type:	Member function	
Syntax:	bool ara::rest::RequestHeader::EraseField(const	
	StringView &key) noexept	
Function param:	key	key of the field to be erased.
Return value:	true if field has been erased otherwise false	
Exceptions:	noexept	
Header file:	ara/rest/header.h	



Class:	ara::rest::RequestHeader	
Description:	Erases a field from the header	

Table 8.193: ara::rest::RequestHeader::EraseField

[SWS_REST_02501] ara::rest::RequestHeader::EraseField [Table 8.193 describes the interface ara::rest::RequestHeader::EraseField.](RS_CM_00300, RS_CM_00304)

8.19.8 GetField

Service name:	ara::rest::RequestHea	ader::GetField	
Type:	Member function	Member function	
Syntax:	StringView ara::rest::RequestHeader::GetField(const		
	StringView &key)		
Function param:	key key of the field to be accessed.		
Return value:	StringView to the value of the field		
Exceptions:	std::invalid_argument if key does not exist		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Accesses a field value	9	

Table 8.194: ara::rest::RequestHeader::GetField

[SWS_REST_02502] ara::rest::RequestHeader::GetField [Table 8.194 describes] the interface ara::rest::RequestHeader::GetField.](RS_CM_00300, RS_CM_00304)

8.19.9 SetField

Service name:	ara::rest::RequestHeader::SetField		
Type:	Member function	Member function	
Syntax:	void ara::rest::	RequestHeader::SetField(const	
	StringView &key, const StringView &value) noexcept		
Function param:	key key of the field to be set.		
Function param:	value value of the field to be set.		
Return value:	void		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Sets a fields value. If field does not exist, it is inserted.		

Table 8.195: ara::rest::RequestHeader::SetField

[SWS_REST_02503] ara::rest::RequestHeader::SetField [Table 8.195 describes the interface ara::rest::RequestHeader::SetField.](RS_CM_00300, RS_CM_00304)



8.19.10 NumFields

Service name:	ara::rest::RequestHeader::NumFields
Type:	Member function
Syntax:	<pre>std::size_t ara::rest::RequestHeader::NumFields()</pre>
	const noexcept
Return value:	the number of fields.
Exceptions:	noexcept
Header file:	ara/rest/header.h
Class:	ara::rest::RequestHeader
Description:	Returns the number of fields in this header.

Table 8.196: ara::rest::RequestHeader::NumFields

[SWS_REST_02505] ara::rest::RequestHeader::NumFields [Table 8.196 describes the interface ara::rest::RequestHeader::NumFields.](RS_CM_00300, RS_CM_00304)

8.19.11 ClearFields

Service name:	ara::rest::RequestHeader::ClearFields
Type:	Member function
Syntax:	void ara::rest::RequestHeader::ClearFields() noexcept
Return value:	void
Exceptions:	noexcept
Header file:	ara/rest/header.h
Class:	ara::rest::RequestHeader
Description:	Erases all fields in this header.

Table 8.197: ara::rest::RequestHeader::ClearFields

[SWS_REST_02506] ara::rest::RequestHeader::ClearFields [Table 8.197 describes the interface ara::rest::RequestHeader::ClearFields.] (RS_CM_00300, RS_CM_00304)

8.19.12 FieldIteratorRange

Name:	FieldIteratorRange	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::RequestHeader::FieldIteratorRange =</pre>	
	ara::rest::IteratorRange <unspecified_iterator_type></unspecified_iterator_type>	
Header file:	ara/rest/header.h	
Class:	ara::rest::RequestHeader	
Description:	! Iterator range of header fields	

Table 8.198: ara::rest::RequestHeader::FieldIteratorRange



[SWS_REST_02528] FieldIteratorRange [Table 8.198 describes the type alias ara::rest::RequestHeader::FieldIteratorRange.] (RS_CM_00300)

8.19.13 ConstFieldIteratorRange

Name:	ConstFieldIteratorRange	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::RequestHeader::ConstFieldIteratorRange =</pre>	
	ara::rest::IteratorRange <unspecified_iterator_type></unspecified_iterator_type>	
Header file:	ara/rest/header.h	
Class:	ara::rest::RequestHeader	
Description:	! Const iterator range of header fields	

Table 8.199: ara::rest::RequestHeader::ConstFieldIteratorRange

[SWS_REST_02529] ConstFieldIteratorRange [Table 8.199 describes the type alias ara::rest::RequestHeader::ConstFieldIteratorRange.|(RS_CM_00300)

8.19.14 FindField

Service name:	ara::rest::RequestHeader::FindField		
Type:	Member function		
Syntax:	FieldIteratorRange::Iterator		
	ara::rest::RequestHeader::FindField(const StringView		
	& key) noexcept		
Function param:	key	key of the field to be found.	
Return value:	an iterator to field		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Returns an iterator to a field.		

Table 8.200: ara::rest::RequestHeader::FindField

[SWS_REST_02511] ara::rest::RequestHeader::FindField [Table 8.200 describes the interface ara::rest::RequestHeader::FindField.](RS_CM_00300, RS_CM_00304)

Service name:	ara::rest::RequestHeader::FindField		
Type:	Member function		
Syntax:	ConstFieldIteratorRange::Iterator		
	ara::rest::RequestHeader::FindField(const StringView		
	& key) const noexcept		
Function param:	key	key of the field to be found.	
Return value:	an iterator to field		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		



Description:	Returns an iterator to a field.
--------------	---------------------------------

Table 8.201: ara::rest::RequestHeader::FindField const

[SWS_REST_02512] ara::rest::RequestHeader::FindField [Table 8.201 describes the interface ara::rest::RequestHeader::FindField.](RS_CM_00300, RS_CM_00304)

8.19.15 GetFields

Service name:	ara::rest::RequestHeader::GetFields	
Type:	Member function	
Syntax:	FieldIteratorRange::Iterator	
	ara::rest::RequestHeader::GetFields() noexcept	
Return value:	an IteratorRange of header fields	
Exceptions:	noexcept	
Header file:	ara/rest/header.h	
Class:	ara::rest::RequestHeader	
Description:	Returns a range of header fields.	

Table 8.202: ara::rest::RequestHeader::GetFields

[SWS_REST_02513] ara::rest::RequestHeader::GetFields [Table 8.202 describes the interface ara::rest::RequestHeader::GetFields.](RS_CM_00300, RS_CM_00304)

Service name:	ara::rest::RequestHeader::GetFields		
Type:	Member function		
Syntax:	ConstFieldIteratorRange::Iterator		
	ara::rest::RequestHeader::GetFields() const noexcept		
Return value:	an IteratorRange of header fields		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Returns a range of header fields.		

Table 8.203: ara::rest::RequestHeader::GetFields const

[SWS_REST_02514] ara::rest::RequestHeader::GetFields [Table 8.203 describes the interface ara::rest::RequestHeader::GetFields.](RS_CM_00300, RS_CM_00304)

8.19.16 GetStatus

Service name:	ara::rest::RequestHeader::GetStatus	
Type:	Member function	



Syntax:	<pre>int ara::rest::RequestHeader::GetStatus()</pre>		
Return value:	a status code.		
Exceptions:	Implementation-defined		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Returns the current message status code. The status codes are binding- specific.		

Table 8.204: ara::rest::RequestHeader::GetStatus

[SWS_REST_02507] ara::rest::RequestHeader::GetStatus [Table 8.204 describes the interface ara::rest::RequestHeader::GetStatus. Status codes are issued by a server in response to a client's request made to the server.](RS_CM_00300, RS_CM_00304)

8.19.17 **SetStatus**

Service name:	ara::rest::RequestHeader::SetStatus		
Type:	Member function	Member function	
Syntax:	void ara::rest::RequestHeader::SetStatus(int code)		
	const		
Function param:	code	an integral status code	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/header.h		
Class:	ara::rest::RequestHeader		
Description:	Sets a message status code. Status codes are binding-specific		

Table 8.205: ara::rest::RequestHeader::SetStatus

[SWS_REST_02508] ara::rest::RequestHeader::SetStatus [Table 8.205 describes the interface ara::rest::RequestHeader::SetStatus.|(RS_CM_00300)

8.20 ara::rest::Request

[SWS_REST_02180] [ara::rest::Request class shall be declared in the ara/rest/client.h header file:

class ara::rest::Request;

(RS CM 00300)

8.20.1 Request

Service name:	ara::rest::Request::Request



Type:	Member function		
Syntax:	ara::rest::Request::Request(const Request &) = delete		
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/client.h		
Class:	ara::rest::Request		
Description:	Non-copyable.		

Table 8.206: ara::rest::Request::Request

[SWS_REST_02181] ara::rest::Request::Request [Table 8.206 describes the interface ara::rest::Request::Request.] (RS_CM_00300)

8.20.2 operator=

Service name:	ara::rest::Request::operator=		
Type:	Member function		
Syntax:	Request& ara::rest::Request::operator=(const Request		
	&)=delete		
Return value:	a value of type Request &		
Exceptions:	Implementation-defined		
Header file:	ara/rest/client.h		
Class:	ara::rest::Request		
Description:	Non-copy-assignable.		

Table 8.207: ara::rest::Request::operator=

[SWS_REST_02182] ara::rest::Request::operator= | Table 8.207 describes the interface ara::rest::Request::operator=.|(RS CM 00300)

8.20.3 Request

Service name:	ara::rest::Request::Request		
Type:	Member function	Member function	
Syntax:	ara::rest::Request::Request(RequestMethod met, const		
	Uri &uri)		
Function param:	met	one of RequestMethod	
Function param:	uri	a Uri	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/client.h		
Class:	ara::rest::Request		
Description:	Constructs a Request.		

Table 8.208: ara::rest::Request::Request



[SWS_REST_02183] ara::rest::Request::Request [Table 8.208 describes the interface ara::rest::Request::Request.](RS_CM_00300)

8.20.4 Request

Service name:	ara::rest::Request::Request	
Type:	Member function	
Syntax:	ara::rest::Request::Request(RequestMethod met, Uri	
	&&uri)	
Function param:	met	one of RequestMethod
Function param:	uri	a Uri
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Request	
Description:	Constructs a Request.	

Table 8.209: ara::rest::Request::Request

[SWS_REST_02184] ara::rest::Request::Request | Table 8.209 describes the interface ara::rest::Request::Request.|(RS_CM_00300)

8.20.5 Request

Service name:	ara::rest::Request::Request	
Type:	Member function	
Syntax:	ara::rest::Request::Request(RequestMethod met, const	
	Uri &uri, const Pointer< ogm::Object > &obj)	
Function param:	met	one of RequestMethod
Function param:	uri	a Uri
Function param:	obj	data payload of request message
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Request	
Description:	Constructs a Request.	

Table 8.210: ara::rest::Request::Request

[SWS_REST_02185] ara::rest::Request::Request [Table 8.210 describes the interface ara::rest::Request:: (RS_CM_00300)

8.20.6 Request

Service name:	ara::rest::Request::Request	
Type:	Member function	



Syntax:	ara::rest::Request::Request(RequestMethod met, const	
	Uri &uri, Pointer< ogm::Object > &&obj)	
Function param:	met	one of RequestMethod
Function param:	uri	a Uri
Function param:	obj	data payload of request message
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Request	
Description:	Constructs a Request.	

Table 8.211: ara::rest::Request::Request

[SWS_REST_02186] ara::rest::Request::Request | Table 8.211 describes the interface ara::rest::Request::Request.] (RS_CM_00300)

8.20.7 Request

Service name:	ara::rest::Request::Request		
Type:	Member function		
Syntax:	ara::rest::Reque	ara::rest::Request::Request(RequestMethod met, Uri	
	&&uri, const Poi	&&uri, const Pointer< ogm::Object > &obj)	
Function param:	met	one of RequestMethod	
Function param:	uri	a Uri	
Function param:	obj	data payload of request message	
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/client.h		
Class:	ara::rest::Request		
Description:	Constructs a Request.		

Table 8.212: ara::rest::Request::Request

[SWS_REST_02187] ara::rest::Request::Request [Table 8.212 describes the interface ara::rest::Request::Request.] (RS_CM_00300)

8.20.8 Request

Service name:	ara::rest::Request::Request	
Type:	Member function	
Syntax:	ara::rest::Request::Request(RequestMethod met, Uri	
	&&uri, Pointer< ogm::Object > &&obj)	
Function param:	met	one of RequestMethod
Function param:	uri	a Uri
Function param:	obj	data payload of request message
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	



Class:	ara::rest::Request	
Description:	Constructs a Request.	

Table 8.213: ara::rest::Request::Request

[SWS_REST_02188] ara::rest::Request::Request | Table 8.213 describes the interface ara::rest::Request:|(RS_CM_00300)

8.20.9 Request

Service name:	ara::rest::Request::Request	
Type:	Member function	
Syntax:	ara::rest::Request::Request(RequestMethod met, const	
	Uri &uri, Pointer< ara::core::String > &&bin)	
Function param:	met	one of RequestMethod
Function param:	uri	a Uri
Function param:	bin	binary data payload of request message
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/client.h	
Class:	ara::rest::Request	
Description:	Constructs a Request.	

Table 8.214: ara::rest::Request::Request

[SWS_REST_02989] ara::rest::Request::Request | Table 8.214 describes the interface ara::rest::Request::Request.|(RS CM 00300)

8.21 ara::rest::Router

[SWS_REST_02189] \[\text{ara::rest::Router class shall be declared in the ara/rest/routing.h header file:} \]

class ara::rest::Router;

(RS_CM_00300)

8.21.1 RouteHandlerType

Name:	RouteHandlerType	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::Router::RouteHandlerType =</pre>	
	Route::Upshot(const ServerRequest&, ServerReply&, const	
	Matches&)	
Header file:	ara/rest/routing.h	



Class:	ara::rest::Router	
Description:	! User-define route handler function type	

Table 8.215: ara::rest::Router::RouteHandlerType

[SWS_REST_02190] RouteHandlerType [Table 8.215 describes the type alias ara::rest::Router::RouteHandlerType.|(RS_CM_00300)

8.21.2 RouteRange

Name:	RouteRange	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::Router::RouteRange =</pre>	
	<pre>IteratorRange<unspecified_iterator_type></unspecified_iterator_type></pre>	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	! Iterator range of routes	

Table 8.216: ara::rest::Router::RouteRange

[SWS_REST_02191] RouteRange [Table 8.216 describes the type alias ara::rest::Router::RouteRange.|(RS_CM_00300)

8.21.3 ConstRouteRange

Name:	ConstRouteRange	
Туре:	Member type alias	
Syntax:	<pre>using ara::rest::Router::ConstRouteRange =</pre>	
	<pre>IteratorRange<unspecified_iterator_type></unspecified_iterator_type></pre>	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	! Const iterator range of routes	

Table 8.217: ara::rest::Router::ConstRouteRange

[SWS_REST_02192] ConstRouteRange [Table 8.217 describes the type alias ara::rest::Router::ConstRouteRange.] (RS_CM_00300)

8.21.4 Router

Service name:	ara::rest::Router::Router	
Type:	Member function	
Syntax:	ara::rest::Router::Router(Allocator	
	*alloc=GetDefaultAllocator())	



Function param:	alloc	an allocator for all internal dynamic memory requirements
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	Constructs an empty Router.	

Table 8.218: ara::rest::Router::Router

[SWS_REST_02193] ara::rest::Router::Router [Table 8.218 describes the interface ara::rest::Router::Router.|(RS CM 00300)

8.21.5 Router

Service name:	ara::rest::Router::Rou	ter
Type:	Member function	
Syntax:	ara::rest::Route	r::Router(std::initializer_list<
	Route > routes,	Allocator
	*alloc=GetDefaultAllocator())	
Function param:	routes	a list of routes
Function param:	alloc	an allocator for all internal dynamic memory requirements
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	Constructs a router from a given list of routes.	

Table 8.219: ara::rest::Router::Router

[SWS_REST_02194] ara::rest::Router::Router [Table 8.219 describes the interface ara::rest::Router::Router.] (RS CM 00300)

8.21.6 operator()

Service name:	ara::rest::Router::oper	rator()	
Type:	Member function	Member function	
Syntax:	void ara::rest::	Router::operator()(const	
	ServerRequest &r	ServerRequest &req, ServerReply &rep) const	
Function param:	req	a request	
Function param:	rep	a reply	
Return value:	None		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/routing.h		
Class:	ara::rest::Router		
Description:		tion. This function serves as the user-defined re-	
	quest handler function	passed to Server	



Table 8.220: ara::rest::Router::operator()

[SWS_REST_02195] ara::rest::Router::operator() [Table 8.220 describes the interface ara::rest::Router::operator().|(RS_CM_00300)

8.21.7 InsertRoute

Service name:	ara::rest::Router::Inse	rtRoute
Type:	Member function	
Syntax:	Router& ara::res	t::Router::InsertRoute(const Route
	&route)	
Function param:	route	a route
Return value:	a reference to this	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	Inserts a route into the	e set of potential matches. If a route already exists
	nothing is inserted.	

Table 8.221: ara::rest::Router::InsertRoute

[SWS_REST_02196] ara::rest::Router::InsertRoute [Table 8.221 describes the interface ara::rest::Router::InsertRoute.](RS_CM_00300)

8.21.8 EmplaceRoute

Service name:	ara::rest::Router::Emp	laceRoute	
Type:	Member function		
Syntax:	Router& ara::res	t::Router::EmplaceRoute(RequestMethod	
	met, Pattern pat	, const Function< RouteHandlerType >	
	&hnd)		
Function param:	met	a set of request methods	
Function param:	pat	a URI Pattern	
Function param:	hnd	a user-defined routing handler	
Return value:	a reference to this		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/routing.h	ara/rest/routing.h	
Class:	ara::rest::Router		
Description:	Constructs a route in-place Similar to Insert except that the route is con-		
	structed in-place. Th	structed in-place. The given arguments are forwarded to the internal	
	Route. If such a route already exists nothing is inserted.		

Table 8.222: ara::rest::Router::EmplaceRoute

[SWS_REST_02197] ara::rest::Router::EmplaceRoute [Table 8.222 describes the interface ara::rest::Router::EmplaceRoute.|(RS_CM_00300)



8.21.9 SetDefaultHandler

Service name:	ara::rest::Router::Set[DefaultHandler
Type:	Member function	
Syntax:	Router& ara::res	t::Router::SetDefaultHandler(const
	Function< Server	::RequestHandlerType > &hnd)
Function param:	hnd	a user-defined request handler
Return value:	a reference to this.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	Enables a user to se	t a default request handler The given handler is
	called if none of the routes matched of it at least once of the routes called	
	Route::Default().	

Table 8.223: ara::rest::Router::SetDefaultHandler

[SWS_REST_02198] ara::rest::Router::SetDefaultHandler [Table 8.223 describes the interface ara::rest::Router::SetDefaultHandler.|(RS_CM_00300)

8.21.10 RouteCount

Service name:	ara::rest::Router::RouteCount
Type:	Member function
Syntax:	<pre>std::size_t ara::rest::Router::RouteCount()</pre>
Function param:	None
Return value:	the number of user-defined routes
Exceptions:	Implementation-defined
Header file:	ara/rest/routing.h
Class:	ara::rest::Router
Description:	Returns the number of routes. Returns the number of specified routes,
	exclusive of the default route.

Table 8.224: ara::rest::Router::RouteCount

[SWS_REST_02199] ara::rest::Router::RouteCount [Table 8.224 describes the interface ara::rest::Router::RouteCount.] (RS_CM_00300)

8.21.11 Routes

Service name:	ara::rest::Router::Routes
Type:	Member function
Syntax:	RouteRange ara::rest::Router::Routes()
Function param:	None
Return value:	an iterator range of routes
Exceptions:	Implementation-defined
Header file:	ara/rest/routing.h
Class:	ara::rest::Router



Description:	Provides direc access to the set of routes.
--------------	---

Table 8.225: ara::rest::Router::Routes

[SWS_REST_02200] ara::rest::Router::Routes [Table 8.225 describes the interface ara::rest::Router::Routes.|(RS_CM_00300)

8.21.12 Routes

Service name:	ara::rest::Router::Routes
Type:	Member function
Syntax:	ConstRouteRange ara::rest::Router::Routes() const
Function param:	None
Return value:	an iterator range of routes
Exceptions:	Implementation-defined
Header file:	ara/rest/routing.h
Class:	ara::rest::Router
Description:	Provides direc access to the set of routes.

Table 8.226: ara::rest::Router::Routes

[SWS_REST_02201] ara::rest::Router::Routes [Table 8.226 describes the interface ara::rest::Router::Routes.|(RS_CM_00300)

8.21.13 RemoveRoute

Service name:	ara::rest::Router::RemoveRoute		
Type:	Member function		
Syntax:	void		
	ara::rest::Route	r::RemoveRoute(RouteRange::Iterator	
	iter)		
Function param:	iter	iter iterator referencing the route to remove	
Return value:	None		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/routing.h		
Class:	ara::rest::Router		
Description:	Removes a route from	the set.	

Table 8.227: ara::rest::Router::RemoveRoute

[SWS_REST_02202] ara::rest::Router::RemoveRoute [Table 8.227 describes the interface ara::rest::RemoveRoute.](RS_CM_00300)

8.21.14 FindRoute



Service name:	ara::rest::Router::Find	Route
Type:	Member function	
Syntax:	RouteRange::Iter	ator
	ara::rest::Router::FindRoute(const Route &route)	
Function param:	route	route to search for
Return value:	an iterator to the route if it exists in the set or Routes.end() if no such	
	route was found.	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/routing.h	
Class:	ara::rest::Router	
Description:	Searches for a given r	oute.

Table 8.228: ara::rest::Router::FindRoute

[SWS_REST_02203] ara::rest::Router::FindRoute [Table 8.228 describes the interface ara::rest::Router::FindRoute.|(RS_CM_00300)

8.21.15 Clear

Service name:	ara::rest::Router::Clear
Type:	Member function
Syntax:	<pre>void ara::rest::Router::Clear()</pre>
Function param:	None
Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/routing.h
Class:	ara::rest::Router
Description:	Removes all routes.

Table 8.229: ara::rest::Router::Clear

[SWS_REST_02204] ara::rest::Router::Clear [Table 8.229 describes the interface ara::rest::Router::Clear.] (RS_CM_00300)

8.22 ara::rest::Route

[SWS_REST_02205] [ara::rest::Route class shall be declared in the ara/rest/routing.h header file:

class ara::rest::Route;

(RS_CM_00300)

8.22.1 **Upshot**



Name:	Upshot	
Type:	Member enumeration	
Range:	kAccept	
	kYield	
	kDefault	
Syntax:	enum class Upshot {	
	kAccept,	
	kYield,	
	kDefault	
	} ;	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Route	
Description:	Instructions for a Router on how to proceed after a route handler functions	
	returns. A route handler function must return one of these values to instruct	
	the router how to proceed after executing the current handler.	

Table 8.230: ara::rest::Route::Upshot

[SWS_REST_02206] Upshot [Table 8.230 describes the enumeration datatype ara::rest::Route::Upshot.] (RS_CM_00300)

8.22.2 RouteHandlerType

Name:	RouteHandlerType	
Type:	Member type alias	
Syntax:	using ara::rest::Route::RouteHandlerType = Upshot(const	
	ServerRequest&, ServerReply&, const Matches&)	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Route	
Description:	The type of the user-define handler function to be invoked if this Route matches	
	the Pattern.	

Table 8.231: ara::rest::Route::RouteHandlerType

[SWS_REST_02207] RouteHandlerType [Table 8.231 describes the type alias ara::rest::Route::RouteHandlerType.](RS_CM_00300)

8.22.3 Route

Service name:	ara::rest::Route::Route		
Type:	Member function		
Syntax:	ara::rest::Route	ara::rest::Route::Route(RequestMethod met, const	
	Pattern &pat, co.	nst Function< RouteHandlerType >	
	&hnd)		
Function param:	met	a disjunction (logical OR) of RequestMethods to	
		match against	
Function param:	pat	a URI Pattern to match against	
Function param:	hnd	a user-defined handler	



Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/routing.h
Class:	ara::rest::Route
Description:	Constructs a route.

Table 8.232: ara::rest::Route::Route

[SWS_REST_02208] ara::rest::Route::Route [Table 8.232 describes the interface ara::rest::Route::Route.](RS_CM_00300)

8.22.4 operator()

Service name:	ara::rest::Route::opera	ator()		
Type:	Member function	Member function		
Syntax:	Upshot ara::rest	::Route::operator()(const		
	ServerRequest &r	ServerRequest &req, ServerReply &rep) const		
Function param:	req	a request		
Function param:	rep	a reply		
Return value:	a value of type Upshot			
Exceptions:	noexcept			
Header file:	ara/rest/routing.h			
Class:	ara::rest::Route			
Description:	ara::rest::Server compliant handler function This function is invoked by			
	the Router to test the	the Router to test the current Route for a match		

Table 8.233: ara::rest::Route::operator()

[SWS_REST_02209] ara::rest::Route::operator() [Table 8.233 describes the interface ara::rest::Route::operator().|(RS_CM_00300)

8.22.5 GetRequestMethod

Service name:	ara::rest::Route::GetRequestMethod
Type:	Member function
Syntax:	RequestMethod ara::rest::Route::GetRequestMethod()
	const
Function param:	None
Return value:	reference to a Pattern
Exceptions:	noexcept
Header file:	ara/rest/routing.h
Class:	ara::rest::Route
Description:	Provides access to the underlying Pattern object.

Table 8.234: ara::rest::Route::GetRequestMethod



[SWS_REST_02210] ara::rest::Route::GetRequestMethod [Table 8.234 describes the interface ara::rest::Route::GetRequestMethod.] (RS_CM_00300)

8.22.6 GetPattern

Service name:	ara::rest::Route::GetPattern	
Type:	Member function	
Syntax:	const Pattern& ara::rest::Route::GetPattern() const	
Function param:	None	
Return value:	reference to a Pattern	
Exceptions:	noexcept	
Header file:	ara/rest/routing.h	
Class:	ara::rest::Route	
Description:	Provides access to the underlying Pattern object.	

Table 8.235: ara::rest::Route::GetPattern

[SWS_REST_02211] ara::rest::Route::GetPattern [Table 8.235 describes the interface ara::rest::Route::GetPattern.] (RS_CM_00300)

8.22.7 operator==

Service name:	ara::rest::Route::opera	ator==	
Type:	Non-member funct	Non-member function	
Syntax:	friend bool oper	friend bool operator == (const Route &a, const Route	
	(d&)	&b)	
Function param:	а	a a route	
Function param:	b	a route	
Return value:	true if equal		
Exceptions:	noexcept		
Header file:	ara/rest/routing.h		
Namespace:	ara::rest::Route		
Description:	Tests for equality.		

Table 8.236: ara::rest::Route::operator==

[SWS_REST_02212] ara::rest::Route::operator== [Table 8.236 describes the interface ara::rest::Route::operator==.|(RS CM 00300)

8.22.8 operator!=

Service name:	ara::rest::Route::operator!=		
Type:	Non-member function		
Syntax:	friend bool operator!=(const Route &a, const Route		
	&b)		
Function param:	а	a route	



Function param:	b	a route
Return value:	true if unequal	
Exceptions:	noexcept	
Header file:	ara/rest/routing.h	
Namespace:	ara::rest::Route	
Description:	Tests for inequality.	

Table 8.237: ara::rest::Route::operator!=

[SWS_REST_02213] ara::rest::Route::operator!= [Table 8.237 describes the interface ara::rest::Route::operator!=.|(RS_CM_00300)

8.22.9 operator<

Service name:	ara::rest::Route::operator<			
Type:	Non-member funct	Non-member function		
Syntax:	friend bool oper	friend bool operator<(const Route &a, const Route &b)		
Function param:	а	a route		
Function param:	b	a route		
Return value:	true if a compares less-than b			
Exceptions:	noexcept			
Header file:	ara/rest/routing.h			
Namespace:	ara::rest::Route			
Description:	Tests whether a route	is less-than another.		

Table 8.238: ara::rest::Route::operator<

[SWS_REST_02214] ara::rest::Route::operator< [Table 8.238 describes the interface ara::rest::Route::operator<.](RS_CM_00300)

8.23 ara::rest::ServerEvent

[SWS_REST_02215] [ara::rest::ServerEvent class shall be declared in the ara/rest/server.h header file:

class ara::rest::ServerEvent;

(RS CM 00300)

8.23.1 ServerEvent

Service name:	ara::rest::ServerEvent::ServerEvent
Type:	Member function
Syntax:	ara::rest::ServerEvent::ServerEvent(const ServerEvent
	&)=delete



Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerEvent
Description:	Non-copyable.

Table 8.239: ara::rest::ServerEvent::ServerEvent

[SWS_REST_02216] ara::rest::ServerEvent::ServerEvent | Table 8.239 describes the interface ara::rest::ServerEvent::ServerEvent.] (RS_CM_00300)

8.23.2 operator=

Service name:	ara::rest::ServerEvent::operator=	
Type:	Member function	
Syntax:	ServerEvent& ara::rest::ServerEvent::operator=(const	
	ServerEvent &) = delete	
Return value:	a value of type ServerEvent &	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::ServerEvent	
Description:	Non-copy-assignable.	

Table 8.240: ara::rest::ServerEvent::operator=

[SWS_REST_02217] ara::rest::ServerEvent::operator= [Table 8.240 describes the interface ara::rest::ServerEvent::operator=.|(RS_CM_00300)

8.23.3 Notify

Service name:	ara::rest::ServerEvent::Notify	
Type:	Member function	
Syntax:	Task <void> ara::rest::ServerEvent::Notify(const</void>	
	Pointer< ogm::Object > &data)	
Function param:	data payload to be notified	
Return value:	A task waiting for the notification to complete.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::ServerEvent	
Description:	ara::rest::ServerEvent Issues a change notification to its corresponding Server. Each server- side event has at least one corresponding client-side event. Notify does NOT notify these clients. It notifies its corresponding server of poten- tial changes to the data referenced by the event (URI). It is the server's decision if this event is sent to the clients or not based on the trigger conditions. The data that should be notified is given in the parameter data.	

Table 8.241: ara::rest::ServerEvent::Notify



[SWS_REST_02218] ara::rest::ServerEvent::Notify [Table 8.241 describes the interface ara::rest::ServerEvent::Notify.](RS_CM_00300)

8.23.4 Notify

Service name:	ara::rest::ServerEvent::Notify	
Type:	Member function	
Syntax:	Task <void> ara::rest::ServerEvent::Notify()</void>	
Return value:	A task waiting for the notification to complete.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::ServerEvent	
Description:	Issues a change notification to its corresponding Server. Each server-side event has at least one corresponding client-side event. Notify does NOT notify these clients. It notifies its corresponding server of potential changes to the data referenced by the event (URI). It is the server's decision if this event is send to the clients or not based on the trigger conditions. Note that this function will trigger automatically an GET request to ara::rest::Server application to get the newest data.	

Table 8.242: ara::rest::ServerEvent::Notify

[SWS_REST_02889] ara::rest::ServerEvent::Notify [Table 8.242 describes the interface ara::rest::ServerEvent::Notify.](RS_CM_00300)

8.23.5 SetSubscriptionState

Service name:	ara::rest::ServerEvent::SetSubscriptionState		
Type:	Member function	Member function	
Syntax:	<pre>void ara::rest::ServerEvent::SetSubscriptionState(</pre>		
	<pre>const ara::rest::SubscriptionState)</pre>		
Function param:	state	SubscriptionState of corresponding server event	
Return value:	void		
Exceptions:	Implementation-defined		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerEvent		
Description:	Set subscription state from server side. Enables the server application to		
	react to event subscriptions received from ara::rest::Client		

Table 8.243: ara::rest::ServerEvent::SetSubscriptionState

[SWS_REST_02219] ara::rest::ServerEvent::SetSubscriptionState [Table 8.243 describes the interface ara::rest::ServerEvent::SetSubscriptionState.] (RS CM 00300)

8.23.6 GetSubscriptionState



Service name:	ara::rest::ServerEvent::GetSubscriptionState		
Type:	Member function		
Syntax:	SubscriptionState		
	ara::rest::ServerEvent::GetSubscriptionState() const		
Function param:	None		
Return value:	the current subscription state as perceived by the client		
Exceptions:	noexcept		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerEvent		
Description:	Denotes the current subscription state.		

Table 8.244: ara::rest::ServerEvent::GetSubscriptionState

[SWS_REST_02220] ara::rest::ServerEvent::GetSubscriptionState [Table 8.244 describes the interface ara::rest::ServerEvent::GetSubscriptionState.] (RS CM 00300)

8.23.7 **GetUri**

Service name:	ara::rest::ServerEvent::GetUri		
Type:	Member function		
Syntax:	const Uri& ara::rest::ServerEvent::GetUri() const		
Function param:	None		
Return value:	the Uri corresponding to this event subscription		
Exceptions:	noexcept		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerEvent		
Description:	Returns the event Uri.		

Table 8.245: ara::rest::ServerEvent::GetUri

[SWS_REST_02221] ara::rest::ServerEvent::GetUri [Table 8.245 describes the interface ara::rest::ServerEvent::GetUri.|(RS_CM_00300)

8.23.8 SendError

Service name:	ara::rest::ServerEvent::SendError		
Type:	Member function	Member function	
Syntax:	<pre>void ara::rest::ServerEvent::SendError(const unsigned</pre>		
	<pre>int errorCode, const StringView& errorMessage);</pre>		
Function param:	errorCode	The error code	
Function param:	errorMessage	The error code message	
Return value:	None		
Exceptions:	noexept		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerEvent		



Description:	During the life time of an event an error can occur. E.g. the subscribed
	resource is no longer available. With this method the subscribed Client
	can be notified.

Table 8.246: ara::rest::ServerEvent::SendError

[SWS_REST_02805] ara::rest::ServerEvent::SendError [Table 8.246 describes the interface ara::rest::ServerEvent::SendError.] (RS_CM_00300)

8.23.9 operator==

Service name:	ara::rest::ServerEvent::operator==	
Type:	Non-member funct	ion
Syntax:	friend bool operator == (const ServerEvent &a, const	
	ServerEvent &b)	
Function param:	а	an event
Function param:	b	an event
Return value:	true if a and b are equal	
Exceptions:	noexcept	
Header file:	ara/rest/server.h	
Namespace:	ara::rest::ServerEvent	
Description:	Tests events for equality.	

Table 8.247: ara::rest::ServerEvent::operator==

[SWS_REST_02222] ara::rest::ServerEvent::operator== [Table 8.247 describes the interface ara::rest::ServerEvent::operator==.|(RS_CM_00300)

8.23.10 operator!=

Service name:	ara::rest::ServerEvent::operator!=		
Type:	Non-member funct	Non-member function	
Syntax:	friend bool operator!=(const ServerEvent &a, const		
	ServerEvent &b)		
Function param:	а	an event	
Function param:	b	an event	
Return value:	true if a and b are unequal		
Exceptions:	noexcept		
Header file:	ara/rest/server.h		
Namespace:	ara::rest::ServerEvent		
Description:	Tests events for inequality.		

Table 8.248: ara::rest::ServerEvent::operator!=

[SWS_REST_02223] ara::rest::ServerEvent::operator!= [Table 8.248 describes the interface ara::rest::ServerEvent::operator!=.|(RS CM 00300)



8.23.11 operator<

Service name:	ara::rest::ServerEvent::operator<		
Type:	Non-member funct	Non-member function	
Syntax:	friend bool operator<(const ServerEvent &a, const		
	ServerEvent &b)	ServerEvent &b)	
Function param:	а	an event	
Function param:	b	an event	
Return value:	true if a less-than b		
Exceptions:	noexcept		
Header file:	ara/rest/server.h		
Namespace:	ara::rest::ServerEvent		
Description:	Tests events for their partial order Order criterion is implementation-		
	defined.		

Table 8.249: ara::rest::ServerEvent::operator<

[SWS_REST_02224] ara::rest::ServerEvent::operator< [Table 8.249 describes the interface ara::rest::ServerEvent::operator<.|(RS_CM_00300)

8.24 ara::rest::ServerReply

[SWS_REST_02225] [ara::rest::ServerReply class shall be declared in the ara/rest/server.h header file:

class ara::rest::ServerReply;

(RS_CM_00300)

8.24.1 ServerReply

Service name:	ara::rest::ServerReply::ServerReply	
Type:	Member function	
Syntax:	<pre>ara::rest::ServerReply::ServerReply(const ServerReply</pre>	
	&)=delete	
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::ServerReply	
Description:	Non-copyable.	

Table 8.250: ara::rest::ServerReply::ServerReply

[SWS_REST_02226] ara::rest::ServerReply::ServerReply [Table 8.250 describes the interface ara::rest::ServerReply::ServerReply.|(RS_CM_00300)



8.24.2 operator=

Service name:	ara::rest::ServerReply::operator=
Type:	Member function
Syntax:	ServerReply& ara::rest::ServerReply::operator=(const
	ServerReply &) =delete
Return value:	a value of type ServerReply &
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerReply
Description:	Non-copy-assignable.

Table 8.251: ara::rest::ServerReply::operator=

[SWS_REST_02227] ara::rest::ServerReply::operator= [Table 8.251 describes the interface ara::rest::ServerReply::operator=.|(RS_CM_00300)

8.24.3 GetHeader

Service name:	ara::rest::ServerReply::GetHeader
Type:	Member function
Syntax:	ReplyHeader& ara::rest::ServerReply::GetHeader()
Function param:	None
Return value:	a reference to a RequestHeader
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerReply
Description:	Provides access to the reply message header.

Table 8.252: ara::rest::ServerReply::GetHeader

[SWS_REST_02228] ara::rest::ServerReply::GetHeader [Table 8.252 describes the interface ara::rest::ServerReply::GetHeader.] (RS_CM_00300)

8.24.4 Send

Service name:	ara::rest::ServerReply::Send		
Type:	Member function	Member function	
Syntax:	Task <void> ara::</void>	Task <void> ara::rest::ServerReply::Send(const</void>	
	Pointer< ogm::Ob	ject > &data={})	
Function param:	data	payload to be transmitted	
Return value:	a task waiting for the transmission to complete		
Exceptions:	Implementation-defined		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerReply		
Description:	Send a reply to the peer that has issued the request. If this function is not		
	invoked explicitly, the endpoint will transmit a default reply. If Redirect()		
	has been called before	e, these functions must be used.	



Table 8.253: ara::rest::ServerReply::Send

[SWS_REST_02229] ara::rest::ServerReply::Send [Table 8.253 describes the interface ara::rest::ServerReply::Send.] (RS_CM_00300)

8.24.5 Send

Service name:	ara::rest::ServerReply	::Send	
Type:	Member function		
Syntax:	Task <void> ara::</void>	Task <void> ara::rest::ServerReply::Send(const</void>	
	Pointer< ogm::Ob	Pointer< ogm::Object > &&data)	
Function param:	data	payload to be transmitted	
Return value:	a task waiting for the transmission to complete		
Exceptions:	Implementation-defined		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerReply		
Description:	Send a reply to the p	Send a reply to the peer that has issued the request. Same as other	
	Send(), only with move semantics		

Table 8.254: ara::rest::ServerReply::Send

[SWS_REST_02230] ara::rest::ServerReply::Send [Table 8.254 describes the interface ara::rest::ServerReply::Send.] (RS_CM_00300)

8.24.6 Send

Service name:	ara::rest::ServerReply::Send		
Type:	Member function	Member function	
Syntax:	Task <void> ara:::</void>	Task <void> ara::rest::ServerReply::Send(const</void>	
	StringView &data)		
Function param:	data	binary payload to be transmitted	
Return value:	a task waiting for the t	ransmission to complete	
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerReply		
Description:	Send a reply with bina	Send a reply with binary data to the peer that has issued the request.	

Table 8.255: ara::rest::ServerReply::Send

[SWS_REST_02932] ara::rest::ServerReply::Send [Table 8.255 describes the interface ara::rest::ServerReply::Send.] (RS_CM_00300)

8.24.7 Redirect



Service name:	ara::rest::ServerReply	ara::rest::ServerReply::Redirect	
Type:	Member function	Member function	
Syntax:	Task <void> ara::</void>	Task <void> ara::rest::ServerReply::Redirect(const Uri</void>	
	&uri)	&uri)	
Function param:	uri	location to redirect to	
Return value:	a value of type Task< void >		
Exceptions:	Implementation-defined		
Header file:	ara/rest/server.h		
Class:	ara::rest::ServerReply		
Description:	Issues a redirect command to the connected client. Must not be called after Send().		

Table 8.256: ara::rest::ServerReply::Redirect

[SWS_REST_02231] ara::rest::ServerReply::Redirect [Table 8.256 describes the interface ara::rest::ServerReply::Redirect.|(RS_CM_00300)

8.25 ara::rest::ServerRequest

[SWS_REST_02232] [ara::rest::ServerRequest class shall be declared in the ara/rest/server.h header file:

```
class ara::rest::ServerRequest;
```

(RS CM 00300)

8.25.1 ServerRequest

Service name:	ara::rest::ServerRequest::ServerRequest
Type:	Member function
Syntax:	ara::rest::ServerRequest::ServerRequest(const
	ServerRequest &) =delete
Return value:	None
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerRequest
Description:	Non-copyable.

Table 8.257: ara::rest::ServerRequest::ServerRequest

8.25.2 operator=



Service name:	ara::rest::ServerRequest::operator=
Type:	Member function
Syntax:	ServerRequest&
	ara::rest::ServerRequest::operator=(const
	ServerRequest &) = delete
Return value:	a value of type ServerRequest &
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerRequest
Description:	Non-copy-assignable.

Table 8.258: ara::rest::ServerRequest::operator=

[SWS_REST_02234] ara::rest::ServerRequest::operator= [Table 8.258 describes the interface ara::rest::ServerRequest::operator=.](RS_CM_00300)

8.25.3 GetHeader

Service name:	ara::rest::ServerRequest::GetHeader	
Type:	Member function	
Syntax:	RequestHeader const&	
	ara::rest::ServerRequest::GetHeader() const	
Function param:	None	
Return value:	a reference to a RequestHeader	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::ServerRequest	
Description:	Provides access to the message header. Requests the message header	
	from the endpoint. Accessing the message header is always syn-	
	chronous.	

Table 8.259: ara::rest::ServerRequest::GetHeader

[SWS_REST_02235] ara::rest::ServerRequest::GetHeader [Table 8.259 describes the interface ara::rest::ServerRequest::GetHeader.] (RS_CM_00300)

8.25.4 GetObject

Service name:	ara::rest::ServerRequest::GetObject
Type:	Member function
Syntax:	Task <ogm::object const&=""></ogm::object>
	ara::rest::ServerRequest::GetObject() const
Function param:	None
Return value:	returns a task waiting for the message payload to be received.
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerRequest
Description:	Obtains the request message payload.



Table 8.260: ara::rest::ServerRequest::GetObject

[SWS_REST_02236] ara::rest::ServerRequest::GetObject [Table 8.260 describes the interface ara::rest::ServerRequest::GetObject.|(RS_CM_00300)

8.25.5 ReleaseObject

Service name:	ara::rest::ServerRequest::ReleaseObject
Type:	Member function
Syntax:	Task <pointer<ogm::object> ></pointer<ogm::object>
	ara::rest::ServerRequest::ReleaseObject()
Function param:	None
Return value:	returns a task waiting for the message payload to be received.
Exceptions:	Implementation-defined
Header file:	ara/rest/server.h
Class:	ara::rest::ServerRequest
Description:	Obtains the reply message payload.

Table 8.261: ara::rest::ServerRequest::ReleaseObject

[SWS_REST_02237] ara::rest::ServerRequest::ReleaseObject [Table 8.261 describes the interface ara::rest::ServerRequest::ReleaseObject.] (RS CM 00300)

8.25.6 ReleaseBinary

Service name:	ara::rest::ServerRequest::ReleaseBinary	
Type:	Member function	
Syntax:	Task <pointer<ara::core::string> ></pointer<ara::core::string>	
	ara::rest::ServerRequest::ReleaseBinary()	
Function param:	None	
Return value:	returns a task waiting for the message payload to be received.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::ServerRequest	
Description:	Obtains the reply message payload.	

Table 8.262: ara::rest::ServerRequest::ReleaseBinary

[SWS_REST_02991] ara::rest::ServerRequest::ReleaseBinary [Table 8.262 describes the interface ara::rest::ServerRequest::ReleaseBinary.] (RS CM 00300)



8.26 ara::rest::Server

[SWS_REST_02238] \[\text{ara::rest::Server class shall be declared in the ara/rest/server.h header file:

class ara::rest::Server;

(RS CM 00300, RS CM 00301)

8.26.1 RequestHandlerType

Name:	RequestHandlerType	
Туре:	Member type alias	
Syntax:	<pre>using ara::rest::Server::RequestHandlerType = void(const</pre>	
	ServerRequest&, ServerReply&)	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Type of user-defined request handlers.	

Table 8.263: ara::rest::Server::RequestHandlerType

[SWS_REST_02239] RequestHandlerType [Table 8.263 describes the type alias ara::rest::Server::RequestHandlerType.] (RS CM 00300, RS CM 00301)

8.26.2 SubscriptionHandlerType

Name:	SubscriptionHandlerType	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::Server::SubscriptionHandlerType =</pre>	
	void(ServerEvent)	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Denotes a subscription handler type.	

Table 8.264: ara::rest::Server::SubscriptionHandlerType

[SWS_REST_02240] SubscriptionHandlerType [Table 8.264 describes the type alias ara::rest::Server::SubscriptionHandlerType.](RS_CM_00300, RS_CM_00301)

8.26.3 SubscriptionStateHandlerType

Name:	SubscriptionStateHandlerType	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::Server::SubscriptionStateHandlerType =</pre>	
	<pre>void(ServerEvent&, SubscriptionState)</pre>	



Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Denotes a callback to call if subscription status changes.	

Table 8.265: ara::rest::Server::SubscriptionStateHandlerType

[SWS_REST_02241] SubscriptionStateHandlerType [Table 8.265 describes the type alias ara::rest::Server::SubscriptionStateHandlerType.] (RS_CM_00300, RS_CM_00301)

8.26.4 Server

Service name:	ara::rest::Server::Server		
Type:	Member function		
Syntax:	ara::rest::Server::Server(const Server &)=delete		
Return value:	None		
Exceptions:	Implementation-defined		
Header file:	ara/rest/server.h		
Class:	ara::rest::Server		
Description:	Server is non-copy-constructible.		

Table 8.266: ara::rest::Server::Server

[SWS_REST_02242] ara::rest::Server::Server [Table 8.266 describes the interface ara::rest::Server::Server.|(RS_CM_00300, RS_CM_00301)

8.26.5 **operator=**

Service name:	ara::rest::Server::operator=	
Type:	Member function	
Syntax:	Server& ara::rest::Server::operator=(const Server	
	&)=delete	
Return value:	a value of type Server &	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Server is non-copy-assignable.	

Table 8.267: ara::rest::Server::operator=

[SWS_REST_02243] ara::rest::Server::operator= [Table 8.267 describes the interface ara::rest::Server::operator=.|(RS CM 00300, RS CM 00301)

8.26.6 Server



Service name:	ara::rest::Server::Server	
Type:	Member function	
Syntax:	ara::rest::Serve	r::Server(const
	ara::rest::Insta	nceIdentifier &inst_id, const
	Function< Reques	tHandlerType > &hnd, Allocator
	*alloc=GetDefaultAllocator())	
Function param:	inst_id	ara::rest::InstanceIdentifier identifies
		concrete service instace
Function param:	hnd	request handler function
Function param:	alloc	allocator for dynamic memory
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Constructs a server.	

Table 8.268: ara::rest::Server::Server

[SWS_REST_02244] ara::rest::Server::Server [Table 8.268 describes the interface ara::rest::Server::Server.] (RS_CM_00300, RS_CM_00301, RS_CM_00310)

8.26.7 Start

Service name:	ara::rest::Server::Start	
Type:	Member function	
Syntax:	Task <void> ara::</void>	rest::Server::Start(StartupPolicy
	policy=StartupPo	licy::kDetached)
Function param:	policy denotes whether caller is blocked or not.	
Return value:	a task waiting for Stop	o() to be invoked
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Instruct a server to begin serving clients. A server does not serve anything unless Start() is invoked. A server can be started within the execution context of the caller or within its own execution context (usually this is a thread). If StartupPolicy::kAttached, then Start() blocks its caller and only returns of Stop() is called. If Startuppolicy::kDetached, Start() does not block its caller but returns a task for synchronization. The caller may wait on the task, which blocks until Stop() is invoked.	

Table 8.269: ara::rest::Server::Start

[SWS_REST_02245] ara::rest::Server::Start [Table 8.269 describes the interface ara::rest::Server::Start.] (RS_CM_00300, RS_CM_00301)

8.26.8 Stop

Service name:	ara::rest::Server::Stop
---------------	-------------------------



Type:	Member function	
Syntax:	Task <void> ara::rest::Server::Stop(ShutdownPolicy</void>	
	policy=ShutdownP	olicy::kGraceful)
Function param:	policy denotes how server is stopped.	
Return value:	return type	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Instructs a server to stop serving clients. A client can be stopped either as fast as possible or "gracefully". If ShutdownPolicy::kForced then all connections are terminates instantly and all ongoing processes shall be terminated as fast as possible. If ShutdownPolicy::kGraceful then a server will stop accepting new requests but will wait until all requests have been served.	

Table 8.270: ara::rest::Server::Stop

[SWS_REST_02246] ara::rest::Server::Stop [Table 8.270 describes the interface ara::rest::Server::Stop.|(RS_CM_00300, RS_CM_00301)

8.26.9 ObserveSubscriptions

Service name:	ara::rest::Server::ObserveSubscriptions	
Type:	Member function	
Syntax:	<pre>void ara::rest::Server::ObserveSubscriptions(const</pre>	
	Function < Subscr	iptionHandlerType > &shnd, const
	Function< SubscriptionStateHandlerType > &sshnd)	
Function param:	shnd a subscription handler function	
Function param:	sshnd	a subscription state handler function
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/server.h	
Class:	ara::rest::Server	
Description:	Registers a user-defined subscription handler. A server can handle event subscriptions by default. Unless a user-defined handler function is registered explicitly, event subscriptions are not visible to the user. This implies that subscriptions with EventPolicy::kTriggered never receive notifications.	

Table 8.271: ara::rest::Server::ObserveSubscriptions

[SWS_REST_02247] ara::rest::Server::ObserveSubscriptions [Table 8.271 describes the interface ara::rest::Server::ObserveSubscriptions.] (RS_CM_00300, RS_CM_00301)

8.26.10 **GetError**

Service name:	ara::rest::Server::GetError



Type:	Member function
Syntax:	ara::core:ErrorCode ara::rest::Server::GetError()
	const
Function param:	None
Return value:	a reference to the server Status
Exceptions:	noexcept
Header file:	ara/rest/server.h
Class:	ara::rest::Server
Description:	Obtain server status.

Table 8.272: ara::rest::Server::GetError

[SWS_REST_02248] ara::rest::Server::GetError [Table 8.272 describes the interface ara::rest::Server::GetError.|(RS CM 00300, RS CM 00301)

8.26.11 ObserveError

Service name:	ara::rest::Server::ObserveError		
Type:	Member function	Member function	
Syntax:	<pre>void ara::rest::Server::ObserveError(const Function<</pre>		
	void(ara::core:E	rrorCode)> &hnd)	
Function param:	hnd	user-defined handler function to to called on status	
		changes	
Return value:	None		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/server.h		
Class:	ara::rest::Server		
Description:	Observe status chang	es.	

Table 8.273: ara::rest::Server::ObserveError

[SWS_REST_02249] ara::rest::Server::ObserveError [Table 8.273 describes the interface ara::rest::Server::ObserveError.](RS_CM_00300, RS_CM_00301)

8.27 ara::rest::StdAllocator

[SWS_REST_02250] [ara::rest::StdAllocator class shall be declared in the ara/rest/allocator.h header file:

```
template <typename T>
class ara::rest::StdAllocator;
```

8.27.1 value_type

(RS CM 00300)

175 of 241



Name:	value_type
Type:	Member type alias
Syntax:	<pre>using ara::rest::StdAllocator< T >::value_type = T</pre>
Header file:	ara/rest/allocator.h
Class:	ara::rest::StdAllocator
Description:	Type this allocator is bound to.

Table 8.274: ara::rest::StdAllocator::value_type

[SWS_REST_02251] value_type [Table 8.274 describes the type alias ara::rest::StdAllocator::value_type.|(RS_CM_00300)

8.27.2 StdAllocator

Service name:	ara::rest::StdAllocator::StdAllocator
Type:	Member function
Syntax:	ara::rest::StdAllocator< T >::StdAllocator()
Function param:	None
Return value:	None
Exceptions:	noexcept
Header file:	ara/rest/allocator.h
Class:	ara::rest::StdAllocator
Description:	Default constructs this allocator See std::pmr::polymorphic_allocator
	documentation for details.

Table 8.275: ara::rest::StdAllocator::StdAllocator

[SWS_REST_02252] ara::rest::StdAllocator::StdAllocator [Table 8.275 describes the interface ara::rest::StdAllocator::StdAllocator.] (RS CM 00300)

8.27.3 StdAllocator

Service name:	ara::rest::StdAllocator::StdAllocator		
Type:	Member function	Member function	
Syntax:	ara::rest::StdAl	locator< T >::StdAllocator(Allocator	
	*a)		
Function param:	а	an allocator	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/allocator.h		
Class:	ara::rest::StdAllocator		
Description:	Default constructs th	is allocator See std::pmr::polymorphic_allocator	
	documentation for det	ails.	

Table 8.276: ara::rest::StdAllocator::StdAllocator



[SWS_REST_02253] ara::rest::StdAllocator::StdAllocator [Table 8.276 describes the interface ara::rest::StdAllocator::StdAllocator.](RS_CM_00300)

8.27.4 StdAllocator

Service name:	ara::rest::StdAllocator	::StdAllocator	
Type:	Member function	Member function	
Syntax:	template <typena< th=""><th colspan="2">template <typename u=""></typename></th></typena<>	template <typename u=""></typename>	
	ara::rest::StdAl	locator< T	
	>::StdAllocator(StdAllocator< U > const &do_not_use)		
Function param:	do_not_use	meaningless.	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/allocator.h		
Class:	ara::rest::StdAllocator		
Description:		Do not call. See detailed API description. This function exists only for	
	the sake of 'noexcept'	. never invoked directly.	

Table 8.277: ara::rest::StdAllocator::StdAllocator

[SWS_REST_02254] ara::rest::StdAllocator::StdAllocator [Table 8.277 describes the interface ara::rest::StdAllocator::StdAllocator.|(RS CM 00300)

8.27.5 allocate

Service name:	ara::rest::StdAllocator	::allocate	
Type:	Member function		
Syntax:	value_type* ara:	<pre>value_type* ara::rest::StdAllocator< T</pre>	
	>::allocate(std::size_t n)		
Function param:	n	number of bytes to allocator	
Return value:	a value of type value_type *		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/allocator.h		
Class:	ara::rest::StdAllocator		
Description:	Allocate		

Table 8.278: ara::rest::StdAllocator::allocate

[SWS_REST_02255] ara::rest::StdAllocator::allocate [Table 8.278 describes the interface ara::rest::StdAllocator::allocate.|(RS_CM_00300)

8.27.6 deallocate

Service name:	ara::rest::StdAllocator::deallocate	
Type:	Member function	



Syntax:	<pre>void ara::rest::StdAllocator< T</pre>	
	>::deallocate(value_type *p, std::size_t s)	
Function param:	р	pointer to allocated memory region
Function param:	S	size of allocated memory region
Return value:	None	
Exceptions:	noexcept	
Header file:	ara/rest/allocator.h	
Class:	ara::rest::StdAllocator	
Description:	Deallocate.	

Table 8.279: ara::rest::StdAllocator::deallocate

[SWS_REST_02256] ara::rest::StdAllocator::deallocate [Table 8.279 describes the interface ara::rest::StdAllocator::deallocate.|(RS CM 00300)

8.27.7 select_on_container_copy_construction

Service name:	ara::rest::StdAllocator::select_on_container_copy_construction	
Type:	Member function	
Syntax:	StdAllocator ara::rest::StdAllocator< T	
	>::select_on_container_copy_construction() const	
Function param:	None	
Return value:	a value of type StdAllocator	
Exceptions:	Implementation-defined	
Header file:	ara/rest/allocator.h	
Class:	ara::rest::StdAllocator	
Description:	Returns the allocator to use when a standard container using it is copied.	
	See std::pmr::polymorphic_allocator documentation for details	

Table 8.280: ara::rest::StdAllocator::select_on_container_copy_construction

[SWS_REST_02257] ara::rest::StdAllocator::select_on_container_copy_construction

[Table 8.280 describes the interface ara::rest::StdAllocator::select_on_container_co
(RS_CM_00300)

8.27.8 resource

178 of 241

Service name:	ara::rest::StdAllocator::resource
Type:	Member function
Syntax:	Allocator* ara::rest::StdAllocator< T >::resource()
	const
Function param:	None
Return value:	a value of type Allocator *
Exceptions:	noexcept
Header file:	ara/rest/allocator.h
Class:	ara::rest::StdAllocator
Description:	Returns the Allocator behind this adapter. See
	std::pmr::polymorphic_allocator documentation for details



Table 8.281: ara::rest::StdAllocator::resource

[SWS_REST_02258] ara::rest::StdAllocator::resource [Table 8.281 describes the interface ara::rest::StdAllocator::resource.|(RS_CM_00300)

8.28 ara::rest::Uri::Builder

[SWS_REST_02259] [ara::rest::Uri::Builder class shall be declared in the ara/rest/uri.h header file:

class ara::rest::Uri::Builder;

(RS_CM_00300, RS_CM_00304)

8.28.1 Builder

Service name:	ara::rest::Uri::Builder::Builder	
Type:	Member function	
Syntax:	ara::rest::Uri::Builder::Builder(Allocator	
	*alloc=GetDefaultAllocator())	
Function param:	alloc	an allocator
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Default-constructs a builder.	

Table 8.282: ara::rest::Uri::Builder::Builder

8.28.2 Builder

Service name:	ara::rest::Uri::Builder::Builder	
Type:	Member function	
Syntax:	ara::rest::Uri::Builder::Builder(StringView uri,	
	Allocator *alloc=GetDefaultAllocator())	
Function param:	uri	an URI to initiazlize from
Function param:	alloc	an allocator
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	



Class:	ara::rest::Uri::Builder	
Description:	Parses a URI in string format.	

Table 8.283: ara::rest::Uri::Builder::Builder

8.28.3 Builder

Service name:	ara::rest::Uri::Builder::Builder	
Type:	Member function	
Syntax:	ara::rest::Uri::Builder::Builder(const Uri &uri,	
	Allocator *alloc=GetDefaultAllocator())	
Function param:	uri	an URI to initiazlize from
Function param:	alloc	an allocator
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Initializes this builder with an existing Uri.	

Table 8.284: ara::rest::Uri::Builder::Builder

[SWS_REST_02262] ara::rest::Uri::Builder::Builder::Builder.] (RS_CM_00300, RS_CM_00304)

8.28.4 Builder

Service name:	ara::rest::Uri::Builder::Builder	
Type:	Member function	
Syntax:	ara::rest::Uri::Builder::Builder(Uri &&uri, Allocator	
	*alloc=GetDefaultAllocator())	
Function param:	uri	an URI to initiazlize from
Function param:	alloc	an allocator
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Initializes this builder with an existing Uri.	

Table 8.285: ara::rest::Uri::Builder::Builder



[SWS_REST_02263] ara::rest::Uri::Builder::Builder::Builder.] (RS_CM_00300, RS_CM_00304)

8.28.5 Scheme

Service name:	ara::rest::Uri::Builder::	ara::rest::Uri::Builder::Scheme	
Type:	Member function		
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >	
	Builder& ara::re	Builder& ara::rest::Uri::Builder::Scheme(T &&value)	
Function param:	value a value of an output-streamable type		
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Set scheme by parsing	g the given argument Throws std::invalid_argument	
	if parsing fails.		

Table 8.286: ara::rest::Uri::Builder::Scheme

[SWS_REST_02264] ara::rest::Uri::Builder::Scheme [Table 8.286 describes the interface ara::rest::Uri::Builder::Scheme.|(RS CM 00300, RS CM 00304)

8.28.6 UserInfo

Service name:	ara::rest::Uri::Builder::	ara::rest::Uri::Builder::UserInfo	
Type:	Member function		
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >	
	Builder& ara::re	Builder& ara::rest::Uri::Builder::UserInfo(T &&value)	
Function param:	value a value of an output-streamable type		
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Set user info be std::invalid_argument	by parsing the given argument Throws if parsing fails.	

Table 8.287: ara::rest::Uri::Builder::UserInfo

[SWS_REST_02265] ara::rest::Uri::Builder::UserInfo | Table 8.287 describes the interface ara::rest::Uri::Builder::UserInfo.](RS_CM_00300, RS_CM_00304)

8.28.7 Host

Service name:	ara::rest::Uri::Builder::Host
---------------	-------------------------------



Type:	Member function		
Syntax:	template <typena< th=""><th colspan="2">template <typename t=""></typename></th></typena<>	template <typename t=""></typename>	
	Builder& ara::re	Builder& ara::rest::Uri::Builder::Host(T &&value)	
Function param:	value a value of an output-streamable type		
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Sets host by parsing the given argument Throws std::invalid_argument if parsing fails.		

Table 8.288: ara::rest::Uri::Builder::Host

[SWS_REST_02266] ara::rest::Uri::Builder::Host [Table 8.288 describes the interface ara::rest::Uri::Builder::Host.] (RS_CM_00300, RS_CM_00304)

8.28.8 Port

Service name:	ara::rest::Uri::Builder::Port	
Type:	Member function	
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >
	Builder& ara::rest::Uri::Builder::Port(T &&value)	
Function param:	value	a value of an output-streamable type
Return value:	a reference to this builder	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Sets the the Uri	1 0
	std::invalid_argument	if parsing fails.

Table 8.289: ara::rest::Uri::Builder::Port

[SWS_REST_02267] ara::rest::Uri::Builder::Port [Table 8.289 describes the interface ara::rest::Uri::Builder::Port.] (RS_CM_00300, RS_CM_00304)

8.28.9 Path

Service name:	ara::rest::Uri::Builder::Path		
Type:	Member function	Member function	
Syntax:	Builder& ara::re	st::Uri::Builder::Path(StringView	
	value)	value)	
Function param:	value	a value of an output-streamable type	
Return value:	a reference to this builder		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Sets the URI path std::invalid_argument,	h by parsing the given argument Throws if parsing fails.	



Table 8.290: ara::rest::Uri::Builder::Path

[SWS_REST_02268] ara::rest::Uri::Builder::Path [Table 8.290 describes the interface ara::rest::Uri::Builder::Path.|(RS_CM_00300, RS_CM_00304)

8.28.10 Path

Service name:	ara::rest::Uri::Builder::	ara::rest::Uri::Builder::Path	
Type:	Member function		
Syntax:	Builder& ara::re	st::Uri::Builder::Path(const	
	Uri::Path &value	Uri::Path &value)	
Function param:	value	a value of an output-streamable type	
Return value:	a reference to this builder		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Sets a path from	an existing Uri::Path components Throws	
	std::invalid_argument	if parsing fails.	

Table 8.291: ara::rest::Uri::Builder::Path

[SWS_REST_02269] ara::rest::Uri::Builder::Path [Table 8.291 describes the interface ara::rest::Uri::Builder::Path.] (RS_CM_00300, RS_CM_00304)

8.28.11 PathSegment

Service name:	ara::rest::Uri::Builder::PathSegment		
Type:	Member function		
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >	
	Builder& ara::re	Builder& ara::rest::Uri::Builder::PathSegment(T	
	&&seg)		
Function param:	seg of a path segment		
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Inserts a path segmer	nt to the end of the path.	

Table 8.292: ara::rest::Uri::Builder::PathSegment

[SWS_REST_02425] ara::rest::Uri::Builder::PathSegment [Table 8.292 describes the interface ara::rest::Uri::Builder::PathSegment.](RS_CM_00300, RS_CM_00304)



8.28.12 PathSegments

Service name:	ara::rest::Uri::Builder::PathSegments	
Type:	Member function	
Syntax:	template <typenam< th=""><th>ne Ts></th></typenam<>	ne Ts>
	Builder& ara::res	st::Uri::Builder::PathSegments(Ts
	&&values)	
Function param:	values values of output-streamable types	
Return value:	a reference to this builder	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:		from the given function arguments Throws
	std::invalid_argument i	f parsing fails.

Table 8.293: ara::rest::Uri::Builder::PathSegments

[SWS_REST_02270] ara::rest::Uri::Builder::PathSegments [Table 8.293 describes the interface ara::rest::Uri::Builder::PathSegments.](RS_CM_00300, RS_CM_00304)

8.28.13 PathSegmentsFrom

Service name:	ara::rest::Uri::Builder::	ara::rest::Uri::Builder::PathSegmentsFrom	
Type:	Member function	Member function	
Syntax:	template <typena< th=""><th>me Ts></th></typena<>	me Ts>	
	Builder&		
	ara::rest::Uri::	Builder::PathSegmentsFrom(std::size_t	
	pos, Ts &&values)		
Function param:	pos	pos index to start from	
Function param:	values	values values of output-streamable type	
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Constructs a path fro	m the given function arguments starting from the	
	n'th path segment.	-	

Table 8.294: ara::rest::Uri::Builder::PathSegmentsFrom

[SWS_REST_02271] ara::rest::Uri::Builder::PathSegmentsFrom [Table 8.294 describes the interface ara::rest::Uri::Builder::PathSegmentsFrom.] (RS_CM_00300, RS_CM_00304)

8.28.14 PathSegmentAt

Service name:	ara::rest::Uri::Builder::PathSegmentAt	
Type:	Member function	



Syntax:	template <typename ,="" t="" typename="" u=""></typename>		
	Builder& ara::re	st::Uri::Builder::PathSegmentAt(T	
	&&oldseg, U &≠	wseg)	
Function param:	oldseg replaced segment		
Function param:	newseg	replacing segment	
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Replaces an existing path segment. If old exists, then it is replaced by		
	new. Otherwise no ac	new. Otherwise no action is performed.	

Table 8.295: ara::rest::Uri::Builder::PathSegmentAt

[SWS_REST_02426] ara::rest::Uri::Builder::PathSegmentAt [Table 8.295 describes the interface ara::rest::Uri::Builder::PathSegmentAt.] (RS_CM_00300, RS_CM_00304)

8.28.15 PathSegmentAt

Service name:	ara::rest::Uri::Builder:	:PathSegmentAt
Type:	Member function	
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >
	Builder& ara::re	st::Uri::Builder::PathSegmentAt(T
	&&seg)	
Function param:	seg	segment to remove
Return value:	a reference to this but	lder
Exceptions:	Implementation-define	ed
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Removes a path segraction is performed.	ment. If segment exists, removes it. Otherwise no

Table 8.296: ara::rest::Uri::Builder::PathSegmentAt

[SWS_REST_02427] ara::rest::Uri::Builder::PathSegmentAt [Table 8.296 describes the interface ara::rest::Uri::Builder::PathSegmentAt.] (RS_CM_00300, RS_CM_00304)

8.28.16 Query

Service name:	ara::rest::Uri::Builder::Query	
Type:	Member function	
Syntax:	Builder& ara::rest::Uri::Builder::Query(const Uri::Query &q)	
Function param:	q	a query
Return value:	a reference to this builder	



Exceptions:	Implementation-defined
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri::Builder
Description:	Needs documentation.

Table 8.297: ara::rest::Uri::Builder::Query

[SWS_REST_02272] ara::rest::Uri::Builder::Query [Table 8.297 describes the interface ara::rest::Uri::Builder::Query.|(RS_CM_00300, RS_CM_00304)

8.28.17 QueryParameter

Service name:	ara::rest::Uri::Builder::	QueryParameter
Type:	Member function	
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >
	Builder& ara::re	st::Uri::Builder::QueryParameter(T
	&&key)	
Function param:	key	of a query parameter
Return value:	a reference to this bui	der
Exceptions:	Implementation-define	ed
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Inserts a query paran action is performed.	neter (key only) If the given key already exists, no

Table 8.298: ara::rest::Uri::Builder::QueryParameter

[SWS_REST_02273] ara::rest::Uri::Builder::QueryParameter [Table 8.298 describes the interface ara::rest::Uri::Builder::QueryParameter.] (RS CM 00300, RS CM 00304)

8.28.18 QueryParameter

Service name:	ara::rest::Uri::Builder::	ara::rest::Uri::Builder::QueryParameter	
Type:	Member function		
Syntax:	template <typena< th=""><th>me T , typename U ></th></typena<>	me T , typename U >	
	Builder& ara::re	st::Uri::Builder::QueryParameter(T	
	&&key, U &&value)	
Function param:	key	a key	
Function param:	value	a value	
Return value:	a reference to this builder		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Inserts a query param no action is performed	eter (key and value) If the given key already exists, d.	

Table 8.299: ara::rest::Uri::Builder::QueryParameter



[SWS_REST_02274] ara::rest::Uri::Builder::QueryParameter [Table 8.299 describes the interface ara::rest::Uri::Builder::QueryParameter.] (RS CM 00300, RS CM 00304)

8.28.19 QueryParameterAt

Service name:	ara::rest::Uri::Builder::	QueryParameterAt	
Type:	Member function		
Syntax:	template <typena< th=""><th>me T , typename U ></th></typena<>	me T , typename U >	
	Builder& ara::re	st::Uri::Builder::QueryParameterAt(T	
	&&oldkey, U &≠	wkey)	
Function param:	oldkey	a key	
Function param:	newkey	a value	
Return value:	a reference to this buil	der	
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Replaces an existing paramater (key only) If old exists, then it is replaced		
	by new. Otherwise no	by new. Otherwise no action is performed. If the existing key is part of a	
	key/value pair, the ent	ire pair is replaced.	

Table 8.300: ara::rest::Uri::Builder::QueryParameterAt

[SWS_REST_02275] ara::rest::Uri::Builder::QueryParameterAt [Table 8.300 describes the interface ara::rest::Uri::Builder::QueryParameterAt.] (RS CM 00300, RS CM 00304)

8.28.20 QueryParameterAt

Service name:	ara::rest::Uri::Builder:	:QueryParameterAt
Type:	Member function	
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >
	Builder& ara::re	st::Uri::Builder::QueryParameterAt(T
	&&key)	
Function param:	key	a key
Return value:	a reference to this bui	lder
Exceptions:	Implementation-define	ed
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:		ameter (by key) If key exists, removes it. Otherwise
		ed. If key belong to a key/value pair, the pair is
	removed. Throws std:	:invalid_argument if parsing fails.

Table 8.301: ara::rest::Uri::Builder::QueryParameterAt

[SWS_REST_02276] ara::rest::Uri::Builder::QueryParameterAt [Table 8.301 describes the interface ara::rest::Uri::Builder::QueryParameterAt.] (RS_CM_00300, RS_CM_00304)



8.28.21 QueryParameterAt

Service name:	ara::rest::Uri::Builder::	QueryParameterAt	
Type:	Member function	Member function	
Syntax:	template <typena< th=""><th>me T , typename U , typename V ></th></typena<>	me T , typename U , typename V >	
	Builder& ara::re	st::Uri::Builder::QueryParameterAt(T	
	&&oldkey, U &≠	wkey, V &&newvalue)	
Function param:	oldkey	a key	
Function param:	newkey	a value	
Function param:	newvalue	a value	
Return value:	a reference to this buil	a reference to this builder	
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Replaces an existing paramater (key + value) If oldkey exists, then it is		
	replaced (including its	replaced (including its value) by newkey and newvalue. Otherwise no	
	action is performed. If	no old value exists, it is set.	

Table 8.302: ara::rest::Uri::Builder::QueryParameterAt

[SWS_REST_02277] ara::rest::Uri::Builder::QueryParameterAt [Table 8.302 describes the interface ara::rest::Uri::Builder::QueryParameterAt.] (RS_CM_00300, RS_CM_00304)

8.28.22 Fragment

Service name:	ara::rest::Uri::Builder::	Fragment
Type:	Member function	
Syntax:	template <typena< th=""><th>me T ></th></typena<>	me T >
	Builder& ara::re	st::Uri::Builder::Fragment(T &&value)
Function param:	value	a value of an output-streamable type
Return value:	a reference to this buil	der
Exceptions:	Implementation-define	ed
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Sets the fragment cor parsing fails.	mponent of a URI Throws std::invalid_argument if

Table 8.303: ara::rest::Uri::Builder::Fragment

[SWS_REST_02278] ara::rest::Uri::Builder::Fragment [Table 8.303 describes the interface ara::rest::Uri::Builder::Fragment.](RS_CM_00300, RS_CM_00304)

8.28.23 Fragment

Service name:	ara::rest::Uri::Builder::Fragment	
Type:	Member function	



Syntax:	Builder& ara::rest::Uri::Builder::Fragment()
Function param:	None
Return value:	a reference to this builder
Exceptions:	Implementation-defined
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri::Builder
Description:	Clears the fragment component.

Table 8.304: ara::rest::Uri::Builder::Fragment

[SWS_REST_02279] ara::rest::Uri::Builder::Fragment [Table 8.304 describes the interface ara::rest::Uri::Builder::Fragment.](RS_CM_00300, RS_CM_00304)

8.28.24 ToUri

Service name:	ara::rest::Uri::Builder::ToUri
Type:	Member function
Syntax:	Uri ara::rest::Uri::Builder::ToUri() const
Function param:	None
Return value:	a value of type Uri
Exceptions:	Implementation-defined
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri::Builder
Description:	Returns a Uri.

Table 8.305: ara::rest::Uri::Builder::ToUri

[SWS_REST_02280] ara::rest::Uri::Builder::ToUri [Table 8.305 describes the interface ara::rest::Uri::Builder::ToUri.|(RS_CM_00300, RS_CM_00304)

8.28.25 ToPath

Service name:	ara::rest::Uri::Builder::ToPath		
Type:	Member function		
Syntax:	<pre>Uri::Path ara::rest::Uri::Builder::ToPath() const</pre>		
Function param:	None		
Return value:	a value of type Uri::Path		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Builder		
Description:	Returns a Uri path.		

Table 8.306: ara::rest::Uri::Builder::ToPath

[SWS_REST_02422] ara::rest::Uri::Builder::ToPath | Table 8.306 describes the interface ara::rest::Uri::Builder::ToPath.|(RS_CM_00300, RS_CM_00304)



8.28.26 ToQuery

Service name:	ara::rest::Uri::Builder::ToQuery	
Type:	Member function	
Syntax:	<pre>Uri::Query ara::rest::Uri::Builder::ToQuery() const</pre>	
Function param:	None	
Return value:	a value of type Uri::Query	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Builder	
Description:	Returns a Uri query.	

Table 8.307: ara::rest::Uri::Builder::ToQuery

[SWS_REST_02424] ara::rest::Uri::Builder::ToQuery [Table 8.307 describes the interface ara::rest::Uri::Builder::ToQuery.](RS_CM_00300, RS_CM_00304)

8.29 ara::rest::Uri::Path::Segment

[SWS_REST_02281] [ara::rest::Uri::Path::Segment class shall be declared in the ara/rest/uri.h header file:

```
class ara::rest::Uri::Path::Segment;
```

(RS_CM_00300, RS_CM_00304)

8.29.1 Get

Service name:	ara::rest::Uri::Path::Segment::Get		
Type:	Member function		
Syntax:	StringView ara::rest::Uri::Path::Segment::Get()		
Function param:	None		
Return value:	a string representation of this path segment		
Exceptions:	noexcept(std::is_nothrow_constructible< StringView		
	>::value)		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Path::Segment		
Description:	Returns a string representation of this path segment. The representation		
	is non-percent-encoded		

Table 8.308: ara::rest::Uri::Path::Segment::Get

[SWS_REST_02282] ara::rest::Uri::Path::Segment::Get [Table 8.308 describes the interface ara::rest::Uri::Path::Segment::Get.](RS_CM_00300, RS_CM_00304)



8.29.2 GetAs

Service name:	ara::rest::Uri::Path::Segment::GetAs	
Type:	Member function template	
Syntax:	template <typename t=""></typename>	
	T ara::rest::Uri	::Path::Segment::GetAs(T &&def={})
	const	
Function param:	def	a default value
Return value:	an instance of type T that represents this URI component.	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Path::Segment	
Description:	Returns this segment converted to a user-defined type. The conversion	
	result is assigned to the function argument which is subsequently re-	
	turned. If conversion fails the function argument is returned unchanged.	
	So either form is val	<pre>id: GetAs<string>(), GetAs(string{my_allocator}),</string></pre>
	GetAs <string>("conve</string>	rsion failed")

Table 8.309: ara::rest::Uri::Path::Segment::GetAs

[SWS_REST_02283] ara::rest::Uri::Path::Segment::GetAs [Table 8.309 describes the interface ara::rest::Uri::Path::Segment::GetAs.](RS_CM_00300, RS_CM_00304)

8.29.3 operator==

Service name:	ara::rest::Uri::Path::Segment::operator==		
Type:	Non-member funct	ion	
Syntax:	friend bool oper	friend bool operator == (const Segment &a, const	
	Segment &b)		
Function param:	а	object to compare	
Function param:	b	object to compare	
Return value:	true if segments compare equal		
Exceptions:	noexcept		
Header file:	ara/rest/uri.h		
Namespace:	ara::rest::Uri::Path::Segment		
Description:	Tests two segments for	Tests two segments for equality.	

Table 8.310: ara::rest::Uri::Path::Segment::operator==

[SWS_REST_02284] ara::rest::Uri::Path::Segment::operator== [Table 8.310 describes the interface ara::rest::Uri::Path::Segment::operator==.] (RS_CM_00300, RS_CM_00304)

8.29.4 operator!=

Service name:	ara::rest::Uri::Path::Segment::operator!=	
Type:	Non-member function	



Syntax:	friend bool operator!=(const Segment &a, const	
	Segment &b)	
Function param:	a object to compare	
Function param:	b	object to compare
Return value:	true if segments compare unequal	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest::Uri::Path::Segment	
Description:	Tests two segments for inequality.	

Table 8.311: ara::rest::Uri::Path::Segment::operator!=

[SWS_REST_02285] ara::rest::Uri::Path::Segment::operator!= [Table 8.311 describes the interface ara::rest::Uri::Path::Segment::operator!=.] (RS_CM_00300, RS_CM_00304)

8.29.5 operator<

Service name:	ara::rest::Uri::Path::Segment::operator<			
Type:	Non-member funct	Non-member function		
Syntax:	friend bool oper	friend bool operator<(const Segment &a, const Segment		
	(d3			
Function param:	а	object to compare		
Function param:	b object to compare			
Return value:	true if a compares less-than b			
Exceptions:	noexcept			
Header file:	ara/rest/uri.h			
Namespace:	ara::rest::Uri::Path::Segment			
Description:	Compares two path segments according to their lexicographical order.			

Table 8.312: ara::rest::Uri::Path::Segment::operator<

[SWS_REST_02286] ara::rest::Uri::Path::Segment::operator< [Table 8.312 describes the interface ara::rest::Uri::Path::Segment::operator<.] (RS CM 00300, RS CM 00304)

8.30 ara::rest::Uri::Path

[SWS_REST_02287] [ara::rest::Uri::Path class shall be declared in the ara/rest/uri.h header file:

class ara::rest::Uri::Path;

(RS_CM_00300, RS_CM_00304)



8.30.1 IteratorRange

Name:	IteratorRange	
Type:	Member type alias	
Syntax:	<pre>using ara::rest::Uri::Path::IteratorRange =</pre>	
	ara::rest::IteratorRange <unspecified_iterator_type></unspecified_iterator_type>	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Path	
Description:	Iterator range of path segments.	

Table 8.313: ara::rest::Uri::Path::IteratorRange

[SWS_REST_02288] IteratorRange [Table 8.313 describes the type alias ara::rest::Uri::Path::IteratorRange.|(RS_CM_00300, RS_CM_00304)

8.30.2 NumSegments

Service name:	ara::rest::Uri::Path::NumSegments		
Type:	Member function		
Syntax:	<pre>std::size_t ara::rest::Uri::Path::NumSegments() const</pre>		
Function param:	None		
Return value:	a number of path segmeents		
Exceptions:	noexcept		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Path		
Description:	Returns the number of path segments.		

Table 8.314: ara::rest::Uri::Path::NumSegments

8.30.3 GetSegments

Service name:	ara::rest::Uri::Path::GetSegments	
Type:	Member function	
Syntax:	<pre>IteratorRange ara::rest::Uri::Path::GetSegments()</pre>	
	const	
Function param:	None	
Return value:	an iterator range of path segments	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Path	
Description:	Returns a range of path segments.	

Table 8.315: ara::rest::Uri::Path::GetSegments



[SWS_REST_02290] ara::rest::Uri::Path::GetSegments [Table 8.315 describes the interface ara::rest::Uri::Path::GetSegments.](RS_CM_00300, RS_CM_00304)

8.30.4 operator==

Service name:	ara::rest::Uri::Path::operator==	
Type:	Non-member function	
Syntax:	friend bool operator==(const Path &a, const Path &b)	
Function param:	a	object to compare
Function param:	b	object to compare
Return value:	true if equal	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest::Uri::Path	
Description:	Tests two paths for equality.	

Table 8.316: ara::rest::Uri::Path::operator==

[SWS_REST_02291] ara::rest::Uri::Path::operator== [Table 8.316 describes the interface ara::rest::Uri::Path::operator==.](RS_CM_00300, RS_CM_00304)

8.30.5 operator!=

Service name:	ara::rest::Uri::Path::operator!=	
Type:	Non-member function	
Syntax:	friend bool operator!=(const Path &a, const Path &b)	
Function param:	а	object to compare
Function param:	b	object to compare
Return value:	true if not equal	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest::Uri::Path	
Description:	Tests two paths for inequality.	

Table 8.317: ara::rest::Uri::Path::operator!=

[SWS_REST_02292] ara::rest::Uri::Path::operator!= [Table 8.317 describes the interface ara::rest::Uri::Path::operator!=.](RS_CM_00300, RS_CM_00304)

8.30.6 operator<

Service name:	ara::rest::Uri::Path::operator<



Type:	Non-member function	
Syntax:	friend bool operator<(const Path &a, const Path &b)	
Function param:	а	object to compare
Function param:	b	object to compare
Return value:	true if a compares less-than b	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest::Uri::Path	
Description:	Relates two paths according to their lexicographical order.	

Table 8.318: ara::rest::Uri::Path::operator<

[SWS_REST_02293] ara::rest::Uri::Path::operator< [Table 8.318 describes the interface ara::rest::Uri::Path::operator<.|(RS CM 00300, RS CM 00304)

8.31 ara::rest::Uri::Query::Parameter

[SWS_REST_02294] [ara::rest::Uri::Query::Parameter class shall be declared in the ara/rest/uri.h header file:

```
class ara::rest::Uri::Query::Parameter;
```

(RS CM 00300, RS CM 00304)

8.31.1 **GetKey**

Service name:	ara::rest::Uri::Query::Parameter::GetKey	
Type:	Member function	
Syntax:	StringView ara::rest::Uri::Query::Parameter::GetKey()	
	const	
Function param:	None	
Return value:	a string representation	
Exceptions:	noexcept(std::is_nothrow_constructible< StringView	
	>::value)	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Query::Parameter	
Description:	Returns a string representation of the parameter key The representation	
	is non-percent-encoded.	

Table 8.319: ara::rest::Uri::Query::Parameter::GetKey



8.31.2 GetKeyAs

Service name:	ara::rest::Uri::Query::I	Parameter::GetKeyAs	
Type:	Member function template		
Syntax:	template <typena< th=""><th colspan="2">template <typename t=""></typename></th></typena<>	template <typename t=""></typename>	
	T ara::rest::Uri	::Query::Parameter::GetKeyAs(T	
	&&def={}) const		
Function param:	def	a default value	
Return value:	an instance of type T	an instance of type T that represents this URI component.	
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Query::Parameter		
Description:	Converts a query parameter key to the specified type. The conversion		
	result is assigned to the function argument which is subsequently re-		
	turned. If conversion fails the function argument is returned unchanged.		
	So either form is valid: GetAs <string>(), GetAs(string{my_allocator}),</string>		
	GetAs <string>("conve</string>	ersion failed")	

Table 8.320: ara::rest::Uri::Query::Parameter::GetKeyAs

[SWS_REST_02296] ara::rest::Uri::Query::Parameter::GetKeyAs [Table 8.320 describes the interface ara::rest::Uri::Query::Parameter::GetKeyAs.] (RS_CM_00300, RS_CM_00304)

8.31.3 HasValue

Service name:	ara::rest::Uri::Query::Parameter::HasValue	
Type:	Member function	
Syntax:	<pre>bool ara::rest::Uri::Query::Parameter::HasValue()</pre>	
	const	
Function param:	None	
Return value:	true if this query paramater has a value component	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Query::Parameter	
Description:	Needs documentation.	

Table 8.321: ara::rest::Uri::Query::Parameter::HasValue

8.31.4 GetValue

Service name:	ara::rest::Uri::Query::Parameter::GetValue	
Type:	Member function	



Syntax:	StringView	
	ara::rest::Uri::Query::Parameter::GetValue() const	
Function param:	None	
Return value:	a string representation of the value	
Exceptions:	noexcept(std::is_nothrow_constructible< StringView	
	>::value)	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Query::Parameter	
Description:	Obtains the value of a query parameter If none exists the result is unde-	
	fined.	

Table 8.322: ara::rest::Uri::Query::Parameter::GetValue

[SWS_REST_02298] ara::rest::Uri::Query::Parameter::GetValue [Table 8.322 describes the interface ara::rest::Uri::Query::Parameter::GetValue.] (RS CM 00300, RS CM 00304)

8.31.5 GetValueAs

Service name:	ara::rest::Uri::Query::	Parameter::GetValueAs	
Type:	Member function template		
Syntax:	template <typena< th=""><th colspan="2">template <typename t=""></typename></th></typena<>	template <typename t=""></typename>	
	T ara::rest::Uri	::Query::Parameter::GetValueAs(T	
	&&def={}) const		
Function param:	def	a default value	
Return value:	an instance of type T	that represents this URI component.	
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Query::Parameter		
Description:	Converts a query parameter value to the specified type. The conversion result is assigned to the function argument which is subsequently re-		
	turned. If conversion fails the function argument is returned unchanged.		
		id: GetAs <string>(), GetAs(string{my_allocator}),</string>	
	GetAs <string>("conve</string>	ersion tailed")	

Table 8.323: ara::rest::Uri::Query::Parameter::GetValueAs

[SWS_REST_02299] ara::rest::Uri::Query::Parameter::GetValueAs [Table 8.323 describes the interface ara::rest::Uri::Query::Parameter::GetValueAs.] (RS CM 00300, RS CM 00304)

8.32 ara::rest::Uri::Query

[SWS_REST_02300] [ara::rest::Uri::Query class shall be declared in the ara/rest/uri.h header file:

class ara::rest::Uri::Query;



(RS CM 00300, RS CM 00304)

8.32.1 IteratorRange

Name:	IteratorRange
Type:	Member type alias
Syntax:	using ara::rest::Uri::Query::IteratorRange =
	ara::rest::IteratorRange <unspecified_iterator_type></unspecified_iterator_type>
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri::Query
Description:	A range of query parameters.

Table 8.324: ara::rest::Uri::Query::IteratorRange

[SWS_REST_02301] IteratorRange [Table 8.324 describes the type alias ara::rest::Uri::Query::IteratorRange.|(RS CM 00300, RS CM 00304)

8.32.2 NumParameters

Service name:	ara::rest::Uri::Query::NumParameters	
Type:	Member function	
Syntax:	<pre>std::size_t ara::rest::Uri::Query::NumParameters()</pre>	
	const	
Function param:	None	
Return value:	the number of query parameters	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Query	
Description:	Returns the number of query parameters.	

Table 8.325: ara::rest::Uri::Query::NumParameters

[SWS_REST_02302] ara::rest::Uri::Query::NumParameters [Table 8.325 describes the interface ara::rest::Uri::Query::NumParameters.](RS_CM_00300, RS_CM_00304)

8.32.3 GetParameters

Service name:	ara::rest::Uri::Query::GetParameters	
Type:	Member function	
Syntax:	<pre>IteratorRange ara::rest::Uri::Query::GetParameters()</pre>	
	const	
Function param:	None	
Return value:	an iterator range of query parameters	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	



Class:	ara::rest::Uri::Query
Description:	Returns the range of all query parameters.

Table 8.326: ara::rest::Uri::Query::GetParameters

[SWS_REST_02303] ara::rest::Uri::Query::GetParameters [Table 8.326 describes the interface ara::rest::Uri::Query::GetParameters.](RS_CM_00300, RS_CM_00304)

8.32.4 GetParameter

Service name:	ara::rest::Uri::Query::0	GetParameter
Type:	Member function	
Syntax:	const Parameter&	
	ara::rest::Uri::	Query::GetParameter(std::size_t i)
	const	
Function param:	i	an index
Return value:	a reference to the query parameter	
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Query	
Description:	Returns a specific que	ery parameter by index.

Table 8.327: ara::rest::Uri::Query::GetParameter

[SWS_REST_02304] ara::rest::Uri::Query::GetParameter | Table 8.327 describes the interface ara::rest::Uri::Query::GetParameter.](RS_CM_00300, RS_CM_00304)

8.32.5 Find

Service name:	ara::rest::Uri::Query::F	ind
Type:	Member function	
Syntax:	IteratorRange::Iterator	
	ara::rest::Uri::	Query::Find(StringView key) const
Function param:	key	a key
Return value:	an iterator to the respe	ective query parameter
Exceptions:	noexcept	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri::Query	
Description:	Searches for a query	parameter by key.

Table 8.328: ara::rest::Uri::Query::Find

[SWS_REST_02305] ara::rest::Uri::Query::Find [Table 8.328 describes the interface ara::rest::Uri::Query::Find.](RS_CM_00300, RS_CM_00304)



8.32.6 HasKey

Service name:	ara::rest::Uri::Query::l	HasKey	
Type:	Member function		
Syntax:	bool ara::rest::	bool ara::rest::Uri::Query::HasKey(StringView key)	
Function param:	key	a key	
Return value:	true of key exists		
Exceptions:	noexcept		
Header file:	ara/rest/uri.h		
Class:	ara::rest::Uri::Query		
Description:	Tests whether a query	parameter of a given key exists.	

Table 8.329: ara::rest::Uri::Query::HasKey

[SWS_REST_02306] ara::rest::Uri::Query::HasKey [Table 8.329 describes the interface ara::rest::Uri::Query::HasKey.|(RS_CM_00300, RS_CM_00304)

8.33 ara::rest::Uri

[SWS_REST_02307] [ara::rest::Uri class shall be declared in the ara/rest/uri.h header file:

class ara::rest::Uri;

(RS_CM_00300, RS_CM_00304)

8.33.1 Part

Name:	Part	
Type:	Member enumera	tion
Range:	kScheme	= 1 « 1
	kUserInfo	= 1 « 2
	kHost	= 1 « 3
	kPort	= 1 « 4
	kPath	= 1 « 5
	kQuery	= 1 « 6
	kFragment	= 1 « 7
	kPathAndQuery	= Part::kPath Part::kQuery
	kPathEtc	= Part::kPath Part::kQuery
		Part::kFragment
	kAll	= ~std::underlying_type <part>::type{0}</part>



```
Syntax:
             enum class Part : std::uint32_t {
             kScheme = 1 \ll 1,
             kUserInfo = 1 \ll 2,
             kHost = 1 \ll 3,
             kPort = 1 \ll 4
             kPath = 1 \ll 5,
             kQuery = 1 \ll 6,
             kFragment = 1 \ll 7,
             kPathAndQuery = Part::kPath | Part::kQuery,
             kPathEtc = Part::kPath | Part::kQuery
             |Part::kFragment,
             kAll = ~std::underlying_type<Part>::type{0}
Header file:
             ara/rest/uri.h
Class:
             ara::rest::Uri
Description: Used to specify a subset of a URI. Part defines components of a
```

Table 8.330: ara::rest::Uri::Part

[SWS_REST_02308] Part [Table 8.330 describes the enumeration datatype ara::rest::Uri::Part.|(RS_CM_00300, RS_CM_00304)

8.33.2 LENGTH MAX

Name:	LENGTH_MAX
Туре:	Member variable
Syntax:	static constexpr std::size_t LENGTH_MAX = 2048;
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	The maximum length of a URI. The suggested length maximum is around 2000 characters which roughly conforms to the typical limit that mainstream webbrowsers support. A bound is specified to enable optimization potential in the internal encoding.

Table 8.331: ara::rest::Uri::LENGTH_MAX

[SWS_REST_02309] ara::rest::Uri::LENGTH_MAX [Table 8.331 describes the variable ara::rest::Uri::LENGTH_MAX.] (RS_CM_00300, RS_CM_00304)

8.33.3 operator

Service name:	ara::rest::Uri::operator	
Type:	Non-member functi	Lon
Syntax:	friend constexpr	Part operator (Part a, Part b)
Function param:	a	(set of) Part enumerator(s)
Function param:	b	(set of) Part enumerator(s)
Return value:	a set of Part enumerators	
Exceptions:	noexcept	



Header file:	ara/rest/uri.h
Namespace:	ara::rest::Uri
Description:	Computes a set of Part enumerators.

Table 8.332: ara::rest::Uri::operator

[SWS_REST_02310] ara::rest::Uri::operator| [Table 8.332 describes the interface ara::rest::Uri::operator|.|(RS CM 00300, RS CM 00304)

8.33.4 Uri

Service name:	ara::rest::Uri::Uri	
Type:	Member function	
Syntax:	ara::rest::Uri::Uri() =default	
Function param:	None	
Return value:	None	
Exceptions:	noexcept=default	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri	
Description:	Constructs a default URI. A default-constructed URI is empty. To popu-	
	late an existing URI, Uri::Builder must be used. Uri member functions	
	must not throw unless in those cases where StringView is used and	
	StringView is not 'nothrow_constructible'.	

Table 8.333: ara::rest::Uri::Uri

[SWS_REST_02311] ara::rest::Uri::Uri $\[$ Table 8.333 describes the interface ara::rest::Uri::Uri.] $\[$ (RS_CM_00300, RS_CM_00304) $\]$

8.33.5 HasScheme

Service name:	ara::rest::Uri::HasScheme
Type:	Member function
Syntax:	bool ara::rest::Uri::HasScheme() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Has scheme.

Table 8.334: ara::rest::Uri::HasScheme

[SWS_REST_02312] ara::rest::Uri::HasScheme [Table 8.334 describes the interface ara::rest::Uri::HasScheme.|(RS CM 00300, RS CM 00304)



8.33.6 GetScheme

Service name:	ara::rest::Uri::GetScheme	
Type:	Member function	
Syntax:	StringView ara::rest::Uri::GetScheme() const	
Function param:	None	
Return value:	a value of type StringView	
Exceptions:	<pre>noexcept(std::is_nothrow_constructible< StringView</pre>	
	>::value)	
Header file:	ara/rest/uri.h	
Class:	ara::rest::Uri	
Description:	gets scheme.	

Table 8.335: ara::rest::Uri::GetScheme

[SWS_REST_02313] ara::rest::Uri::GetScheme [Table 8.335 describes the interface ara::rest::Uri::GetScheme.|(RS_CM_00300, RS_CM_00304)

8.33.7 HasUserInfo

Service name:	ara::rest::Uri::HasUserInfo
Type:	Member function
Syntax:	bool ara::rest::Uri::HasUserInfo() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	has user info.

Table 8.336: ara::rest::Uri::HasUserInfo

[SWS_REST_02314] ara::rest::Uri::HasUserInfo [Table 8.336 describes the interface ara::rest::Uri::HasUserInfo.](RS_CM_00300, RS_CM_00304)

8.33.8 GetUserinfo

Service name:	ara::rest::Uri::GetUserinfo
Type:	Member function
Syntax:	StringView ara::rest::Uri::GetUserinfo() const
Function param:	None
Return value:	a value of type StringView
Exceptions:	<pre>noexcept(std::is_nothrow_constructible< StringView</pre>
	>::value)
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	get user info.

Table 8.337: ara::rest::Uri::GetUserinfo



[SWS_REST_02315] ara::rest::Uri::GetUserinfo [Table 8.337 describes the interface ara::rest::Uri::GetUserinfo.](RS_CM_00300, RS_CM_00304)

8.33.9 HasHost

Service name:	ara::rest::Uri::HasHost
Type:	Member function
Syntax:	bool ara::rest::Uri::HasHost() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	has host.

Table 8.338: ara::rest::Uri::HasHost

[SWS_REST_02316] ara::rest::Uri::HasHost [Table 8.338 describes the interface ara::rest::Uri::HasHost.|(RS CM 00300, RS CM 00304)

8.33.10 GetHost

Service name:	ara::rest::Uri::GetHost
Type:	Member function
Syntax:	StringView ara::rest::Uri::GetHost() const
Function param:	None
Return value:	a value of type StringView
Exceptions:	noexcept(std::is_nothrow_constructible< StringView
	>::value)
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	get host.

Table 8.339: ara::rest::Uri::GetHost

[SWS_REST_02317] ara::rest::Uri::GetHost [Table 8.339 describes the interface ara::rest::Uri::GetHost.|(RS_CM_00300, RS_CM_00304)

8.33.11 HasPort

Service name:	ara::rest::Uri::HasPort
Type:	Member function
Syntax:	bool ara::rest::Uri::HasPort() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept



Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	has host.

Table 8.340: ara::rest::Uri::HasPort

[SWS_REST_02318] ara::rest::Uri::HasPort [Table 8.340 describes the interface ara::rest::Uri::HasPort.|(RS CM 00300, RS CM 00304)

8.33.12 **GetPort**

Service name:	ara::rest::Uri::GetPort
Type:	Member function
Syntax:	<pre>int ara::rest::Uri::GetPort() const</pre>
Function param:	None
Return value:	a value of type int
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	get port.

Table 8.341: ara::rest::Uri::GetPort

[SWS_REST_02319] ara::rest::Uri::GetPort [Table 8.341 describes the interface ara::rest::Uri::GetPort.](RS_CM_00300, RS_CM_00304)

8.33.13 HasPath

Service name:	ara::rest::Uri::HasPath
Type:	Member function
Syntax:	bool ara::rest::Uri::HasPath() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	has path.

Table 8.342: ara::rest::Uri::HasPath

[SWS_REST_02320] ara::rest::Uri::HasPath [Table 8.342 describes the interface ara::rest::Uri::HasPath.|(RS_CM_00300, RS_CM_00304)

8.33.14 GetPath



Service name:	ara::rest::Uri::GetPath
Type:	Member function
Syntax:	const Path& ara::rest::Uri::GetPath() const
Function param:	None
Return value:	a value of type const Path &
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	get path.

Table 8.343: ara::rest::Uri::GetPath

[SWS_REST_02321] ara::rest::Uri::GetPath [Table 8.343 describes the interface ara::rest::Uri::GetPath.] $(RS_CM_00300, RS_CM_00304)$

8.33.15 HasQuery

Service name:	ara::rest::Uri::HasQuery
Type:	Member function
Syntax:	bool ara::rest::Uri::HasQuery() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	has query.

Table 8.344: ara::rest::Uri::HasQuery

[SWS_REST_02322] ara::rest::Uri::HasQuery [Table 8.344 describes the interface ara::rest::Uri::HasQuery.|(RS_CM_00300, RS_CM_00304)

8.33.16 GetQuery

Service name:	ara::rest::Uri::GetQuery
Type:	Member function
Syntax:	const Query& ara::rest::Uri::GetQuery() const
Function param:	None
Return value:	a value of type const Query &
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	get query.

Table 8.345: ara::rest::Uri::GetQuery



[SWS_REST_02323] ara::rest::Uri::GetQuery [Table 8.345 describes the interface ara::rest::Uri::GetQuery.] (RS_CM_00300, RS_CM_00304)

8.33.17 HasFragment

Service name:	ara::rest::Uri::HasFragment
Type:	Member function
Syntax:	bool ara::rest::Uri::HasFragment() const
Function param:	None
Return value:	a value of type bool
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Has Fragment.

Table 8.346: ara::rest::Uri::HasFragment

[SWS_REST_02324] ara::rest::Uri::HasFragment [Table 8.346 describes the interface ara::rest::Uri::HasFragment.](RS_CM_00300, RS_CM_00304)

8.33.18 GetFragment

Service name:	ara::rest::Uri::GetFragment
Type:	Member function
Syntax:	StringView ara::rest::Uri::GetFragment() const
Function param:	None
Return value:	a value of type StringView
Exceptions:	noexcept(std::is_nothrow_constructible< StringView
	>::value)
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Get Fragment as string.

Table 8.347: ara::rest::Uri::GetFragment

[SWS_REST_02325] ara::rest::Uri::GetFragment [Table 8.347 describes the interface ara::rest::Uri::GetFragment.|(RS_CM_00300, RS_CM_00304)

8.33.19 GetFragmentAs

Service name:	ara::rest::Uri::GetFragmentAs	
Type:	Member function template	
Syntax:	template <typename t=""></typename>	
	T ara::rest::Uri::GetFragmentAs(T &&def={}) const	
Function param:	def	a default value
Return value:	an instance of type T that represents this URI component	



Exceptions:	Implementation-defined
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Converts a URI fragment part to a given type. The conversion result is assigned to the function argument which is subsequently returned. If conversion fails the function argument is returned unchanged. So either form is valid: GetFragmentAs <string>(), GetFragmentAs(string{my_allocator}), GetFragmentAs<string>("conversion failed")</string></string>

Table 8.348: ara::rest::Uri::GetFragmentAs

[SWS_REST_02326] ara::rest::Uri::GetFragmentAs [Table 8.348 describes the interface ara::rest::Uri::GetFragmentAs.|(RS_CM_00300, RS_CM_00304)

8.33.20 IsEmpty

Service name:	ara::rest::Uri::IsEmpty
Type:	Member function
Syntax:	bool ara::rest::Uri::IsEmpty() const
Function param:	None
Return value:	true if empty
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Is URI empty.

Table 8.349: ara::rest::Uri::IsEmpty

[SWS_REST_02327] ara::rest::Uri::IsEmpty | Table 8.349 describes the interface ara::rest::Uri::IsEmpty.|(RS_CM_00300, RS_CM_00304)

8.33.21 IsRelative

Service name:	ara::rest::Uri::IsRelative
Type:	Member function
Syntax:	bool ara::rest::Uri::IsRelative() const
Function param:	None
Return value:	true if relative
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Is URI relative. An URI is relative if it does not starts with a scheme.

Table 8.350: ara::rest::Uri::IsRelative



[SWS_REST_02328] ara::rest::Uri::IsRelative [Table 8.350 describes the interface ara::rest::Uri::IsRelative.](RS_CM_00300, RS_CM_00304)

8.33.22 **IsOpaque**

Service name:	ara::rest::Uri::isOpaque
Type:	Member function
Syntax:	bool ara::rest::Uri::isOpaque() const
Function param:	None
Return value:	true if this URI is opaque
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Denotes whether the URI is opaque. An opaque URI is an absolute URI whose scheme-specific part does not begin with a slash character ('/').

Table 8.351: ara::rest::Uri::isOpaque

[SWS_REST_02329] ara::rest::Uri::isOpaque [Table 8.351 describes the interface ara::rest::Uri::isOpaque.](RS_CM_00300, RS_CM_00304)

8.33.23 IsHierarchical

Service name:	ara::rest::Uri::isHierarchical
Type:	Member function
Syntax:	bool ara::rest::Uri::isHierarchical() const
Function param:	None
Return value:	true if this URI is hierarchical
Exceptions:	noexcept
Header file:	ara/rest/uri.h
Class:	ara::rest::Uri
Description:	Denotes wether this URI is hierarchical. A hierarchical URI is either an
	absolute URI whose scheme-specific part begins with a slash character,
	or a relative URI, that is, a URI that does not specify a scheme.

Table 8.352: ara::rest::Uri::isHierarchical

[SWS_REST_02330] ara::rest::Uri::isHierarchical [Table 8.352 describes the interface ara::rest::Uri::isHierarchical.|(RS_CM_00300, RS_CM_00304)

8.34 ara::rest::Uuid

[SWS_REST_02331] [ara::rest::Uuid class shall be declared in the ara/rest/uuid.h header file:

class ara::rest::Uuid;



(RS CM 00300)

8.34.1 MakeV1

ara::rest::Uuid::MakeV1
Member function
static Uuid ara::rest::Uuid::MakeV1()
Generated Uuid
Implementation-defined
ara/rest/uuid.h
ara::rest::Uuid
Creates an UUID with version 1 defined in RFC4122 (date-time and MAC address).
]

Table 8.353: ara::rest::Uuid::MakeV1

[SWS_REST_02418] ara::rest::Uuid::MakeV1 | Table 8.353 describes the interface ara::rest::Uuid::MakeV1.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.34.2 MakeV3

Service name:	ara::rest::Uuid::Make\	/3	
Type:	Member function		
Syntax:	static Uuid ara:	static Uuid ara::rest::Uuid::MakeV3(const String& ns)	
Function param:	ns	UUID namespace	
Return value:	Generated Uuid		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/uuid.h		
Class:	ara::rest::Uuid		
Description:	Creates an UUID with MD5).	h version 3 defined in RFC4122 (namespace with	

Table 8.354: ara::rest::Uuid::MakeV3

[SWS_REST_02419] ara::rest::Uuid::MakeV3 | Table 8.354 describes the interface ara::rest::Uuid::MakeV3.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.34.3 MakeV4

Service name:	ara::rest::Uuid::MakeV4
Type:	Member function
Syntax:	static Uuid ara::rest::Uuid::MakeV4()
Return value:	Generated Uuid
Exceptions:	Implementation-defined



Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Creates an UUID with version 4 defined in RFC4122 (random).

Table 8.355: ara::rest::Uuid::MakeV4

[SWS_REST_02420] ara::rest::Uuid::MakeV4 | Table 8.355 describes the interface ara::rest::Uuid::MakeV4.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.34.4 MakeV5

Service name:	ara::rest::Uuid::Make\	/5	
Type:	Member function		
Syntax:	static Uuid ara:	static Uuid ara::rest::Uuid::MakeV5(const String& ns)	
Function param:	ns	UUID namespace	
Return value:	Generated Uuid		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/uuid.h		
Class:	ara::rest::Uuid		
Description:	Creates an UUID with SHA1).	n version 5 defined in RFC4122 (namespace with	

Table 8.356: ara::rest::Uuid::MakeV5

[SWS_REST_02421] ara::rest::Uuid::MakeV5 | Table 8.356 describes the interface ara::rest::Uuid::MakeV5.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.34.5 Uuid

Service name:	ara::rest::Uuid::Uuid
Type:	Member function
Syntax:	ara::rest::Uuid::Uuid() =default
Function param:	None
Return value:	None
Exceptions:	noexcept=default
Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Default constructs a Uuid.

Table 8.357: ara::rest::Uuid::Uuid

[SWS_REST_02332] ara::rest::Uuid::Uuid [Table 8.357 describes the interface ara::rest::Uuid::Uuid.](RS_CM_00300)



8.34.6 Uuid

Service name:	ara::rest::Uuid::Uuid		
Type:	Member function		
Syntax:	ara::rest::Uuid:	ara::rest::Uuid::Uuid(StringView id)	
Function param:	id	a UUID in RFC4122 format	
Return value:	None		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/uuid.h		
Class:	ara::rest::Uuid		
Description:	Constructs a Uuid std::invalid_argument		

Table 8.358: ara::rest::Uuid::Uuid

[SWS_REST_02333] ara::rest::Uuid::Uuid [Table 8.358 describes the interface ara::rest::Uuid::Uuid.|(RS_CM_00300)

8.34.7 **Uuid**

Service name:	ara::rest::Uuid::Uuid		
Type:	Member function	Member function	
Syntax:	ara::rest::Uuid:	ara::rest::Uuid::Uuid(std::uint32_t timeLow,	
	std::uint16_t ti	meMid, std::uint16_t	
	timeHighAndVersi	on, std::uint16_t clockSeq,	
	std::uint64_t node)		
Function param:	timeLow	see RFC 4122	
Function param:	timeMid	see RFC 4122	
Function param:	timeHighAndVersion	see RFC 4122	
Function param:	clockSeq	see RFC 4122	
Function param:	node	see RFC 4122	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/uuid.h		
Class:	ara::rest::Uuid		
Description:	Constructs a Uuid from its components explicitly.		

Table 8.359: ara::rest::Uuid::Uuid

[SWS_REST_02334] ara::rest::Uuid::Uuid [Table 8.359 describes the interface ara::rest::Uuid::Uuid.](RS_CM_00300)

8.34.8 GetTimeLow

Service name:	ara::rest::Uuid::GetTimeLow
Type:	Member function
Syntax:	std::uint32_t ara::rest::Uuid::GetTimeLow() const
Function param:	None



Return value:	a numeric value
Exceptions:	noexcept
Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Returns time low.

Table 8.360: ara::rest::Uuid::GetTimeLow

[SWS_REST_02335] ara::rest::Uuid::GetTimeLow [Table 8.360 describes the interface ara::rest::Uuid::GetTimeLow.|(RS_CM_00300)

8.34.9 GetTimeMid

Service name:	ara::rest::Uuid::GetTimeMid
Type:	Member function
Syntax:	std::uint16_t ara::rest::Uuid::GetTimeMid() const
Function param:	None
Return value:	a numeric value
Exceptions:	noexcept
Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Returns time mid.

Table 8.361: ara::rest::Uuid::GetTimeMid

[SWS_REST_02336] ara::rest::Uuid::GetTimeMid [Table 8.361 describes the interface ara::rest::Uuid::GetTimeMid.|(RS_CM_00300)

8.34.10 GetTimeHighAndVersion

Service name:	ara::rest::Uuid::GetTimeHighAndVersion
Type:	Member function
Syntax:	std::uint16_t
	ara::rest::Uuid::GetTimeHighAndVersion() const
Function param:	None
Return value:	a numeric value
Exceptions:	noexcept
Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Returns time high and version.

Table 8.362: ara::rest::Uuid::GetTimeHighAndVersion



8.34.11 GetClockSeq

Service name:	ara::rest::Uuid::GetClockSeq
Type:	Member function
Syntax:	std::uint16_t ara::rest::Uuid::GetClockSeq() const
Function param:	None
Return value:	a numeric value
Exceptions:	noexcept
Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Returns clock sequence count.

Table 8.363: ara::rest::Uuid::GetClockSeq

[SWS_REST_02338] ara::rest::Uuid::GetClockSeq [Table 8.363 describes the interface ara::rest::Uuid::GetClockSeq.] (RS_CM_00300)

8.34.12 GetNode

Service name:	ara::rest::Uuid::GetNode
Type:	Member function
Syntax:	std::uint64_t ara::rest::Uuid::GetNode() const
Function param:	None
Return value:	return type
Exceptions:	noexcept
Header file:	ara/rest/uuid.h
Class:	ara::rest::Uuid
Description:	Returns node value.

Table 8.364: ara::rest::Uuid::GetNode

[SWS_REST_02339] ara::rest::Uuid::GetNode [Table 8.364 describes the interface ara::rest::Uuid::GetNode.|(RS_CM_00300)

8.34.13 operator==

Service name:	ara::rest::Uuid::operator==	
Type:	Non-member function	
Syntax:	friend bool operator==(const Uuid &a, const Uuid &b)	
Function param:	а	a uuid
Function param:	b	a uuid
Return value:	true if equal	
Exceptions:	noexcept	
Header file:	ara/rest/uuid.h	
Namespace:	ara::rest::Uuid	
Description:	Compares UUIDs.	

Table 8.365: ara::rest::Uuid::operator==



[SWS_REST_02340] ara::rest::Uuid::operator== [Table 8.365 describes the interface ara::rest::Uuid::operator==.](RS_CM_00300)

8.34.14 operator!=

Service name:	ara::rest::Uuid::operator!=	
Type:	Non-member function	
Syntax:	friend bool operator!=(const Uuid &a, const Uuid &b)	
Function param:	а	a uuid
Function param:	b	a uuid
Return value:	true if unequal	
Exceptions:	noexcept	
Header file:	ara/rest/uuid.h	
Namespace:	ara::rest::Uuid	
Description:	Compares UUIDs.	

Table 8.366: ara::rest::Uuid::operator!=

[SWS_REST_02341] ara::rest::Uuid::operator!= [Table 8.366 describes the interface ara::rest::Uuid::operator!=.](RS_CM_00300)

8.34.15 operator<

Service name:	ara::rest::Uuid::operator<	
Type:	Non-member function	
Syntax:	friend bool operator<(const Uuid &a, const Uuid &b)	
Function param:	а	a uuid
Function param:	b	a uuid
Return value:	true if uuid compares	less than lexicographically less by component
Exceptions:	noexcept	
Header file:	ara/rest/uuid.h	
Namespace:	ara::rest::Uuid	
Description:	Compares UUIDs.	

Table 8.367: ara::rest::Uuid::operator<

[SWS_REST_02342] ara::rest::Uuid::operator< [Table 8.367 describes the interface ara::rest::Uuid::operator<.|(RS_CM_00300)

8.35 ara::rest::ogm

8.35.1 Copy

Service name:	Сору
Type:	Non-member function



Syntax:	template <typename t=""></typename>		
	Pointer <t> ara::rest::ogm::Copy(const T &g, Allocator</t>		
	*alloc=GetDefaultAllocator())		
Function param:	g	OGM graph to copy	
Function param:	alloc	allocator to use for the copy	
Return value:	a copy		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/copy.h		
Namespace:	ara::rest::ogm		
Description:	Copies an object graph. Performs a deep copy of the argument		

Table 8.368: ara::rest::ogm::Copy

[SWS_REST_02343] Copy [Table 8.368 describes the interface Copy.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.2 Copy

Service name:	Сору		
Type:	Non-member function		
Syntax:	template <typename t=""></typename>		
	Pointer <t> ara::rest::ogm::Copy(const Pointer< T ></t>		
	&g, Allocator *alloc=GetDefaultAllocator())		
Function param:	g	OGM graph to copy	
Function param:	alloc	allocator to use for the copy	
Return value:	а сору		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/copy.h		
Namespace:	ara::rest::ogm		
Description:	Copies an object graph. Performs a deep copy of the argument		

Table 8.369: ara::rest::ogm::Copy

[SWS_REST_02344] Copy [Table 8.369 describes the interface Copy.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.3 Visit

Service name:	Visit		
Type:	Non-member function		
Syntax:	<pre>template <typename ,="" nodet="" typename="" visitors=""> void ara::rest::ogm::Visit(const NodeT &u, Visitors &&vis)</typename></pre>		
Function param:	u	OGM node to resolve	
Function param:	vis	a set of functors	
Return value:	None		
Exceptions:	noexcept		
Header file:	ara/rest/ogm/visit.h		



Namespace:	ara::rest::ogm
Description:	Resolves the exact type of the OGM node passed to it. The function accepts a set of functors to call with the exact type of the graph node argument. Overload resolution shall apply here. If no visitor matches,
	the function silently returns without calling any visitor.

Table 8.370: ara::rest::ogm::Visit

[SWS_REST_02345] Visit [Table 8.370 describes the interface Visit.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.4 Visit

Service name:	Visit	
Type:	Non-member funct:	ion
Syntax:	<pre>template <typename ,="" nodet="" typename="" visitors=""> void ara::rest::ogm::Visit(const Pointer< NodeT > &u, Visitors &&vis)</typename></pre>	
Function param:	u	OGM node to resolve
Function param:	vis	a set of functors
Return value:	None	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/visit.h	
Namespace:	ara::rest::ogm	
Description:	See documentation of	void Visit(const Node&, Visitors&&);.

Table 8.371: ara::rest::ogm::Visit

[SWS_REST_02346] Visit [Table 8.371 describes the interface Visit.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.5 Visit

Service name:	Visit		
Type:	Non-member funct	ion	
Syntax:	template <typena< th=""><th>me NodeT , typename Visitors></th></typena<>	me NodeT , typename Visitors>	
	void ara::rest::	ogm::Visit(NodeT &u, Visitors	
	&&vis)		
Function param:	u	OGM node to resolve	
Function param:	vis	a set of functors	
Return value:	None	None	
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/visit.h		
Namespace:	ara::rest::ogm		
Description:	See documentation of	void Visit(const Node&, Visitors&&);.	

Table 8.372: ara::rest::ogm::Visit



[SWS_REST_02347] Visit [Table 8.372 describes the interface Visit.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.6 Visit

Service name:	Visit	
Type:	Non-member funct	ion
Syntax:	template <typena< th=""><th>me NodeT , typename Visitors></th></typena<>	me NodeT , typename Visitors>
	void ara::rest::	ogm::Visit(Pointer< NodeT > &u,
	Visitors &&vis)	
Function param:	u	OGM node to resolve
Function param:	vis	a set of functors
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/visit.h	
Namespace:	ara::rest::ogm	
Description:	See documentation of	void Visit(const Node&, Visitors&&);.

Table 8.373: ara::rest::ogm::Visit

[SWS_REST_02348] Visit [Table 8.373 describes the interface Visit.] (RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.35.7 **VisitAll**

Service name:	VisitAll		
Type:	Non-member funct	ion	
Syntax:	template <typena< th=""><th>me NodeT , typename Visitors></th></typena<>	me NodeT , typename Visitors>	
	void ara::rest::	ogm::VisitAll(const NodeT &u,	
	Visitors &&vi	s)	
Function param:	u	OGM node to resolve	
Function param:	vis	a set of functors	
Return value:	None	None	
Exceptions:	noexcept		
Header file:	ara/rest/ogm/visit.h		
Namespace:	ara::rest::ogm		
Description:	graph traversal. The exact type of the grap	Resolves the exact types of the OGM nodes in the graph and performs graph traversal. The function accepts a set of functors to call with the exact type of the graph node argument. Overload resolution shall apply here. If no visitor matches, the function silently returns without calling	

Table 8.374: ara::rest::ogm::VisitAll

[SWS_REST_02411] VisitAll [Table 8.374 describes the interface VisitAll.] (RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)



8.35.8 VisitAll

Service name:	VisitAll	
Type:	Non-member funct	ion
Syntax:	template <typena< th=""><th>me NodeT , typename Visitors></th></typena<>	me NodeT , typename Visitors>
	void ara::rest::	ogm::VisitAll(const Pointer< NodeT >
	&u, Visitors &&vis)	
Function param:	u	OGM node to resolve
Function param:	vis	a set of functors
Return value:	None	
Exceptions:	noexcept	
Header file:	ara/rest/ogm/visit.h	
Namespace:	ara::rest::ogm	
Description:	See documentation of	void VisitAll(const Node&, Visitors&&);.

Table 8.375: ara::rest::ogm::VisitAll

[SWS_REST_02412] VisitAll [Table 8.375 describes the interface VisitAll.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.9 VisitAll

Service name:	VisitAll	
Type:	Non-member funct	ion
Syntax:	template <typena< th=""><th>me NodeT , typename Visitors></th></typena<>	me NodeT , typename Visitors>
	void ara::rest::	ogm::VisitAll(NodeT &u, Visitors
	&&vis)	
Function param:	u	OGM node to resolve
Function param:	vis	a set of functors
Return value:	None	
Exceptions:	Implementation-defined	
Header file:	ara/rest/ogm/visit.h	
Namespace:	ara::rest::ogm	
Description:	See documentation of	void VisitAll(const Node&, Visitors&&);.

Table 8.376: ara::rest::ogm::VisitAll

[SWS_REST_02413] VisitAll [Table 8.376 describes the interface VisitAll.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.10 VisitAll

Service name:	VisitAll	
Type:	Non-member funct:	ion
Syntax:		<pre>me NodeT , typename Visitors> ogm::VisitAll(Pointer< NodeT > &u, s)</pre>
Function param:	u	OGM node to resolve



Function param:	vis	a set of functors
Return value:	None	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/ogm/visit.h	
Namespace:	ara::rest::ogm	
Description:	See documentation of void VisitAll(const Node&, Visitors&&);.	

Table 8.377: ara::rest::ogm::VisitAll

[SWS_REST_02414] VisitAll [Table 8.377 describes the interface VisitAll.] (RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.35.11 Get

Service name:	Get	Get	
Type:	Non-member funct	ion	
Syntax:	template <typena< th=""><th>me ValueNodeT , typename NodeT></th></typena<>	me ValueNodeT , typename NodeT>	
	ValueNodeT& ara:	:rest::ogm::Get(const NodeT &u, const	
	StringView &n)		
Function param:	u	Root of the search operation	
Function param:	n	Field name to search	
Return value:	value of the field		
Exceptions:	Implementation-define	ed	
Header file:	ara/rest/ogm/util.h		
Namespace:	ara::rest::ogm		
Description:	Returns a Value objec	t with the given field name and type. Only ascends	
	the graph from the give	ven graph object. Found value is the first suitable	
	value.		

Table 8.378: ara::rest::ogm::Get

[SWS_REST_02389] Get [Table 8.378 describes the interface Get.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.12 Get

Service name:	Get	
Type:	Non-member funct:	ion
Syntax:	template <typena< th=""><th>me ValueNodeT , typename NodeT></th></typena<>	me ValueNodeT , typename NodeT>
	ValueNodeT& ara:	:rest::ogm::Get(const Pointer< NodeT
	> &u, const StringView &n)	
Function param:	u	Root of the search operation
Function param:	n	Field name to search
Return value:	value of the field	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/ogm/util.h	
Namespace:	ara::rest::ogm	
Description:	See documentation of	void Get(const NodeT&, const StringView&);.



Table 8.379: ara::rest::ogm::Get

[SWS_REST_02390] Get [Table 8.379 describes the interface Get.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.13 **GetValue**

Service name:	GetValue	
Type:	Non-member function	
Syntax:	template <typena< th=""><th>me ValueNodeT , typename NodeT></th></typena<>	me ValueNodeT , typename NodeT>
	typename ValueNo	deT::ValueType
	ara::rest::ogm::	GetValue(const NodeT &u, const
	StringView &n)	
Function param:	u	Root of the search operation
Function param:	n	Field name to search
Return value:	value of the field	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/ogm/util.h	
Namespace:	ara::rest::ogm	
Description:	Returns a Value object's primitive value with the given field name and	
	type. Only ascends th	e graph from the given graph object. Found value
	is the first suitable valu	Je.

Table 8.380: ara::rest::ogm::GetValue

[SWS_REST_02391] GetValue [Table 8.380 describes the interface Get.] (RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.35.14 GetValue

Service name:	GetValue			
Type:	Non-member funct	ion		
Syntax:	template <typena< th=""><th>me ValueNodeT , typename NodeT></th></typena<>	me ValueNodeT , typename NodeT>		
	typename ValueNo	deT::ValueType		
	ara::rest::ogm::	GetValue(const Pointer< NodeT > &u,		
	const StringView &n)			
Function param:	u	u Root of the search operation		
Function param:	n	Field name to search		
Return value:	value of the field			
Exceptions:	Implementation-defined			
Header file:	ara/rest/ogm/util.h			
Namespace:	ara::rest::ogm			
Description:	See documentation	of void GetValue(const NodeT&, const		
	StringView&);.			

Table 8.381: ara::rest::ogm::GetValue



[SWS_REST_02392] GetValue [Table 8.381 describes the interface Get.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.15 Set

Service name:	Set		
Type:	Non-member funct	ion	
Syntax:	template <typena< th=""><th>me ValueNodeT , typename ValueT></th></typena<>	me ValueNodeT , typename ValueT>	
	bool ara::rest::	bool ara::rest::ogm::Set(ValueNodeT &u, ValueT &v)	
Function param:	u Node that will be updated		
Function param:	٧	Value that will be set for the node	
Return value:	returns true if value was set, otherwise false		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/util.h		
Namespace:	ara::rest::ogm		
Description:	Sets a value to a node if the value differs from the already set value.		

Table 8.382: ara::rest::ogm::Set

[SWS_REST_02393] Set [Table 8.382 describes the interface Set.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.16 Set

Service name:	Set		
Type:	Non-member funct:	Non-member function	
Syntax:	bool ara::rest::	ogm::Set(Array &u, Array::MoveRange	
	(∨3		
Function param:	u	Array that will be updated	
Function param:	V	Values that will be set for the array	
Return value:	returns true if value was set, otherwise false		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/util.h		
Namespace:	ara::rest::ogm		
Description:	Sets values to an array if the given values differ from the already set		
	value.		

Table 8.383: ara::rest::ogm::Set

[SWS_REST_02405] Set [Table 8.383 describes the interface Set.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.17 Set

Service name:	Set
Type:	Non-member function



Syntax:	bool ara::rest::ogm::Set(Object &u,		
	Object::MoveFiel	Object::MoveFieldRange &v)	
Function param:	u Object that will be updated		
Function param:	v Fields that will be set for the object		
Return value:	returns true if fields were set, otherwise false		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/util.h		
Namespace:	ara::rest::ogm		
Description:	Sets fields to a object if the field values differ from the already set fields.		

Table 8.384: ara::rest::ogm::Set

[SWS_REST_02406] Set [Table 8.384 describes the interface Set.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.18 SetValue

Service name:	SetValue		
Type:	Non-member function		
Syntax:	template <typena< th=""><th>me ValueNodeT , typename NodeT ,</th></typena<>	me ValueNodeT , typename NodeT ,	
	typename ValueT>		
	bool ara::rest::	ogm::SetValue(const ValueNodeT &u,	
	const StringView	&n, ValueT &v)	
Function param:	u	u Node that will be updated	
Function param:	n	Field name to set value to	
Function param:	V	v Value that will be set for the field	
Return value:	returns true if value was set, otherwise false		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/util.h		
Namespace:	ara::rest::ogm		
Description:	Sets a primitive value	Sets a primitive value to a node field if the value differs from the already	
	set value.		

Table 8.385: ara::rest::ogm::SetValue

[SWS_REST_02407] SetValue [Table 8.385 describes the interface SetValue.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.35.19 SetValue

Service name:	SetValue	
Type:	Non-member functi	on
Syntax:	template <typenam< th=""><th>ne ValueNodeT , typename NodeT ,</th></typenam<>	ne ValueNodeT , typename NodeT ,
	typename ValueT>	
	bool ara::rest::ogm::SetValue(const Pointer<	
	ValueNodeT > &u, const StringView &n, ValueT &v)	
Function param:	u	Node that will be updated
Function param:	n	Field name to set value to



Function param:	V	Value that will be set for the field
Return value:	returns true if value wa	as set, otherwise false
Exceptions:	Implementation-define	ed
Header file:	ara/rest/ogm/util.h	
Namespace:	ara::rest::ogm	
Description:	See documentation StringView&, ValueT);	of void SeTvalue(const ValueNodeT&, const .

Table 8.386: ara::rest::ogm::SetValue

[SWS_REST_02409] SetValue [Table 8.386 describes the interface SetValue.] (RS CM 00300, RS CM 00305, RS CM 00306, RS CM 00307, RS CM 00308)

8.35.20 Cast

Service name:	Cast		
Type:	Non-member funct	ion	
Syntax:	template <typena< th=""><th>me NodeT></th></typena<>	me NodeT>	
	Pointer< NodeT >	ara::rest::ogm::Cast(Pointer <node></node>	
	n)		
Function param:	n Node to cast		
Return value:	returns pointer to casted node		
Exceptions:	Implementation-defined		
Header file:	ara/rest/ogm/util.h		
Namespace:	ara::rest::ogm		
Description:	Casts a node to a con	Casts a node to a concrete node type.	

Table 8.387: ara::rest::ogm::Cast

[SWS_REST_02410] Cast [Table 8.387 describes the interface Cast.] (RS_CM_00300, RS_CM_00305, RS_CM_00306, RS_CM_00307, RS_CM_00308)

8.36 ara::rest

8.36.1 RequestMethod

Name:	RequestMethod	
Type:	Non-member enu	meration
Range:	kGet	= 1 « 0
	kPost	= 1 « 1
	kPut	= 1 « 2
	kDelete	= 1 « 3
	kOptions	= 1 « 4
	kHead	= 1 « 5



Syntax:	enum class RequestMethod : std::uint32_t {
	kGet = 1 « 0,
	kPost = 1 « 1,
	kPut = 1 « 2,
	kDelete = 1 « 3,
	kOptions = 1 « 4,
	$kHead = 1 \ll 5$
	};
Header file:	ara/rest/endpoint.h
Namespace:	ara::rest
Description:	Specifies a set possible API access methods. RequestMethod largely
	corresponds to typical RESTful API access methods.

Table 8.388: ara::rest::RequestMethod

[SWS_REST_02349] RequestMethod [Table 8.388 describes the enumeration datatype $ara::rest::RequestMethod.|(RS_CM_00300)$

8.36.2 SubscriptionState

Name:	SubscriptionState
Туре:	Non-member enumeration
Range:	kSubscribed
	kCanceled
	kResubscribe
	kInvalid
Syntax:	enum class SubscriptionState {
	kSubscribed,
	kCanceled,
	kResubscribe,
	kInvalid
	} ;
Header file:	ara/rest/endpoint.h
Namespace:	ara::rest
Description:	Denotes the state of the subscription relation represented by an Event. The
	enumerators have the following meaning:

Table 8.389: ara::rest::SubscriptionState

[SWS_REST_02350] SubscriptionState [Table 8.389 describes the enumeration datatype ara::rest::SubscriptionState.](RS_CM_00300)

8.36.3 EventPolicy

Name:	EventPolicy	
Type:	Non-member enumeration	
Range:	kTriggered	= 1u « 0
	kPeriodic	= 1u « 1



Syntax:	<pre>enum class EventPolicy : std::uint32_t {</pre>	
	kTriggered = 1u « 0,	
	kPeriodic = 1u « 1	
];	
Header file:	ara/rest/endpoint.h	
Namespace:	ara::rest	
Description:	Mode of operation for event subscriptions. Defines the mode of operation for	
	event subscriptions. The modes have the following semantics:	

Table 8.390: ara::rest::EventPolicy

[SWS_REST_02351] EventPolicy [Table 8.390 describes the enumeration datatype ara::rest::EventPolicy.|(RS CM 00300)

8.36.4 ShutdownPolicy

Name:	ShutdownPolicy		
Type:	Non-member enumeration		
Range:	kForced		
	kGraceful		
Syntax:	enum class ShutdownPolicy : std::uint32_t {		
	kForced,		
	kGraceful		
	} ;		
Header file:	ara/rest/endpoint.h		
Namespace:	ara::rest		
Description:	Specifies shutdown behavior of endpoints. Endpoints can shut down "gracefully", which allows all ongoing transactions to finish while blocking the caller. A forced shutdown must cancel or terminate all transactions as fast as possible does not block the caller for "unreasonably" long period of time. During a forced shutdown I/O is not allowed. Precise semantics of these policies are implementation defined.		

Table 8.391: ara::rest::ShutdownPolicy

[SWS_REST_02352] ShutdownPolicy [Table 8.391 describes the enumeration datatype ara::rest::ShutdownPolicy.|(RS_CM_00300)

8.36.5 StartupPolicy

Name:	StartupPolicy		
Type:	Non-member enumeration		
Range:	kDetached		
	kAttached		
Syntax:	enum class StartupPolicy : std::uint32_t {		
	kDetached,		
	kAttached		
	};		



Header file:	ara/rest/endpoint.h
Namespace:	ara::rest
Description:	Specifies whether a server will detach itself from its owning context. If a
	server is started "detached" then are::rest::Server::Start() does not block.
	Effecticely it will request a separate exection context (such as a thread) from

Table 8.392: ara::rest::StartupPolicy

[SWS_REST_02353] StartupPolicy [Table 8.392 describes the enumeration datatype ara::rest::StartupPolicy.|(RS_CM_00300)

8.36.6 Function

Name:	Function	
Type:	Non-member type alias	
Syntax:	template <typename t=""></typename>	
	<pre>using ara::rest::Function = std::function<t></t></pre>	
Header file:	ara/rest/function.h	
Namespace:	ara::rest	
Description:	A generalized function pointer.	

Table 8.393: ara::rest::Function

[SWS_REST_02354] Function [Table 8.393 describes the type alias ara::rest::Function.|(RS CM 00300, RS CM 00311)

8.36.7 **Pointer**

Name:	Pointer	
Type:	Non-member type alias	
Syntax:	template <typename t=""></typename>	
	<pre>using ara::rest::Pointer = std::unique_ptr<t></t></pre>	
Header file:	ara/rest/pointer.h	
Namespace:	ara::rest	
Description:	The equivalent if std::unique_ptr for ara::rest internal uses.	

Table 8.394: ara::rest::Pointer

[SWS_REST_02355] Pointer [Table 8.394 describes the type alias ara::rest::Pointer.](RS_CM_00300, RS_CM_00311)

8.36.8 Task

Name:	Task
Туре:	Non-member type alias



Syntax:	template <typename t=""></typename>	
	<pre>using ara::rest::Task = ara::core::Future<t></t></pre>	
Header file:	ara/rest/task.h	
Namespace:	ara::rest	
Description:	Represents an asynchronous task for which a user might want to wait for.	

Table 8.395: ara::rest::Task

[SWS_REST_02360] Task [Table 8.395 describes the type alias $ara::rest::Task.|(RS_CM_00300, RS_CM_00311)$

8.36.9 duration t

Name:	duration_t	
Type:	Non-member type alias	
Syntax:	<pre>using ara::rest::duration_t = std::chrono::microseconds</pre>	
Header file:	ara/rest/types.h	
Namespace:	ara::rest	
Description:	Specifies an amount of time of granularity of at least microseconds.	

Table 8.396: ara::rest::duration_t

[SWS_REST_02361] duration_t [Table 8.396 describes the type alias ara::rest::duration_t.](RS_CM_00300)

8.36.10 operator==

Service name:	operator==	
Type:	Non-member function	
Syntax:	bool ara::rest::operator==(const Allocator &a, const	
	Allocator &b)	
Function param:	а	an allocator
Function param:	b	an allocator
Return value:	true allocators compare equal	
Exceptions:	Implementation-defined	
Header file:	ara/rest/allocator.h	
Namespace:	ara::rest	
Description:	Tests two allocators for equality.	

Table 8.397: ara::rest::operator==

[SWS_REST_02362] operator== [Table 8.397 describes the interface operator==.] (RS_CM_00300)



8.36.11 operator!=

Service name:	operator!=	
Type:	Non-member function	
Syntax:	bool ara::rest::operator!=(const Allocator &a, const	
	Allocator &b)	
Function param:	а	an allocator
Function param:	b	an allocator
Return value:	true allocators compare unequal	
Exceptions:	Implementation-defined	
Header file:	ara/rest/allocator.h	
Namespace:	ara::rest	
Description:	Tests two allocators for inequality.	

Table 8.398: ara::rest::operator!=

[SWS_REST_02363] operator!= [Table 8.398 describes the interface operator!=.] (RS_CM_00300)

8.36.12 NewDeleteAllocator

Service name:	NewDeleteAllocator		
Type:	Non-member function		
Syntax:	Allocator* ara::rest::NewDeleteAllocator()		
Function param:	None		
Return value:	a pointer to a NewDeleteAllocator		
Exceptions:	noexcept		
Header file:	ara/rest/allocator.h		
Namespace:	ara::rest		
Description:	Identical to std::pmr::new_delete_resource.		

Table 8.399: ara::rest::NewDeleteAllocator

[SWS_REST_02364] NewDeleteAllocator | Table 8.399 describes the interface | NewDeleteAllocator. | (RS CM 00300)

8.36.13 GetDefaultAllocator

Service name:	GetDefaultAllocator		
Type:	Non-member function		
Syntax:	Allocator* ara::rest::GetDefaultAllocator()		
Function param:	None		
Return value:	a pointer to the default allocator		
Exceptions:	noexcept		
Header file:	ara/rest/allocator.h		
Namespace:	ara::rest		
Description:	See std::pmr::get_default_allocator for details.		

Table 8.400: ara::rest::GetDefaultAllocator



[SWS_REST_02365] GetDefaultAllocator [Table 8.400 describes the interface GetDefaultAllocator.] (RS_CM_00300)

8.36.14 SetDefaultAllocator

Service name:	SetDefaultAllocator	
Type:	Non-member function	
Syntax:	Allocator* ara::rest::SetDefaultAllocator(Allocator	
	*a)	
Function param:	а	an allocator
Return value:	a pointer to the allocator just set	
Exceptions:	noexcept	
Header file:	ara/rest/allocator.h	
Namespace:	ara::rest	
Description:	See std::pmr::set_default_allocator for details.	

Table 8.401: ara::rest::SetDefaultAllocator

[SWS_REST_02366] SetDefaultAllocator [Table 8.401 describes the interface SetDefaultAllocator.] (RS_CM_00300)

8.36.15 operator==

Service name:	operator==	
Type:	Non-member funct:	ion
Syntax:	template <typena< th=""><th>me T , typename U ></th></typena<>	me T , typename U >
	bool ara::rest::	operator==(const StdAllocator< T >
	&a, const StdAllocator< U > &b)	
Function param:	a an allocator	
Function param:	b an allocator	
Return value:	true if memory allocated in one can be freed via other	
Exceptions:	noexcept	
Header file:	ara/rest/allocator.h	
Namespace:	ara::rest	
Description:	Tests allocators for eq	uality.

Table 8.402: ara::rest::operator==

[SWS_REST_02367] operator== [Table 8.402 describes the interface operator==.] (RS CM 00300)

8.36.16 operator!=

Service name:	operator!=	
Type:	Non-member function	



Syntax:	<pre>template <typename ,="" t="" typename="" u=""> bool ara::rest::operator!=(StdAllocator< T > const &x, StdAllocator< U > const &y)</typename></pre>	
Function param:	x an allocator	
Function param:	у	an allocator
Return value:	true if memory allocated in x cannot be freed via y	
Exceptions:	noexcept	
Header file:	ara/rest/allocator.h	
Namespace:	ara::rest	
Description:	Tests allocators for inequality.	

Table 8.403: ara::rest::operator!=

[SWS_REST_02368] operator!= [Table 8.403 describes the interface operator!=.] (RS_CM_00300)

8.36.17 operator

Service name:	operator		
Type:	Non-member function		
Syntax:	constexpr Reques	tMethod	
	ara::rest::opera	tor (RequestMethod a, RequestMethod	
	b)		
Function param:	a (set of) request method enumerator(s)		
Function param:	b	b a (set of) request method enumerator(s)	
Return value:	a set of request method enumerator(s)		
Exceptions:	noexcept		
Header file:	ara/rest/endpoint.h		
Namespace:	ara::rest		
Description:	Computes a set of RequestMethod enumerators.		

Table 8.404: ara::rest::operator

[SWS_REST_02369] operator | Table 8.404 describes the interface operator |.] (RS_CM_00300)

8.36.18 operator

Service name:	operator			
Type:	Non-member funct:	Non-member function		
Syntax:	constexpr EventPo	constexpr EventPolicy		
	<pre>ara::rest::operator (EventPolicy a, EventPolicy b)</pre>			
Function param:	a (set of) request event policy enumerator(s)			
Function param:	b a (set of) request event policy enumerator(s)			
Return value:	a set of request event policy enumerator(s)			
Exceptions:	noexcept			
Header file:	ara/rest/endpoint.h			
Namespace:	ara::rest			



Table 8.405: ara::rest::operator

[SWS_REST_02370] operator| [Table 8.405 describes the interface operator|.] (RS CM 00300)

8.36.19 MakelteratorRange

Service name:	MakelteratorRange		
Type:	Non-member function		
Syntax:	template <typena< th=""><th>me IterT ></th></typena<>	me IterT >	
	IteratorRange <it< th=""><th>erT></th></it<>	erT>	
	ara::rest::MakeIteratorRange(IterT a, IterT b)		
Function param:	a iterator that denotes the start of the sequence		
Function param:	b iterator that denotes the end of the sequence		
Return value:	an IteratorRange		
Exceptions:	Implementation-defined		
Header file:	ara/rest/iterator.h		
Namespace:	ara::rest		
Description:	Helper for type deduct	Helper for type deduction to construct an IteratorRange.	

Table 8.406: ara::rest::MakeIteratorRange

[SWS_REST_02371] MakeIteratorRange | Table 8.406 describes the interface MakeIteratorRange.| (RS CM 00300)

8.36.20 MakeMovelteratorRange

Service name:	MakeMoveIteratorRange	
Type:	Non-member funct	ion
Syntax:	template <typena< th=""><th>me IterT ></th></typena<>	me IterT >
	MoveIteratorRange	e <itert></itert>
	ara::rest::MakeMoveIteratorRange(IterT a, IterT b)	
Function param:	a iterator that denotes the start of the sequence	
Function param:	b iterator that denotes the end of the sequence	
Return value:	an MakeMovelteratorRange	
Exceptions:	Implementation-defined	
Header file:	ara/rest/iterator.h	
Namespace:	ara::rest	
Description:	Helper for type deduction to construct an MovelteratorRange.	

Table 8.407: ara::rest::MakeMoveIteratorRange

[SWS_REST_02396] MakeMoveIteratorRange [Table 8.407 describes the interface MakeMoveIteratorRange.|(RS_CM_00300)



8.36.21 Resolve

Service name:	Resolve	
Type:	Non-member function	
Syntax:	Uri ara::rest::R	esolve(const Uri &base, const Uri
	&rel, Allocator	*alloc=GetDefaultAllocator())
Function param:	base the URI to resolve against	
Function param:	rel	a relative URI
Function param:	alloc	an allocator
Return value:	a resolved URI	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest	
Description:	Resolves a relative URI against a base URI. See section 5.2 of RFC 3986 for the algorithm used.	

Table 8.408: ara::rest::Resolve

[SWS_REST_02372] Resolve [Table 8.408 describes the interface Resolve.] $(RS_CM_00300, RS_CM_00304)$

8.36.22 Normalize

Service name:	Normalize		
Type:	Non-member funct:	Non-member function	
Syntax:	Uri ara::rest::No	ormalize(const Uri &uri, Allocator	
	*alloc=GetDefaul	tAllocator())	
Function param:	uri	URI to normalize	
Function param:	alloc	an allocator	
Return value:	a noralized URI		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Namespace:	ara::rest		
Description:	Normalizes a given Uf	RI.	

Table 8.409: ara::rest::Normalize

[SWS_REST_02373] Normalize Table 8.409 describes the interface Normalize.] (RS CM 00300, RS CM 00304)

8.36.23 Relativize

Service name:	Relativize	
Type:	Non-member function	
Syntax:	Uri ara::rest::Relativize(const Uri &base, const Uri	
	<pre>&uri, Allocator *alloc=GetDefaultAllocator())</pre>	
Function param:	base	a base URI as reference
Function param:	uri	a URI to relativize



Function param:	alloc	an allocator
Return value:	a relative URI	
Exceptions:	Implementation-define	ed
Header file:	ara/rest/uri.h	
Namespace:	ara::rest	
Description:	Relativizes a URI with respect to a given base URI. The relativization of	
	the given URI against this URI is computed as follows:	

Table 8.410: ara::rest::Relativize

[SWS_REST_02374] Relativize [Table 8.410 describes the interface Relativize.] (RS CM 00300, RS CM 00304)

8.36.24 ToString

Service name:	ToString	ToString	
Type:	Non-member funct	Non-member function	
Syntax:	String ara::rest	::ToString(const Uri &uri, Uri::Part	
	part, bool encod	e, Allocator	
	*alloc=GetDefaul	tAllocator())	
Function param:	uri	URI to encode	
Function param:	part	denotes which components of a URI should be	
		encoded	
Function param:	encode	if true, then the string will be percent-encoded. If	
		false, the string must not be string encoded.	
Function param:	alloc	a user-defined allocator passed to the string object	
		being returned	
Return value:	the encoded URI		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Namespace:	ara::rest		
Description:	Returns a string representation of a Uri.		

Table 8.411: ara::rest::ToString

[SWS_REST_02375] ToString [Table 8.411 describes the interface ToString.] $(RS_CM_00300, RS_CM_00304)$

8.36.25 **ToString**

Service name:	ToString	
Type:	Non-member function	
Syntax:	String ara::rest::ToString(const Uri &uri, Uri::Part part, Allocator *alloc=GetDefaultAllocator())	
Function param:	uri	URI to encode
Function param:	part	denotes which components of a URI should be encoded



Function param:	alloc	a user-defined allocator passed to the string object being returned
Return value:	the encoded URI	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest	
Description:	Returns a string representation of a Uri.	

Table 8.412: ara::rest::ToString

[SWS_REST_02376] ToString [Table 8.412 describes the interface ToString.] (RS CM 00300, RS CM 00304)

8.36.26 **ToString**

Service name:	ToString	
Type:	Non-member function	
Syntax:	String ara::rest	::ToString(const Uri &uri, Allocator
	*alloc=GetDefaul	tAllocator())
Function param:	uri	URI to encode
Function param:	alloc	a user-defined allocator passed to the string object
		being returned
Return value:	the encoded URI	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest	
Description:	Returns a string representation of a Uri.	

Table 8.413: ara::rest::ToString

[SWS_REST_02377] ToString [Table 8.413 describes the interface ToString.] $(RS_CM_00300, RS_CM_00304)$

8.36.27 **ToString**

Service name:	ToString	
Type:	Non-member function	
Syntax:	String ara::rest	::ToString(Uri &&uri, Uri::Part part,
	bool encode, All	ocator *alloc=GetDefaultAllocator())
Function param:	uri URI to encode	
Function param:	part	denotes which components of a URI should be encoded
Function param:	encode	if true, then the string will be percent-encoded. If false, the string must not be string encoded.
Function param:	alloc	a user-defined allocator passed to the string object being returned
Return value:	the encoded URI	
Exceptions:	Implementation-defined	



Header file:	ara/rest/uri.h
Namespace:	ara::rest
Description:	Returns a string representation of a Uri.

Table 8.414: ara::rest::ToString

[SWS_REST_02378] ToString [Table 8.414 describes the interface ToString.] (RS CM 00300, RS CM 00304)

8.36.28 **ToString**

Service name:	ToString		
Type:	Non-member funct	Non-member function	
Syntax:	String ara::rest	::ToString(Uri &&uri, Uri::Part part,	
	Allocator *alloc	=GetDefaultAllocator())	
Function param:	uri	URI to encode	
Function param:	part	denotes which components of a URI should be encoded	
Function parami	alloc	a user-defined allocator passed to the string object	
Function param:	alloc	being returned	
Return value:	the encoded URI		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uri.h		
Namespace:	ara::rest		
Description:	Returns a string repre	sentation of a Uri.	

Table 8.415: ara::rest::ToString

[SWS_REST_02379] ToString [Table 8.415 describes the interface ToString.] $(RS_CM_00300, RS_CM_00304)$

8.36.29 **ToString**

Service name:	ToString	
Type:	Non-member function	
Syntax:	String ara::rest::ToString(Uri &&uri, Allocator	
	*alloc=GetDefaul	tAllocator())
Function param:	uri	URI to encode
Function param:	alloc	a user-defined allocator passed to the string object
		being returned
Return value:	the encoded URI	
Exceptions:	Implementation-defined	
Header file:	ara/rest/uri.h	
Namespace:	ara::rest	
Description:	Returns a string repre	sentation of a Uri.

Table 8.416: ara::rest::ToString



[SWS_REST_02380] ToString [Table 8.416 describes the interface ToString.] $(RS_CM_00300, RS_CM_00304)$

8.36.30 **ToString**

Service name:	ToString		
Type:	Non-member funct	Non-member function	
Syntax:	String ara::rest	::ToString(const Uuid &uuid,	
	Allocator *alloc	=GetDefaultAllocator())	
Function param:	uuid	a UUID	
Function param:	alloc	an allocator	
Return value:	its canonic textual representation		
Exceptions:	Implementation-defined		
Header file:	ara/rest/uuid.h		
Namespace:	ara::rest		
Description:	Converts Uuid into its	canonical textual representation.	

Table 8.417: ara::rest::ToString

[SWS_REST_02381] ToString [Table 8.417 describes the interface ToString.] (RS CM 00300, RS CM 00304)

8.36.31 InstanceIdentifier

Service name:	InstanceIdentifier						
Type:	Non-member variable						
Syntax:	<pre>using ara::rest::InstanceIdentifier =</pre>						
	ara::core::StringView;						
Header file:	ara/rest/endpoint.h						
Namespace:	ara::rest						
Description:	Identifies the concrete ara::rest::Client and						
	ara::rest::Server instance.						

Table 8.418: ara::rest::InstanceIdentifier

[SWS_REST_10902] InstanceIdentifier [Table 8.418 describes the interface InstanceIdentifier.|(RS_CM_00300, RS_CM_00304)



A Mentioned Class Tables

For the sake of completeness, this chapter contains a set of class tables representing meta-classes mentioned in the context of this document but which are not contained directly in the scope of describing specific meta-model semantics.

Enumeration	HttpAcceptEncodingEnum			
Package	M2::AUTOSARTemplates::AdaptivePlatform::REST::RESTDeployment			
Note	This enumeration defines the value for the accept-encoding field of the HTTP header.			
	Tags: atp.Status=draft			
Literal	Description			
deflate	Use deflate compression.			
	Tags: atp.EnumerationValue=1			
gzip	Use gzip pcompression.			
	Tags: atp.EnumerationValue=0			

Table A.1: HttpAcceptEncodingEnum

Class	Ipv4Configuration				
Package	M2::AUTOSARTemplates::SystemTemplate::Fibex::Fibex4Ethernet::EthernetTopology				
Note	Internet Protocol version 4 (IPv4) configuration.				
Base	ARObject, NetworkEndp	ointAddres	s		
Attribute	Type Mul. Kind Note				
assignment Priority	PositiveInteger	01	attr	Priority of assignment (1 is highest). If a new address from an assignment method with a higher priority is available, it overwrites the IP address previously assigned by an assignment method with a lower priority.	
defaultGateway	lp4AddressString	01	attr	IP address of the default gateway.	
dnsServer	lp4AddressString	*	attr	IP addresses of preconfigured DNS servers.	
Address				Tags: xml.namePlural=DNS-SERVER-ADDRESSES	
ipAddressKeep Behavior	IpAddressKeepEnum	01	attr	Defines the lifetime of a dynamically fetched IP address.	
ipv4Address	lp4AddressString	01	attr	IPv4 Address. Notation: 255.255.255.255. The IP Address shall be declared in case the ipv4Address Source is FIXED and thus no auto-configuration mechanism is used.	
ipv4Address Source	Ipv4AddressSource Enum	01	attr	Defines how the node obtains its IP address.	
networkMask	lp4AddressString	01	attr	Network mask. Notation 255.255.255	
ttl	PositiveInteger	01	attr	Lifespan of data (0255). The purpose of the TimeToLive field is to avoid a situation in which an undeliverable datagram keeps circulating on a system.	

Table A.2: Ipv4Configuration



Class	Ipv6Configuration				
Package	M2::AUTOSARTemplates::SystemTemplate::Fibex::Fibex4Ethernet::EthernetTopology				
Note	Internet Protocol version 6 (IPv6) configuration.				
Base	ARObject, NetworkEndp	ointAddres	ss		
Attribute	Туре	Mul.	Kind	Note	
assignment Priority	PositiveInteger	01	attr	Priority of assignment (1 is highest). If a new address from an assignment method with a higher priority is available, it overwrites the IP address previously assigned by an assignment method with a lower priority.	
defaultRouter	lp6AddressString	01	attr	IP address of the default router.	
dnsServer	lp6AddressString	*	attr	IP addresses of pre configured DNS servers.	
Address				Tags: xml.namePlural=DNS-SERVER-ADDRESSES	
enableAnycast	Boolean	01	attr	This attribute is used to enable anycast addressing (i.e. to one of multiple receivers).	
hopCount	PositiveInteger	01	attr	The distance between two hosts. The hop count n means that n gateways separate the source host from the destination host (Range 0255)	
ipAddressKeep Behavior	IpAddressKeepEnum	01	attr	Defines the lifetime of a dynamically fetched IP address.	
ipAddressPrefix Length	PositiveInteger	01	attr	IPv6 prefix length defines the part of the IPv6 address that is the network prefix.	
ipv6Address	lp6AddressString	01	attr	IPv6 Address. Notation: FFFF::FFFF. The IP Address shall be declared in case the ipv6Address Source is FIXED and thus no auto-configuration mechanism is used.	
ipv6Address Source	Ipv6AddressSource Enum	01	attr	Defines how the node obtains its IP address.	

Table A.3: lpv6Configuration

Class	NetworkEndpoint					
Package	M2::AUTOSARTemplates::SystemTemplate::Fibex::Fibex4Ethernet::EthernetTopology					
Note	The network endpoint defi	The network endpoint defines the network addressing (e.g. IP-Address or MAC multicast address).				
	Tags: atp.ManifestKind=N	/lachineMa	anifest			
Base	ARObject, Identifiable, Mu	ARObject, Identifiable, MultilanguageReferrable, Referrable				
Attribute	Туре	Mul.	Kind	Note		
fullyQualified DomainName	String	01	attr	Defines the fully qualified domain name (FQDN) e.g. some.example.host.		
infrastructure Services	InfrastructureServices	01	aggr	Defines the network infrastructure services provided or consumed.		
ipSecConfig	IPSecConfig	01	aggr	Optional IPSec configuration that provides security services for IP packets.		
				Tags: atp.Status=draft		
network	NetworkEndpoint	1*	aggr	Definition of a Network Address.		
Endpoint Addre Address Addres	Address			Tags: xml.name Plural=NETWORK-ENDPOINT-ADDRESSES		
priority	PositiveInteger	01	attr	Defines the frame priority where values from 0 (best effort) to 7 (highest) are allowed.		

Table A.4: NetworkEndpoint



Class	RestHttpPortPrototypeMapping						
Package	M2::AUTOSARTemplates::AdaptivePlatform::REST::RESTDeployment						
Note	This meta-class represents the ability to define pieces of a URI for the REST service that cannot be contributed from the design point of view.						
	atp.Status=draft	Tags: atp.ManifestKind=ExecutionManifest atp.Status=draft atp.recommendedPackage=RestHttpPortPrototypeMappings					
Base	ARElement, ARObject, C Element, Referrable, Uplo			ldentifiable, MultilanguageReferrable, Packageable ment			
Attribute	Туре	Mul.	Kind	Note			
accepts Encoding	HttpAcceptEncoding	*	aggr	This aggrgation represents the collection of accepted encodings.			
				Tags: atp.Status=draft			
host	NetworkEndpoint	01	ref	This reference identifies the host configuration of the remote end.			
				Tags: atp.Status=draft			
portPrototype	PortPrototype	01	iref	This reference identifies the instance of the PortPrototype to which the elements of the URI shall be defined.			
				Tags: atp.Status=draft			
portPrototype SlugFragment	String	01	attr	This attribute contributes a string value to be taken as the slug reference that represents the PortPrototype level of a REST service.			
				Tags: atp.Status=draft			
process	Process	01	ref	This reference represents the process required for context of the mapping.			
				Tags: atp.Status=draft			
tcpPort	PositiveInteger	1	attr	This attribute represents the value of the TCP port applicable for this mapping.			
				Tags: atp.Status=draft			
tlsSecureCom Props	TlsSecureComProps	01	ref	This represents the configuration of TLS applicable for the mapping.			
				Tags: atp.Status=draft			

Table A.5: RestHttpPortPrototypeMapping

Class	RestServiceInterface					
Package	M2::AUTOSARTemplates	M2::AUTOSARTemplates::AdaptivePlatform::REST::RESTDesign				
Note	This meta-class represen	ts a REST	service.			
	Tags: atp.Status=draft atp.recommendedPackage=RestServiceInterfaces					
Base		ARElement, ARObject, AtpBlueprint, AtpBlueprintable, AtpClassifier, AtpType, CollectableElement, Identifiable, MultilanguageReferrable, PackageableElement, PortInterface, Referrable				
Attribute	Type Mul. Kind Note					
resource	RestResourceDef	*	aggr	This aggregation represents the collection of resources owned by the enclosing REST service.		
		Tags: atp.Status=draft				

Table A.6: RestServiceInterface



Class	TIsSecureComProps			
Package	M2::AUTOSARTemplates::AdaptivePlatform::ServiceInstanceManifest::SecureCommunication			
Note	Configuration of the Transport Layer Security protocol (TLS).			
	Tags: atp.ManifestKind=ServiceInstanceManifest atp.Status=draft			
Base	ARObject, Identifiable, MultilanguageReferrable, Referrable, SecureComProps			
Attribute	Туре	Mul.	Kind	Note
keyExchange	CryptoServicePrimitive	*	ref	This reference identifies the shared (i.e. applicable for each of the aggreated cipher suites) crypto service primitive for the execution of key exchange during the handshake phase.
				Tags: atp.Status=draft
tlsCipherSuite	TlsCryptoCipherSuite	*	aggr	Collection of supported cipher suites that are used to negotiate the security settings for a network connection defined by the ServiceInstanceToMachineMapping.
				Tags: atp.Status=draft

Table A.7: TIsSecureComProps