cronologic

Thunderbolt to PCIe USER GUIDE



www.cronologic.de

Contents

| 1 | Introduction | 3 |
|----|---|---------------|
| 2 | Hardware 2.1 Installing a TDC board | 4 4 |
| No | ote: This user guide is under active development. | |

1 Introduction

The TBT2PCIe crate offers the ability to connect our time-to-digital converters (TDCs), that is,

- TimeTagger
- xTDC4-PCle

to any USB4/Thunderbolt port.

This user guide provides an overview of the crate. The APIs and interfaces of the respective TDC-card are unchanged. Refer to the respective user guides at www.cronologic.de/support/downloads.

This user guide is available at readthedoc and at www.docs.cronologic.de as HTML and as PDF download.

2 Hardware

Figure 2.1 gives an overview of the TBT2PCIe crate with an HPTDC4 board installed.



Figure 2.1: TBT2PCIe crate with removed top cover and an HPTDC4 board.

2.1 Installing a TDC board

- 1. Remove the top cover of the TBT2PCIe crate by doing XYZ.
- 2. Remove the metal rail from your TDC board by removing the two screws holding it in place.
- 3. Connect your TDC board to the PCIe slot of the TBT2PCIe crate.
- 4. Use the threaded holes where the metal cover of the TDC board was connected to secure the TDC board to the TBT2PCIe crate.
- 5. If present, connect the J25 connector.
- 6. Close up the TBT2PCIe crate.