J10 = Mars88 MC board connector - TE Connectivity 281739-5


X8 = connector TE Connectivity 281839-5

X9 = modem connector on Mars88 panel

GND

GNDGNDGND

X12 = DB9 male PC COM port/USB to serial adapter



Lennartz RS232-GATEWAY cable 352-0085

