USB360 PRO MICRO PINOUT

Interfaz USB PC Xcaja 360 Compatible de 1P

Xbox 360	PINES		Francis La		PINES	Xbox 360
Select	PIND, 3	o 💿		<u>o</u>	RAW	-
Start	PIND, 2	<u>o</u>		<u>o</u>	GND	GND
GND	GND	<u>o</u>		<u>o</u>	RST	-
GND	GND	<u>o</u>	106C	0	VCC	-
Dpad-UP	PIND, 1	ō 💿		0	PINF, 4	Nada
Dpad-Down	PIND, 0	o 🔾		<u>O</u> 0	PINF, 5	XBOX
Dpad-Left	PIND, 4	o 🔾		<u>O</u> 0	PINF, 6	L3
Dpad-Right	PINC, 6	o 🔾		<u>O</u> 0	PINF, 7	R3
Υ	PIND,7	o 🔵	•	<u>O</u> 0	PINB, 2	LT
В	PINE, 6	o 🔵		<u></u>	PINB, 6	RT
х	PINB, 4	o 🔵		<u></u>	PINB, 1	LB
A	PINB, 5	○		0	PINB, 3	RB



