

Troubleshooting: Mini PCI Type 3B Data Fax Modem by 3Com User's Guide

[Common Problems and Solutions](#) • [How to Properly Uninstall Modem Drivers](#)

Common Problems and Solutions

Message/Symptom	Possible Solution
ERROR	1 If you are typing from the command line in terminal mode, try retyping the command. 1 Make sure that you issued the correct AT command.
Modem Communication Error or Modem not found.	1 If fax software is being used, make sure the correct fax class (Class 1) is selected. 1 Make sure that you selected the correct COM port in the software setup.
NO DIAL TONE	1 Make sure that the cable connections are secure. The connection to the phone line could be incomplete or the phone cable could be bad. 1 Make sure that the telephone line being used is not in use by someone else. 1 Make sure that a standard analog telephone line is being used. If the connection being attempted is to a digital phone system or a private branch exchange (PBX), an error message may result. 1 Make sure that the phone line is working by connecting a standard telephone and listening for a dial tone.
DIGITAL LINE ERROR	1 The modem is trying to connect to a digital phone system (see Modem Features), a public branch exchange (PBX), or another kind of invalid line. Change lines to connect to a standard analog telephone line.
Can not hear modem or speaker	1 Make sure that the modem's speaker is turned on (ATM1). 1 Make sure that the computer's speaker is turned on. Refer to the computer's manual for instructions.
Modem does not dial correctly	1 Make sure that the telephone number that you dialed is correct if the dialing directory is being used. 1 Make sure that the number that you dialed is correct if you dialed in terminal mode. 1 Make sure that you dialed 1 before dialing the number if dialing long distance. 1 Make sure that you dialed a prefix (such as 9) if required. 1 The other line could be busy or not answering. Make sure it is available to answer before calling. 1 If you are dialing internationally, the modem may not recognize the dial tone. Try blind dialing using the ATX1 command (see AT Commands) and the telephone number. 1 If you have Call Waiting, disable it (usually *70).
Modem does not dial	1 Check the phone line and cable connections. 1 Make sure that no other phone extension has been picked up on the same line. 1 Make sure that you are using a standard analog telephone line. An error could result if you are trying to connect to a digital phone system or a private branch exchange (PBX). 1 Listen for a normal dial tone on the line. If there is no dial tone or the dial tone sounds differently than normal, use another telephone line.
Modem does not fax	1 Make sure that you selected fax Class 1. 1 Make sure that no other communications programs are open.
Modem does not connect	1 If there is no trouble communicating with any modem except on one particular line, the problem may be with the modem on the other end. 1 Disable error correction (see &M0 in AT Commands) and data compression (see &K0 in AT Commands) and try again.
Modem connects, but characters are garbled	1 Make sure the parity, modem speed, word length, and stop bits match on both sending and receiving modems. 1 Disable error correction (see &M0 in AT Commands) and data compression (see &K0 in AT Commands) and try again.
Modem clicks repeatedly, but no connection is made	1 Ordinarily, a DIGITAL LINE ERROR message would appear, but if the current is under 100mA, the modem will click repeatedly but a no dial tone message will appear. 1 The cable may not be seated securely. Check all cable connections.