WIRING FOR BENCH BUILD

TEST AUDIO

NOTE!! PUT 100K log attenuator pot between signal and "in"

1J24B Timbre Experimenter's board   1-9-22

1J24B Timbre Experimenter's board   1-9-22