## **CORRIDOR Aircraft Data Load**

## **CORRIDOR Add Aircraft Load Format**

Column	Field Name	Type of Field	Notes
A/1	Registration Number	Text(255)	REQUIRED
B/2	Aircraft Description	Text(255)	Aircraft Call Name populated if blank.
<b>C/3</b>	Aircraft Manufacturer Code	Text(255)	<b>REQUIRED Table Validated: Companies</b>
D/4	Aircraft Model	Text(255)	REQUIRED Table Validated: Aircraft Models
E/5	Serial Number Core	Text(255)	REQUIRED - Numbers only
F/6	Serial Number Prefix	Text(255)	Alpha Numeric
G/7	Serial Number Suffix	Text(255)	Alpha Numeric
H/8	Operating Condition	Text(255)	Table Validated: Operating Conditions
1/9	Status	Text(255)	Table Validated: Aircraft Status
J/10	Home Airport Code	Text(255)	Table Validated: Airports
K/11	Purchased From Code	Text(255)	Table Validated: Companies
L/12	Owned By Code	Text(255)	Table Validated: Companies
M/13	Base Of Operation Title	Text(255)	Table Validated: Owner Address
N/14	Base Of Operation Text	Text(255)	Populates text from Owner Address
0/15	Leased By Code	Text(255)	Table Validated: Companies
P/16	Managed By Code	Text(255)	Table Validated: Companies
Q/17	Operated By Code	Text(255)	Table Validated: Companies
R/18	Warranty	Text(255)	Table Validated: Warranty
S/19	Warranty Terms	Text(255)	Populates text from Warranty
T/20	Manufactured Date	Date	MM/DD/YYYY
U/21	Purchased On Date	Date	MM/DD/YYYY
V/22	Current Hours	Number	
W/23	Current Cycles	Number	
X/24	Projected Hours	Number	
Y/25	Projected Cycles	Number	
Z/26	Source Of Information	Text(255)	
AA/27	Current Hour Meter Reading	Number	
AB/28	Comments	Text(255)	
AC/29	Default Fuel Lot	Text(255)	Table Validated: Fuel Lots
AD/30	As of Date	Date	MM/DD/YYYY Aircraft As of Date for Time and Cycles
AE/31	UDF.		User Defined Data

<sup>\*</sup> Note: Column identifiers represents column placement in the CSV file. The alpha characters indicate the corresponding spreadsheet field position when generating a data file in Excel and the numbers are numeric representations of the same.

<sup>\*</sup> Note: Starting with field number 31, the user can have an unlimited number of user-defined fields. CorImport Field Association screen will display as many user defined fields as have been set up by the user.