


isthmus-ablation-core

Build and install path



Standalone mode

Standalone input
core-only DSMC-style script
ia-core -in sphere.in

Standalone mass source
constant, expression, file
source q1 constant 0.9

Standalone outputs
history, VTU, VTP, .surf
voxel_dump hist ...

Shared core library

Voxel model
IDs, mass, material, fields
voxel_create solid sphere ...

Generate/update surface
ISTHMUS mesh + ownership map
isthmus_surf surf1 ...

Surface cache
triangle IDs, areas, voxel fractions
map default yes

Map surface data
flux/reaction mass to voxels
isthmus map surf1 ...

Ablate voxel mass
local, column, axial, normal carryover
voxel_ablate solid ...

DSMC overlay mode

DSMC overlay input
native variables, loops, jumps
dsmc-iac -in case.in

Run DSMC interval
particles, collisions, reactions, MPI
run 10000

Sample surface chemistry
reactions/collisions by triangle ID
fix ave/surf ...

Reinstall DSMC surface
remap particles and grid-surface state
surface update surf1 install yes

standalone
loop

coupled
DSMC loop