LOG IN
 REGISTER
 SUBSCRIBE
 SHOP
 HELP
 0 items
 Search

SOUND ON SOUND

NEWS FORUM

MAGAZINE REVIEWS

TECHNIQUES

PEOPLE

SOUND ADVICE

MUSIC BUSINESS

HOME > TECHNIQUES >

Practical Bowed-string Synthesis

Synth Secrets

Synthesizers > Synth Secrets, Synthesis / Sound Design

By Gordon Reid

Published May 2003




Figure 1.

Having looked at the mechanics of how a bowed string instrument generates its sound last month, it's time to put these principles into practice, using nothing more complex than a miniKorg 700 monophonic synth...

Last month, we discussed the nature of the orchestral instruments that are usually bowed to create their sounds. These are commonly accepted to be the violin, viola and cello, although — despite its use as a plucked instrument in jazz and rock & roll — the double bass is also a member of the family. We will now attempt to recreate the sounds of the smallest of these using a simple, analogue, subtractive synthesizer.

The Basics

As I explained in the previous instalment of this series, the action of the bow upon the string and the action of the string upon the bridge produce a sawtooth wave in the bridge itself. This energy is then modified by the bridge resonances before being transmitted to the body of the instrument. We can represent this as a synthesizer patch using just a single sawtooth oscillator, plus a complex filter bank to model the bridge resonances (see Figure 1, above).

What happens when we energise the body of




Figure 2a.

the instrument is a little more complex, although we can describe it in similar fashion; the body has a complex frequency response that imposes another set of resonances and anti-resonances upon the sound.

In this article...

- Introduction
- The Basics
- Inserting The Waveform

In this Series

- Synth Secrets: all 63 Parts on Sound On Sound site
- What's In A Sound?
- The Physics Of Percussion
- Modifiers & Controllers
- Of Filters & Phase Relationships
- Further With Filters
- Of Responses & Resonance
- Envelopes, Gates & Triggers
- More About Envelopes
- An Introduction To VCAs
- Modulation
- Amplitude Modulation
- An Introduction To Frequency Modulation
- More On Frequency Modulation
- An Introduction To Additive Synthesis
- An Introduction To ESPs & Vocoders
- From Sample & Hold To Sample-rate Converters

 (1)
- From Sample & Hold To Sample-rate Converters (2)
- Priorities & Triggers
- Duophony
- Introducing Polyphony
- From Polyphony To Digital Synths
- From Springs, Plates & Buckets To Physical Modelling
- Formant Synthesis
- Synthesizing Wind Instruments
- Synthesizing Brass Instruments
- Brass Synthesis On A Minimoog
- Roland SH101 & ARP Axxe Brass Synthesis
- Synthesizing Plucked Strings
- The Theoretical Acoustic Guitar Patch
- A Final Attempt To Synthesize Guitars
- Synthesizing Percussion
- Practical Percussion Synthesis: Timpani
- Synthesizing Drums: The Bass Drum

Figure 2(a) shows the response for a typical violin body, and Figure 2(b) shows the rather different spectrum obtained when the body is energised by the modified sawtooth wave produced by the filter bank in Figure 1. As you can see, there are three prominent resonant regions in Figure 2(b), with a sharp roll-off in the bass, and a gentler roll-off at high frequencies. And, complex though this appears to be, we can approximate it using just three synthesizer modules: a low-pass filter, a highpass filter, and a resonant filter bank (Figure 3).




Figure 2b. Overall spectrum.




Figure 3. String bridge body resonances.

Fortunately, when modelling the violin, we don't need to add the filter bank in Figure 1 to the filter bank in Figure 3. We can use a single bank and set the filter frequencies, gains and Qs to the appropriate values for the combined response of the bridge and body. This then gives us a model for the basic timbre of a violin's sound, as shown in Figure 4 below.




Figure 4. Simple violin model.

Now, I'm at a loss to recall an integrated subtractive synthesizer that offers a low-pass filter, a high-pass filter and a resonant, parametric filter bank. However, this need not be a problem, because if we ignore a number of secondary effects, the order in which the filter appears need not matter to us, and we can place the filter bank after the low-pass and high-pass filters. In other words, we can create the basic sound using any synth with a low-pass filter and an high-pass filter, and then pass the output through an external filter bank.

Of course, not everybody has access to an external filter bank, but there are a number of affordable units available. I have one of them... an Analogue Systems RS360 Vocal/Phase Filter Bank (as shown in Figure 5), so I will use this to




Figure 5: Analogue Solutions RS360 filter bank.

replace the signal model in Figure 4 with that in Figure 6. By the way, note that Formant synthesis (for this is what we are discussing -- see the 'Band-pass Filter' box later) requires at

- Practical Bass Drum Synthesis
- Synthesizing Drums: The Snare Drum
- Practical Snare Drum Synthesis
- **Analysing Metallic Percussion**
- Synthesizing Realistic Cymbals
- Practical Cymbal Synthesis
- Synthesizing Bells
- Synthesizing Cowbells & Claves
- Synthesizing Pianos
- Synthesizing Acoustic Pianos On The Roland JX10
- Synthesizing Acoustic Pianos On The Roland JX10 [Part 2]
- Synthesizing Acoustic Pianos On The Roland JX10 [Part 3]
- Synthesizing Strings: String Machines
- Synthesizing Strings: PWM & String Sounds
- Synthesizing Bowed Strings: The Violin Family
- Practical Bowed-string Synthesis
- Practical Bowed-string Synthesis (continued)
- Articulation & Bowed-string Synthesis
- Synthesizing Pan Pipes
- Synthesizing Simple Flutes
- **Practical Flute Synthesis**
- Synthesizing Tonewheel Organs: Part 1
- Synthesizing Tonewheel Organs: Part 2
- Synthesizing Hammond Organ Effects
- Synthesizing The Rest Of The Hammond Organ:
- Synthesizing The Rest Of The Hammond Organ: Part 2
- From Analogue To Digital Effects
- Creative Synthesis With Delays
- More Creative Synthesis With Delays
- The Secret Of The Big Red Button

SOS Competitions

WIN! Milab VIP-60 Microphone WIN! Best Service The Orchestra Complete 2, by Sonuscore WIN! Apogee Duet 3 Bundle



least three formants per sound. This means that the RS360 or an equivalent is the minimum suitable configuration for our purposes.

If you study Figure 5, you will see that each of the RS350's three filters offers a Sig In Level, a Frequency control, and Resonance. Each filter produces the four common filter characteristics (24dB-per-octave low-pass, 24dB-per-octave high-pass, 12dB-per-octave band-pass and 12dB-per-octave notch filtering), and the cutoff frequencies of the high-pass and low-pass filters are the centre frequencies of the band-pass and notch filters. The summed outputs on the right-hand edge of the module offer the low-pass outputs of all three filters, the high-pass outputs of all three, and so on.




Figure 6: External filter bank.

Now, we're not interested in the lowpass and high-pass filters offered, nor are the notch filters of any use this month. But if we use the summed outputs of the band-pass filters, we can achieve some useful results.

To set up the RS360 appropriately, we will set the first two filters to accentuate the body resonances at 300Hz and 700Hz. We do this by

FURTHER READING

FILTER	SIG IN LEVEL	FREQUENCY	RESONANCE
VCF1	4	300Hz	3.5
VCF2	5	700Hz	3.5
VCF3	MAX	3kHz	2

setting the Frequency controls of VCF1 and VCF2 to the appropriate positions, setting the signal levels to imitate the height of the peaks in Figure 2, and then adjusting their resonances to emphasise any signal partials that lie at, or close to, these frequencies. To create the broader peak at 2kHz to 4kHz, we set VCF3 to about 3kHz and use a lower resonance. This allows a wider spread of frequencies to pass.

I have summarised the settings necessary to recreate Figure 2 in the table above, and I can represent their combined frequency response as Figure 7.

At this point, you may be wondering how on earth you go about tuning a filter bank to precise frequencies. Synthesizer filters with calibrated initial cutoff frequencies are vanishingly rare, and Analogue Systems' annotation from 'Min' to 'Max' is of no help whatsoever. So here's the trick...

now on lk to so with see ms' phelp

Figure 7.

Placing a suitable attenuator somewhere in the signal chain between the filter bank and your speakers, you should set the cutoff of VCF1 to a middling value, and then increase the resonance to maximum. A tortured shriek will result... and it will be you doing the shrieking if you ignored my warning about the attenuator. The filter is now emitting a sine wave at the cutoff frequency so, given a suitable reference, we can tune it to the desired pitch.

Few of us have a pitch-to-frequency chart in front of us (and even fewer have memorised one) so we need to be able to judge the cutoff frequency using a simple, mnemonic rule of thumb. The one I devised and use is this: We know that the fundamental frequency of the 'A' above middle 'C' is 440Hz or

FURTHER READING

NOTE	APPROXIMATE	
	FREQUENCY (HZ)	
ΑO	55	


Readers' Ads

VIEW ALL ADS CREATE FREE AD

On the same subject

- The Secret Of The Big Red Button July 2004
- More Creative Synthesis With Delays June 2004
- Creative Synthesis With Delays May 2004
- From Analogue To Digital Effects April 2004
- Synthesizing The Rest Of The Hammond Organ: Part 2 March 2004

SIGN UP TO SOS NEWSLETTERS



Latest SOS Videos



Cutting Vinyl At Abbey Road

4 days 23 hours ago.



Your Questions Answered

2 months 1 week ago.



thereabouts. We also know that the 'A' above this oscillates at double the frequency, and the 'A' below oscillates at half the frequency. Furthermore, we know that a perfect fifth -- ie. close to the 'E' above A440 -- oscillates at 3/2 times A440, as do all the other 'E's relative to the 'A's below them. We can, therefore, create a simple table that defines a number of frequencies across the keyboard, as shown here.

Tuning our filters now becomes simple. If you want	E4
to set VCF1 to about 300Hz, you find the closest	A4
Figure in the table (which is E3 at 330Hz) and by	E5
simple comparison – tune the self-oscillation to a	
note a semitone or two below this; ie. in the region of	A5
D#3 or D3. Likewise, the closest to 700Hz – the	E6
frequency we desire for VCF2 – is E4 at 660Hz, so you	
tune the self-oscillation of VCF2 to F4 or thereabouts.	A6
Finally, 3000Hz lies about halfway between E6 and	


A6, so you tune VCF3 in the region of F#6 or G6. Having found the correct setting for each filter in turn, you then turn down the resonance to the values shown in the table on the last page (a self-oscillating filter is not what we want in our sound this month, after all). It's a crude method, given that pitch operates on a logarithmic scale, not a linear one -- but it works.

E1	82.5
A1	110
E2	165
A2	220
E3	330
A440 (MIDI A3)	440
E4	660
A4	880
E5	1320
A5	1760
E6	2640
A6	3520



Radiophonic Recording At Eve Studios

3 months 6 days ago.



Band-pass Filter Banks

Filter banks of the sort described here are often used to create Formants. These are the static resonances inherent in sound generators such as the human voice and hollow-bodied musical instruments, and they are important elements within sound synthesis. This is because, just as the precise positions and shapes of the formants in a human voice allow you to identify the vowel sounds spoken, they make the timbres of acoustic instruments consistent and recognisable from one instrument to the next. It therefore follows that recreating the formants of a given instrument represents a big step toward the accurate synthesis of its sounds.

Inserting The Waveform

Now we have to select a synth to provide the filtered sawtooth wave that we're going to pass through the RS360. Oh yes... and we're going to need an amplitude envelope, an LFO and a keyboard or other controller of some sort.

These are simple requirements, and we could use almost any synth to satisfy them. I'm going to turn to the first synth I ever owned; one of the most basic ever built, yet still capable of producing some rather super sounds. It's the Korg 700.

Figure 8 shows the entire control panel of the little Korg. If you've never played one, you might think that it is incredibly limiting; it offers no ADSR envelopes, no filter resonance controls, no obvious routing... in fact, little of anything. But appearances can be deceptive, and the 700 was responsible for many classic patches in the mid-1970s.



Figure 8: The entire Korg 700 control panel.

Setting it up to produce the desired waveform and filter roll-offs is trivial. First, we turn to the Scale and Mode selectors, setting the first to 4' (the violin is, after all, a fairly high-pitched instrument) and the latter to sawtooth. Next, we find the 'Traveler', which is a combined high-pass/low-pass filter. The upper slider controls a 12dB-per-octave low-pass filter, so we lower this somewhat to roll off the highest frequencies. Likewise, the lower slider controls a 12dB-per-octave high-pass filter, so we raise this to attenuate the low frequencies (see Figure 9 below).



Figure 9: Korg 700 settings.

If we now play the Korg through the RS360 filter bank, we obtain a sound that is nothing like a violin; in fact, it is closer to that of a banjo. This is because the envelope of the sound is percussive. We need to find the ADSR envelope generator and create something more in keeping with a 'bowed' sound.


Umm... except that the Korg 700 has no ADSR envelope generator. There are only three contour controls: the two sliders marked 'Attack/Slow' and 'Percussion/Singing', and the Sustain switch found in the group of eight switches near the centre of the panel. You'll note that each of these is coloured orange. This is not a coincidence. Korg colour-coded all the controls on their early synths: orange for amplitude controls, red for timbre controls, blue for pitch controls, yellow for the repeat LFO, and green for portamento.



Figure 10: Setting the Korg violin VCA.

We need to modify the contour of the sound so far obtained, and we do so by increasing the Attack to somewhere in the region of '5' or '6', and by increasing the Percussion to Singing, which is equivalent to a Sustain setting of 10 on a conventional synth. But beware... do not switch on Sustain by flipping the switch downward, because it applies a fixed amount of what we would normally term 'release' to the envelope, and that would be inappropriate for what we want (yes, I know that it's confusing, but that's part of the charm of the Korg 700; it does things differently, and forces you to approach sound creation in a novel manner). Anyway, we have now set the amplitude controls as shown in Figure 10, and obtained the amplitude contour shown in Figure 11. Things are starting to sound decidedly stringier.

So... how does it sound? Well, it has a 'bowing' sort of attack, and a similar timbre to a violin, but it still sounds little like a violin. It sounds like a synthesizer. On the other hand, if I were to pick up a violin and try to play it, the result would also sound nothing like a violin. The explanation for this is simple; I'm incapable of playing a bowed string instrument, and my attempts would surely incur the wrath of the Cats Protection League. Sure, I can scrape a basic tone from the instrument, but there is no finesse, no articulation, no feeling. And this is what is wrong with the patch I have just created. While a single note may sound vaguely Figure 11. The unusual Korg 700 VCA contour. like a bow being dragged across a violin string,



a succession of notes have none of the attributes that make them sound like a musical instrument. So we're going to attempt to correct this by adding the most important element in the violinist's playing technique... vibrato.

A human violinist creates vibrato by wiggling the finger that is pressing the string against the neck of the instrument, The modulation speed is usually in the range of about 5Hz to 8Hz, and the amplitude can be surprisingly high; up to about a quarter of a tone. However, the vibrato is not consistent, and we should be aware that players tend to introduce it after the initial bowing action, and modify it to suit the requirements of the music.

Surprisingly, due to the physics of the violin, this vibrato also creates amplitude modulation (tremolo) and a good bowed string patch will take account of this. But the Korg 700 is not capable of tremolo, so we will have to ignore this.

Figure 12 shows the vibrato controls for our patch. We choose modest settings for the vibrato speed and depth, adjusting these by ear to generate a pleasing amount of motion in the sound. Note that I have chosen to use the 'Delay Vib' setting in preference to straight 'Vibrato' because this introduces the effect a



fraction of a second after you play the note. It's a ইঞ্জিটে নির্মারের জিপ্টিস্থাপটালি পুলারির performer, but it's far superior to having the vibrato present from the moment that you press a key.

The next problem concerns the pitching of the notes. This patch, like a piano or organ, plays notes discretely; that is, overlooking the vibrato for a moment, an 'A' is an 'A' from the moment that you press the key, a 'B' is precisely a 'B' and so on. This is not what happens when you play an unfretted string instrument, and even the best violinists will play notes a fraction sharp or flat, and then 'hunt' for the correct pitch. Add to that the glide used in violin performances, and it is clear that — to imitate the sound more accurately — we must introduce some sort of 'performance' attribute to the pitch.

On a more sophisticated synth, we could use the pitch-bend wheel to add glide, and even (with practice) to create a more musical vibrato. But the Korg 700 has no such controls; no pitch wheel, no joystick, no touchpad -- no nuffink! What it does have, however, is portamento, and we can use the tiniest amount of this to create an almost



Figure 13: Adding a little glide to the patch.

imperceptible glide between notes (see Figure 13). Any more than the tiniest amount will destroy the illusion instantly, but if you can get the Portamento slider to sit just off 'zero', it can improve the patch considerably.

And that's all there is to it. So let's summarise: firstly, we used the synth to generate a sawtooth wave, and filtered it using the internal low-pass and high-pass filters to satisfy the requirements of Figure 5. Secondly, we chose contour settings that create a slight 'bowing' attack to the beginning of the sound, and which sustain it for as long as a key is depressed. Thirdly, in an attempt to reduce the rather synthetic nature of the sound, we added delayed vibrato, plus a smidgen of portamento to make the transitions between notes less like an organ and more like an unfretted instrument. Finally, and again in keeping with Figure 5, we passed the result through a three-band parametric 'formant' filter that provides a rough emulation of the most prominent body resonances of the real instrument.

So, does it now sound like a real violin? Don't be silly – it still sounds like a 1970s synth patch of a violin. Nevertheless, played sympathetically, and with careful tuning of the RS360, it has a pleasing 'violin-y' quality, particularly at higher pitches.




Figure 14: The 'factory' violin patch from the Korg 700 manual, printed in 1974.

But what if you don't have a filter bank? Does the patch still work? Indeed it does, although it loses a little of the timbre that I've been trying to create. To demonstrate this, Figure 14 shows the original Korg 700 'factory' violin patch, and you can see both the similarities and differences to mine. For example, I prefer a slower Attack, and use the high-pass filter to remove more of the lower frequencies. What's more, I use less vibrato and have added that tiny amount of portamento, but the basis of the patch is essentially the same.

Still, neither sound is the best imitation of a violin that I have heard produced by an analogue synth, so next month we'll investigate bowed string sounds further, and see what improvements we can obtain on more sophisticated equipment.

Previous article Next article





New forum posts

2022/3/28 12:46

Re: OK? Genelec 8010's.

ef37a

Recording: Gear & Techniques 28 Mar 2022, 10:41

Re: New album Rose Garden out in a fev

Arpangel

Self-Promotion 28 Mar 2022, 10:41

Re: Apple unveil Mac Studio and Studio

ien

Mac Music 28 Mar 2022, 10:39

Re: Using a spare MacMini for soft-synth

Folderol

Mac Music 28 Mar 2022, 10:31

Re: Need mic help

blinddrew

Recording: Gear & Techniques 28 Mar 2022, 10:18

Active topics

Need mic help

Boz Digital Labs The Hoser | 71% OFF Ex

Is Logic Pro backwards compatible?

Using a spare MacMini for soft-synths

Roland BTM-1

Electric Guitar T, Fender's legendary Tele

Ian Boddy recognition

Cutting vinyl at Abbey Road.

Analog tape transfer to digital

Spotify news

Recently active forums

- Forum FAQs
- Recording: Gear & Techniques
- Mixing, Mastering & Post Production
- New Products & Industry News
- Music Business
- Mac Music
- Windows Music
- Apps & Other Computers/OS
- Guitar Technology
- Keyboards & Synthesis
- DIY Electronics & Studio Design
- Live Sound & Performance
- Music Theory, Songwriting & Composition
- User Reviews
- Remote Collaboration
- Self-Promotion
- Feedback

Contact Us Cookie Policy Help Privacy Policy Terms of Use

All contents copyright © SOS Publications Group and/or its licensors, 1985-2022. All rights reserved.

The contents of this article are subject to worldwide copyright protection and reproduction in whole or part, whether mechanical or electronic, is expressly forbidden without the prior written consent of the Publishers. Great care has been taken to ensure accuracy in the preparation of this article but neither Sound On Sound Limited nor the publishers can be held responsible for its contents. The views expressed are those of the contributors and not necessarily those of the publishers.

Web site designed & maintained by PB Associates & SOS