LOG IN REGISTER SUBSCRIBE SHOP HELP 0 items Search

SOUND ON SOUND

NEWS

FORUM

MAGAZINE

REVIEWS

TECHNIQUES

PEOPLE

SOUND ADVICE

MUSIC BUSINESS

HOME > TECHNIQUES >

From Sample & Hold To Sample-rate Converters (1)

Synth Secrets

• Synthesizers > Synthesis / Sound Design, Synth Secrets

By Gordon Reid

Published August 2000

Gordon Reid introduces the synthesis modules that allow you to create a number of commonly used 'random' effects, and their close relatives — analogue sequencers.

You might think that after more than a year's worth of articles about oscillators, filters, amplifiers, LFOs, contour generators, external signal processors, and heaven knows what else, we would have exhausted the modules that make up an analogue synthesizer. Not a bit of it! This month, we're going to start with a common synth component, the Sample and Hold module, and consider its use with a few less common ones. This potentially obscure discussion will nevertheless take us from Emerson, Lake and Palmer to Donna Summer, and from clock pulses to the the threshold of analogue-to-digital conversion. Not bad, eh?

Not All Samples Are Digital

Given that it's not necessary for generating any conventional imitative sounds, the Sample and Hold (S&H) module is remarkably common. Early Moog modulars had them, as did classic synths such as the ARP 2600 and Odyssey, so many of the characteristic sounds they make possible have entered common usage. To understand S&H, take a peek at Figure 1 (below). This is another of my 'remarkably simple' circuits, comprising just two components: a capacitor, and a switch.

Imagine, if you will, that a standard synthesizer signal is presented to the input on the left of the diagram. If doesn't matter whether this is an audio signal, an LFO, an envelope, or anything else. Now imagine that, just for an instant, the switch closes. Provided that the capacitor can react quickly enough, it then charges up (or discharges down) to the voltage at the input, thus 'sampling' that voltage. Then, once the switch has opened again, the voltage across the capacitor cannot change. This is because on the left-hand side there is no circuit and, on the right-hand side, the impedance is infinite (which means that no current can flow). However, although no current flows, you can still measure the voltage across the output. (Of course, the impedance is never truly infinite, so the voltage will decay slowly, and one measure of the quality of an S&H module is the slowness of the rate at which this decay occurs.)

So that's all there is to it... when the switch is closed, the capacitor 'samples' the input voltage. When the switch is open, the capacitor 'holds' that voltage, allowing other circuits to respond to it as appropriate. Sample and Hold... simple, yes?

Clock Generators

Now, if you were limited to closing the switch in Figure 1 manually, the S&H would not be of much use. So synthesizers have electronic switches, and provide another module that is capable of opening and closing them at high speeds. The most common such module is one that we have not yet discussed in Synth Secrets. It is the Clock Generator.

In this article...

- Introduction
- Not All Samples Are Digital
- Clock Generators
- Introducing Sequencers
- Voltage Quantisation
- Programmable Scale Generators
- Slewing The Output


In this Series

- Synth Secrets: all 63 Parts on Sound On Sound site
- What's In A Sound?
- The Physics Of Percussion
- Modifiers & Controllers
- Of Filters & Phase Relationships
- Further With Filters
- Of Responses & Resonance
- Envelopes, Gates & Triggers
- More About Envelopes
- An Introduction To VCAs
- Modulation
- Amplitude Modulation
- An Introduction To Frequency Modulation
- More On Frequency Modulation
- An Introduction To Additive Synthesis
- An Introduction To ESPs & Vocoders
- From Sample & Hold To Sample-rate Converters (1)
- From Sample & Hold To Sample-rate Converters
 (2)
- Priorities & Triggers
- Duophony
- Introducing Polyphony
- From Polyphony To Digital Synths
- From Springs, Plates & Buckets To Physical Modelling
- Formant Synthesis
- Synthesizing Wind Instruments
- Synthesizing Brass Instruments
- Brass Synthesis On A Minimoog
- Roland SH101 & ARP Axxe Brass Synthesis
- Synthesizing Plucked Strings
- The Theoretical Acoustic Guitar Patch

From Sample & Hold To Sample-rate Converters (1)

As you might guess from its name, a Clock Generator provides an evenly spaced stream of 'ticks' in the form of short pulses (see Figure 2). Of course, this is simply a specialised form of oscillator: one that produces a pulse wave at, typically, subsonic and low audio frequencies. Most often, you would use the clock as a timer, for example, triggering envelopes or as a 'sync' or reset source for conventional audio oscillators and LFOs. However, those are topics for another day.

Today's use for the Clock Generator is to provide a stream of very short pulses that trigger the switch in Figure 1. In other words, when the pulse is On, the S&H circuit samples, and when the pulse is Off, the S&H holds. As you can see, I have shown the clock ticks as +10V pulses with negligible width. In practice, many S&H circuits will perceive a trigger when they receive any positive-going waveform with a sharp leading edge.



Switch

Figure 1: [top] The simplest representation of a S&H circuit. Figure 2: [bottom] The output from a Clock Generator.

If we marry our clock generator to the S&H circuit, we can devise a composite module that incorporates two sub-modules: the clock and the S&H circuit itself (see Figure 3).

Let's analyse what's happening in Figure 3. It shows a sine wave entering the signal input of the S&H module. At the same time, a clock provides a stream of pulses that it presents to the S&H's trigger input. The output produced by the S&H circuit is then the 'rectangular' waveform shown in the Figure.

If the reason for this output is not clear, Figure 4 should clarify things. Each time the S&H module receives a trigger from the clock generator, it measures (or 'samples') the voltage of the input signal (shownin red). It then holds this voltage (the blue line) until it receives the next trigger, at which point it repeats the operation. It 'samples' and it 'holds', just as we've discussed.

This result would not be very interesting if a sine wave was the only signal you could present to the S&H's audio input. Fortunately, the input signal can be anything: a synthesized audio

waveform, a slowly varying CV, or even an external signal such as the sound from a CD player or of an instrument being played. However, most synthesizers also have a noise generator that produces a 'random' signal, and this is the most commonly used type of S&H input. Why? Because it creates a number of musically pleasing effects.

Figure 5 shows what happens when you S&H a noise signal. Again, the input is the red line, with the output shown in blue. Now, what can we do with this output? The first thing to remember is that there's nothing stopping us from directing the output signal to the inputs of any other synthesizer modules, whereupon it will modify any other CVs or signals within the synthesizer. However, there are two common uses that you will have heard many times, and which deserve special mention here.

The first involves directing the S&H output to an oscillator's CV input so that it makes the pitch vary randomly. Interesting on an analogue synth, this facility comes into its own on a digital synth. This is because — with a suitable amplifier to attenuate the variations — you can use this effect to add delicate random fluctuations to the pitch of a sound. Far less obvious (and therefore more interesting) than cyclic LFO modulation, it's the





Figure 3: [top] A simple example of S&H. Figure 4: [bottom] Explaining S&H.



- A Final Attempt To Synthesize GuitarsSynthesizing Percussion
- Practical Percussion Synthesis: Timpani
- Synthesizing Drums: The Bass Drum
- Practical Bass Drum Synthesis
- Synthesizing Drums: The Snare Drum
- Synthesizing Drums: The Share Druf
 Practical Share Drum Synthesis
- Analysing Metallic Percussion
- Synthesizing Realistic Cymbals
- Practical Cymbal Synthesis
- Synthesizing Bells
- Synthesizing Cowbells & Claves
- Synthesizing Pianos
- Synthesizing Acoustic Pianos On The Roland JX10 [Part 1]
- Synthesizing Acoustic Pianos On The Roland JX10 [Part 2]
- Synthesizing Acoustic Pianos On The Roland JX10 [Part 3]
- Synthesizing Strings: String Machines
- Synthesizing Strings: PWM & String Sounds
- Synthesizing Bowed Strings: The Violin Family
- Practical Bowed-string Synthesis
- Practical Bowed-string Synthesis (continued)
- Articulation & Bowed-string Synthesis
- Synthesizing Pan Pipes
- Synthesizing Simple Flutes
- Practical Flute Synthesis
- Synthesizing Tonewheel Organs: Part 1
- Synthesizing Tonewheel Organs: Part 2
- Synthesizing Hammond Organ Effects
- Synthesizing The Rest Of The Hammond Organ: Part 1
- Synthesizing The Rest Of The Hammond Organ: Part 2
 - From Analogue To Digital Effects
- Creative Synthesis With Delays
- More Creative Synthesis With Delays
- The Secret Of The Big Red Button


SOS Competitions

WIN! Milab VIP-60 Microphone WIN! Best Service The Orchestra Complete 2, by Sonuscore WIN! Apogee Duet 3 Bundle key to humanising many digital sounds, and it's Figure 5: A waveform produced by passing a random absolutely vital to any impersonations of real

(noise) signal through an S&H module.

instruments that waver slightly as the note plays. For this reason, many LFOs offer a 'random' output waveform alongside the sine, pulse and triangle waves that most provide.

The second example requires you to direct the S&H output to the CV input of a low-pass filter. This affects the high-frequency content of the sound and, therefore, each clock pulse changes the timbre of the audio passing through the filter. If, like me, you grew up with 'First Impression' from ELP's 'Karn Evil 9' ringing in your ears, you'll know this sound intimately. Indeed, this combination of clock, S&H and noise (Figure 6) is so deeply routed in synthesis that some synthesizers combine them in a single module. The RS Integrator module in Figure 7 demonstrates this. At the top of its panel, you'll find a noise generator with an



noise, S&H and clock configuration.

associated level control and output. Beneath this, you have the signal input for the S&H, the clock input, the S&H output, and a level control that adjusts the gain of the output signal. Below this, you have the clock itself, with a frequency control and output. There is just one control that is less than obvious: the 'one shot' button allows you to trigger the S&H switch manually.

Unlike some other synthesizers with prepatched S&H modules, the three sub-modules in the RS40 are not pre-connected 'behind the scenes' (if they were, the 'one shot' button would not work). This means that you must patch sources into both the EXT SRC IN and EXT CLK IN sockets. The simplest and most obvious sources for these purposes are the noise generator and clock outputs that lie immediately above and below them but, as suggested above, you are by no means limited to these.

Before moving on, we should look at two further refinements to the S&H concept. The first involves the nature of the signals that will trigger the sampling operation. If you think about the pulses produced by the clock generator you will realise that they can not be truly instantaneous — they have a duration. So, is the sample taken on the leading edge of the pulse, on the trailing edge, or (less usually) on both edges? On analogue synthesizers, it's usually the leading edge that does the trick. Nevertheless, if you want to experiment with trailing-edge triggering you can do so if you invert the trigger signal and provide a suitable DC offset.

module. The second refinement is even more esoteric. Let's face it, you won't often trip across a Buchla Model 264 Quad Sample and Hold/Polyphonic Adaptor (on which this feature appears) at your local car-boot sale. However, you'll find the same features on one of the most common patchable analogue synthesizers of them all. The

Of course, Buchla and Korg didn't silkscreen the name 'T&H' on their modules; they called them S&H modules like everybody else. However, there's a difference, and it lies in way that the circuit handles the clock pulse. Unlike everything discussed above, sampling is not triggered by an edge of the clock pulse and then held until the next equivalent edge. Instead, the circuit is transparent when the pulse is high, and the hold is initiated by the falling edge, remaining constant until the clock goes high again. As you might imagine, this means that you can use the


effect is 'Track and Hold' and the common synth is the Korg MS20.



Korg MS20.

duty cycle of your clock pulse to determine the proportion of time that the output (in blue) tracks the input (in red), and the proportion that it holds (see Figure 8).

T&H modules are powerful tools that provide many possibilities not achievable using conventional S&H modules. For example, you can use one together with one of last month's Envelope Followers so that the amplitude of an external audio signal determines whether the module Tracks or Holds. Interesting, yes? Furthermore, you can use the T&H as a conventional S&H if you use a clock with a pulse of minimal duration.





module.

Figure 7: A combined Noise, S&H and Clock

Readers' Ads

VIEW ALL ADS **CREATE FREE AD**


On the same subject

- The Secret Of The Big Red Button July 2004
- More Creative Synthesis With Delays
- Creative Synthesis With Delays May 2004
- From Analogue To Digital Effects April 2004
- Synthesizing The Rest Of The Hammond Organ: Part 2 March 2004


From the same manufacturer

- · Analogue Solutions Leipzig V3 October 2021
- **Analogue Solutions Impulse Command** September 2019
- **Analogue Solutions Generator** March 2019
- **Analogue Solutions Treadstone** November 2018
- Analogue Solutions Fusebox July 2018

SIGN UP TO SOS NEWSLETTERS



Latest SOS Videos



Introducing Sequencers

There are many other enhancements to the basic S&H concept, and other modules — such as pulse shapers — that you can add to generate specific effects. Nevertheless, while an S&H module is very useful for creating random effects, and for adding that ineffable sparkle to many sounds, it is not easy to create melodies using one. Nor will an S&H easily provide conventional movement within your sounds. For this, we need a module that allows you to decide the value of its output CV at every clock step. We call such a device an analogue sequencer.

Figure 9 shows the simplest form of analogue sequencer (which, henceforth, I'll simply call a 'sequencer'). It has 16 steps, and a dedicated potentiometer, controlled by a fader, determines the output at each step. A clock generator (which may be internal or provided by an outside source) causes the sequencer to step from one fader to the next, and from step




Figure 8: A Track & Hold (T&H) input/output graph.




Figure 9: A simple analogue sequencer.

16 back to step 1 when it reaches the end of the row. Of course, the potentiometers could be knobs — and they often are — but it's much easier to see what's happening using faders.

Let's suppose that the output is 0V when a fader is at the bottom of its travel, and +2V when it is at the top. If you then direct the output voltage to the pitch CV input of a 1V/octave oscillator, you can determine the pitch anywhere in a two-octave range. This makes it possible to construct simple 16-note melodies that repeat continuously while the clock is running.

Look at Figure 10. If you've used a sequencer extensively, you'll recognise it immediately. It's the 'do-do de-de da-da de-de' bass line from thousands of best-forgotten disco hits inspired by Donna Summer's 'I Feel Love'. If you look at Figure 11, you'll see that the configuration of the faders on the sequencer exactly mimics the notes as they would appear on a musical staff. The similarity is not surprising, given that the two systems use identical concepts for representing musical pitch.

In reality, sequencers are often far more complex than the one shown in Figure 9. A powerful unit will offer multiple rows of CV




Figure 10: [top] A typical 1970s disco bass sequence. Figure 11: [bottom] The same sequence written in traditional notation.

generators, multiple outputs, multiple clock inputs for the rows, CVs for the clocks themselves, range controls for the CVs, note-skip capabilities, variable sequence lengths, and many other facilities (see Figure 12 for an example). However, the underlying concept remains the same.

Voltage Quantisation

Despite the power of the sequencer shown right, it's a very laborious task to make it create musical sequences. Why? It's because the faders (or, in this case, the knobs) are capable of producing any voltage within their range including values that lie between the notes in a conventional musical scale. This means that, instead of the 25 semitones that exist in the full two octaves discussed above, or the 121 that lie within the 0V to +10V range of the sequencer in Figure 12, there are thousands, maybe millions, of discrete voltages available. This makes precise tuning almost impossible.



Cutting Vinyl At Abbey Road

4 days 23 hours ago.




Your Questions Answered

2 months 1 week ago.



Radiophonic Recording At Eve Studios

3 months 6 days ago.



The solution to this problem lies in a module called a Voltage Quantiser, or simply a 'quantiser' — a device that rounds every voltage passing through it up or down to that which produces an exact semitone. It does this by making sure that, no matter what the input voltage may be, the output is one of the voltages that define the well-tempered scale for a 1V/Octave synthesizer (see Table 1 and Figure 13). As you can see, the 'spacing' between the voltages of the notes is 1/12th of a volt (although the relationship between the frequencies is not so simple).

The presence of the quantiser makes it much easier to set the controls on the sequencer to create recognisable melodies or bass lines. Similarly, you can use it to quantise the output from your S&H module to be in semitones (ie. 'real' notes) rather than random pitches. You can even use it to convert a continuously rising or falling CV into a 'stepped' one — an effect that we often use to convert portamento into glissando (see Figure 14). As you can see, this is very similar to the output of the S&H module in Figure 3. The difference is that, whereas the S&H measures a new voltage every time it receives a trigger from an outside source, the quantiser steps between voltages every time the input moves between ranges of values.

Programmable Scale Generators

There's an enhanced type of quantiser that's also worthy of special mention. This is the 'Scale Generator' (or Scale Quantiser), a module that quantises the voltage in such a way that the output conforms to a predetermined musical scale. A programmable scale generator takes this idea one stage further: while it may include predetermined scales as options, it also allows you to choose the notes that define any desired scale. This leads to an unexpected combination of modules, and one that produces interesting musical effects. Figure 15 shows how it works.

Firstly, the S&H module produces a succession of random voltages. The programmable scale generator (the 'PSG') then quantises these voltages to conform to the notes in a desired scale. You direct the output from the PSG to the pitch CV input of an oscillator which, as a consequence, produces random notes — but always within that desired scale. This is particularly pleasing if you make the defined



Figure 12. A sophisticated step sequencer from Doepfer.

Note Name	Frequency	Misineuro	Macciness	Output
-	(Hz)	Input Voltage	Ispet Voltage	Voltage
C2	131	0.958	1.042	1.000
C#2 (Dh2)	139	1.042	1.125	1.083
02	147	1.125	1.268	1.167
0#2 (Eb2)	156	1.208	1.292	1.250
62	165	1.292	1.375	1.333
F2	175	1.375	1.458	1.417
F#2 (Qb2)	185	1.458	1.542	1.500
02	196	1.542	1.625	1.583
G#2 (Ah2)	208	1.625	1.708	1.667
A2	220	1.708	1.792	1.750
A#2 (Bh2)	233	1.792	1.875	1.833
B2	247	1.875	1.958	1.917
C3	262	1.958	2.042	2.000
Ca3 (0h3)	277	2,042	2.125	2.083
03	294	2.125	2.208	2.167
D#3 (Eb3)	311	2.208	2.292	2.250
E2	330	2.292	2.375	2.333
F3	349	2,375	2,458	2.417
F#3 (0b3)	370	2.458	2.542	2.500
03	392	2.542	2.625	2.583
G#3 (Ah3) :	415	2,625	2.708	2.667
A3	440	2.708	2.792	2,750
A#3 (853)	466	2.762	2.875	2.833
83	494	2.875	2.958	2.917
C4	523	2.958	3.042	3.000

Table 1: Part of the logarithmic frequencies and linear voltages that represent the notes between C2 and C4.




Figure 13: Any voltage between the maximum and minimum is corrected to the exact note value.




Figure 14: Converting a smoothly varying voltage into a stepped one.

scale an arpeggio because you then have a random arpeggiator — one of my favourite effects, and still available only on a handful of synths.




Figure 15: Producing a random series of notes in a desired scale.

Slewing The Output

So far this month, we've only discussed the creation of stepped voltages from continuously varying signals. But there are many times when you would like the transitions from one voltage to another to be a little less abrupt. So let's finish by looking at ways in which we can smooth our S&H or sequenced output.

When you press a key on a voltage-controlled synth, you provide a voltage sample to an oscillator's pitch CV input. You specify the voltage itself by choosing which key to play. Then, when you press a second key, you present a second sample to the oscillator's input, and the pitch jumps almost instantaneously to that defined by the new voltage. But if you insert a simple Slew Generator (see last month's instalment of this series) into the keyboard CV signal path, you smooth the transitions at the oscillator's CV input, thus making the pitch glide from one note to the next. This, of course, is portamento.




Figure 16: [top] A slewed S&H output. Figure 17: [bottom] Filtering the S&H output using a powerful audio filter.

Figure 16 shows the change that a simple slew generator will make to an S&H signal. As you can see, it rounds the transitions and creates a characteristic 'shark's tooth' pattern in the output waveform. We obtain this shape because the rate of transition between states is much lower that the slew generator's cut-off frequency, and because I've depicted the slew as an exponential glide between voltages, as it would be on most vintage synths. But what happens if we increase the speed of the S&H clock, or change the nature of the filter so that the signal is 'smoothed' in a more conventional way? Figure 17 shows what happens when we smooth a stepped voltage using a sophisticated filter that has a response more in keeping with the sample rate.

But look again: is the red line the input from an S&H module, with the blue line the smoothed output? Or is the blue line an audio signal input, with the red line the S&H output? Tricky! And

it's the question that, in one leap, takes us all the way from the analogue domain to the digital domain and back again. It's a leap that we'll take next month.

Find ALL Synth Secrets Parts

Previous article	Next article	1
New forum posts	Active topics	Recently active forums
Re: new hum from fender champ amp	new hum from fender champ amp	Forum FAQsRecording: Gear & Techniques
Wonks Guitar Technology 28 Mar 2022, 11:47	Need mic help	Mixing, Mastering & Post Production
Re: Noise from pedals in a patchbay who	Boz Digital Labs The Hoser 71% OFF Ex	New Products & Industry NewsMusic Business
Wonks Recording: Gear & Techniques 28 Mar 2022, 11:34	Is Logic Pro backwards compatible?	Mac Music Windows Music
new hum from fender champ amp	Using a spare MacMini for soft-synths	Apps & Other Computers/OS
rggillespie Guitar Technology 28 Mar 2022, 11:17	Roland BTM-1	 Guitar Technology Keyboards & Synthesis
Re: Need mic help	Electric Guitar T, Fender's legendary Tel	 DIY Electronics & Studio Design Live Sound & Performance
ef37a Recording: Gear & Techniques 28 Mar 2022, 11:07	lan Boddy recognition	Music Theory, Songwriting & Composition
Re: OK? Genelec 8010's.	Cutting vinyl at Abbey Road.	 User Reviews Remote Collaboration
Hugh Robjohns Recording: Gear & Techniques 28 Mar 2022, 11:04	Analog tape transfer to digital	Self-PromotionFeedback

Contact Us Cookie Policy Help Privacy Policy Terms of Use

All contents copyright © SOS Publications Group and/or its licensors, 1985-2022. All rights reserved.

The contents of this article are subject to worldwide copyright protection and reproduction in whole or part, whether mechanical or electronic, is expressly forbidden without the prior written consent of the Publishers. Great care has been taken to ensure accuracy in the preparation of this article but neither Sound On Sound Limited nor the publishers can be held responsible for its contents. The views expressed are those of the contributors and not necessarily those of the publishers.

Web site designed & maintained by PB Associates & SOS