

Bootloader Compiling User Guide

Calterah Semiconductor

Date	Version	Description	Author
2020.06.08	V0.1.0	First version	Xudong Ran

Table of Contents

1.	Introduction	3
2.	Compiling	4

CHAPTER

ONE

INTRODUCTION

The purpose of this document is to help customer understand the basic compiling procedure of bootloader. This document applies to Alps and Rhine series only.

By default, the binary bootloader file (Bootloader.bin) is ready in root directory of Calterah Flash Tool. In some cases, you may need to modify bootloader. Please recompile it according to the instructions below and copy it to the root directory Calterah Radar Flash Tool. For more information, please contact Calterah FAE for help.


COMPILING

- (1) Open the command line in bootloader source code folder /downloader/
- (2) Run the following command to compile firmware

make clean && make bin



(3) **Bootloader.bin** is generated in the folder



(4) Copy **bootloader.bin** to the installation directory of CalterahDownloader (the default path is C:\Calterah_downloader).